
Printer Calibration Grid



Instructions:

- 1. Measure any 10mm grid square with a ruler
- 2. Measure the test rectangles (should be 50x30mm and 40x40mm)
- 3. Calculate scale_factor = measured_mm / expected_mm for X and Y