EEE 5109 Digital Signal Processing.

Dr. Ciira Maina ciira.maina@dkut.ac.ke

27 May, 2020

Course Content

- 1. Introduction to discrete time signals and systems
- 2. Discrete time system properties
- 3. Linear time invariant (LTI) systems
- 4. Frequency-domain representation of discrete time systems
- 5. z-transform
- 6. Sampling of continuous time signals
- 7. Filter design
- 8. The discrete Fourier transform

Today's Lecture

- 1. Introduction to discrete time signals
- 2. Basic discrete time signals


Discrete time signals - sequences


- ▶ Discrete time signals are represented mathematically as a sequence of numbers
- ► The sequence is indexed by the integers and the nth number in the sequence is denoted x[n].
- ▶ Often these sequences arise from sampling a continuous time signal x(t). The nth number in the sequence is the value of x(t) at time nT_s

$$x[n] = x(nT_s) - \infty < n < \infty$$

Discrete time signals - sequences

- $ightharpoonup T_s$ is known as the sampling period
- Note that x[n] is not defined for non-integer values of n
- ▶ Below we show the continuous time signal $x(t) = \sin(2\pi t)$ and the corresponding stem plot of the discrete time signal with $T_s = \frac{1}{8}$






Examples in Notebook


▶ The unit sample sequence is defined as

$$\delta[n] = \begin{cases} 0 & n \neq 0 \\ 1 & n = 0 \end{cases}$$




► The unit step is defined as

$$u[n] = \begin{cases} 1 & n \ge 0 \\ 0 & n < 0 \end{cases}$$



▶ The unit ramp is defined as


$$r[n] = \begin{cases} n & n \ge 0 \\ 0 & n < 0 \end{cases}$$



Exponential sequences have the general form

$$x[n] = A\alpha^n$$

where A and α are complex in general.



Sinusoidal sequences take the form

$$x[n] = A\cos(\omega_0 n + \phi) \quad \forall n$$

where A and ϕ are real constants.

