Lecture Notes

PET504E Advanced Well Test Analysis

January 2012

by Prof. Dr. Mustafa Onur

1 Introduction

The term "Well Testing" ^{c1} <u>as it</u> is used in Petroleum Industry means the measuring of a formation's (or reservoir's) pressure (and/or rate) response to flow from a well. The term "Well Testing" is generally used with the term "Pressure Transient Analysis", interchangeably. It is an indirect measurement technique as opposed to direct methods such as fluid sampling or coring. Well testing provides dynamic information on the reservoir whereas direct measurements only provide static information, which is not sufficient for predicting the behavior of the reservoir.

^{c1}Murat Çınar: Text added.

Simply, the objective of well testing is to deduce quantitative information about the well/reservoir system under consideration from its response to a given input. Input (or input signal) is used for perturbing one or more wells so that the output (signal) exhibiting the response of the reservoir is obtained at the perturbated well and/or adjacent wells. In practice, the input is equivalent to controlling the well behavior ^{c2} created by changing the flow rate or the pressure at the well (Mathematically specifying the well behavior is equivalent to specifying a boundary condition). A common example for creating an input signal is ^{c3}a build up test ^{c4}where we change the rate to zero by shutting-in the well. Reservoir response, ^{c5} also called output signal, to a given input is monitored by measuring the pressure change (or rate change) at the ^{c6} well. This process is illustrated as,

c2 Murat Çınar: and




Fig. 1.1. Block diagram ?????

Typical examples for input and output signals as used in petroleum industry are shown in Fig. 1.2.


From reservoir response as monitored by the "output signal", we would like to determine information related to the followings:

- Fluid in place; pore volume, ϕhA .

c3 Murat Çınar: Text added.

c4 Murat Çınar: in which

^{c5} Murat Çınar: which is ^{c6} Murat Cınar: same



 ${\bf Fig.\,1.2.}$ Typical input and output signals - Transient phenomena.

- 4 PET504E Advanced Well Test Analysis
 - Ability of reservoir to transfer fluid, kh (or transmissibility, $\frac{kh}{\mu}$).
- Determination of average reservoir c1 <u>pressure</u>, \overline{P} , which is the driving force in the reservoir c2
- Prediction of rate versus time data.
- Initial recovery, is the reservoir worth producing.
- Is there any damage around the wellbore impeding the flow? skin factor, s.
- Reservoir description (type of reservoir, flow boundaries (faults)).
- Distance to fluid interface ^{c3}that is important determining swept zone for secondary and tertiary methods.

Interpretation of well test data consist of basically three steps:

(i) Determination of the one most appropriate reservoir / wellbore (mathematical) model ^{c4}of the actual system. We also call such a model as the interpretation model. ^{c5}Here our intention is to find a representative mathematical model that reproduces, as close as possible, the output of the actual system for a given input. This is known as the inverse problem. ^{c6}We are trying to obtain information about the physical system by using observed measurements. Unfortunately, the solution of inverse problem often yields non-unique results. ^{c7}By non-unique results, we mean that several different interpretation models ^{c8}may generate an output signal (response) to a given input ^{c9}that is similar (or identical) to that of the actual system. The inverse problem can be represented by the following equation.

$$\Sigma = O/I \approx S \tag{1.1}$$

where Σ denotes the interpretation model, S denotes the actual system. In inverse problem, as can be seen from Eq.1.1, it may be possible to obtain the same outputs to a given I for different Σ_i 'sc¹⁰,however, the number of alternative models (solutions) can be reduced as the number and the range of output signal measurements.

(ii) Once the appropriate model is determined, estimate the parameters of the actual system S. c11 These parameters are kh, s, ϕ , C, λ , w etc. This is known as c12 parameter estimation c13 c14 and achieved by adjusting the parameters of the model by different c15 mathematical methods to obtain an output signal, Ω , that is always qualitatively identical (within some tolerance) to that of c16 the actual system, O. The computation of Ω is known as the c17 forward problem" in mathematics. Contrary to the inverse problem, the solution of the c18 forward problem is always unique for a given system; that is,

$$I \times \Sigma = \Omega \approx 0 \tag{1.2}$$

The adjusted parameters of the interpretation model are assumed to represent the parameters of the real system S. c19

(iii) Validate the results of the interpretation. This can be achieved by using the parameters determined from part (ii) in the model to generate output

- ^{c1}Murat Çınar: average
- c²Murat Çınar: Based upon the explanation you gave about the pressure decline recently, I am not sure if this statement is correct.
- c3 Murat Cinar: which
- c4 Murat Cinar: to
- c5 Murat Çınar: Here our hope is that the model chosen will produce an output signal to a given input which is as close as possible to that of the actual system.
- $^{c6}Murat\ {\it Cinar:}\ Text\ added.$
- ^{c7}Murat Çınar: With
- c8 Murat Cinar: can
- c9 Murat Cinar: which
- c10 Murat Çınar: . However
- c¹¹Murat Çınar: Such parameters can be
- c12 Murat Cinar: the
- c13 Murat Cinar: problem
- c14 Murat Cinar: . It is
- c15 Murat Çınar: Text added.
- $^{c16}Murat\ {\it Cinar}$: Text added.
- c17 Murat Çınar: direct
- c18 Murat Cinar: direct
- c19 Murat Çınar: I think we should discuss this phrase. Does the real system have any parameters? I do not think so... This is something conceptual we need to think about

signals for the entire range of $^{c20}\underline{\text{the}}$ test and by comparing these outputs with the c21 physical measurements.

 c20 Murat Çınar: Text added.
 c21 Murat Çınar: measured




Fig. 1.3. Parameters estimated based on the analysis of buildup data.

vell at the center. The partial differential equation (PDE) describing the flow is given by,

$$\frac{1}{r}\frac{\partial}{\partial r}\left(\frac{kr}{\mu}\frac{\partial p}{\partial r}\right) = \phi c_t \frac{\partial p}{\partial t} \tag{1.3}$$

or if k, μ are constant,

$$\frac{1}{r}\frac{\partial}{\partial r}\left(r\frac{\partial p}{\partial r}\right) = \frac{\phi c_t \mu}{k}\frac{\partial p}{\partial t} = \frac{1}{\eta}\frac{\partial p}{\partial t} \tag{1.4}$$

 $^{c3}\eta = \frac{k}{\phi c_t \mu_-}$ is the hydraulic diffusivity c4 ; a measure of the c5 speed at which a pressure disturbance c6 propagates through the formation. If we specify, k, ϕ , c_t , μ , and the flow rate, then p(r,t) is uniquely determined. This is an example for the c7 forward problem.

Inverse problem, given q and p, c^8 helps us to

- 1. determine the PDE that describes the reservoir best
- 2. find k, ϕ , etc.

c9

^{c10}Analytical solutions have been presented in the literature for a variety of different well and reservoir settings for single phase flow. A summary of these responses are given by Bourdet [1].

2 Flow Equations

In this chapter, we will derive the equations which describe the fluid flow in porous media. Such equations are derived from the conservation of mass and the momentum equation as given by Darcy's semi-empirical equation. With the exception of thermal recovery schemes, all well-testing models assume isothermal conditions in the reservoir and thus the energy conservation is not needed.

c1 Murat Çınar: To illustrate an example of direct and inverse problems, let's consider single phase flow in a closed cylindrical reservoir produced by a single well at the center.

^{c2}Murat Çınar: pd.E

^{c4}Murat Çınar: which is ^{c5}Murat Çınar: rapidity

with


c6 Murat Çınar: Text added.

^{c7}Murat Çınar: direct


c8 Murat Çınar: Text added.

c9 Murat Cinar: -During the past ten years, a lot of work has been done to develop models to a wide variety of reservoir / well configurations such as fractures, lavered reservoirs, multiple porosities (composite zones), fractured wells. slanted and horizontal wells, etc. Well testing literature is almost complete for single phase problems, but some work needs to be done for multi-phase problems and heterogeneous reservoir systems.

Recently, people are much focused on the model recognition problem and the computer-aided parameter estimation by using non-linear regression techniques. Pressure derivatives and integrals are proven to be very useful in identifying



 ${\bf Fig.\,1.4.}$ Homogeneous vs heterogeneous reservoir, pressure difference .



 ${\bf Fig.\,1.5.}\ {\bf Homogeneous}\ {\bf vs}\ {\bf heterogeneous}\ {\bf reservoir\ -logarithmic\ derivative}.$




Fig. 1.6. Flow diagram of computer aided parameter estimation.

2.1 Conservation of mass

For a single phase fluid ^{c11}, the mathematical form of the mass balance in porous media is given by

$$-\nabla \cdot (\rho \mathbf{v}) = \frac{\partial (\rho \phi)}{\partial t} \tag{2.1}$$

c¹ where ρ is the density of the fluid in c² \mathbf{M}/\mathbf{L}^3 and \mathbf{v} is the fluid velocity vector in c³ \mathbf{L}/\mathbf{T} . Note that the units of Eq. 2.1 is c⁴ $\mathbf{M}/\mathbf{L}^3\mathbf{T}$ It is also important to note that Eq. 2.1 applies for any coordinate system and can be derived either from a mass balance done on a control volume for a coordinate system under consideration or from c⁵ divergence theorem (or Gauss Theorem see Supplement II).

In^{c6}Cartesian coordinate system,

$$\nabla \cdot (\rho \mathbf{v}) = \frac{\partial}{\partial x} (\rho v_x) + \frac{\partial}{\partial y} (\rho v_y) + \frac{\partial}{\partial z} (\rho v_z)$$
 (2.2)

In^{c7}cylindrical coordinate system,

$$\nabla \cdot (\rho \mathbf{v}) = \frac{1}{r} \frac{\partial}{\partial r} (r \rho v_r) + \frac{1}{r} \frac{\partial}{\partial \theta} (\rho v_\theta) + \frac{\partial}{\partial z} (\rho v_z)$$
 (2.3)

c11 Murat Çınar: (or a fluid composed of one hydrocarbon component)

c1 Murat Çınar: I removed the constant -5.615 from the equation

^{c2}Murat Çınar: lbm/ft³

c3 Murat

Çınar: RB/ft^2day ^{c4} Murat

Cinar: lbm/ft³day
c5 Murat Cinar: a

c6 Murat Cinar: x-y-x

^{c7}Murat Çınar: r-θ-z

c8 Murat Çınar: typo in the equation corrected

^{c9}Murat Çınar: can be

c10 Murat Çınar: must be c11 Murat Çınar: a Freenh hyraulic engineer Henry c12 Murat Çınar: the velocity vector and the

pressure gradient for a

single phase viscous flow

 $^{\rm c1}Murat\ \mbox{\it Cinar};$ I removed the filed unit constants $^{\rm c2}Murat\ \mbox{\it Cinar};$ RB/ft^2day

^{c3}Murat Çınar: Text added.

^{c4}Murat Çınar: which

^{c5}Murat Çınar: a

^{c6}Murat Cinar: x-v-z

^{c7}Murat Çınar: use

$^{\mathrm{c}8}\mathit{Murat}$ Çınar: x-y-z

^{c9}Murat Çınar: Eq. 2.5

c10 Murat Çınar: We generally denote γ as the specific weight of fluid and define as,

2.2 Conservation of momentum in porous media

The principle of momentum conservation is described by the equation of motion. For most hydrocarbon fluids, the shear stress - shear rate behavior c9 is described by the Newton's law of friction, combined with the equation of motion, results in the well known Navier-Stokes equation. Solution of the Navier-Stokes equation with the appropriate boundary conditions yields the velocity distribution of a given problem. Although, it is possible to solve Navier-Stokes in pipe flow, it is almost impossible to solve due to complexity of the pore geometry and its distribution. This hinders the formation of the boundary conditions for flow through a porous medium. Therefore, a different approach c10 is taken. In 1856, c11 Darcy discovered that c12 for a single phase viscous flow in porous media, the velocity is proportional to the pressure gradient with a proportionality constant k. The general form of Darcy's Law including gravity effects is given by Eq.2.4.

$$\mathbf{v} = -\frac{\mathbf{k}}{\mu} \left(\nabla p - \rho g \nabla z' \right) \tag{2.4}$$

c¹ where \mathbf{v} is defined as a volumetric flow rate across a unit cross-section area (solid+fluid) averaged over a small region of space. The unit of \mathbf{v} is in c² \mathbf{L}/\mathbf{T} . Eq. 2.4 yieldc³s a velocity vector c⁴that replaces the solution of Navier-Stokes equation. In Eq. 2.4 \mathbf{k} is c⁵the permeability tensor. Operationally, \mathbf{k} acts like a matrix in c⁴coordinate system, we usually c⁴assume

$$\mathbf{k} \nabla p = \begin{bmatrix} k_x & 0 & 0 \\ 0 & k_y & 0 \\ 0 & 0 & k_z \end{bmatrix} \begin{bmatrix} \frac{\partial p}{\partial x} \\ \frac{\partial p}{\partial y} \\ \frac{\partial p}{\partial z} \end{bmatrix} = \begin{bmatrix} k_x \frac{\partial p}{\partial x} \\ k_y \frac{\partial p}{\partial y} \\ k_z \frac{\partial p}{\partial z} \end{bmatrix}$$
(2.5)

$$\nabla z' = \begin{bmatrix} \frac{\partial z'}{\partial x} \\ \frac{\partial z'}{\partial y} \\ \frac{\partial z'}{\partial z} \end{bmatrix}$$
 (2.6)

where, z' is the direction in which gravity acts, i.e., the direction towards the center of the earth. In ^{c8}Cartesian coordinate system, ^{c9} for each velocity component,

$$v_{\xi} = -\frac{k_{\xi}}{\mu} \left(\frac{\partial p}{\partial \xi} - \rho g \frac{\partial z'}{\partial \xi} \right), \quad \xi = x, y, z$$
 (2.7)

c10

References

1. D. Bourdet. Well test analysis: the use of advanced interpretation models. Handbook of petroleum exploration and production. Elsevier, 2002.