# ARM Assembly Language & Programming

ARM7

### **Clicker question**

Have you installed ARMSim#?

- A. Yes
- B. No

http://armsim.cs.uvic.ca/

## GNU Assembler Quick Reference

This section summarizes the more useful commands and expressions available with the GNU assembler, gas, when you target this assembler for ARM. Each assembly line has the format

```
(<label>:) (<instruction or directive>) @ comment
```

Unlike the ARM assembler, you needn't indent instructions and directives. Labels are recognized by the following colon rather than their position at the start of the line. The following example shows a simple assembly file defining a function add that returns the sum of the two input arguments:

```
.section .text. "x"
                            @ give the symbol add external linkage
.global
          add
add:
          ADD rO, rO, r1 @ add input arguments
          MOV
                  pc. 1r @ return from subroutine
```

#### **GNU Assembler Directives**

Here is an alphabetical list of the more common gas directives.

### Assembler directives

```
.align n
.ascii "<string>"
.asciiz "<string>"
.byte <byte1> {, <byte2>, ...}
.data {<addr>}
.global <symbol>
.text {<addr>}
.word<word1> {, <word2>, ...}
```

### The ARMSim# User Guide

Table 4. SWI I/O operations (0x00 - 0xFF)

Opcode		Description and Action	Inputs	Outputs	EQU	
swi	0x00	Display Character on Stdout	r0: the character		SWI_PrChr	
swi	0x02	Display String on Stdout	r0: address of a null ter- minated ASCII string	(see also 0x69 below)		
swi	0x11	Halt Execution			SWI_Exit	
swi	0x12	Allocate Block of Mem- ory on Heap	r0: block size in bytes	r0:address of block	SWI_MeAlloc	
swi	0x13	Deallocate All Heap Blocks			SWI_DAlloc	
swi	0x66	Open File (mode values in r1 are: 0 for input, 1 for output, 2 for appending)	r0: file name, i.e. address of a null terminated ASCII string containing the name r1: mode	r0:file handle If the file does not open, a result of -1 is returned	SWI_Open	
swi	0x68	Close File	r0: file handle		SWI_Close	
swi	0x69	Write String to a File or to Stdout	r0: file handleor Stdout r1: address of a null termi- nated ASCII string		SWI_PrStr	

Table 4. SWI I/O operations (0x00 - 0xFF)

Opcode		Description and Action	Inputs	Outputs	EQU	
swi	0x6a	Read String from a File	r0: file handle r1: destination address r2: max bytes to store	r0: number of bytes stored	SWI_RdStr	
swi	0x6b	Write Integer to a File	r0: file handle r1: integer		SWI_Print	
swi	0x6c	Read Integer from a File	r0: file handle	r0: the integer	SWI_RdInt	
swi	0x6d	Get the current time (ticks)		r0: the number of ticks (milliseconds)	SWI_Timer	

.data

str: .asciz "Hello World!\n"


.text .align 2

.global main

main: mov r0, #1

Idr r1, =str

swi 0x69




#### **ARM Programming**

Branch (cmp, beq, bne)

"If-then-else"

Example:

if(i==j) 
$$f = g + h$$
;  
else  $f = g - h$ ;



# assume f, g, h, i, and j are in r0, r1, r2, r3, and r4 respectively

CMP (73, r4)

**BNE Else** 

ADD r0, r1, r2

Exit В

r0, r1, r2 🛶 Else: sub

**Exit:** 

A more compact and efficient version:

**CMP** r3, r4

ADDEQ r0, r1, r2 @ f = g + h (skipped if  $i \neq j$ )

SUBNE r0, r1, r2 @ f = g - h (skipped if i = j)

## Signed versus unsigned comparison

#### Suppose

```
r0 = 1111 \ 1111 \ 1111 \ 1111 \ 1111 \ 1111 \ 1111 \ 1111 \ 1111 \ 1111 \ 1111 \ 1111 \ r1 = 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000 \ 0000
```

#### If the following instructions are executed

0x0000 1000: CMP r0, r1 0x0000 1004: BLO L1 0x0000 1008: BLT L2

#### Where will be the PC at?

**A**: L1 **B**: L2

**C**: 0x0000 100C **D**: 0x0000 1010

Value	Meaning	Value	Meaning
0	EQ (EQual)	8	HI (unsigned Higher)
1	NE (Not Equal)	9	LS (unsigned Lower or Same)
2	HS (unsigned Higher or Same)	10	GE (signed Greater than or Equal)
3	LO (unsigned LOwer)	11	LT (signed Less Than)
4	MI (Minus, <0)	12	GT (signed Greater Than)
5	PL - (PLus, >=0)	13	LE (signed Less Than or Equal)
6	VS (oVerflow Set, overflow)	14	AL (Always)
7	VC (oVerflow Clear, no overflow)	15	NV (reserved)

Based on this result,

N = 1 (the result is negative, treated as two's complement)

Z = 0 (the result is not zero)

C = 1 (there is carry out of the left-most bit)

V = 0 (there is no overflow)

Therefore, the instruction "BLO" is not taken because of suffix "LO" indicates unsigned lower, which is only taken when the carry bit is clear. - because if r0 is unsigned lower than r1, r0 - r1 will never have a carry.

Instead instruction "BLT" is taken when N != V, which is the case as shown above.

### **Condition Mnemoics**

cond	Mnemonic	Name	CondEx
0000	EQ	Equal	Z
0001	NE	Not equal	$ar{Z}$
0010	CS / HS	Carry set / Unsigned higher or same	С
0011	CC / LO	Carry clear / Unsigned lower	Ē
0100	МІ	Minus / Negative	N
0101	PL	Plus / Positive of zero	$\overline{N}$
0110	VS	Overflow / Overflow set	V
0111	VC	No overflow / Overflow clear	$ar{V}$
1000	HI	Unsigned higher	Σ̄C
1001	LS	Unsigned lower or same	$Z OR \bar{C}$
1010	GE	Signed greater than or equal	$\overline{N \oplus V}$
1011	LT	Signed less than	$N \oplus V$
1100	GT	Signed greater than	$\bar{Z}(\overline{N \oplus V})$
1101	LE	Signed less than or equal	$Z OR (N \oplus V)$
1110	AL (or none)	Always / unconditional	ignored

#### CMP Compare two 32-bit integers

```
1. CMP<cond> Rn, #<rotated_immed> ARMv1
2. CMP<cond> Rn, Rm {, <shift>} ARMv1
3. CMP Ln, #<immed8> THUMBv1
4. CMP Rn, Rm THUMBv1
```

#### Action

```
    cpsr flags set on the result of (Rn - <rotated_immed>)
    cpsr flags set on the result of (Rn - <shifted_Rm>)
    cpsr flags set on the result of (Ln - <immed8>)
    cpsr flags set on the result of (Rn - Rm)
```

#### Notes

- In the *cpsr*:  $N = \langle Negative \rangle$ ,  $Z = \langle Zero \rangle$ ,  $C = \langle NoUnsigned Overflow \rangle$ ,  $V = \langle Signed Overflow \rangle$ . The carry flag is set this way because the subtract x y is implemented as the add  $x + \sim y + 1$ . The carry flag is one if  $x + \sim y + 1$  overflows. This happens when  $x \ge y$  (equivalently when  $x \hat{A}y$  doesn't overflow).
- If Rn or Rm is pc, then the value used is the address of the instruction plus eight bytes for ARM instructions, or plus four bytes for Thumb instructions.

#### Example

```
CMP r0, r1, LSR\#2; compare r0 with (r1/4) BHS label; if (r0 >= (r1/4)) goto label;
```

Q: In instruction CMP r0, r1, if the values of r0 have a one as their left most bit, should we assume these values are signed integers or unsigned?

A: Yes, you assume they are signed integers. The instruction "CMP r0, r1" subtracts value in r0 by value in r1. What matters is the subtraction result, though not saved, based on which the high 4 flag bits NZCV of the current program status register (CPSR) are set accordingly. It is these four bits that determine the behavior of the next conditional instruction. Although r0 – r1 is carried out as subtraction of two signed integers, careful analysis of the NZCV values allows us to know what would be the answer for "BLO r0, r1" if r0 and r1 are treated as unsigned.

## Loop

Example:

while (save[i] == k)

i += 1;

assume i is in r3, k is in r5, and the base of the array is in r6.

Loop: ADD r12, r6, r3, LSL #2
LDR r0, [r12, #0]
CMP r0, r5
BNE Exit
ADD r3, r3, #1
B Loop

**Exit:** 

#### Procedure call and stack

motivation: abstraction and code reusability.

## C code:

```
while(b != 0) {
    sum = sum + a;
    b = b -1;
}
```

e.g., we like to reuse the code for multiplication a \* b

#### **ARM Assembly code:**

@  $c = a \times b$ , assume a is in r0, b is in r1

sub r7, r7, r7
Loop:cmp r1, #0
beq Done
add r7, r7, r0
sub r1, r1, #1
b Loop

@ initialize

@if b == 0

@sum += a

@a = a-1

Done:

How do we make use of that piece of code (let's give it a name MUL)?

E.g., a\*b + c

solution 1: ("*cut-and-paste*": embed the code of MUL to where it is needed)
(a valid approach under certain circumstances, inline function in C++)
@ assume a, b, c, are in r0, r1, r7

	mov	r2, r7	@ move c out of r7, as it is to be used by MUL
Loop:	sub cmp	r7, r7, r7 r1, #0	@initialize
-	beq	Done	@ if b == 0
	add	r7, r7, r0	@ sum += a
	sub	r1, r1, #1	@b = b-1
	b	Loop	
Done:			
	add	r7, r7, r2	@add c to a*b CISC260, Liao

### Solution 2: ("call-by-name": Jump to the MUL code and jump back when it is done)

@ assume a, b, c are in r2, r3, r4

	mov	ru, rz
	move	r1, r3
	b	MUL
Done:	add	r7, r7, r4

- @ move a to r0
- @ move b to r1
- @ call MUL, product a\*b will be put in r7
  @add c to a\*b



MVL:

	sub	r7, r7, r7
oop:	cmp	r1, #0
	beq	Done
	add	r7, r7, r0
	sub	r1, r1, #1

Loop.

b

@initialize

We want "MUL" to return to the next instruction where it is called. In this example, the return address "Done" is hard coded -- so it can only return to one place.

Can we reuse the routine "MUL" multiple times?

We don't want to write the same piece of code wherever it is used; we may not know how many times it is to be used when we write the code, e.g., multiply integer *a* by itself for *b* times where b is an integer to be read from the keyboard.

So we want to write the MUL code once and reuse it.

### For example, let's compute a\*a + b\*b, assume a, b are in r2 and r3

```
mov r0, r2
                          @ copy a to r0
        mov r1, r2
                          @ copy a to r1
        b MUL
                          @ call MUL, product a*a will be in r7
                          @ move a*a to r4
Done:
        mov r4, r7
                          @ copy b to r0
        mov r0, r3
                         @ copy b to r1
        mov r1, r3
        MUL
                            @ call MUL, product b*b will be in r7
Done : add r7, r7, r4
                         @ a*a + b*b is put to r7
                                                           A hard-coded return address
                 r7, r7, r70
                                  @ initialize
                 r1, #0
Loop:
        cmp
                                                           "Done" is not working well -- it
                                  \emptyset if a == 0
        beq
                 Done
                                                           can only return to one place.
        add
                 r7, r7, r0
                                  @ sum += a
                 r1, r1, #1
                                  \emptyset b = b-1
        sub
                 Loop
        b
```

#### Solution:

- 1. save the return address to a register before calling the subroutine
- 2. jump to the saved return address when the subroutine is done.

### Hardware support:

**bl** ProcedureAddress

@save the return address (PC+4) into a designated

@register r14 and then jump to the address of the callee.

mov pc, r14

@ reset PC to the return address stored in register r14.

- @ For example, let's compute a\*a + b\*b
- @ assume a and b are in r3 and r4

	mov	r0, r3	@ copy a to r0
	mov	r1, r4	@ copy b to r1
	bl	MUL	@ call MUL, address of next instruction is put in r14
		r5, r7	@ move a*a to r5
	5		
	mov	r0, r4	@ copy b to r0
	mov	r1, r4	@ copy b to r1
	bl	MUL	@call MUL, address of next instruction is put in r14
	拳 add	r7, r7, r5	@a*a + b*b is put to r7
N/III.			
MUL:	aula		
1.0000	sub	r7, r7, r7	@ initialize
Loop:		r1, #0	
	beq	Done	@ if a == 0
	add	r7, r7, r0	@ sum += a
	sub	r1, r1, #1	@ $b = b-1$
	b	Loop	
Done:	mov	pc, r14	@ this is always the last executed instruction for a procedure

## Six steps

- 1. (caller) place parameters in a location where the procedure (callee) can access them (r0, r1, r2, r3)
- 2. transfer control to the procedure. (BL)

\_\_\_\_\_\_

- 3. acquire the storage resources needed for the procedure.
- 4. perform the desired task
- 5. place the result value in a place where the caller can access it.
- 6. return control to the point next to where the program is called. (MOV pc, r14)

#### ARM conventions:

- r0 r3, r12: registers for storing arguments or scratch registers to used by the callee (not preserved).
- r4-r11: registers that need to be preserved, if used by callee.
- Ir: register storing the return address (r14)
- sp: stack pointer (r13)

caller

callee

#### Clicker question:

### What is a leaf-procedure?

- A. It is a routine you do during the fall to clean up the falling leaves.
- B. It is a procedure that does not call any other procedures
- C. It is a procedure that is not called by any other procedures
- D. It is a procedure that calls other procedures but itself
- E. It is a procedure that calls only itself.

### What if a procedure calls another procedure?


```
Addr:
                  PC \rightarrow
                                             bl
                                                      proc1
                                                                @ r14 = *
proc1(a);
                                   proc1:
proc1(A) {
                                             bL
                                                      proc2
                                                                 @r14 = * *
   proc2(A);
                             **)
                                                      pc, r14
                                                                 @r14 has wrong
                                             mov
                                                                    return address
                                   proc2:
proc2(B) {
                                                      pc, r14
                                             mov
```

Follow the PC and monitor the value change in r14 CISC260, Liao

Brock Proces

### Solution: Stack (LIFO)

Acquire storage space in main memory, the acquired space is called activation frame



Note: Ir is still in memory until some new value is written in the same location. Potential security loophole.

```
\begin{array}{ll} \text{Main()} \, \{ \\ \text{int n = 4;} \\ \text{int res = fact(n);} \\ \text{printf(res);} \\ \} \\ \\ \text{int fact (int n)} \, \{ \\ \text{if(n < 1) return (1);} \\ \\ \text{else return (n * fact (n-1));} \\ \end{array} = \begin{array}{ll} \text{fact(4)} \\ = 4^*\text{fact(3)} \\ = 4^*3^*\text{fact(2)} \\ = 4^*3^*2^*\text{fact(1)} \\ = 4^*3^*2^*1^*\text{fact(0)} \\ = 4^*3^*2^*1^*1 \end{array}
```

fact: **SUB sp, sp, #8** @move stack pointer downwards to accommodate 2 items STR Ir, [sp, #0] @store the return address @store the argument n STR r1, [sp,#4] int fact (int n) { @check if n < 1 CMP r1, #1 if(n < 1) return (1);@ branch to Else if n >= 1 BGE Else else return (n \* fact (n-1)); MOV r1, #1 @ make a value of 1, and save it to register \$r1 POP 2 items off the stack; Ir and r1 haven't been overwritten, ADD sp, sp, @ so need not to restore MOV pc, Ir @ return 81 Else: SUB r1, r1, #1 @ n = (n-1) BL fact @ call fact with argument (n-1); Ir and r1 are overwritten MOV r2, r1 LDR r1, [sp, #4] @ restore r1 @ restore r14 LDR Ir, [sp, #0] @ move stack pointer upwards ADD sp, sp, #8 MUL r1, r1, r2 @ multiply fact(n-1) in r2 with n in r1 and write the result to r1 MOV pc, Ir @ return to the caller CISC260, Liao

## A Programmer's Perspective

#### Memory




Figure 6.30 Example ARM memory map


Liao, CISC260

```
Address:
                                                                 114 < $
                                             Main() {
              fact: SUB sp, sp, #8
0x 0000 1000
                                                                                         1266
                                                                  Y1 < 74
                                              int n = 4;
                   STR Ir, [sp, #0]
0x 0000 1004
                                               int res = fact(n);
                   STR r1, [sp,#4]
0x 0000 1008
                                             printf(res);
                    CMP r1, #1
0x 0000 100C
                    BGE Else
0x 0000 1010
                                             int fact (int n) {
                    MOV r1, #1
0x 0000 1014
                                              if(n < 1) return (n, n);
else return (n * fact (n-1));
                                               if(n < 1) return (1);
                          sp, sp, #8
                   ADD
0x 0000 1018
                    MOV
                          pc, Ir
0x 0000 101C
              Else: SUB
                         r1, r1, #1
0x 0000 1020
                                             fact(4)
                    BL
                          fact
0x 0000 1024
                                             = 4*fact(3)
                   -MOV r2, r1
0x 0000 1028
                    LDR
                           r1, [sp, #4]
                                             = 4*3*fact(2)
0x 0000 102C
                    LDR
                           Ir, [sp, #0]
0x 0000 1030
                                             = 4*3*2*fact(1)
                   ADD
                          sp, sp, #8
0x 0000 1034
                                             = 4*3*2*1*fact(0)
                                             = 4*3*2*1*1
                    MUL
                           r1, r1, r2,
0x 0000 1038
                    MOV
                          pc, Ir
0x 0000 103C
```

Q: The instruction MOV r1, #1 will overwrite what's already in r1. Is that a problem?

A.Yes

B.No



### Source code

```
while (a!=b) {
    if (a > b) {
        a = a - b;
    } else {
        b = b - a;
    }
} return a;
```

### Assembler1 (using branch instructions)


```
while: cmp r0, r1
beq return
blt else
sub r0, r0, r1
else: sub r1, r1, r0
b while
return:
```

### Assembler2 (using ARM conditional instructions)

while: cmp r0, r1
subgt r0, r0, r1
sublt r1, r1, r0
bne while
return:

**Little-endian** byte ordering – least-significant byte of word or half-word stored at lower address in memory

**Big-endian** byte ordering – most-significant byte of word or half-word stored at lower address in memory




cisc260, Liao

 The ARM architecture supports both little-endian and big-endian access to memory. The ARM-Sim# supports only the little-endian format (the same as the Intel architecture which hosts the ARMSim#).

• This is only relevant when data is stored by words and is then accessed by bytes.

### Etymology [edit]

In 1726, Jonathan Swift described in his satirical novel *Gulliver's Travels* tensions in Lilliput and Blefuscu: whereas royal edict in Lilliput requires cracking open one's soft-boiled egg at the small end, inhabitants of the rival kingdom of Blefuscu crack theirs at the big end (giving them the moniker *Big-endians*). The terms *little-endian* and *endianness* have a similar intent. [4]



Danny Cohen's "On Holy Wars and a Plea for Peace" published in 1980<sup>[3]</sup> ends with: "Swift's point is that the difference between breaking the egg at the little-end and breaking it at the big-end is trivial. Therefore, he suggests, that everyone does it in his own preferred way. We agree that the difference between sending eggs with the little- or the big-end first is trivial, but we insist that everyone must do it in the same way, to avoid anarchy. Since the difference is trivial we may choose either way, but a decision must be made."

This trivial difference was the reason for a hundred-years war between the fictional kingdoms. It is widely assumed that Swift was either alluding to the historic War of the Roses or – more likely – parodying through oversimplification the religious discord in England, Ireland and Scotland brought about by the conflicts between the Roman Catholics (Big Endians) on the one side and the Anglicans and Presbyterians (Little Endians) on the other.

Credit: http://en.wikipedia.org/wiki/Endianness

#### Handling large immediate values, label addresses, words, and bytes, ...

.text

@mov r0, #345

pseudo instruction

@ see this number cannot be used as immediate value

ldr r0, =0x12345678

@ the way to load a large number to register

@ see where the number is and pc-relative addressing

ldr r1, =myByte

@ the way to load address of a label to register

ldr r2, [r1]

@ see the order of these 4 bytes in memory and in register

str r0, [r1]

@ see the 4 bytes in a word are stored in memory (little endian)

ldrb r4, [r1]

@ see which byte in 0x12345678 is loaded back

.data

myByte: .byte 1, 2, 3, 4

literal pool