ELECTRONICS AND COMMUNICATION TECHNOLOGIES: ELECTRONICS SYSTEMS

LM Cyber Security – Fall 2024

Federico Baronti, Luca Crocetti

Dip. Ing. Informazione

Via G. Caruso, 16 – Stanza B-1-09

050 2217581 – <u>federico.baronti@unipi.it</u>

Office hours:

Friday 14-16. Please, contact me in advance before showing up. We can also arrange an appointment remotely on Microsoft Teams.



RISC Instruction Set Architecture: Intel Nios 2 Proc.

Instructions Set Architecture

- Instruction Set Architecture (ISA) can be seen as the specifications of a processor
 - ISA affects processor performances (RISC, CISC, GPU, ASIP*)
 - Possible different implementations of the same ISA
- Instructions for a computer must support:
 - data transfers to and from the memory
 - arithmetic and logic operations on data
 - program sequencing and control
 - input/output transfers

^{*} Application-Specific Instruction set Processor

RISC and CISC Instruction Sets

- Nature of instructions distinguishes computer
- Two fundamentally different approaches:
 - Reduced Instruction Set Computers (RISC) have one-word instructions and require arithmetic operands to be in registers
 - Complex Instruction Set Computers (CISC)
 have multi-word instructions and
 allow operands directly from memory

RISC Instruction Sets

- Each RISC instruction occupies a single word
- A load/store architecture is used, meaning:
 - Only Load and Store instructions are used to access memory operands
 - Operands for arithmetic/logic instructions must be in registers, or one of them can be provided explicitly in the instruction word (*Immediate* operand)
 - E.g. Load proc_register, mem_location
 - Addressing mode specifies actual memory location

Nios II Main Characteristics

- RISC-style architecture (all instructions are 32-bit long)
- 32-bit data word
- 2x memory interfaces (Harvard architecture)
- Byte-addressable memory space:
 - With little-endian addressing scheme (lower byte addresses used for less significant bytes)
 - The LOAD and STORE instructions can transfer data in: word, half-word, and byte
- 32 general-purpose registers, 32-bit long
- Several additional control registers
- 2 versions: economy (5-stage) and fast (6-stage w. pipelining)

Nios II registers

General-purpose registers (r0-r31)

Register	Name	Function	Register	Name	Function		
r0	zero	0x00000000	r16	Callee-saved register			
r1	at	Assembler temporary	r temporary r17 Callee-saved re				
r2		Return value	r18		Callee-saved register		
r3		Return value	r19		Callee-saved register		
r4		Register arguments	r20		Callee-saved register		
r5		Register arguments	r21		Callee-saved register		
r6		Register arguments	r22		Callee-saved register		
r7		Register arguments	r23		Callee-saved register		
r8		Caller-saved register	r24	et	Exception temporary		
r9		Caller-saved register	r25	bt	Breakpoint temporary (1)		
r10		Caller-saved register	r26	gp	Global pointer		
r11		Caller-saved register	r27	sp	Stack pointer		
r12		Caller-saved register	r28	fp	Frame pointer		
r13		Caller-saved register	r29	ea	Exception return address		
r14		Caller-saved register	r30	ba	Breakpoint return address (2)		
r15		Caller-saved register	r31	ra	Return address		

Addressing Modes (1)

- How operands are specified in an instruction
- Nios 2 proc. supports 5 addressing modes:
 - Immediate mode: a 16-bit operand is contained in the instruction itself. This value is (sign-)extended to produce a 32-bit operand for (arithmetic) instructions
 - Register mode: the operand is the content of a register
 - Register indirect mode: the effective address of the operand is the content of a register

Addressing Modes (2)

- Nios 2 proc. supports 5 addressing modes:
 - Displacement mode: the effective address of the operand is obtained by adding the content of a register and a 16-bit value contained in the instruction itself.
 - Absolute mode: is a particular case of the Displacement mode when the register is r0
- E.g. addi r3, r2, 100
 the content of r2 is added to 100 and the result placed in r3

Addressing Modes (3)

Nios II addressing modes.

Involves appropriate extension to 32 bit

Name	Assembler syntax	Addressing function
Immediate	Value	Operand ≠ Value
Register	r <i>i</i>	EA = ri
Register indirect	(ri)	EA = [ri]
Displacement	X(ri)	EA = [ri] + X
Absolute	LOC(r0)	EA = LOC

EA = effective address

Value = a 16-bit signed number

X = a 16-bit signed displacement value

[ri] indicates the content of the register ri

Instruction formats (1)


- RISC-style instructions (all 32-bit long)
 - Load/store architecture for data transfers
 - Arithmetic/logic instructions use registers
- Three instruction types:

```
I-type OP dst_reg, src_reg, immediate
R-type OP dst_reg, src_reg1, src_reg2
J-type OP label_or_address
```


label_or_address is a 26-bit unsigned immediate
 value

Instruction formats (2)

 I-type instructions include arithmetic and logical operations in which one operand is a constant, such as addi and andi; branch operations; load and store operations; and cache management operations.



 R-type instructions include arithmetic and logical operations such as add, and, nor; comparison operations such as cmpeq and cmplt



• **J-type instructions** such as call and jmpi, transfer execution anywhere within a 256-MB range

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
	IMM26										0	P																			

Notation Conventions

Notation	Meaning
X - Y	X is written with Y
PC = X	The program counter (PC) is written with address X; the instruction at X is the next instruction to execute
PC	The address of the assembly instruction in question
rA, rB, rC	One of the 32-bit general-purpose registers
prs.rA	General-purpose register rA in the previous register set
IMMn	An n-bit immediate value, embedded in the instruction word
IMMED	An immediate value
X _n	The nth bit of X, where n = 0 is the LSB
X _{nm}	Consecutive bits n through m of X
0×NNMM	Hexadecimal notation
X : Y	Bitwise concatenation For example, $(0x12:0x34) = 0x1234$
σ(X)	The value of X after being sign-extended to a full register-sized signed integer
X >> n	The value X after being right-shifted n bit positions
X << n	The value X after being left-shifted n bit positions
X & Y	Bitwise logical AND
X Y	Bitwise logical OR
	continued

Notation Conventions (con't)

Notation	Meaning							
X ^ Y	Bitwise logical XOR							
~X	Bitwise logical NOT (one's complement)							
Mem8[X]	The byte located in data memory at byte address X							
Mem16[X]	The halfword located in data memory at byte address X							
Mem32[X]	The word located in data memory at byte address X							
label	An address label specified in the assembly file							
(signed) rX	The value of rX treated as a signed number							
(unsigned) rX	The value of rX treated as an unsigned number							

Load and Store Instructions

- For moving data between memory (or I/O) and general-purpose registers
- Words, half-words, bytes; alignment required
- Variants available for I/O (uncached) access
- Examples:

Arithmetic Instructions

- add, addi (16-bit immediate is signextended)
- sub, subi, mul, and muli are similar
- Mult. is unsigned, result is truncated to 32 bits
- di∨ (signed values), di∨∪ (unsigned values)
- Examples:

```
add r2, r3, r4 //(r2 \leftarrow [r3] + [r4])
muli r6, r7, 4096 //(r6 \leftarrow [r7] \times 4096)
divu r8, r9, r10 //(r8 \leftarrow [r9] / [r10])
```

Logic Instructions

- and, or, xor, nor have 2 register operands
- andi, ori, xori, nori have a register operand and an immediate operand that is zero-extended from 16 bits to 32 bits
- Examples:

```
or r7, r8, r9 //(r7 \leftarrow [r8] \text{ OR } [r9])
andi r4, r5, 0xFF //(r4 \leftarrow [r5] \text{ AND } 255)
```

 andhi, orhi, xorhi shift 16-bit immediate left and clear lower 16 bits to zero

Move Pseudo-Instructions

Pseudoinstructions provided for convenience:

```
mov ri, rj => add ri, r0, rj movi ri, Val16 => addi ri, r0, Val16 moviu ri, Val16 => ori ri, r0, Val16
```

Move Immediate Address for 32-bit value:

```
movia ri, LABEL => orhi ri, r0, LABEL_HI ori ri, ri, LABEL_LO
```

 LABEL_HI is upper 16 bits of LABEL, and LABEL_LO is lower 16 bits of LABEL

Branch and Jump Instructions

- Unconditional branch: br LABEL
- Instruction encoding uses signed 16-bit byte offset
- Signed/unsigned comparison and branch:

```
blt ri, rj, LABEL // signed [ri] < [rj] bltu ri, rj, LABEL // unsigned [ri] < [rj]
```

- beq, bne, bge, bgeu, bgt, bgtu, ble, and bleu
- Unconditional branch beyond 16-bit offset:

```
jmp ri // jump to address in ri
```

Subroutine Linkage Instructions

- Subroutine call instruction: call LABEL
- Saves return address (from PC) in r31 (ra)
- Target encoded as 26-bit immediate, Value26
- At execution time, 32-bit address derived as:
 PC₃₁₋₂₈: Value26: 00
- Call with target in register: callr ri
- **Return** instruction: ref
 - Branches to address saved in r31 (ra)

Comparison Instructions

- Result of comparing two operands is placed in destination register: 1 (if true) or 0 (if false)
- Less-than comparisons that set ri to 0 or 1:

```
cmplt ri, rj, rk // signed [rj] < [rk]
cmpltu ri, rj, rk // unsigned [rj] < [rk]
cmplti ri, rj, Vall6 // signed [rj] < Vall6
cmpltui ri, rj, Vall6 //unsigned [rj] <Vall6</pre>
```

- Val16 is sign- or zero-extended based on type
- Similarly for: ...eq.., ...le.., ...le.., ...ge.., ...gt..

Shift and Rotate Instructions

• Shift right logical rj, destination register is ri:

```
srl ri, rj, rk //shift by amount in rk srli ri, rj, Val5 //shift by immediate value
```

- Shift right arithmetic sra, srai: same as above except that sign in bit rj_{31} is preserved
- Shift left logical sll, slli
- Rotate left rol, roli
- Rotate right ror (no immediate version)

Pseudoinstructions

- mov, movi, and movia already discussed;
 translated to other instructions by assembler
- Subtract immediate is actually add immediate with negation of constant:

```
subi ri, rj, Value16 => addi ri, rj, -Value16
```

Also can swap operands for comparisons:

```
bgt ri, rj, LABEL => blt rj, ri, LABEL
```

 Awareness of pseudoinstructions is not critical, except when examining assembled code

Carry/Overflow Detection for Add

- Nios II does not have condition codes (flags)
- Arithmetic performed in same manner for signed and unsigned operands
- Detect carry/overflow needs more instructions
- Carry Detection (unsigned operands): test if unsigned result is less than either one of the operands:

```
add r4, r2, r3 cmpltu r5, r4, r2
```

Carry bit is in r5

Carry/Overflow Detection for Add

- Overflow Detection (signed operands): compare signs of operands & result
- Use xor, and to check for same operand signs and different sign for result:

```
add r4, r2, r3
xor r5, r4, r2
xor r6, r4, r3
and r5, r5, r6
blt r5, r0, OVERFLOW
```

Similar checks for subtract carry/overflow

References

- Intel, "Nios II Processor Reference Guide," n2cpu-nii5v1gen2-683836-666887-2.pdf
 - 8. Instruction Set Reference
- C. Hamacher, Z. Vranesic, S. Zaky, N. Manjikian "Computer Organization and Embedded Systems," McGraw-Hill International Edition
 - Appendix B: from B.1 to B.10