Introduction Analog and Digital formulations Implementation Examples PID Tuning

Chapter 11 - PID Controllers

July 29, 2015

Outline

- Introduction
- 2 Analog and Digital formulations
- Implementation Examples
- 4 PID Tuning

What is a PID controller?

Definition

A Proportional Integral Deriviative controller is a loop feedback controller with continuous time equation:

$$u(t) = \underbrace{K_{p}e(t)}_{\text{Proportional Action}} + \underbrace{K_{i} \int_{0}^{t} e(\tau)d\tau}_{\text{Integral Action}} + \underbrace{K_{d} \frac{de(t)}{dt}}_{\text{Derivative Action}}$$

More than 90% of all closed loop controllers are PID.

Also controllers where the integral or derivative function is omitted exist.

These are called PI or PD controllers respectively.



What is a PID controller?

- Proportional action $K_pe(t)$: Action depends on the instaneous value of the control error. All advantages of a high loop gain
 - + Reduces rise time
 - + Improves robustness: $K \to \infty \Rightarrow S_P^T \to 0$
 - Reduces but **does not eliminate steady-state error**: Only when $K \to \infty$, error $\to 0$ (unless plant has pole(s) at s = 0)
 - Mind stability: limit on gain
- Integral action $K_i \int_0^t e(\tau) d\tau$: Gives a controller output that is proportional to the accumulated error. Reacts on constant errors
 - + Augments the type of P(s)C(s) by one, thus can eliminate steady state error in some cases
 - Makes transient response slower

- **D**erivative action $K_d \frac{de(t)}{dt}$: Acts on the rate of change of the control error. Reacts on quick variations
 - + Damping effect: reduces overshoot, improves transient response
 - Sensitive for noise, amplifies it if present

Outline

- Introduction
- 2 Analog and Digital formulations
- Implementation Examples
- 4 PID Tuning

Proportional Control

The continuous-time and discrete implementation are identical Continuous:

$$u_p(t) = K_p e(t) \quad \leftrightarrow \quad \frac{U_p(s)}{E(s)} = K_p$$

Discrete:

$$u_p[k] = K_p e[k] \quad \leftrightarrow \quad \frac{U_p(z)}{E(z)} = K_p$$

Derrivative Control

Discretization can be done with **backward Euler**, applying $\dot{y} \approx \frac{y[k]-y[k-1]}{T}$ or $s = \frac{z-1}{Tz}$

Continuous:

$$u_d(t) = K_d \frac{de(t)}{dt} \quad \leftrightarrow \quad \frac{U_d(s)}{E(s)} = K_d s$$

Discrete:

$$u_d[k] = K_d \frac{e[k] - e[k-1]}{T} \quad \leftrightarrow \quad \frac{U_d(z)}{E(z)} = K_d \frac{z-1}{T_s z}$$

with T_s the sampling time.

Other discretization methods can be used, but forward Euler can introduce instability.

Integral Control

Discretization can be done with **backward Euler**, applying $\dot{y} \approx \frac{y[k]-y[k-1]}{T}$ or $s = \frac{z-1}{T_z}$

The continuous equation is:

$$u_i(t) = K_i \int_0^t e(\tau) d\tau \quad \leftrightarrow \quad \frac{U_i(s)}{E(s)} = \frac{K_i}{s}$$

Differentiating this gives:

$$\dot{u}_i = K_i e(t)$$

Then applying backward Euler:

$$u_i[k] = u[k-1] + K_i Te[k] \quad \leftrightarrow \quad \frac{U_i(z)}{E(z)} = K_i \frac{zT_s}{z-1}$$

with T_s the sampling time.

Other discretization methods can be used, here is no significant difference.

Digital formulation combined

Digital PID controller

$$u[k] = K_p e[k] + \frac{K_d}{T_s} (e[k] - e[k-1]) + u_i[k]$$

with $u_i[k] = u_i[k-1] + K_i T_s e[k]$

In z-domain:

$$\frac{U(z)}{E(z)} = \frac{K_p}{T_s} + \frac{K_d}{T_s} \frac{z-1}{z} + \frac{K_i}{T_s} \frac{z}{z-1}$$

where $\frac{K_d}{T_s}$ and $K_i T_s$ are the new derivative and gains.

Alternative Digital PID controller


We can also discretize using the bilinear transformation:

$$\begin{aligned} \frac{U(z)}{E(z)} &= K_p + \frac{K_i}{s} + K_d s \bigg|_{s = \frac{2}{T} \left(\frac{z-1}{z+1}\right)} \\ &= K_p + \frac{K_i T(z+1)}{2(z-1)} + \frac{2K_d(z-1)}{T(z+1)} \\ &= \frac{\alpha_2 z^2 + \alpha_1 z + \alpha_0}{(z-1)(z+1)} \end{aligned}$$

where $\alpha_2, \alpha_1, \alpha_0$ are design parameters.

Alterantive Derivative Action

Imagine a jumping set point or rapidly changing signal. This results in a theoretically infinite, practically very large response of the derivative term.



 \Rightarrow Add a low-pass filter to the derivative term:

$$\frac{U_d(s)}{E(s)} = \frac{K_d s}{1 + s\tau}$$

With $s=j\omega$, breakpoint at $\omega=1/\tau$. This prevents amplification of high frequencies.

Alterantive Derivative Action

$$\frac{U_d(s)}{E(s)} = \frac{K_d s}{1 + s\tau}$$

Further e(t) is replaced by $c \cdot r(t) - y(t)$ with c the set point weighting, which is often set to zero to further reduce immediate influence of a sudden set point jump.

In time domain:

$$u_d(t) = -\tau \frac{du_d}{dt} + K_d(c \cdot r(t) - y(t))$$

This can also be discretized, but the bilinear method then introduces *ringing*, i.e. large oscillations in transient response.




Outline

- Introduction
- 2 Analog and Digital formulations
- Implementation Examples
- 4 PID Tuning

Analog Implementation

The key building block in the op-amp



- PV Process Variable y(t)
- SP Set Point r(t)
- Output Control action u(t)

Analog Implementation







FOXBORO 62H-4E-OH M/62H

Digital Implementation

The difference equations are typically implemented in a micro controller or FPGA:

$$u[k] = K_p e[k] + \frac{K_d}{T} (e[k] - e[k-1]) + u_i[k]$$

with $u_i[k] = u_i[k-1] + K_i Te[k]$

Steps to be implemented:

- Wait for clock interrupt
- Read analog input
- Compute control signal
- Set analog output
- Update controller variables
- Go to 1



Digital Implementation Example

PLC with a digital PID module:



Digital PID's:





Outline

- Introduction
- 2 Analog and Digital formulations
- Implementation Examples
- 4 PID Tuning

Manual Tuning

Effects of adjusting the parameters K_p , K_i , K_d :

PID gains	Rise Time	Overshoot	Setlling time	Steady-State error
$K_p \uparrow$	Decrease	Increase	Small Change	Decrease
$K_i \uparrow$	Decrease	Increase	Increase	Eliminate
$K_d \uparrow$	Small change	Decrease	Decrease	No change

Note: Changing one parameter can influence the effect of the other two. Use this table only as an indication.

Manual Tuning

In case the controller can be tuned while connected to the plant, following routine can be used:

- Set K_i and K_d equal to 0
- ② Increase K_p until you observe that the step response is fast enough and the steady-state error in small
- **3** Start adding some integral action in order to get rid of the steady state error. Keep in mind that too much K_i can cause instability!
- Add some derivative action in order to quickly react to disturbance and/or dampen the response

Heuristic Methods: Ziegler-Nichols rule

This method relies on empirically determining two parameters of the system (should again be practical possible):

- Set the integral and derivative gains to 0
- ② Increase the proportional gain K_p until the output of the control loop starts oscillating with at constant amplitude. The value of K_p at this point is referred to as ultimate gain $K_u \triangleq K_p$
- **3** Measure the period of the oscillations T_u at the output
- 4 Adjust the controller parameters according the table on the next slide.

Heuristic Methods: Ziegler-Nichols rule

With K_u and T_u determined like in the previous slide, a starting point for the parameters can be determined:

Control Type	K_p	K_i	K_d
Р	$0.5K_{u}$	-	-
PI	$0.45K_{u}$	$1.2K_p/T_u$	-
PD	$0.8K_{u}$	_	$K_pT_u/8$
PID	$0.6K_{u}$	$2K_p/T_u$	$K_pT_u/8$
Pessen Integral Rule	$0.7K_{u}$	$2.5K_p/T_u$	$3K_{p}T_{u}/20$
Some overshoot	$0.33K_{u}$	$2K_p/T_u$	$K_pT_u/3$
No overshoot	$0.2K_{u}$	$2K_p/T_u$	$K_pT_u/3$

Heuristic Methods: Ziegler-Nichols rule(example)

Example

Consider a plant with a given model:

$$P(s) = \frac{1}{(s+1)^3}$$

• We compute the critical gain K_c . This is the value of K_p for which $\angle(K_pP(s)) = -180^\circ$. On the Nyquist plot this the value of K_p for which $K_pP(s)$ passes through (-1,0).

$$K_c P(j\omega_c) = -1 \Leftrightarrow K_c = -(j\omega_c + 1)^3$$

$$= (3\omega_c^2 - 1) + j(\omega_c^3 - 3\omega_c)$$

$$\omega_c^3 - 3\omega_c = 0 \Rightarrow \omega_c = \sqrt{3}$$


$$K_c = 8$$

$$K_p = 4.8, K_l = 0.551K_p, K_d = 0.45K_p$$

Numeriacal Optimization Methods

The tuning of a PID controller is posed as a constrained optimization problem.


- For a given set of parameters K_p , K_i and K_d run a simulation of the closed-loop system, and compute some performance parameters (e.g. setting time, rise time, etc.) and a performance index.
- Optimize the performance index over the three PID gains.



Some Software Tools


Software Tool	Brief Description		
pidtool / pidTuner	It is a Matlab tool to interactively de-		
	sign a SISO PID controller in the feed-		
	forward path of single-loop, unity-		
	feedback control configuration		
Pidpy	It is a modular PID control library for		
	python that supports PID auto tun-		
	ing.		
INCA PID Tuner	It is a commercial tuning tool devel-		
	oped by IPCOS. It has a vast library of		
	PID structures for DCS and PLC Sys-		
	tems including Siemens, ABB, Hon-		
	eywell, Emerson, etc.		

pidtool /pidTuner - Demo



https://www.youtube.com/watch?v=2tKeOcaUv1I

INCA PID Tuner Demo



https://www.youtube.com/watch?v=XH2bkq1URSg