# **GLIB Modules & Functionalities**

Thomas Lenzi (thomas.lenzi@cern.ch)

This document describes how to interact with the GLIB modules.

### Contents

Contents	1
OptoHybrid Forward	2
Addressing	
Description	
Tracking Data Readout	
Addressing	
Description	
Counters	
Addressing	
Auui essiiig	4

# OptoHybrid Forward

This module forwards all the requests to the OptoHybrid.

### **Addressing**

Module ID 4

Address 0x4ZXYYYYY

0b 0100 ZZZZ XXXX YYYY YYYY YYYY YYYY YYYY

#### **Description**

All the requests made to this module are forwarded to the OptoHybrid n°X of the GLIB. The Z parameter indicates which module on the OptoHybrid will handle the request (see *OptoHybrid Modules & Functionalities* for more information).

## Tracking Data Readout

This module stores the tracking data coming from the OptoHybrid into a buffer and allows to readout the data through IPBus.

#### Addressing

Module ID 5

Address 0x50X0000Y

X register	Mode	Function
0	Read /write	Data packet
		A write operation will empty the FIFO
1	Read	FIFO occupancy
		Divide by 7 to compute the number of events
2	Read	is FIFO full?
3	Read	Is FIFO empty?

#### **Description**

To read out data, the software must operate a FIFO read on the register. It then has to form the data packets by regrouping the 32-bits words. Writing to the register will empty the buffer which is recommended after flashing the firmware onto the GLIB or OptoHybrid.

One data packet is composed of 7x 32 bits which are formatted as follows, the highest word being read out first.

"1010" & BC[11:0] & "1100" & EC[7:0] & Flags[3:0]
"1110" & ChipID[11:0] & Strips[127:112]
Strips[111:80]
Strips[79:48]
Strips[47:16]
Strips[15:0] & CRC[15:0]
OptoHybrid BX[31:0]

## Counters

This module holds all the counters of the GLIB. Writing to a given register will reset its value.

### Addressing

Module ID 6

Address 0x6000000YY

0b 0110 0000 0000 0000 0000 0000 YYYY YYYY

Y register	Mode	Function		
IPBus				
0 - 4	Read	IPBus strobes		
		Order: OptoHybrid 0, OptoHybrid 1, Tracking data 0, Tracking data 1,		
		Counters		
5 - 9	Read	IPBus acknowledgments		
T1 commands				
10 - 13	Read	T1 from AMC13		
		Order: LV1A, Calpulse, Resync, BC0		
GTX				
14 - 15	Read	Tracking links error		
16 - 17	Read	Trigger links error		
18 - 19	Read	Data packets received		