The ARM Instruction Set

Minsoo Ryu

Department of Computer Science and Engineering Hanyang University

msryu@hanyang.ac.kr

Topics Covered

□ Data Processing Instructions
 □ Branch Instructions
 □ Load-Store Instructions
 □ Software Interrupt Instruction
 □ Program Status Register Instructions
 □ Loading Constants
 □ ARMv5E Extensions
 □ Conditional Execution

Introduction

- ☐ Different ARM architecture revisions support different instructions
 - New revisions usually add instructions and remain backward compatible
 - Code you write for architecture ARMv4T should execute on an ARMv5TE processor

ARM Instruction Set

Mnemonics	ARM ISA	Description
ADC	v1	add two 32-bit values and carry
ADD	v1	add two 32-bit values
AND	v1	logical bitwise AND of two 32-bit values
В	v1	branch relative $+/-32$ MB
BIC	v1	logical bit clear (AND NOT) of two 32-bit values
BKPT	v5	breakpoint instructions
BL	v1	relative branch with link
BLX	v5	branch with link and exchange
ВХ	v4T	branch with exchange
CDP CDP2	v2 v5	coprocessor data processing operation
CLZ	v5	count leading zeros
CMN	v1	compare negative two 32-bit values
CMP	v1	compare two 32-bit values
EOR	v1	logical exclusive OR of two 32-bit values
LDC LDC2	v2 v5	load to coprocessor single or multiple 32-bit values
LDM	v1	load multiple 32-bit words from memory to ARM registers
LDR	v1 v4 v5E	load a single value from a virtual address in memory
MCR MCR2 MCRR	v2 v5 v5E	move to coprocessor from an ARM register or registers
MLA	v2	multiply and accumulate 32-bit values
VOM	v1	move a 32-bit value into a register

ARM Instruction Set

MRC MRC2 MRRC MRS	v2 v5 v5E	move to ARM register or registers from a coprocessor
	v3	move to ARM register from a status register (cpsr or spsr)
MSR	v3	move to a status register (cpsr or spsr) from an ARM register
MUL	v2	multiply two 32-bit values
MVN	v1	move the logical NOT of 32-bit value into a register
ORR	v1	logical bitwise OR of two 32-bit values
PLD	v5E	preload hint instruction
QADD	v5E	signed saturated 32-bit add
QDADD	v5E	signed saturated double and 32-bit add
QDSUB	v5E	signed saturated double and 32-bit subtract
QSUB	v5E	signed saturated 32-bit subtract
RSB	v1	reverse subtract of two 32-bit values
RSC	v1	reverse subtract with carry of two 32-bit integers
SBC	v1	subtract with carry of two 32-bit values
SMLAxy	v5E	signed multiply accumulate instructions ($(16 \times 16) + 32 = 32$ -bit)
SMLAL	v3M	signed multiply accumulate long $((32 \times 32) + 64 = 64$ -bit)
SMLALxy	v5E	signed multiply accumulate long $((16 \times 16) + 64 = 64$ -bit)
SMLAWy	v5E	signed multiply accumulate instruction (((32 × 16) \gg 16) + 32 = 32-bit
SMULL	v3M	signed multiply long $(32 \times 32 = 64$ -bit)

ARM Instruction Set

Mnemonics	ARM ISA	Description
SMULxy	v5E	signed multiply instructions ($16 \times 16 = 32$ -bit)
SMULWy	v5E	signed multiply instruction ($(32 \times 16) \gg 16 = 32$ -bit)
STC STC2	v2 v5	store to memory single or multiple 32-bit values from coprocessor
STM	v1	store multiple 32-bit registers to memory
STR	v1 v4 v5E	store register to a virtual address in memory
SUB	v1	subtract two 32-bit values
SWI	v1	software interrupt
SWP	v2a	swap a word/byte in memory with a register, without interruption
TEQ	v1	test for equality of two 32-bit values
TST	v1	test for bits in a 32-bit value
UMLAL	v3M	unsigned multiply accumulate long $((32 \times 32) + 64 = 64$ -bit)
UMULL	v3M	unsigned multiply long $(32 \times 32 = 64\text{-bit})$

Move Instructions

- □ Copy N into a destination register Rd, where N is a register or immediate value
 - For setting initial values and transferring data between registers
- ☐ Syntax: <instruction>{<cond>}{S} Rd, N

MOV	Move a 32-bit value into a register	Rd = N
MVN	Move the NOT of the 32-bit value into a register	$Rd = \sim N$


$$\Box$$
 PRE: r5 = 5, r7 = 8

MOV
$$r7, r5$$
 ; let $r7 = r5$

□ POST:
$$r5 = 5, r7 = 5$$

Barrel Shifter

- ☐ In the MOV instruction, N can be more than just a register or immediate value
 - It can also be a register Rm that has been preprocessed by the barrel shifter prior to being used by a data processing instruction
 - The barrel shifter can shift a 32-bit binary pattern left or right by a specific number of positions



Barrel Shifter

□ Example: we apply a logical shift left (LSL) to register Rm before moving it to the destination register

 \Box PRE: r5 = 5, r7 = 8

MOV r7, r5, LSL #2 ; let r7 = r5*4 = (r5 << 2)

 \square POST: r5 = 5, r7 = 20

Table 3.2 Barrel shifter operations.

Mnemonic	Description	Shift	Result	Shift amount y
LSL	logical shift left	xLSL y	$x \ll y$	#0–31 or <i>Rs</i>
LSR	logical shift right	xLSR y	$(unsigned)x \gg y$	#1-32 or Rs
ASR	arithmetic right shift	xASR y	$(signed)x \gg y$	#1-32 or Rs
ROR	rotate right	xROR y	$((unsigned)x \gg y) \mid (x \ll (32 - y))$	#1-31 or Rs
RRX	rotate right extended	xRRX	$(c \text{ flag} \ll 31) \mid ((\text{unsigned})x \gg 1)$	none

Note: *x* represents the register being shifted and *y* represents the shift amount.

LSL and **LSR**




Figure 5-6: Logical shift left




Figure 5-7: Logical shift right

ASR and ROR




Figure 5-8: Arithmetic shift right




Figure 5-9: Rotate right

Arithmetic Instructions

- ☐ Implement addition and subtraction of 32-bit signed and unsigned values
- ☐ Syntax: <instruction>{<cond>}{S} Rd, Rn, N
 - N is the result of shift operation

ADC	Add two 32-bit values and carry	Rd = Rn + N + carry
ADD	Add two 32-bit values	Rd = Rn + N
RSB	Reverse subtract of two 32-bit values	Rd = N - Rn
RSC	Reverse subtract with carry of two 32-bit values	Rd = N - Rn -!(carry)
SBC	Subtract with carry of two 32-bit values	Rd = Rn - N -!(carry)
SUB	Subtract two 32-bit values	Rd = Rn - N

Two's Complement Representation

☐ Two's complement

Complement bits, add 1, and ignore the carry out of MSB

$$17_{10} = 00010001_{2}$$

$$111011110_{2}$$

$$+1$$

$$111011111_{2} = -17_{10}$$

sign bit									
0	1	1	1	1	1	1	1	=	127
0	0	0	0	0	0	1	0	=	2
0	0	0	0	0	0	0	1	=	1
0	0	0	0	0	0	0	0	=	0
1	1	1	1	1	1	1	1	=	-1
1	1	1	1	1	1	1	0	=	-2
1	0	0	0	0	0	0	1	=	-127
1	0	0	0	0	0	0	0	=	-128

8-bit two's complement integers

□ Ones' complement has a symmetry but an adder for ones' complement is somewhat trickier

Two's Complement Addition and Subtraction

☐ Two's complement addition

 Two's complement numbers can be added by <u>ordinary binary</u> addition, ignoring any carries beyond the MSB

□ Overflow detection

• If the signs of the addends are the same and the sign of the sum is different from the addends' sign

☐ Two's complement subtraction

 Negate the subtrahend by taking its two's complement, and then add it to the minuend (minuend + (- subtrahend))

Logical Instructions

□ Perform bitwise logical operations on the two source registers

☐ Syntax: <instruction>{<cond>}{S} Rd, Rn, N

AND	Logical bitwise AND of two 32-bit values	Rd = Rn & N
ORR	Logical bitwise OR of two 32-bit values	Rd = Rn N
EOR	Logical exclusive OR of two 32-bit values	Rd = Rn ^ N
BIC	Logical bit clear (AND NOT)	Rd = Rn & ~N

 \square PRE: r1 = 0b1111, r2 = 0b0101

BIC r0, r1, r2

□ POST: r0 = 0b1010

Comparison Instructions

- ☐ Compare or test a register with 32-bit values
 - No need to apply the S suffix to update the flag
- ☐ Syntax: <instruction>{<cond>}{S} Rn, N

CMN	Compare negated	Flags set as a result of Rn + N
CMP	Compare	Flags set as a result of Rn – N
TEQ	Test for equality of two 32-bit values	Flags set as a result of Rn ^ N
TST	Test bits of a 32-bit value	Flags set as a result of Rn & N

 \square PRE: cpsr = nzcvqFt_USER, r0 = 4, r9 = 4

CMP r0, r9

□ POST: cpsr = nZcvqFt_USER

Comparison Instructions

- ☐ The CMP is effectively a subtract instruction with the result discarded
- ☐ The TST instruction is a logical AND operation
- ☐ The TEQ is a logical exclusive OR operation

Multiply Instructions

■ Multiply the contents of a pair of registers and, depending upon the instruction, accumulate the results in with another register

☐ Syntax: MLA{<cond>}{S} Rd, Rm, Rs, Rn

MUL{<cond>}{S} Rd, Rm, Rs

MLA Multiply and accumulate Rd = (Rm*Rs) + Rn

MUL Multiply Rd = Rm*Rs

Multiply Instructions

 \Box PRE: r0 = 0x00000000

r1 = 0x00000002

r2 = 0x00000002

MUL r0, r1, r2; r0 = r1*r2


□ POST: r0 = 0x00000004

r1 = 0x00000002

r2 = 0x00000002

Binary Multiplication

■ Multiplication can be performed by adding a list of shifted multiplicands computed according to the digits of the multiplier



Multiply Instructions

☐ The long multiply instructions produce a 64-bit result

 The result is too large to fit a single 32-bit register so the result is placed in two registers labeled RdLo and RdHi

☐ Syntax: <instruction>{<cond>}{S} RdLo, RdHi, Rm, Rs

SMLAL	Signed multiply accumulate long	[RdHi, RdLo] = [RdHi, RdLo] + (Rm*Rs)
SMULL	Signed multiply long	[RdHi, RdLo] = (Rm*Rs)
UMLAL	Unsigned multiply accumulate long	[RdHi, RdLo] = [RdHi, RdLo] + (Rm*Rs)
UMULL	Unsigned multiply long	[RdHi, RdLo] = (Rm*Rs)

Multiply Instructions

```
□ PRE: r0 = 0x00000000

r1 = 0x00000000

r2 = 0xf0000002

r3 = 0x00000002

UMULL r0, r1, r2, r3; [r1, r0] = r2*r3

□ POST: r0 = 0xe00000004; = RdLo

r1 = 0x000000001; = RdHi
```

☐ Change the flow of execution or is used to call a routine

☐ Syntax: B{<cond>} label


BL{<cond>} label

BX{<cond>} Rm

BLX{<cond>} label | Rm

В	Branch	pc = label
BL	Branch with link	pc = label lr = address of the next instruction after the BL
ВХ	Branch exchange	pc = Rm & 0xfffffffe, T = Rm & 1
BLX	Branch exchange with link	pc = label pc = Rm & 0xfffffffe, T = Rm & 1 lr = address of the next instruction after the BL

□ The branch labels are placed at the beginning of the line and are used to mark an address that can be used later by the assembler to calculate the branch offset



- ☐ The branch with link, or BL, instruction is similar to the B instruction but overwrites the link register Ir with a return address
 - To return from a subroutine, the link register should be copied to the pc

```
BL subroutine ; branch to subroutine CMP r1, #5 ; compare r1 with 5 MOVEQ r1, #0 ; if (r1 == 5) then r1 = 0 subroutine ....

MOV pc, Ir ; return by moving pc = Ir
```

- ☐ The branch exchange (BX) and branch exchange with link (BLX) are the third type of branch instruction
 - The BX instruction uses an absolute address stored in register Rm
 - It is primarily used to branch to and from Thumb code
 - The T bit in the cpsr is updated by the least significant bit of the branch register

Load-Store Instructions

□ Transfer data between memory and registers
 □ Syntax: <LDR|STR>{<cond>}{B} Rd, addressing¹
 LDR {<cond>}{SB|H|SH} Rd, addressing²
 STR{<cond>}H Rd, addressing²

LDR	Load word into a register	Rd ← mem32[address]
STR	Save byte or word from a register	Rd → mem32[address]
LDRB	Load byte into a register	Rd ← mem8[address]
STRB	Save byte from a register	Rd → mem8[address]
LDRH	Load half word into a register	Rd ← mem16[address]
STRH	Save half word into a register	Rd → mem16[address]
LDRSB	Load signed byte into a register	Rd C SignExtend (mem32[address])
LDRSH	Load signed half word into a register	Rd > SignExtend (mem32[address])
		Rd <- SignExtend(mem8[address]) Rd <- SignExtend(mem16[address])

- □ LDR and STR instructions can <u>load and store data on</u> <u>a boundary alignment</u> that is the same as the datatype size being loaded or stored
 - LDR can only load 32-bit words on a memory address that is a multiple of four bytes—0, 4, 8, and so on

```
; load register r0 with the contents of the memory address
; pointed to by register r1

LDR r0, [r1] ; == LDR r0, [r1, #0]

; store the contents of register r0 to the memory address
; pointed to by register r1

STR r0, [r1] ; == STR r0, [r1, #0]
```

- In the above, the offset from register r1 is zero
- Register r1 is called the base address register

☐ Three addressing modes

Index method	Data	Base address register	Example
Preindex with writeback	mem[base + offset]	base + offset	LDR r0,[r1,#4]
Preindex	mem[base + offset]	not updated	LDR r0,[r1,#4]
Postindex	mem[base]	base + offset	LDR r0,[r1],#4

Note: ! indicates that the instruction writes the calculated address back to the base address register.

- In pre-indexed instructions, the offset is calculated and added to the base, and the resulting address is used for the transfer. If writeback is selected, the transfer address is written back into the base register
- In post-indexed instructions the offset is calculated and added to the base after the transfer. The base register is always updated by post-indexed instructions.

PRE r0 = 0x00000000
r1 = 0x00090000
mem32[0x00090000] = 0x01010101
mem32[0x00090004] = 0x02020202

LDR r0, [r1, #4]!

POST r0 = 0x02020202
r1 = 0x00090004

PRE r0 = 0x00000000
r1 = 0x00090000
mem32[0x00090000] = 0x01010101
mem32[0x00090004] = 0x02020202

LDR r0, [r1, #4]

POST r0 = 0x02020202
r1 = 0x00090000

PRE r0 = 0x00000000
r1 = 0x00090000
mem32[0x00090000] = 0x01010101
mem32[0x00090004] = 0x02020202

LDR r0, [r1], #4

POST(1) r0 = 0x01010101
r1 = 0x00090004

base

dest.

Single-register load-store addressing, word or unsigned byte.

Addressing ¹ mode and index method	Addressing ¹ syntax
Preindex with immediate offset	[Rn, #+/-offset 12]
Preindex with register offset	[Rn, +/-Rm]
Preindex with scaled register offset	[Rn, +/-Rm, shift #shift imm]
Preindex writeback with immediate offset	[Rn, #+/-offset 12]!
Preindex writeback with register offset	[Rn, +/-Rm]!
Preindex writeback with scaled register offset	[Rn, +/-Rm, shift #shift imm]!
Immediate postindexed	[Rn], #+/-offset 12
Register postindex	[Rn], +/-Rm
Scaled register postindex	[Rn], +/-Rm, shift #shift_imm

☐ Scaled means the address is calculated using the base address register and a barrel shift operation

	Instruction	r0 =	r1 + =
Preindex with writeback	LDR r0,[r1,#0x4]!	mem32[r1+0x4]	0x4
	LDR r0,[r1,r2]!	mem32[r1+r2]	r2
	LDR r0, [r1, r2, LSR#0x4]!	mem32[r1+(r2 LSR 0x4)]	(r2 LSR 0x4)
Preindex	LDR r0, [r1, #0x4]	mem32[r1+0x4]	not updated
	LDR r0,[r1,r2]	mem32[r1+r2]	not updated
	LDR r0, [r1,-r2, LSR #0x4]	mem32[r1-(r2 LSR 0x4)]	not updated
Postindex	LDR r0,[r1],#0x4	mem32[r1]	0x4
	LDR r0,[r1],r2	mem32[r1]	r2
	LDR r0, [r1], r2, LSR #0x4	mem32[r1]	(r2 LSR 0x4

☐ Transfer multiple registers between memory and the processor in a single instruction

☐ Syntax:

<LDM|STM>{<cond>}<addressing mode> Rn{!}, <registers>{^}

LDM	Load multiple registers	{Rd}* ^N ← mem32[start address + 4*N] optional Rn updated
STM	Store multiple registers	{Rd}*N → mem32[start address + 4*N] optional Rn updated


- ☐ Any subset of the current bank of registers can be transferred to memory or fetched from memory
 - The base register Rn determines the source or destination address
 - Rn can be updated following the transfer when register Rn is followed by!

Addressing mode for load-store multiple instructions.

Addressing mode	Description	Start address	End address	Rn!
IA	increment after	Rn	Rn + 4*N - 4	Rn + 4*N
IB	increment before	Rn+4	Rn + 4*N	Rn + 4*N
DA	decrement after	Rn - 4*N + 4	Rn	Rn - 4*N
DB	decrement before	Rn - 4*N	Rn-4	Rn - 4*N

PRE	mem32[0x80018] = 0x03
	mem32[0x80014] = 0x02
	mem32[0x80010] = 0x01
	$r0 = 0 \times 00080010$
	r1 = 0x00000000
	r2 = 0x00000000
	r3 = 0x00000000
	LDMIA r0!, {r1-r3}
POST	r0 = 0x0008001c
	r1 = 0x0000001
	r2 = 0x00000002
	r3 = 0x00000003
	base des

- □ Register r0 is the base register Rn and is followed by !, indicating that the register is updated after the instruction is executed
- "—" character is used to identify a range of registers
- ☐ Each register can also be listed, using a comma to separate each register within "{" and "}" brackets



Address pointer	Memory address	Data	
	0x80020	0x00000005	
$r\theta = 0x8001c \rightarrow$	0x8001c	0x00000004	
	0x80018	0x00000003	$r3 = 0 \times 000000003$
	0x80014	0x00000002	$r2 = 0 \times 000000002$
	0x80010	0x00000001	$rI = 0 \times 00000001$
	0x8000c	0x00000000	


Address pointer	Memory address	Data	
	0x80020	0x00000005	
$r\theta = 0$ x8001c \rightarrow	0x8001c	0x00000004	$r3 = 0 \times 000000004$
	0x80018	0x00000003	$r2 = 0 \times 000000003$
	0x80014	0x00000002	$r1 = 0 \times 000000002$
	0x80010	0x00000001	
	0x8000c	0x00000000	

<Post-condition for LDMIA>

<Post-condition for LDMIB>

Multiple Register Transfer

Load-store multiple pairs when base update used.



- : register
- If you use a store with base update, then the paired load instruction of the same number of registers will reload the data and restore the base address pointer
 - This is <u>useful when you need to temporarily save a group of</u> registers and restore them later

Multiple Register Transfer

PRE r0 = 0x00090000

r1 = 0x00000009

r2 = 0x00000008

r3 = 0x00000007

STMIB r0!, {r1-r3}

MOV r1, #1

MOV r2, #2

MOV r3, #3

PRE(2) r0 = 0x0009000c

r1 = 0x00000001

r2 = 0x00000002

r3 = 0x00000003

mem32[0x00090004] = 0x00000009

mem32[0x00090008] = 0x00000008

mem32[0x0009000c] = 0x00000007

LDMDA r0!, {r1-r3}

POST r0 = 0x00090000

r1 = 0x00000009

r2 = 0x00000008

r3 = 0x00000007

The decrement versions DA and DB decrement the start address and then store to <u>ascending</u> <u>memory locations</u>. With the increment and decrement load multiples, you can access arrays forwards or backwards.

Block Memory Copy

□ A simple routine that <u>copies blocks of 32 bytes from a some address location to a destination address location</u>
<u>location</u>

```
; r9 points to start of source data
                                                                  High memory
; r10 points to start of destination data
; r11 points to end of the source
                                                                             Source
loop
          ; load 32 bytes from source and update r9 pointer
                                                                                         Copy
                                                                                         memory
          LDMIA
                   r9!, {r0-r7}
                                                                                         location
          ; store 32 bytes to destination and update r10 pointer
         STMIA r10!, {r0-r7}
                                       ; and store them
                                                                             Destination
          : have we reached the end?
         CMP
                   r9, r11
                                                                  Low memory
          BNE
                   loop
                                       ; if not, go to loop
```

Multiple Register Transfer

- ☐ ARM implementations do <u>not usually interrupt</u> <u>instructions while they are executing</u>
 - On an ARM7, a load multiple instruction takes 2 + Nt cycles, where N is the number of registers to load and t is the number of cycles required for each sequential access to memory
 - If an interrupt has been raised, then it has no effect until the load-store multiple instruction is complete
 - Compilers, such as armcc, provide a switch to control the maximum number of registers being transferred on a loadstore, which limits the maximum interrupt latency

Stack Operations

- ☐ The ARM architecture <u>uses the load-store multiple</u> <u>instructions to carry out stack operations</u>
 - The pop operation uses a load multiple instruction
 - The push operation uses a store multiple instruction
- ☐ Ascending (A) or descending (D)
 - Ascending stacks grow towards higher memory addresses
 - Descending stacks grow towards lower memory addresses
- ☐ Full (F) or empty (E)
 - Full stack: stack pointer sp points to an address that is the last used or full location
 - Empty stack: the sp points to an address that is the first unused or empty location

Stack Operations

☐ Addressing methods

Addressing methods for stack operations.

Addressing mode	Description	Pop	= LDM	Push	= STM
FA	full ascending	LDMFA	LDMDA	STMFA	STMIB
FD	full descending	LDMFD	LDMIA	STMFD	STMDB
EA	empty ascending	LDMEA	LDMDB	STMEA	STMIA
ED	empty descending	LDMED	LDMIB	STMED	STMDA

Stack Operations

PRE r1 = 0x00000002

r4 = 0x00000003

sp = 0x00080014

STMFD sp!, {r1, r4}

POST r1 = 0x00000002

r4 = 0x00000003

sp = 0x0008000c

PRE Address Data

0x80018	0x00000001
0x80014	0x00000002
0x80010	Empty
0x8000c	Empty

POST Address Data

| 0x80018 | 0x00000001 |
| 0x80014 | 0x00000002

0x0000003

0x00000002

0x80010

0x8000c

PRE r1 = 0x00000002

r4 = 0x00000003

sp = 0x00080010

STMED sp!, {r1, r4}

POST r1 = 0x00000002

r4 = 0x00000003

sp = 0x00080008

PRE Address Data

0x80018	0x00000001
0x80014	0x00000002
0x80010	Empty
0x8000c	Empty
0x80008	Empty

POST Address Data

0x80018	0x00000001
0x80014	0x00000002
0x80010	0x00000003
0x8000c	0x00000002
sp → 0x80008	Empty

Swap Instructions

- □ Swap the contents of memory with the contents of a register
 - A special case of a load-store instruction
 - And atomic operation
- ☐ Syntax: SWP{B}{<cond>} Rd, Rm, [Rn]

SWP	Swap a word between memory and a register	tmp = mem32[Rn] mem32[Rn] = Rm Rd = tmp
SWPB	Swap a byte between memory and a register	tmp = mem8[Rn] mem8[Rn] = Rm Rd = tmp

Swap Instructions

- □ Swap cannot be interrupted by any other instruction or any other bus access
 - The system "holds the bus" until the transaction is complete

☐ Swap is <u>particularly useful</u>
 <u>when implementing</u>

 <u>semaphores and mutual</u>

 <u>exclusion</u> in an operating

 system

```
PRE mem32[0x9000] = 0x12345678
r0 = 0x00000000
r1 = 0x11112222
r2 = 0x00009000

SWP r0, r1, [r2]

PRE mem32[0x9000] = 0x11112222
r0 = 0x12345678
r1 = 0x11112222
r2 = 0x00009000
```

Software Interrupt Instruction

- ☐ Causes a software interrupt exception
 - Provides a mechanism for applications to call operating system routines
- ☐ Syntax: SWI{<cond>} SWI_number

```
SWI Software interrupt Ir_svc = address of instruction following the SWI spsr_svc = cpsr
pc = vectors + 0x8
cpsr mode = SVC
cpsr I = 1 (mask IRQ interrupt)
```

Software Interrupt Instruction

Before and after SWI instruction

SWI_handler

```
PRE
          cpsr = nzcVqift_USER
                                               ; Store registers r0-r12
          pc = 0x00008000
                                               ; and the link register
                                                         STMFD sp!, {r0-r12, lr}
          Ir = 0x003fffff
                              : Ir = r14
          r0 = 0x12
                              ; parameter
                                               ; Read the SWI instruction
                                                         LDR
                                                                   r10, [lr, #-4]
         parameter convention
                                               ; Mask off top 8 bits
          0x00008000 SWI
                              0x123456
                        comment field (23-0) software interrupt number (system call number)
                                                         BIC
                                                                   r10, r10, #0xff000000
POST
                                               ; r10 – contains the SWI number
         cpsr = nzcVqlft SVC
          spsr = nzcVqift USER
                                                         BL
                                                                   service routine
                                               ; Return from SWI handler
          pc = 0x00000008
          Ir = 0x00008004
                                                         LDMFD sp!, {r0-r12, pc}^
          r0 = 0x12
```

Software Interrupt Instruction




Figure 5-22: Software interrupt instruction

- The bottom 24 bits of the instruction are ignored by the processor, and may be used to communicate information to the supervisor code
- For instance, the supervisor may look at this field and use it to index into an array of entry points for routines which perform the various supervisor functions


Program Status Register Instructions

- □ Two instructions to directly control a program status register
 - The MRS instruction transfers the contents of either the cpsr or spsr into a register
 - The MSR instruction transfers the contents of a register into either the cpsr or spsr

☐ Syntax:

Program Status Register Instructions

MRS	Copy program status register to a general-purpose register	Rd = psr
MSR	Move a general-purpose register to a program status register	Psr[field] = Rm
MSR	Move an immediate value to a program status register	Psr[field] = immediate



Program Status Register Instructions

- ☐ The MSR first copies the cpsr into register r1
- ☐ The BIC instruction clears bit 7 of r1
- □ Register r1 is then copied back into the cpsr, which enables IRQ interrupts

Coprocessor Instructions

☐ Extend the instruction set

- The most common use of a coprocessor is the system coprocessor to control on-chip functions such as the cache and memory management unit on the ARM720
- A floating-point ARM coprocessor also has been developed, and application-specific coprocessors are a possibility

CDP	Coprocessor data processing—perform an operation in a coprocessor
MRC MCR	Coprocessor register transfer—move data from/to coprocessor registers
LDC STC	Coprocessor memory transfer—load and store blocks of memory to/from a coprocessor

Coprocessor Instructions

☐ Syntax:

```
CDP{<cond>} cp, opcode1, Cd, Cn {,opcode2}
<MRC|MCR>{<cond>} cp, opcode1, Rd, Cn, Cm {,opcode2}
<LDC|STC> {<cond>} cp, Cd, addressing
```

- The cp field represents the coprocessor number between p0 and p15
- The opcode fields describe the operation to take place on the coprocessor
- The Cn, Cm, and Cd fields describe registers within the coprocessor
- The interpretation of the opcode and register fields are coprocessor-dependent

Coprocessor Instructions

- □ The coprocessor operations and registers depend on the specific coprocessor you are using
 - Coprocessor (CP15) is reserved for system control purposes, such as memory management, write buffer control, cache control, and identification registers

```
; transferring the contents of CP15 register c0 to register r10 MRC p15, 0, r10, c0, c0, 0
```

- CP15 register-0 contains the processor identification number
 - Copied into the general-purpose register r10

Loading Constants pseudo instruction

- □ There is no ARM instruction to move a 32-bit constant into a register
 - Since ARM instructions are 32 bits in size, they obviously cannot specify a general 32-bit constant
- ☐ There are two pseudoinstructions
 - Syntax: LDR Rd, =constant

ADR Rd, label

LDR	Load constant	Rd = 32-bit constant
ADD	Load address	Rd = 32-bit relative address

LDR pseudoinstruction conversion.

Pseu	doin	struction	Actu	ıal in	structi	on	
LDR	r0,	=0xff	MOV	r0,	#0xf	f	W.
LDR	rO,	=0x5555555	LDR	rO,	[pc,	#offset	_12]

ARMv5E Extensions

☐ The ARMv5E extensions provide many new instructions

Instruction	Description
CLZ { <cond>} Rd, Rm QADD {<cond>} Rd, Rm, Rn QDADD{<cond>} Rd, Rm, Rn QDSUB{<cond>} Rd, Rm, Rn QSUB{<cond>} Rd, Rm, Rn SMLAxy{<cond>} Rd, Rm, Rs, Rn SMLALxy{<cond>} Rd, Rm, Rs, Rn SMLAWy{<cond>} RdLo, RdHi, Rm, Rs SMLAWy{<cond>} Rd, Rm, Rs, Rn</cond></cond></cond></cond></cond></cond></cond></cond></cond>	count leading zeros signed saturated 32-bit add signed saturated double 32-bit add signed saturated double 32-bit subtract signed saturated 32-bit subtract signed multiply accumulate 32-bit (1) signed multiply accumulate 64-bit signed multiply accumulate 32-bit (2)
SMULxy{ <cond>} Rd, Rm, Rs SMULWy{<cond>} Rd, Rm, Rs</cond></cond>	signed multiply (1) signed multiply (2)

ARMv5E Extensions

- □ One of the most important addition is the signed multiply accumulate instructions that operate on 16bit data
 - These operations are single cycle on many ARMv5E implementations
- □ ARM5vE provides greater flexibility and efficiency when manipulating 16-bit values, which is important for applications such as 16-bit digital audio processing

Count Leading Zeros Instruction

☐ Counts the number of zeros between the most significant bit and the first bit set to 1

CLZ r0, r1

POST r0 = 27

Saturated Arithmetic

- □ Normal ARM instructions wrap around when you overflow an integer value
 - 0x7fffffff + 1 = 0x80000000
 - Note that 0x7fffffff is the maximum positive value you can store in 32 bits

```
PRE cpsr = nzcvqiFt_SVC
r0 = 0x00000000
r1 = 0x70000000 (positive)
r2 = 0x7fffffff (positive)

ADDS r0, r1, r2

POST cpsr = NzcVqiFt_SVC
r0 = 0xefffffff (negative)
```

Saturated Arithmetic

☐ Using the ARMv5E instructions, you can saturate the result—once the highest number is exceeded the results remain at the maximum value of 0x7fffffff

Instruction	Saturated calculation
QADD	Rd = Rn + Rm
QDADD	$Rd = Rn + (Rm^*2)$
QSUB	Rd = Rn - Rm
QDSUB	$Rd = Rn - (Rm^*2)$

PRE	<pre>cpsr = nzcvqiFt_SVC r0 = 0x00000000 r1 = 0x70000000 (positive) r2 = 0x7fffffff (positive)</pre>		
	QADD r0, r1, r2		
POST	cpsr = nzcvQiFt_SVC r0 = 0x7fffffff		

ARMv5E Multiply Instructions

Table 3.15 Signed multiply and multiply accumulate instructions.

Instruction	Signed Multiply [Accumulate]	Signed result	Q flag updated	Calculation
SMLAxy SMLALxy SMLAWy SMULxy SMULWy	(16-bit *16-bit)+ 32-bit (16-bit *16-bit)+ 64-bit ((32-bit *16-bit) >> 16)+ 32-bit (16-bit *16-bit) ((32-bit *16-bit)>>> 16)	32-bit 64-bit 32-bit 32-bit 32-bit	yes - yes	$Rd = (Rm.x*Rs.y) + Rn$ $[RdHi, RdLo] += Rm.x*Rs.y$ $Rd = ((Rm*Rs.y) \gg 16) + Rn$ $Rd = Rm.x*Rs.y$ $Rd = (Rm*Rs.y) \gg 16$

- ☐ x and y select which 16 bits of a 32-bit register are used for the first and second operands, respectively
 - These fields are set to a letter T for the top 16-bits, or the letter B for the bottom 16 bits
 - For multiply accumulate operations with a 32-bit result, the Q flag indicates if the accumulate overflowed a signed 32-bit value