

Arithimetia for Computters 2: Floating Roint Numbers

CS 154: Computer Architecture
WeChatLectate 1901CS
Winter 2020

Ziad Matni, Ph.D.

Dept. of Computer Science, UCSB

Administrative

Lab 4 due today!

Assignment Project Exam Help

• Lab 5 out soon https://tutorcs.com

WeChat: cstutorcs

Syllabus (Schedule Section) has been updated

Midterm Exam (Wed. 2/12)

What's on It?

• Everything we've done so far from start to Monday, 2/10

What Should I Bring Assignment Project Exam Help

- Your pencil(s), eraser, MIPS Reference Card (on 1 page)
- You can bring <u>1</u> sheet of hand-written notes (turn it in with exam). 2 sides ok.

WeChat: cstutorcs

What Else Should I Do?

- IMPORTANT: Come to the classroom 5-10 minutes EARLY
- If you are late, I may not let you take the exam
- <u>IMPORTANT</u>: Use the bathroom before the exam once inside, you cannot leave
- Random seat assignments
- Bring your UCSB ID

Lecture Outline

- Floating Point Numbers Representations
- IEEE 754 F-P Standard

 https://tutorcs.com
- Arithmetic in F-P WeChat: cstutorcs
- Instructions for F-P
- Hardware implementations

Floating Point

- Representation for non-integral numbers
- Including very small and very large numbers
 Assignment Project Exam Help
- Usually follows the hormalized form

 We Chat: cstup frequentific notation

Floating Point Numbers in CPUs

We need 3 pieces of information to produce a binary floating point number:

Assignment Project Exam Help


https://tutorcs.com +/- N x 2^E WeChat: cstutorcs

The sign of the number (positive or negative)

The mantissa (aka significand) of the number


The exponent of the number

Representation in MIPS (Single Precision)



- The actual form Asserge The actual form Asserge The Assert Asse
 - Called the IEEE 754 F-P Standard (more on this coming up) https://tutorcs.com
- MIPS design for "single precision" has: tutores
 8 bits for exponent and 23 bits for fraction
- Gives a range from 2.0×10^{-38} to 2.0×10^{38} quite large!
- Overflow can occur: here it means that the exponent is too large to be represented in the exponent field.
- If a negative exponent is too large, then we get underflow.

Double Precision Floating Points



- Single Precision is flotatsin/cycorcs.com
- Double Precision is **double** in C/C++
 WeChat: cstutorcs
- 64 bits (2 words) instead of 32 bits
- 11 bits for exponent (instead of 8)
- 52 bits for fraction (instead of 23)

Gives a wider range and greater precision than single-precision

Range is: 2.0×10^{-308} to 2.0×10^{308}

IEEE 754 Floating-Point Standard

single: 8 bits single: 23 bits double: 11 bits double: 52 bits

S Exponent Fraction

 $x = (-1)^{S} \times (1 + Fraction) \times 2^{(Exponent-Bias)}$

- Includes single and double-precision definitions (since 1980s)
 - Very widespread in almost all CPUs today

Assignment Project Exam Help $S = 0 \Rightarrow positive$ $S = 1 \Rightarrow negative$

- The "1" in "1 + Fractioth "Ss intuition CS.COM

$$(1 + (s1 \times 2^{-1}) + (s2 \times 2^{-2}) + (s3 \times 2^{-3}) + (s4 \times 2^{-4}) + ...)$$

• The "Bias" is 127 for single-precision and 1023 for double-precision

Examples with single-precision:

$$S = 0$$
, $E = 0x82$, $F = 0$ is: $S = 0$, $E = 0x83$, $F = 0x600000$ is: $S = 0$, $E = 0x83$, $E = 0x600000$ is: $S = 0$, $E = 0x83$, $E = 0x600000$ is: $S = 0$, $E = 0x83$, $E = 0x600000$ is: $S = 0$, $E = 0x83$, $E = 0x600000$ is: $S = 0$, $E = 0x83$, $E = 0x600000$ is: $S = 0$, $E = 0x83$, $E = 0x600000$ is: $S = 0$, $E = 0x83$, $E = 0x600000$ is: $S = 0$, $S = 0$,

Useful website: https://www.h-schmidt.net/FloatConverter/IEEE754.html

More Examples!

- Hex word for single-precision F-P is: **0x3FA00000**
- So:

• So: WeChat: cstutorcs

Number = (+1) x (1 + 0.01) x
$$2^{(127-127)}$$
 = 1.01 (bin)
= 1 + 1 x 2^{-2} = **1.25**

Yet More Examples!!

 $2^{-1} = 0.5$ $2^{-2} = 0.25$ $2^{-3} = 0.125$ $2^{-4} = 0.0625$ $2^{-5} = 0.03125$

- Hex word for single-precision F-P is: **0xBF300000**
- So:

Assignment Project Exam Help 1011 1111 0011 0000 ... 0000 $S = 1 \quad E = 0 \times \frac{\text{https://tutpres.com}}{\text{full Pinch Signment Project Exam Help 1011 1111 0011 0000}$

• So:

WeChat: cstutorcs

Number = $(-1) \times (1 + 0.011) \times 2^{(126 - 127)} = 1.011$ (bin) = $-(1 + (1 \times 2^{-2}) + (1 \times 2^{-3})) \times 2^{-1}$ = $-(1 + 0.25 + 0.125) \times 0.5$ = -0.6875

Even More Examples!!!

```
2^{-1} = 0.5
2^{-2} = 0.25
2^{-3} = 0.125
2^{-4} = 0.0625
2^{-5} = 0.03125
```

- What is the single-precision word (in hex) of the F-P number 29.125?
- Ok, here we go:

```
lam remindassingnoment Project Exam Help
```

And, I know that **29** in binary is: **11101** $\frac{\text{https://tutorcs.com}}{\text{So 29.125}_{(10)}} = 11101.001_{(2)} = 1.1101001 \text{ x } 2^4$

This is a positive where set ones

F = 1101001000...0 (23 bits in all)

E = 4 + 127 = 131 = 10000011

• So:

Number in bin = 0 10000011 1101001000...0

or 0100 0001 1110 1001 0...0

= 0x41E90000

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
s	s exponent					fraction																									
1 bit	1 bit 8 bits				23 bits																										

Special Exponent Values

Consider Single-Precision Numbers:

Exponents 0x00 and 0xFF are reserved

Assignment Project Exam Help

- Smallest exponent is $1 \rightarrow$ Actual exponent = 1 127 = -126
- Smallest fraction is 0 https://tutorcs.com
- So, I get ±1.0 x 2⁻¹WeChat x 101torcs
- Largest exponent is 0xFE = 254 → Actual exp. = 127
- Largest fraction is 111...11, which approaches 1
- So, I get $\pm 2.0 \times 2^{+127} \cong \pm 3.4 \times 10^{+38}$

Special IEEE 754 Values

• IEEE 754 allows for special symbols to represent "unusual events"

- When S = 0, Assignment Project Exam Help

 IEEE callstthe: "High of the continuous series of
- "-inf" is when S = 1, E = 0xFF, F = 0WeChat: cstutorcs
- These are to optionally allow programmers to divide by 0.
- Allows for the result of invalid operations
 These are called "Not a Number" or "NaN"
 - Example: 0/0 , inf inf, etc...

Floating-Point Addition

Consider a 4-digit decimal example: $9.999 \times 10^1 + 1.610 \times 10^{-1}$

- Align decimal points

 Assignment Project Exam Help

 Shift number with smaller exponent

 - 9.999 x 10¹ + 0.016ttp9. //tutorcs.com
- 2. Add significands WeChat: cstutorcs
- 3. Normalize result & check for over/underflow
 - 1.0015 x 10²
- 4. Round and renormalize *if necessary* (what? why? Be patient...)
 - 1.002 x 10²

Floating-Point Addition

Consider a 4-digit **binary** example: $1.000 \times 2^{-1} + -1.110 \times 2^{-2}$

- Align decimal points

 Assignment Project Exam Help

 Shift number with smaller exponent

 - $1.000 \times 2^{-1} + -0.11 \times 3^{-1}$://tutorcs.com
- 2. Add significands WeChat: cstutorcs
- 3. Normalize result & check for over/underflow
 - 1.000 x 2⁻⁴
- 4. Round and renormalize *if necessary*
 - $1.000 \times 2^{-4} = 0.0625$

Re: Rounding in Binary F-P

- Can we create ANY floating point number in binary?
- What about 0A333gn(inent/P)Poject Exam Help
- Since we cannot create ALL F-P numbers in binary, rounding (i.e. approximating) is necessary
- Many users are not aware of the approximation because of the way values are displayed
 - The actual stored value is the nearest representable binary fraction

C++ Program to Illustrate Rounding in Binary F-P

```
#include <iostream>
#include <iomanip>
int main()
{
    // Try running stignment Project Exam Helpes
    // as a comparison. Or change the precision number around.
    std::cout << std: https://ctilionces.com
    std::cout << std::fixed;</pre>
                     WeChat: cstutorcs
    float a = 1.0/3;
    double b = 1.0/3;
    std::cout << a << "\n" << b << "\n";
    float x = 1.0/10;
    double y = 1.0/10;
    std::cout << x << "\n" << y;
```

Floating-Point Adder Hardware

- Much more complex than integer adder
 - Remember the 4 steps from a couple of slides ago?...
 Assignment Project Exam Help
- Doing it in one clank sychetword take too long
 - Would force a slower clock on the system
 - How much we can do in 1 clock cycle is a matter for later discussion
- FP adder usually takes several cycles
 - Can be pipelined for more efficient operation

FP Adder Sign Fraction Exponent Sign Exponent Fraction Hardware Compare Small ALU exponents Exponent Step 1 difference 0 Assignment Project Exam Help Control Shift right number right https://tutorcs.com Add Step 2 WeChat: cstutorcs 0 0 Step 3 Increment or Shift left or right Normalize decrement Step 4 Rounding hardware Round Sign Exponent Fraction

Matni, CS154, Wi20

20

2/5/20

FP Other Arithmetic Hardware

- FP multiplier is of similar complexity to FP adder
 - But uses a multiplier for significands instead of an adder Assignment Project Exam Help
- FP arithmetic hardwage/(includdition) is usually in a co-processor & does:
 - Addition, subtraction, multiplication, division, reciprocal, square-root
 - FP ←→ integer conversion
- Operations usually takes several cycles
 - Can be pipelined

MIPS FP Instructions

	Single-Precision	Double-Precision
Addition	add.s	add.d
Subtraction Assign	ment Breject Exam	Help.d
Multiplication ht	tps:Multorcs.com	mul.d
Division	div.s 'eChat: cstutorcs	div.d
Comparisons	C.XX.S	c.xx.d
Where <i>xx</i> can be Example: c.eq.s	eq, neq, lt, gt,	le, ge
Load	lwc1	lwd1
Store	swc1	swd1

Also, F-P branch, true (bc1t) and branch, false (bc1f)

MIPS FP Instructions

- FP instructions operate only on FP registers
- Programs generally don't do integer ops on FP data,
 or vice versa https://tutorcs.com
- More registers with minimal code-size impact

The Floating Point Registers

- MIPS has 32 *separate* registers for floating point:
 - **\$f0**, **\$f1**, etc...

Assignment Project Exam Help

- Paired for double-precision
 - \$f0/\$f1, \$f2/\$f3, etc...

WeChat: cstutorcs

• Example MIPS assembly code:

```
lwc1 $f4, 0($sp)  # Load 32b F.P. number into F4
lwc1 $f6, 4($sp)  # Load 32b F.P. number into F6
add.s $f2, $f4, $f6  # F2 = F4 + F6 single precision
swc1 $f2, 8($sp)  # Store 32b F.P. number from F2
```

Example Code

jr \$ra

```
C++ code:
   float f2c (float fahr) {
      return ((5.0/9.0)*(fahr - 32.0));}
              Assignment Project Exam Help
Assume:
fahr in $f12, result in $f0pqqpstantsintslebel memory space (i.e. defined in .data)
Compiled MIPS code: WeChat: cstutorcs
   f2c: lwc1 $f16, const5
        lwc1 $f18, const9
        div.s $f16, $f16, $f18
        lwc1 $f18, const32
        sub.s $f18, $f12, $f18
        mul.s $f0, $f16, $f18
```

25

YOUR TO-DOs for the Week

Readings!

Assignment Project Exam Help

• Work on Lab 5! https://tutorcs.com

WeChat: cstutorcs

Start studying for the midterm!

26

Assignment Project Exam Help

