
Contents

Controls	2
Layout overview	2
Non-layered inputs	4
Top encoder section	
Normal mode	
Shift mode	4
Button matrix pages	5
Layer Page	
Normal mode	
Shift mode	5
Page A	6
Normal mode	
Shift mode	6

Controls

Layout overview


Roughly speaking, the top encoder section controls looping and beat jumps, the left rotary potentiometer section controls the stem EQ, the switch matrix section controls a range of deck and global controls, and the bottom rotary section control browser, pitch and UI views. Shift retains it's use of providing access to alternate controls for a lot of inputs, the layer button accesses other command layers




Latch layers functionality does not use inbuilt, hardware-side, layering system. It's written from the ground up in VirtualDJ and mimics inbuilt latch-layer setting 2. That is, the latch layer button changes the functionality of the button matrix A-P. However, instead of cycling through 3 layers by repeatedly pressing the latch layer button, the button brings you to a menu page where each of the buttons represents a unique layer. This makes for a total of 16 layers, with 16 more theoretically possible using the shift button.

Faders of both controllers and the rotary potentiometer section including the pot switches of the right controller are completely unmapped, allowing for custom user mapping in VirtualDJ or other software (e.g. channel faders in Ableton, controls of external FX, etc).

With the exception of the stem EQ, controls targeting individual decks are split across the two controllers.



The arrangement mimics the way decks are shown in performance mode within VirtualDJ. Deck controls are thus "stacked" vertically, instead of being lined up in columns horizontally like in most other mappings.



The upper encoder section has the "top" deck on the left and the "bottom" deck on the right.

Non-layered inputs

Top encoder section

Normal mode Left controller

Right controller

global deck 1

y set loop deck 3

▼ set loop deck 2

 set loop deck 4

 $\underset{deck\ 1}{\longleftarrow}\ \text{jump long} \quad \underset{deck\ 1}{\longleftarrow}\ \text{loop size} \quad \underset{deck\ 3}{\longleftarrow}\ \text{loop size}$

Shift mode

Left controller

Right controller

deck 1

deck 1

jump short → move loop → jump short → move loop deck 3

deck 3

deck 2

deck 2

 $_{lackloss}$ jump short $_{lackloss}$ move loop $_{lackloss}$ jump short $_{lackloss}$ move loop deck 4

deck 4

Button matrix pages

Layer Page

=a,o ago								
Normal mode Left controller				Right controller				
A: play cntrl deck 1 & 3	B: slicer deck 1 & 3	C: beat roll deck 1 & 3	D: keycue deck 1 & 3	A: play cntrl deck 2 & 4	B: slicer deck 2 & 4	C: beat roll deck 2 & 4	D: keycue deck 2 & 4	
E: hotcues	F: cueloop	blank page	blank page	E: hotcues	F: cueloop	blank page	blank page	
deck 1 & 3	deck 1 & 3	N/A	N/A	deck 2 & 4	deck 2 & 4	N/A	N/A	
blank page	blank page	blank page	blank page	blank page	blank page	blank page	blank page	
N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
blank page	blank page	blank page	blank page	blank page	blank page	blank page	blank page	
N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A	
Shift mode Left controller					Right co	ontroller		
Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	
Non shift	Non shift	Non shift	Non shift	<i>Non shift</i>	<i>Non shift</i>	Non shift	Non shift	
Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	
<i>Non shift</i>	Non shift	Non shift	<i>Non shift</i>	<i>Non shift</i>	<i>Non shift</i>	<i>Non shift</i>	Non shift	
Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	
<i>Non shift</i>	Non shift	Non shift	<i>Non shift</i>	Non shift	Non shift	<i>Non shift</i>	Non shift	
Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	
Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	Non shift	

Page A

Normal m	ode						
Left controller				Right controller			
Cue	Set master	< nudge	nudge >	Cue	Set master	< nudge	nudge >
deck 1	deck 1	deck 1	deck 1	deck 2	deck 2	deck 2	deck 2
Play	Sync	slip	reverse	Play	Sync	slip	reverse
deck 1	deck 1	deck 1	deck 1	deck 2	deck 2	deck 2	deck 2
Cue deck 3	Set master deck 3	< nudge deck 3	nudge > deck 3	Cue deck 4	Set master deck 4	< nudge deck 4	nudge > deck 4
Play	Sync	slip	reverse	Play	Sync	slip	reverse
deck 3	deck 3	deck 3	deck 3	deck 4	deck 4	deck 4	deck 4
Shift mode Left controller				Right co	ntroller		
jump start	master tempo	edit grid	load track	jump start	master tempo	edit grid	load track
deck 1	deck 1	deck 1	deck 1	deck 2	deck 2	deck 2	deck 2
N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
deck 1	deck 1	deck 1	deck 1	deck 2	deck 2	deck 2	deck 2
jump start	master tempo	edit grid	load track	jump start	master tempo	edit grid	load track
deck 3	deck 3	deck 3	deck 3	deck 4	deck 4	deck 4	deck 4
N/A	N/A	N/A	N/A	N/A	N/A	N/A	N/A
deck 3	deck 3	deck 3	deck 3	deck 4	deck 4	deck 4	deck 4

