Lecture 12

$<\!2016\text{-}05\text{-}23~Mon\!>$

Contents

| | 4 |
|-------|---|
| ons . | 4 |
| | |
| | ļ |
| | ļ |
| | (|
| | (|
| | , |
| | |
| | |
| | |

| | RISC | CISC |
|---------------------|-----------|----------------------------------|
| registers | 32 | 6, 8, 16 |
| register class | 1 | some |
| arithmetic operands | registers | ${\it memory} + {\it registers}$ |
| instructions | 3-addr | 2-addr |
| addressing modes | r; M[r+c] | several |
| instruction length | 32 bits | variable |
| side effect | none | some |
| instruction cost | uniform | varied |


1.1 MIPS: example of RISC

- \bullet all instructions are 32-bit
- $\bullet\,$ following an opcode

1.2 Main Types of Instructions

- \bullet arithmetic
 - integer
 - floating point
- memory access instructions
 - load & store
- control flow
 - jump
 - conditional jump
 - call & return

I-Type:



```
example:
add $rt, $rs, immed
```

R-Type

example:

J-Type

example:

- j Label
 - I-Type instructions
 - load word, store word
 - arithmetic with immediate
 - R-Type instructions
 - arithmetic: add, and, or, etc.
 - control type instructions
 - I-Type control: op(6) + RS(5) + RT(5) + IMM(5)
 - J-Type control: op(6) + immediate(26)

1.2.1 Arithmetic

- most instructions have 3 operand
- arithmetic operands are registers, not memory
- operand order is fixed (destination first)
- e.g. add \$s0,\$s1,\$s2

```
A = B + C + D;

E = F - A;

add $t0, $s1, $s2

add $s0, $t0, $s3

sub $s4, $s5, $s0
```

1.2.2 Load and Store (Data Transfer): I-Type Instructions

```
A[8] = h + A[8];

lw $t0, 32($s3)

add $t0, $s2, $t0

sw $t0, 32($s3)
```

• store word operation has no destination (register) operand

| instructions | explanation |
|--------------|-----------------------|
| li \$v0, 4 | \$v0 <- 4 |
| la \$a0, msg | a0 < - address of msg |
| lw \$t0, x | \$t0 <- x |
| sw \$t0, y | y <- \$t0 |

- la, li
 - since a label represents a fixed memory address after assembly, la is actually a special case of li (load immediate)
- lw, la
 - e.g. x at address 10, contains 2

• lw \$t0 8(\$sp)

1.2.3 Control

- decision making instructions
 - alter control flow
 - change the "next" instruction to be executed

Label:

- conditional branch: I-Type Instructions
- unconditional branch: J-Type Instructions

instructions explanation

jal proc jump and link, start procedure proc, \$ra holds address of instruction following jal jump register, return from procedure call puts \$ra value back into PC

- address in branches
 - I-Type:
 - * specify a register and add it to address
 - · use instruction address register
 - \cdot most branches are local

1.3 MIPS Miscellaneous & Examples

1.3.1 MIPS Compiler Conventions

| name | register number | usage |
|-----------|-----------------|--|
| \$zero | 0 | the constant value 0 |
| \$v0-\$v1 | 2-3 | values for results and expression evaluation |
| \$a0-\$a3 | 4-7 | arguments |
| \$t0-\$t7 | 8-15 | temporaries |
| \$s0-\$s7 | 16-23 | saved (by callee) |
| \$t8-\$t9 | 24-25 | more temporaries |
| \$gp | 28 | global pointer |
| \$sp | 29 | stack pointer |
| \$fp | 30 | frame pointer |
| \$ra | 31 | return address |

1.3.2 System Calls

```
service
               code
                      arguments
                                                            result
 print integer
                      a0 = integer
                                                            console print
 print string
                  4
                      $a0 = string addr
                                                            console print
 read integer
                  5
                                                            a0 = result
                  8
                      a0 = string addr, a1 = length limit
 read string
                                                            console read
 exit
                 10
                                                            end of program
;; R-Type
         $s1, $s2, $s3
add
sub
         $s1, $s2, $s3
;; I-Type
         $s1, 100($s2)
lw
SW
         $s1, 100($s2)
bne
        $s4, $s5, Label
        $s4, $s5, Label
beq
;; J-Type
        Label
j
       Example
1.3.3
void swap(int v[], int k) {
    int temp;
    temp = v[k];
    v[k] = v[k+1];
    v[k+1] = temp;
}
swap:
        multi
                  $2, $5, 4
         add
                  $2, $4, $2
                  $15, 0($2)
         lw
                  $16, 4($2)
         lw
                  $16, 0($2)
         SW
                  $16, 4($2)
         sw
         jr
                  $31
                           variable
                                    register
                           k
                                     $5
                                     $4
```

\$2

&v[k]

1.3.4 Summary

MIPS assembly language

| | | MIII O GOODIIII | ory ranguage | |
|-----------------------|-------------------------|----------------------|---|-----------------------------------|
| Category | Instruction | Example | Meaning | Comments |
| Arithmetic | add | add \$s1, \$s2, \$s3 | \$s1 = \$s2 + \$s3 | Three operands; data in registers |
| | subtract | sub \$s1, \$s2, \$s3 | \$s1 = \$s2 - \$s3 | Three operands; data in registers |
| | add immediate | addi \$s1, \$s2, 100 | \$s1 = \$s2 + 100 | Used to add constants |
| | load word | lw \$s1, 100(\$s2) | \$s1 = Memory[\$s2 + 100] | Word from memory to register |
| | store word | sw \$s1, 100(\$s2) | Memory[\$s2 + 100] = \$s1 | Word from register to memory |
| Data transfer | load byte | lb \$s1, 100(\$s2) | \$s1 = Memory[\$s2 + 100] | Byte from memory to register |
| | store byte | sb \$s1, 100(\$s2) | Memory[\$s2 + 100] = \$s1 | Byte from register to memory |
| | load upper immediate | lui \$s1, 100 | \$s1 = 100 * 2 ¹⁶ | Loads constant in upper 16 bits |
| Conditional branch | branch on equal | beq \$s1, \$s2, 25 | if (\$s1 == \$s2) go to PC + 4 + 100 | Equal test; PC-relative branch |
| | branch on not equal | bne \$s1, \$s2, 25 | if (\$s1 != \$s2) go to PC + 4 + 100 | Not equal test; PC-relative |
| | set on less than | slt \$s1, \$s2, \$s3 | if (\$s2 < \$s3) \$s1 = 1; else \$s1 = 0 | Compare less than; for beq, bne |
| | set less than immediate | slti \$s1, \$s2, 100 | if (\$s2 < 100) \$s1 = 1; else \$s1 = 0 | Compare less than constant |
| | jump | j 2500 | go to 10000 | Jump to target address |
| Uncondi- | jump register | jr \$ra | go to \$ra | For switch, procedure return |
| tional jump | jump and link | jal 2500 | \$ra = PC + 4; go to 10000 | For procedure call |