
COMP 231 Introduction to Computer Organization Lab 2



This lab consists of four subproblems. For each one, you will need to write a short ARM assembly language program and create a matching Altera Monitor Program project. You will submit your work with GitHub Classroom. Your lab submission should consist of four folders named part1, part2, etc.

The purpose of this assignment is to gain familiarity with basic ARM assembly programming, use use arithmetic and logic instructions, and to interact with some of the simple output devices on the board.

Part 1: A simple algorithm

In the first part, you will need to construct a small program that counts the longest string of 1's in a 32-bit word of data. For example, if the input is 0x103fe00f, the result should be 9.

- 1. Create a folder called part1 for the files that go with this part of the project. In this folder, create a new assembly program file called part1.s. You should take time and work through some examples to understand how this program works. (i.e. it's fair game to ask you questions about this algorithm later)
- 2. Create a new Monitor Program project in the same folder. Use the DE10-Standard Computer.
- 3. Compile and load the program onto the FPGA board. You should single step through this program to verify that it works and to help you understand the algorithm.

```
/* Program that counts consecutive 1's */
          .text
                                    // executable code follows
          .global _start
_start:
                   R1, TEST_NUM
                                   // load the data word into R1
          LDR
          MOV
                   R0, #0
                                   // RO will hold the result
LOOP:
                                   // loop until the data contains no more 1's
          CMP
                   R1,
                       #0
          BEQ
                   END
                                   // perform SHIFT, followed by AND
                   R2, R1, #1
          LSR
          AND
                   R1, R1, R2
                   R0, #1
                                   // count the string length so far
          ADD
                   LOOP
          В
END:
                   END
TEST_NUM: .word
                   0x103fe00f
          .end
```

Figure 1: Assembly code that finds the longest string of 1's

Part 2: Functions as blocks of re-usable code

- 1. Create a folder called part2 for the files that go with this part of the project. Copy your part1.s file into this directory as part2.s.
- 2. In part1.s, extract the code that calculates the longest sequence of ones and makeit into a function. The function should be called ONES. Use register tt r1 for the input, and r0 for returning the result.
- 3. At the TEST_NUM label in the program is the word used as an example above. Add at least four more 32-bit values after this that will be used to test your function. The list should be terminated with a zero to signal the end of the list (i.e. .word 0).
- 4. In the _start: block, call the ONES program in a loop until it finds a zero. Track and store the longest sequence of ones into r5.
- 5. Create a new Monitor Program project in the same folder. Use the DE10-Standard Computer. Compile and load the program onto the FPGA board. You should single step through this program to verify that it works correctly. Your program may be tested with values other than those included in the list.

Part 3: Extending our program

Now we have a function that determines the longest string of ones, what if we wanted to find some other attributes of our data? For example, we could look for the longest string of zeros, or the longest string of alternating zeros and ones. Write a new program part3.s inside of a new part3 folder that computes the following:

- The longest string of 1's (as before) in a function called ones
- The longest string of 0's in a function called zeros
- The longest string of alternating 1's and 0's (e.g. 1010101) in a function called alternate. For example the string 101101010001 has a sequence of 6 alternating zeros and ones.

ones() should return its result in r5, zeros() in r6, and alternate() in r7. To write the alternate() function, consider what happens when a 32-bit string of alternating 0's and 1's is XORed against another string.

Again, in your _start: block, call all three functions in a loop and keep track of the longest sequences in registers r8, r9, and r10.

Create a new Monitor Program project and run/test your code so that it works correctly.

Part 4: Displaying our results

In part 3, we could only see the results of our calculations by inspecting specific register values in the monitor program. To make our program a little more useful we will add some more functionality to show our results on the seven-segment displays that are on teh DE10 board. The board has six 7-segment displays. Each display is capable of shwoing a single hex digit from 0 to F. We will need two displays to show an 8-bit value (i.e. 00 to FF).

You should copy over part3.s over to part4.s in a new folder and extend your program to display all three of the string counts on the seven segment displays. Show the longest string of 1's (r8) on HEX1-HEX0, the longest string of 0's (r9) on HEX3-HEX2, and the longest string of alternating bits (r10) on HEX5-HEX4.

A seven segment display is a simple output device that is shown in Fig. ??. The display devices are memory-mapped devices, in that they have fixed memory addresses. Performing a store operation to the device address will turn on the lights that have ones in the corresponding bits, and turn off those that are zero. The four displays corresponding to HEX3-HEX0 are controlled by writing a 32-bit value to memory address 0xff200020. Similarly, HEX5-HEX4 are controlled




Figure 2: DE10 Parallel Ports for 7-segment displays HEX5..HEX0

by the lowest 16 bits of the word at 0xff20030. Only the seven bits for each display are connected to wires – any unused bits are discarded.

To write an eight to the display, you would write a string of seven 1's to the display. To write a one, you would write a string with 1's in the 1 and 2 position, but 0's in the other bits (0,3-6).

You are given code for a function that provides the correct bit pattern for the values 0x0 to 0xf in Fig. ??. Note that the first entry in the BIT_CODES: array (0x0) has 1's in bits 0-5, but bit 6 is zero. Similarly the next entry has bits 1 and 2 turned on, which would light up the right-most segments corresponding to the number 0x1.

Lastly, the code in Fig. ?? provides some of the code that converts an 8-bit input value into two 4-bit values and displays them on the display device.

A couple of important nodes about the DISPLAY function. First, this code uses the DIVIDE function from your lab 1. You should copy that function into your part4.s file. Second, note that there will be only a single *store* instruction to each of the display devices. You will need to construct a single 32-bit value that has the bit patterns for all of the displays you are using (4 for HEX3-HEX0) and 2 for HEX5-HEX4).

```
/* Subroutine to convert the digits from 0 to 9 to be shown on a HEX display.
      Parameters: R0 = the decimal value of the digit to be displayed
      Returns: R0 = bit patterm to be written to the HEX display
SEG7_CODE:
                    R1, =BIT_CODES
            LDR
            LDRB
                    R0,
                        [R1, R0]
            BX
                    0b00111111, 0b00000110, 0b01011011, 0b01001111, 0b01100110
BIT CODES:
            .byte
                    0b01101101, 0b011111101, 0b00000111, 0b01111111, 0b01100111
            .byte
                            // pad with 2 bytes to maintain word alignment
            .skip
```

Figure 3: Subroutine to fetch bit patterns for use with 7-segment displays

```
/* Display R5 on HEX1-0, R6 on HEX3-2 and R7 on HEX5-4 */
                     R8, =0xFF200020 // base address of HEX3-HEX0
DISPLAY:
            LDR
                     R0, R5
                                      // display R5 on HEX1-0
            MOV
                                      // ones digit will be in RO; tens
                     DIVIDE
            _{
m BL}
                                      // digit in R1
                     R9, R1
                                      // save the tens digit
                     SEG7_CODE
            _{
m BL}
            MOV
                     R4, R0
                                      // save bit code
            MOV
                     R0, R9
                                      // retrieve the tens digit, get bit
                                      // code
                     SEG7_CODE
            _{
m BL}
                     R4, R4, R0, LSL # 8
            ORR
            code for R6 (not shown)
            code for R7 (not shown)
             . . .
```

Figure 4: Subroutine to display values on the 7-segment displays

Submission

When you have completed this entire exercise and have a functioning program, submit your lab 2 project folder with four folders and four project files via GitHub Classroom.