# This is comment list on Form Factors & Structure factors available in the Irena package

#### Content

- 1. Form factors parameters
- 2. List of form factors
  - 2.1. Spheroid
  - 2.2. Integrated Spheroid
  - 2.3. Cylinder & cylinderAR
  - 2.4. Algebraic\_Globules
  - 2.5. Algebraic Rods
  - 2.6. Algebraic Disks
  - 2.7. Unified\_Sphere
  - 2.8. Unified Rod & Unified RodAR
  - 2.9. Unified Disk
  - 2.10. CoreShell
  - 2.11. Core shell cylinder (Tube)
  - 2.12. Fractal Aggregate
- 3. Testing and using Form factors in users own code
- 4. Structure factors description
  - 4.1 Interferences
  - 4.2 Hard Spheres
  - 4.3 Square Well
  - 4.4 Sticky Hard Spheres
  - 4.5 Hayter Penfold MSA
  - 4.6 Interprecipitate SF

Form Factor	Parameter(s)		
spheroid	AspectRatio = ParticlePar1		
Integrated_Spheroid	AspectRatio=ParticlePar1		
Cylinders	Length=ParticlePar1		
CylindersAR	AspectRatio=ParticlePar1		
Unified_Disc	thickness = ParticlePar1		
Unified_Rod	length = ParticlePar1		
Unified_RodAR	AspectRatio = ParticlePar1		
Unified_Sphere	none needed		
Algebraic_Globules	AspectRatio = ParticlePar1		
Algebraic_Rods	AspectRatio = ParticlePar1, AR > 10		
Algebraic_Disks	AspectRatio = ParticlePar1, AR < 0.1		
User	uses user provided functions.		
	There are two user provided functions necessary -		
	F(q,R,par1,par2,par3,par4,par5)		
	and V(R,par1,par2,par3,par4,par5)		
	the names for these need to be provided in strings		
	the input is q and R in angstroms		
Tube	length=ParticlePar1 //length in A		
	WallThickness=ParticlePar2 //in A		
	CoreRho =ParticlePar3		
	COTENTIO - FAITICIEFAIS		

//rho [10^10 cm-2] (not delta rho squared!!!) of core

material

ShellRho =ParticlePar4

//rho [10^10 cm-2] (not delta rho squared!!!) of shell

material

SolventRho =ParticlePar5

//rho [10^10 cm-2] (not delta rho squared!!!) of surrounding

medium (air=0)

CoreShell CoreShellThickness=ParticlePar1

//skin thickness in Angstroms

CoreRho =ParticlePar2

//rho [10^10 cm-2] (not delta rho squared!!!) of core

material

ShellRho =ParticlePar3

//rho [10^10 cm-2] (not delta rho squared!!!) of shell

material

SolventRho =ParticlePar4

//rho [10^10 cm-2] (not delta rho squared!!!) of surrounding

medium (air=0)

Fractal aggregate Fractal Radius Of PriPart = Particle Par1

//radius of primary particle FractalDimension=ParticlePar2 //Fractal dimension

Structure factors included

Interferences reference: Beaucage, G. (1995). J Appl Crystallogr 28, 717-728.

Par1: ETA (center-to-center distance

Par2: Pack (number of particles In nearest neighbor sphere)

Hard Spheres reference: Percus-Yevick model, PERCUS, YEVICK PHYS.

REV. 110 1 (1958), THIELE J. CHEM PHYS. 39 474 (1968),

WERTHEIM PHYS. REV. LETT. 47 1462 (1981)

Par1: Radius [A]

Par2: Volume fraction (fraction)

Square Well reference: SHARMA, SHARMA, PHYSICA 89A,(1977),212,

NOTE - depths >1.5kT and volume fractions > 0.08 give UNPHYSICAL RESULTS when compared to Monte Carlo

simulations
Par1: Radius [A]

Par2: Volume fraction [fraction]

Par3: Well depth e/kT, dimensionless, positive values are

attractive

Par4: Well width, multiples of diameters

Sticky hard spheres no reference given in NIST macros...

Par1: Radius [A] Par2: Vol. fraction

Par3: Perturbation parameter (0.1)

Par4: Stickiness, tau

Hayer Penfold MSA no reference given in NIST macros...

Par1: Radius [A] Par2: Charges

Par3: Volume fraction

Par4: Temperature in Kelvin

Par5: Monovalent salt concentration (M)

Par6: dielectric constant of solvent

Interprecipitate SF Formula 6 in APPLIED PHYSICS LETTERS 93, 161904

(2008)...

Par1: Distance L [A]

Par2: Sigma (root-mean-square deviation (ordering factor))

# Important comment for Core-shell and Core shell cylinder (and Unified tube)

The volume definition for Core-shell objects is matter of discussion. Heated at times and I suspect that the appropriate answer depends on the case when and how the FF is used. Therefore from version 2.26 Irena macros include option which needs to be set – both Core shell and Core shell cylinder will share common parameter (this parameter is global for all cases of calls to core shell form factors or their volumes) of volume definition. The options are: whole particle, core, and shell.

Note: Unified tube is using as volume the volume of shell. It is how it is defined at this time and it is meant for cases like Carbon nanotubes, when this is appropriate. To match with core shell cylinder us "shell" as volume of particle.

#### List and graphs of each form factor included

## 2.1. Spheroid


uses sphere form factor for aspect ratio between 0.99 and 1.01:

$$F^2 = 3/(QR^3))*(sin(QR)-(QR*cos(QR))$$

volume:  $V=((4/3)*pi*radius^3)$ 

This calculation approximates integral ove R as rectangle (compare with Integrated spheroid).

graph for R = 50A




For aspect rations smaller than 0.99 and larger than 1.01 uses standard form factor for spheroid:


$$F = Integral of (3/(QR^3))*(sin(QR)-(QR*cos(QR)))$$

where QR=Qvalue\*radius\*sqrt(1+(((AR^2)-1)\*CosTh^2))

over of CosTh = 0 to 1. This is numerically calculated using 50 points (step in CosTh = 0.02). Following graphs are examples:



AR=0.1




## 2.2. Integrated Spheroid

same code as in the spheroid, but in this case the code integrates over the width of the R bin. Note, the bin star and end points are calcualted linearly (even for log-binned data) as half way distance:


$$R_{start} = (R_n + R_{n-1})/2$$
  
 $R_{end} = (R_n + R_{n+1})/2$ 


Uses adaptive steps to integrate essel function oscillations of the form factor over the width of the bin in R - note, the averaging is done including the volume of particles involved. This code is quite convoluted and time consuming. Its only reasonable use is for cases with wide bins in radius (R), when this removes some of the bessel function oscillations.

Examples with R width 40A, average size 50A (that means R varies from 30 to 70A). Note that the bessel function oscillations are somewho smooth out. With wider bins in R these oscillations may disappear all together.



AR=10 (Spheroid)





## 2.3. Cylinder & cylinderAR

The code uses the following code to calculate form factor for cylinder. Note, that also this code is doing the same integration as integrated spheroid above (see 2).

Form factor = integral over (Ft) for Alpha = 0 to pi/2, Ft is below:


LargeBes=sin(0.5\*Qvalue\*length\*Cos(Alpha)) / LargeBesArg

SmallBessDivided=BessJ(1, Qvalue\*radius\*Sin(Alpha))/Qvalue\*radius\*Sin(Alpha)


Ft = LargeBes\*SmallBessDivided

#### Examples

Cylinder with length 500A and radius 50A.



Disk (cylinder) with radius 500A and length 50A.



#### 2.4. Algebraic\_Globules

#### Note, that for this model 1/3 <= Aspect ratio <=3 is appropriate

This is form factor created by Andrew Allen, it is a formula, which satisfies the basic form factor requirements:


- 1. Terminate at 1 at small q
- 2. Place Gunier region in the right place
- 3. Have the right terminal slope

```
This is the code
```


```
argument = sqqt / AspectRatio
    surchi = (1 + AspectRatio^2 * asin(argument) / (sqqt)) / (2 * AspectRatio)
else
    //AspectRatio==1
    surchi = 1
endif
QR = currentR * Q_vector
bott = 1 + QR^2 * (2 + AspectRatio^2)/15 + 2 * AspectRatio * QR^4 / (9 * surchi)
F^2 = 1 / bott
```

#### Following are examples


#### AR=1, R=50A




#### AR=10, R=50A





#### AR=0.1, R=50A



Comparison of Algebraic globule with spheroid:








## 2.5. Algebraic\_Rods

#### Note, that this formula is valid for Aspect ratio >=10


Another formula Andrew Allen...

This is the code:

# Examples AR10



#### Comparison with cylinder AR = 10



## 2.6. Algebraic\_Disks


Note, that this formula is valid for Aspect ratio <=0.1

Another formula Andrew Allen...


This is the code:

```
QH = Q * R
QRd = Q * R * AspectRatio
topp = 1 + QRd^3 / (3 + QH^2) + (QH^2 * QRd / 3)^2
bott = 1 + QRd^2 * (1 + QH * QRd^2)/16 + (QH^3 * QRd^2 / 3)^2
F^2 = topp/bott
```

#### Examples Radius 500A, AR = 0.1



#### Comparison with cylinder AR 0.1



2.7. Unified_Sphere			
********	*******	*******	*******
********	*******	*******	*******
*********	********	*******	*******

This is formula from Unified fit model by Greg Beaucage (see Unified tool and documentation for it). The parameters are calculated from the code in the manual for each different shape. Specific formulas for these shapes were provided by Dale Schaefer...

This is the code:

G1=1 P1=4

Rg1=sqrt(3/5)\*radius B1=1.62\*G1/Rg1^4

QstarVector=qvalue/(erf(qvalue\*Rg1/sqrt(6)))^3

 $F^2 = G1*exp(-qvalue^2*Rg1^2/3)+(B1/QstarVector^P1)$ 

Example for R=50A compared with the spheroid with aspect ratio =1



### 2.8. Unified Rod & Unified rodAR

This is formula from Unified fit model by Greg Beaucage (see Unified tool and documentation for it). The parameters are calculated from the code in the manual for each different shape. Specific formulas for these shapes were provided by Dale Schaefer...

This is the code:

G2 = 1

Rg2=sqrt(Radius^2/2+Length^2/12)

B2=G2\*pi/length

P2=1

Rg1=sqrt(3)\*Radius/2

RgCO2=Rg1

G1=2\*G2\*Radius/(3\*Length)

B1=4\*G2\*(Length+Radius)/(Radius^3\*Length^2)

P1=4

QstarVector=qvalue/(erf(qvalue\*Rg2/sqrt(6)))^3

A=G2\*exp(-qvalue^2\*Rg2^2/3)+(B2/QstarVector^P2) \* exp(-RGCO2^2 \* qvalue^2/3)

QstarVector=qvalue/(erf(qvalue\*Rg1/sqrt(6)))^3

 $F^2 = A + G1*exp(-qvalue^2*Rg1^2/3)+(B1/QstarVector^P1)$ 

Example for R=50A and length 500A compared with the cylinder

***************************************
***************************************
***************************************

### 2.9. Unified Disk

This is formula from Unified fit model by Greg Beaucage (see Unified tool and documentation for it). The parameters are calculated from the code in the manual for each different shape. Specific formulas for these shapes were provided by Dale Schaefer...

```
This is the code:
       G2 = 1
       Rg2=sqrt(Radius^2/2+thickness^2/12)
       B2=G2*2/(radius^2)//dws guess
       Rg1=sqrt(3)*thickness/2// Kratky and glatter = Thickness/2
       RgCO2=1.1*Rg1
       G1=2*G2*thickness^2/(3*radius^2)
       B1=4*G2*(thickness+Radius)/(Radius^3*thickness^2)//same as rod
       P1=4
       QstarVector=Q/(erf(Q*Rq2/sqrt(6)))^3
       A=G2*exp(-Q^2*Rg2^2/3)+(B2/QstarVector^P2) * exp(-RGCO2^2 * Q^2/3)
       QstarVector=Q/(erf(Q*Rg1/sqrt(6)))^3
       F^2 = A + G1*exp(-Q^2*Rg1^2/3) + (B1/QstarVector^P1)
```

Example for R=250A and thickness 10A compared with the cylinder



#### 2.10. CoreShell

Note, this form factor calculation also includes integration over the width of bin in radii (same as integrated spheroid and cylinder).

Note: Input contrast is delta-rho-squared of core to surrounding (solvent/matrix)! this is very important to keep in mind.

Note, that there is volume definition choice you need to do: Whole particle, core, or shell, as appropriate for given problem. This volume definition is used for all volume calculations for this particle. It is global parameter for all core shell cylinder or core shell calls in the WHOLE EXPERIMENT....

Code (heavily simplified!):

```
Contrast = CoreRho - ShellRho
Result1=(3/(Q*R)^3)*(\sin(Q*R)-(Q*R*\cos(Q*R))) * Contrast * (4/3 * pi * R^3)
//Now add the shell (skin), thickness Rshell
r = R+Rshell
Contrast = ShellRho - SolventRho
Result2 = (3/(Q*r)^3)*(\sin(Q*r)-(Q*r*\cos(Q*r)))* Contrast * (4/3 * pi * r^3)
//summ them together and normalize by the total particle volume
F^2 = ( result1 + result2 )^2 / Volume
```

Volume definition depends on the setting of above discussed global parameter and is either:


Whole particle volume =  $4/3 * pi * (R+r)^3$ 


Core volume = 4/3 \* pi \* R^3

Shell volume =  $4/3 * pi * r^3$ 

Make sure your choice is appropriate

Note, that to my surprise these calculations (copied from NIST Form factors) do not normalize correctly to 1 at low q. The reason is that the weighting is done by volume and contrast. I'll need to look into this again and in detail...





## 2.11. Core shell cylinder

Note, this form factor calculation also includes integration over the width of bin in radii (same as integrated spheroid and cylinder).

This code has been developed some time ago and I am not sure about it's function...

Code which is being used is direct copy of NIST Core shell cylinder.

Note, that there is volume definition choice you need to do: Whole particle, core, or shell, as appropriate for given problem. This volume definition is used for all volume calculations for this particle. It is global parameter for all core shell cylinder or core shell calls in the WHOLE EXPERIMENT....

Volume definition depends on the setting of above discussed global parameter and is either: Whole particle volume =  $pi * (R+r)^2 * (L+2*r)$ Core volume = pi \* R^2 \* L Shell volume = pi \* r^2 \* L

#### 2.12. Fractal Aggregate

This form factor was requested by Dale Schaefer and I cannot very well guarantee its functionality....

code:


```
f = IR1T CalcSphereFormFactor(Qw[p],(2*Param1))
       //calculates the F(Q,r) part fo formula
       //this is same as for sphere of diameter = 2*Param1
       //(= radius of primary particle, which is hard sphere)
       //fractal part is next
        F^2 =f^2 * IR1T_CalculateFractAggSQPoints(Qw[p],currentR,Param1, Param2)
where
IR1T_CalculateFractAggSQPoints(Qvalue,R,r0, D) is
         QR=Qvalue*R
         part1=1
         part2=(qR*r0/R)^{-D}
         part3=D*(exp(gammln(D-1)))
         part5= (1+(qR)^{2})((D-1)/2)
         part4=abs(sin((D-1)*atan(qR)))
          return (part1+part2*part3*part4/part5)
```

Note, that parameters are:

Param1 - radius of primary particle

param2 - fractal dimension of the fractal particles

Example for R=100A, radius of primary particle 10 A and fractal dimension 2.5.



Comment: Note, that this is not scaled correctly at all... I have no idea why - apparently this formula is either wrongly coded or plainly does not behave right.

#### 3. Testing and using Form factors in users own code

To verify that the form factor works for you and to use the form factor if your own functions use following process and functions:

- 1. Generate Q wave with Qs for which the data are to be calculated
- 2. Generate intensity wave (will be redimensioned as necessary, so the only thing is, it should be double precision).
- 3. Generate distributipon of radii wave if you want to use single R, create wave with single point
- **4.** decide what you want to calculate:

```
F^2
              powerFct=0
V*F^2
              powerFct=1
V^2 * F^2
              powerFct=2
```

### **5.** Run following command:

```
IR1T_GenerateGMatrix(R_FF,Q_wave,R_dist,powerFct,"form factor
      name",param1,param2,param3,param4,param5, "", "")
```

This function will return R intensity, which is generally matrix with dimensions numpoints(Q vector) x numpoints(R dist), if R dist has 1 point only, returned is wave (vector) as expected and reasonable...

The param1 - param5 are form factor parameters, as desribed in chapter 1, the "" at the end are for user form factor functions (there go the strings with names of user form factor and volume function).

"form factor name" is name from list in chapter 1.

**6.** Create log-log plot of the data if R dist has single point. If R dist has more point, well, you have to pull out the right column of data you need to plot.

Note, that if the IR1T GenerateGMatrix function returns wave of NaN values if unknown name of form factor is passed in.

#### **Example of code:**

```
make/N=100 Q wave
Q wave=0.001+p/100
       //will create 100 points wave with values 0.001 to 1) values
Make/O/D R FF
      //makes some place for form factor
make R dist
R dist=50
//or
//make/N=3 R dist
//R dist={10,50,100}
       //creates R distribution and sets values
IR1T GenerateGMatrix(R FF,Q wave,R dist,powerFct,"form factor
       name",param1,param2,param3,param4,param5, "", "")
```

```
//Note, above lines belong on one line together!
       // replace powerFct with 0, 1, or 2!
// replace "form factor name" with name of form factor you want to use
Display R_FF vs Q_wave
ModifyGraph log=1
     //creates log-log graph of
```

## Structure factors


This is list of library of structure factors. These structure factors enable to deal with limited S(Q) effects in Irena package. The functionality is provided by library, which can be called by any other user code. The library provides also GUI for setting the user parameters. In principle, further structure factors can be added if they have less than 5 parameters.

## Interferences

This is original structure factor in Irena package. It has been provided as part of Unified fit model by Gregg Beaucage and is listed in his publication: Beaucage, G. (1995). Chapter 9 in "Hybrid Organic-Inorganic Composites", ACS symposium Series 585, edited by J. E. Mark, C. Y-C. Lee, and P. A. Bianconi, 207<sup>th</sup> National Meeting of the American Chemical Society, San Diego, CA, March 13-17, 1994. American Chemical Society, Washington, DC 1995. Pg. 97 – 111.

$$S(Q) = \frac{1}{1 + k * \frac{3*(\sin(Q\zeta) - Q\zeta\cos(Q\zeta))}{(Q\zeta)^3}}$$


Note, that this model is, for most practical purposes, close to Hard spheres model with different definition of the parameters k ("pack") and  $\zeta$  ("ETA"). Modeling II extends the capabilities by including three more structure factors using code available from NIST Igor package (ref). Included are now: Hard spheres, Square Well, and Sticky Hard Spheres, which can be used in addition to interferences model above and no structure factor (dilute limit).



# Hard spheres


The code for this structure factor has been copied from NIST SAS macros (Kline, S. R. (2006). J Appl Crystallogr 39, 895-900). Please, give them credit when using this structure factor. (http://www.ncnr.nist.gov/programs/sans/data/data\_anal.html)...

This is graph of NIST model and Irena implementation.



# Sticky hard spheres


The code for this structure factor has been copied from NIST SAS macros (Kline, S. R. (2006). J Appl Crystallogr 39, 895-900). Please, give them credit when using this structure factor. (http://www.ncnr.nist.gov/programs/sans/data/data\_anal.html)...



# Square well


The code for this structure factor has been copied from NIST SAS macros (Kline, S. R. (2006). J Appl Crystallogr **39**, 895-900). Please, give them credit when using this structure factor.

(http://www.ncnr.nist.gov/programs/sans/data/data\_anal.html)...



# Hayter Penfold MSA model

The code for this structure factor has been copied from NIST SAS macros (Kline, S. R. (2006). For any details on the use of these, please see the original code and description from NIST data analysis package (http://www.ncnr.nist.gov/programs/sans/data/data\_anal.html)... Please, give them credit when using this structure factor.



This is graph fro standard NIST set of parameters for both Irena package (black line) and NIST package (red dots). Both assume ONLY structure factor (Form factor is set to 1). The parameters were:

Diameter (A) 41.5 NOTE: Irena uses here radius, which is converted to diameter inside the

structure factor. This is to keep consistency with other structure factors.

Charge 19 0.0192 Volume Fraction Temperature(K) 298 monovalent salt conc. (M) 0 dielectric constant of solvent 78

Units are mentioned in the help for each filed on the Structure factor panel (you may have to enable help on Mac, it is shown always on PC in the bottom left corner of the Igor window).

Important note: this is comment from original NIST code....

// \*\*\* NOTE \*\*\*\* THIS CALCULATION REQUIRES THAT THE NUMBER OF

// Q-VALUES AT WHICH THE S(Q) IS CALCULATED BE

// A POWER OF 2

//!!!!! this is at this time NOT enforced in Irena implementation...

// I am not sure if this is really problem or not.

// How do I find out? Users need to test this for me and if necessary, I need to try it out. // in my testing there was NO problem with the results when the number of g pointds was arbitrary number of points...

# Inteprecipiatate SF

The code for this structure factor has been created on user request for study of precipitation in metals. It is based on formula 6 from APPLIED PHYSICS LETTERS 93, 161904 (2008), Study of nanoprecipitates in a nickel-based superalloy using small-angle neutron scattering and transmission electron microscopy by: E-Wen Huang, Peter K. Liaw, Lionel Porcar, Yun Liu, Yee-Lang Liu, Ji-Jung Kai, and Wei-Ren Chen. This manuscript refers for this formula to paper by R. Giordano, A. Grasso, and J. Teixeira, Phys. Rev. A 43, 6894 (1991). I did not look up original reference, so check it youself to make sure theformula is OK...

Structure factor has two parameters - L distance and sigma - root-mean-square deviation (ordering factor):

The interprecipitate structure factor S(Q) is expressed as a function of Q, L, and  $\sigma$ 


$$S(Q, L, \sigma) = 2 \left\{ \frac{1 - \exp[-(Q^2 \sigma^2)/4] \cos(QL)}{1 - 2 \exp[-(Q^2 \sigma^2)/4] \cos(QL) + \exp[-(Q^2 \sigma^2)/2]} \right\} - 1.$$
(6)

In Igor code this is programmed:

$$\begin{split} & top = 1 - exp(-(Q^2*sigma^2)/4)*cos(Q^*L) \\ & bot = 1-2*exp(-(Q^2*sigma^2)/4)*cos(Q^*L) + exp(-(Q^2*sigma^2)/2) \end{split}$$

$$S(Q,L,sigma) = 2*(top/bot) - 1$$

This is model of the SF for L=200 and Sigma=20 (Sigma/L=10). I have no way of testing this so this formula has not been checked against any data.



# Calling the library and use

Users can use built in library in their own code using following calls:

1. initialize by calling: IR2S InitStructureFactors() this is where the list of known structure factors is: SVAR ListOfStructureFactors=root:Packages:StructureFactorCalc:ListOfStructureFactors

#### 2. use by calling:

IR2S CalcStructureFactor(SFname,Qvalue,Param1,Param2,Param3,Param4,Param5,Param6)

I(Q) = I(Q, dilute limit) \* IR2S CalcStructureFactor(SFname,Qvalue,Param1,Param2,Param3,Param4,Param5,Param6)

//Dilute system;Interferences;HardSpheres;SquareWell;StickyHardSpheres;HayterPenfoldMSA

#### 3. Get panel by calling:

IR2S MakeSFParamPanel(TitleStr,SFStr,P1Str,FitP1Str,LowP1Str,HighP1Str,P2Str,FitP2Str,LowP2Str,H ighP2Str,P3Str,FitP3Str,LowP3Str,HighP3Str,P4Str,FitP4Str,LowP4Str,HighP4Str,P5Str,FitP5Str,LowP5S tr,HighP5Str, P6Str,FitP6Str,LowP6Str,HighP6Str,SFUserSFformula)

to disallow fitting of parameters, simply set FitP1Str="" etc.

then do not have to set low and high limits ...

#### Structure factors package...

IR2 OldInterferences this is roughly hard spheres (close to Percus-Yevick model, not

exactly), the ETA = 2\* radius and Phi = 8 \* vol. fraction for PC model. IR2 HardSphereStruct this is Percus-Yevick model IR2 StickyHS Struct this is sticky hard spheres

IR2 SquareWellStruct this is Square well

this is HayterPenfoldMSA IR2 HayterPenfoldMSA IR2 InterPrecipitateSF this is InterPrecipitate