















FACEPLATE MOUNTING/ SCREW, 4 PLACES

GENERAL NOTES

- SEE ARENA PLM FOR PART NUMBER REFERENCE
- DESIGNATORS AND CURRENT REVISIONS. [♦] CALLOUTS ARE APPLIED TO TOLERANCES THAT MAY REQUIRE SPECIAL QUALITY CONTROL PROCESSES.
 QUALITY CONTROL INSTRUCTIONS ARE OUTSIDE THE SCOPE OF THIS DRAWING AND ARE DEFINED BY EXTERNAL DOCUMENTATION TO BE AGREED TO WITH THE MANUFACTURER.
- ALL DIMENSIONS AND TOLERANCES MUST BE HELD REGARDLESS OF THE USE OF QUALITY CONTROL SYMBOLS
- (X.XX) DIMENSIONS ARE USED AS REFERENCE ONLY AND ARE NOT SUBJECT TO TOLERANCES.
 UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS AND TOLERANCES ARE APPLICABLE AT 20 DEGREES CELCIUS (68 DEGREES FAHRENHEIT) IN ACCORDANCE WITH
- (68 DEGREES FAHRENHEIT) IN ACCORDANCE WITH ANSI/ASME B89.6.2
 ALL HOMOGENOUS MATERIALS AND PROCESSES IN THIS DRAWING SHALL BE COMPLIANT TO THE EU ROHS DIRECTIVE 2011/65/EC
 REFER TO DETAILED WORK INSTRUCTIONS FOR ASSEMBLY SPECIFICATIONS SUCH AS SCREW TORQUE AND GLUE VOLUME.

ASSEMBLY INSTRUCTIONS:

- INSERT THE DRIVETRAIN INSERT INTO THE MAIN BODY. MAKE SURE TO ROUTE THE PRESSURE SENSOR CABLE THROUGH THE HOLE IN
- TO ROUTE THE PRESSURE SENSOR CABLE THROUGH THE HOLE IN THE OUTER BOX AS SHOWN.

 ONCE THE DRIVETRAIN IS INSERTED, SNAP THE MOTOR SIDE AND BUSHING SIDE NUTS INTO THE FLEX FOORS. USE A TOOL TO FULLY ENGAGE THE NUT MUSHROOM FEATURE INTO THE DOOR.

 SECURE THE DRIVETRAIN INSERT TO THE MAIN BODY USING #2-28X1/4" SCREWS IN 8 PLACES. TORQUE SCREWS TO SPEC GIVEN IN THE DETAILED WORK INSTRUCTIONS.

 ROUTE THE MOTOR AND PRESSURE SENSOR WIRES THROUGH THE
- HOLE IN THE FLOOR FACEPLATE.
- MOUNT THE FLOOR FACEPLATE.

 MOUNT THE FLOOR FACEPLATE TO THE MAIN BODY USING #619X1/4" SCREWS IN 4 PLACES. TORQUE SCREWS TO SPEC GIVEN IN
 THE DETAILED WORK INSTRUCTIONS.

 USE TAPE TO SECURE THE VENT BOARD COVER IN PLACE INSIDE
 THE FLOOR FACEPLATE. DO NOT ENGAGE SNAP FIT FEATURES.

 USE TAPE TO SECURE THE PRESSURE SENSOR COVER ONTO THE
- BACK OF THE MAIN BODY AS SHOWN. BATTERY PACK SHIPPED ALONGSIDE VENT IN PULP PACKAGING. DO NOT INSTALL.
- MAGNETICALLY ATTACH THE FLOOR FACEPLATE COVER ONTO
- THE FLOOR FACEPLATE.

 PULP PACKAGING NOT SHOWN. SEE DETAILED WORK
 INSTRUCTIONS FOR PACKAGING ASSEMBLY INSTRUCTIONS.

DRAWING NO. 201-00021 DESCRIPTION INITIAL RELEASE (FROM 900-00007 DRAWING) ECO DATE BY 000082 2/26/16 AK DO NOT SCALE DRAWING. WORK TO DIMENSION 000085 3/15/16 AK REMOVE SCRES (603-00019) FROM PSC NOTICE: CHANGES TO MATERIAL, DESIGN, CONFIGURATION OR PROCESS MAY NOT BE MADE WITHOUT NOTIFICATION TO ECOVENT. ALL MATERIALS AND PROCESSES MUST BE COMPLIANT WITH ENVIRONMENTAL LAWS AND REULATIONS AS REFERENCED IN XXXXX

REVIEW: DATE: TITLE: VENT 10X6 FLOOR 900-00007 DESCRIPTION SCALE:1:2 THIS DOCUMENT IS THE PROPERTY OF ECOVENT. NEITHER THIS DOCUMENT IS THE PROPERTY OF ECOVENT.