VISION 2020 $^{\lceil}$ From Domestic No.1 to Global Top 10 $_{\rfloor}$



SiW Touch Driver v 2.0

2016.04.15

R&D / Touch Team



History

Version	Date	Description
1.0	2016.03.15	1st release
2.0	2016.04.15	Rebuild Driver Framework for HAL layer




Table Of Contents

- 1. **Driver Operation**
 - 1.1 Architecture
 - 1.2 **Initialization Flow**
 - 1.3 Operation
 - 1.4 Kernel Log
- 2. Device Tree



1.1 Architecture

(1) Overview



[Fig. 1-1] Driver Relationship



1.1 Driver Architecture

(2) SiW Touch Driver Files


Layer	Name	Description
	siw_touch.c	Touch Core main control
	siw_touch_bus.c	Touch Bus I/F main
	siw_touch_bus_i2c.c	Touch Bus I/F - I2C type
	siw_touch_bus_spi.c	Touch Bus I/F - SPI type
	siw_touch_bus_event.c	Touch Input & Event control
	siw_touch_gpio.c	Touch GPIO control
Touch Core Lover	siw_touch_irq.c	Touch Interrupt control
Touch Core Layer	siw_touch_notify.c	Touch Notifier Chain
	siw_touch_of.c	Touch Device Tree analysis
	siw_touch_sysfs.c	Touch Sysfs control
	siw_touch_sys.c	Helper for Touch & System Inter-connection
	siw_touch_hal.c	Touch HAL
	siw_touch_hal_abt.c	Touch HAL for ABT
	siw_touch_hal_sysfs.c	Touch HAL for Sysfs
	touch_sw1828.c	Initialization driver for SW1828
Touch Chip Layer	touch_lg4894.c	Initialization driver for LG4894
	touch_lg4946.c	Initialization driver for LG4946
Build Files	Kconfig / Makefile	

[Table. 1-1] Driver File List

* HAL : Hardware Abstraction Layer



- 1.1 Driver Architecture
- (2) SiW Touch Driver Files Kconfig



```
Device Drivers > Input device support > Touchscreens > SiW Touch Support > Search (SIW)
 Symbol: TOUCHSCREEN SIW (=y)
 Type : boolean
Prompt: Silicon Works Touch Driver Core
  Location:
        -> Generic input layer (needed for keyboard, mouse, ...) (INPUT [=y])
         -> Touchscreens (INPUT TOUCHSCREEN (=v1)
            -> SiW Touch Support
  Defined at drivers/input/touchscreen/siw/Kconfig:3
  Depends on: !UML && INPUT [=y] && INPUT_TOUCHSCREEN [=y] && SPI_MASTER [=y] && I2C [=y]
 Symbol: TOUCHSCREEN_SIW_SW1828 [=y]
 Prompt: Silicon Works Touch Driver for SW1828
    -> Device Drivers
      -> Input device support
-> Generic input layer (needed for keyboard, mouse, ...) (INFUT [=y])
           -> SiW Touch Support
              -> Silicon Works Touch Driver Core (TOUCHSCREEN_SIW [=y])
  Defined at drivers/input/touchscreen/siw/Kconfig:25
Depends on: !UML && INPUT [=y] && INPUT_TOUCHSCREEN [=y] && TOUCHSCREEN_SIW [=y]
 Symbol: TOUCHSCREEN SIW LG4894 [=n]
 Type : boolean
 Prompt: Silicon Works Touch Driver for LG4894
    -> Device Drivers
        -> Generic input layer (needed for keyboard, mouse, ...) (INPUT [=y])
          -> Touchscreens (INPUT_TOUCHSCREEN [=y])
                                                                 < Exit >
```

[Fig. 1-2] Kconfig (example)



1.1 Driver Architecture

(2) SiW Touch Driver Files - Test Environment


Test Environment					
H/W		Odroid-XU4(Exynos5422)			
	Platform Version	Android 4.4.4			
S/W	Driver Folder	Kernel 3.10.9 {Kernel Top} / drivers / input / touchscreen / siw			
		{Kernel Top} / include / linux / input : siw_touch_notify.h			

[Table. 1-2] Test Environment



1.2 Initialization Flow

(1) Probe Sequence




[Fig. 1-3] Initial Probe Sequence



1.2 Initialization Flow

(2) siw_touch_probe






[Fig. 1-4] Inside operation of siw_touch_probe

1.2 Initialization Flow

(3) siw hal init




[Fig. 1-5] Inside operation of siw_hal_init




1.3 Operation

(1) Bus Access



[Fig. 1-6] Bus Access Flow for I2C type




[Fig. 1-7] Bus Access Flow for SPI type



1.3 Operation

(2) IRQ Handler (when touch event detected)



[Fig. 1-8] Interrupt Handling

• An appropriate external interrupt connection shall be guaranteed for the accuracy of this IRQ operation



1.4 Kernel Log (example)

(1) Probe message

```
[ 4182.573535] SW1828 driver init
[ 4182.575821] siw touch 5-0028: dev bus probe : 12c70000.i2c/i2c-5/5-0028
[ 4182.581784] siw touch 5-0028: SiW Touch Probe
[ 4182.586090] siw touch 5-0028: SW1828 quirks = 0x10030300
[ 4182.592590] siw touch 5-0028: SW1828 ops is NULL : default ops selected
[4182.598057] siw touch 5-0028: of gpio : reset-gpio(0x1), 23
[ 4182.603801] siw touch 5-0028: of qpio : irq-qpio, 22
[4182.610170] siw touch 5-0028: flags(of) = 0x00000100
[ 4182.613937] siw touch 5-0028: caps max x
[ 4182.619160] siw touch 5-0028: caps max y
[ 4182.625592] input: siw touch input as /devices/virtual/input/input13
[ 4182.631348] input input13: input device[i2c-5/5-0028 - siw touch input] registered (800, 480, 255, 15, 15, 1, 10)
[ 4182.641311] siw touch 5-0028: threaded irq request done(530, siw touch, 0x2002)
[ 4182.649485] siw touch 5-0028: hw reset delay : 210 ms
[ 4182.863458] siw touch 5-0028: fb notif change
[ 4182.869007] siw touch 5-0028: [T] chip id : 1828
[ 4182.872426] siw touch 5-0028: [T] version : v0.00 (0x00000000, 0xFF)
[ 4182.879125] siw touch 5-0028: [T] product id : L0L53P1
[ 4182.884244] siw touch 5-0028: [T] flash boot : idle(done), crc : ok (0x00000044)
[ 4182.894245] siw touch 5-0028: current driving mode is U3
[4182.898659] siw touch 5-0028: DDI Display Mode = 0x00000003
[ 4182.928510] siw touch 5-0028: SW1828 init done
[ 4182.972872] siw touch 5-0028: mon thread[siw touch-0, 5] begin
```

• 5-0028: I2C adaptor(0x12C70000) is registered as I2C-5 and the slave address of the client(SW1828) is 0x28.



1.4 Kernel Log (example)

(2) System Information

```
root@odroidxu3:/sys/bus/i2c/devices/5-0028 # 11
                                    2016-04-12 08:48 driver -> ../../../bus/i2c/drivers/siw touch
                   root
lrwxrwxrwx root
                                                               // = i2c:sw1828
                               4096 2016-04-12 08:40 modalias
-r--r-- root
                   root
                               4096 2016-04-12 08:40 name
                                                                    // = sw1828
-r--r-- root
                   root
                                     2016-04-12 08:40 power
drwxr-xr-x root root
                                    2016-04-12 08:40 subsystem -> ../../../bus/i2c
lrwxrwxrwx root root
-rw-r--r- root root
                               4096 2016-04-12 08:40 uevent
root@odroidxu3:/sys/device/virtual/input # 11
drwxr-xr-x root
                   root
                                     2016-04-12 08:40 input2
drwxr-xr-x root
                   root
                                     2016-04-12 08:41 input4
drwxr-xr-x root root
                                    2016-04-12 08:40 mice
                                    2016-04-12 08:47 siw touch input
drwxr-xr-x root root
root@odroidxu3:/proc/bus/input # cat devices
I: Bus=0018 Vendor=abcd Product=9876 Version=1234
N: Name="siw touch input"
P: Phys=i2c-5/5-0028 - siw touch input
S: Sysfs=/devices/virtual/input/input4
U: Uniq=
H: Handlers=event4
B: PROP=2
B: EV=9
B: ABS=67c8000 0
```



2. Device Tree (example)

Definition of I2C client device for SW1828 (refer to DTS example files for more information)

```
// indicates parent device : I2C_1 adapter block
&i2c 1 {
                                                                                                              (mandatory)
  sw1828@28 {
                                              // define new client device(sw1828) and slave addr. is 0x28
    status = "okay";
    compatible = "siw,sw1828";
                                              // compatible name (see touch xxxxxx.c)
                                              // slave addr.: 0x28
    reg = <0x28>;
    interrupt-parent = <&gpx1>;
                                              // interrupt source : GPIO group gpx1
    interrupts = <6 0x02>;
                                              // index 6(0~7) in gpx1 external interrupts
                                              // IRQF ONESHOT(0x2000) | IRQF TRIGGER FALLING(0x2)
    irqflags = <0x2002>;
    chip flags = <0>;
    reset-gpio = <&gpx1 7 GPIO ACTIVE LOW>;
                                                             // index 7 in gpx1
    irq-gpio = <&gpx1 6 GPIO_ACTIVE_LOW>;
                                                             // index 6 in qpx1
                                                                                  [gpx1 definition in exynos5422 pinctrl device tree]
    /* Caps */
    max x = <800>:
                                                                                     pinctrl@13400000 {
    max y = <480>;
    max pressure = <0xff>;
                                                                                       gpx1: gpx1 {
    max width = <15>;
    max orientation = <1>;
                                                                                                  interrupt-controller;
    max id = <10>;
                                                                                                  interrupt-parent = <&combiner>;
    /* role */
                                                                                                  #interrupt-cells = <2>;
    hw reset delay = <210>;
                                                                                                  interrupts = <28 0>, <28 1>, <29 0>, <29 1>,
    sw reset_delay = <90>;
                                                                                                                 <30 0>, <30 1>, <31 0>, <31 1>;
    use_lpwg = <0>:
    use lpwg test = <0>;
    /* firmware */
    use fw upgrade = <0>;
    use firmware = <0>:
```

- This example has been established based on odroidx-xu4(exynos5422) platform
- The detail configuration shall be modified up to main chipset.