Lab1 Report

Ye Feiyang

Yuan Xiaojie

July 17, 2012

Part2. Time Domain Analysis and Fault Location Test

Procedure

PartA: Fault location measurement

- 1. Carry out one port calibration.
- 2. Change the VNA to time domain.
- 3. Set Velocity Factore to 0.85.
- 4. Add a tested cable to calibrated system. Connect Load to the cable, and observe the peak value in time domain by adding a marker.
- 5. Change the Load to Short, record the peak value.

PartB: Two Fault in transmission line

- 1. Attach an N-type coaxial cable to channel 1 of the VNA. Attach a "Tee" to the end of the cable. Attach a coaxial cable to each of the arms of the "Tee". Leave the ends of the coaxial cables unterminated.
- 2. Record the number of faults and the position of each fault.
- 3. Attach the arms of a second "Tee" between the ends of the two coaxial cables. Attach the other coaxial cable to the third arm od the second "Tee".
- 4. Terminate the end of the network with the matched load. Record the number of faults and the position of each fault.
- 5. Remove the matched load and terminate the network with the short termination. Record the number of faults and the position of each fault.

Measured Data

Length of coaxial cables

Cable #1 = 61.3cm Cable #2 = 33.5cm Cable #3 = 102.1cm Cable #4 = 61.3cm

(Note: cable #1 is directly connected to the VNA, cable #2&3 are between the two "Tee"s and cable #4 is connected to the third arm of the second "Tee".)

Number of faults

Network #1 = 2 Network #2 = 3 Network #3 = 3 Network #4-matched = ∞ Network #4-short = ∞

Network	Fault #1	Fault #2	Fault #3	Fault #4	Fault #5
#1	0	1.15992 m	/	/	
#2	0	$1.25022\mathrm{m}$	$2.54823\mathrm{m}$	/	/
#3	0	$1.21343\mathrm{m}$	$1.93665\mathrm{m}$	$2.66715\mathrm{m}$	$3.38915\mathrm{m}$
#4-matchaed	0	$1.21465\mathrm{m}$	$1.97063\mathrm{m}$	$2.90913\mathrm{m}$	$3.66096\mathrm{m}$
#4-short	0	$1.21485\mathrm{m}$	$1.96214\mathrm{m}$	2.90913 m	$3.32120 \mathrm{m}$

Network	Fault #6	Fault $\#7$	Fault #8	Fault #9	Fault #10
#1	/	/	/	/	
#2	/	/	/	/	/
#3	$4.55284\mathrm{m}$	/	/	/	/
#4-matchaed	$3.86482\mathrm{m}$	$4.61230\mathrm{m}$	/	/	/
#4-short	$3.66096\mathrm{m}$	$3.85633\mathrm{m}$	$4.07717\mathrm{m}$	$4.25555\mathrm{m}$	$4.62080 \mathrm{m}$

Fault location

Comparisons & Comments on the Results

To begin with, when analyzing the data in the table, we should first divide them by 2 to indicate the fault location, since they represent the total distance for a wave to travel forward and backward.

Obviously, fault #1 for the five networks all occurs at the connetor between the VNA and cable. Then let us see the remaining faults.

Here gives a method to find out where the faults occurs at the network: find a path to any one junction point, calculate the total cable length along the path, multiply the result by two and compare with the data in table, then we can get the corresponding fault.

For network #1, since the network is terminated with the matched load, there are only two faults: one at the connector between the VNA and cable(location is 0), another at?

For networl #2, since the network is terminated with the short termination, so reflection will occur at the termination. Then, fault #1 occurs at the first connector, fault #2 at the termination and fault #3 results from the second refelction from the termination.

For network #3, fault #1 occurs at the first connector.

For network #4-matched, fault #2 occurs at the "Tee", fault #3 at the end of

cable #2, fault #5 at the end of cable #3 and the rest are due to multiple reflection. We also notice that there is no fault at the termination of the network.

For network #4-short, fault #2 occurs at the "Tee", fault #3 at the end of cable #2, fault #5 at the end of cable #3, fault #9 occurs at the termination of the network, and the rest are due to multiple reflection.

What I Learned from This Lab

From view of the VNA, it only measures the time for a wave that travelling forward and reflected backward, the distance from the wave generator to the fault location can calculated if we know the frequency and ε_r of the cable. Based on this principle, we can apply VNA to detecting the location where a transmission line has some problems. On the other hand, using VNA, we can also measure the impedance of a transmission line. We connect VNA at on end of the line and a load with varying impedance at the other end, once VNA detects no refelction, then the impedance of the line is equal to the impedance of the load.