

# **Subroutines and Stack**


## **Computer Engineering 1**

CT Team: A. Gieriet, J. Gruber, R. Gübeli, M. Meli, M. Rosenthal, A. Rüst, J. Scheier, M. Thaler

## Motivation



## ■ Do you remember?



## **Motivation**



## main program

## subroutine

```
B proc_a ; 1. call ; next instruction 1 ...

B proc_a ; 2. call ... ; next instruction 2 B ????
```

## Agenda



- Terminology
- Subroutine Call and Return
- Nested Subroutine Calls
- Stack
- ARM: PUSH and POP
- Nested Subroutines (revisited)
- Instructions using SP
- Assembler Directives

# Learning Objectives



At the end of this lesson you will be able

- to explain and discuss the term subroutine
- to comprehend and explain how a subroutine call and return are implemented on ARM Cortex-M
- to implement (nested) subroutines in assembly
- to explain how a processor stack works
- to determine the content of the stack for a given assembly program with nested subroutine calls

# Terminology



#### Subroutine / Procedures / Functions / Methods

- Sequence of instructions to solve a subtask
- Called by "name"
- Interface and functionality known
- Internal design and implementation are hidden
  - → information hiding
- Can be called from miscellaneous places in the program

### Why Subroutines?

- Basic element of structured programing
- Reuse of the same implementation → less mistakes
- Simplifies verification and maintenance
- Requires less memory
  - only one instance for several calls

# Terminology



### Terms used by ARM


- Routine, subroutine
  - A fragment of program to which control can be transferred that, on completing its task, returns control to its caller at an instruction following the call. *Routine* is used for clarity where there are nested calls: a routine is the *caller* and a subroutine is the *callee*.
- Procedure
  - A routine that returns no result value.
- Function
  - A routine that returns a result value.

source: Procedure Call Standard for the ARM Architecture ARM IHI 0042E, 30th November 2012



### Change of control flow

- Call Save PC to Link Register (LR)
- Return Restore PC from LR





#### Structure of Subroutine

- Label with Name
  - e.g. MulBy3
- Return Statement
  - BX LR

00000050	4604	MulBy3	MOV	R4,R0
00000052	0040		LSLS	R0,#1
00000054	4420		ADD	R0,R4
00000056	4770		BX	LR



#### BL <label>

- Store current PC in LR
- Branch to <label>
  - PC = PC +/- offset
  - offset range -16'777'216 to 16'777'214



## BLX (register)

- Store current PC in LR
- Address of subroutine in register
- Branch
  - PC = register
  - Branch address from 0 to 2<sup>32</sup>

```
BLX <Rm>
15 0
0 1 0 0 0 1 1 1 1 Rm 0 0 0


LR = PC - 2 (LSB set to '1')
PC = Rm
```

## **Nested Subroutine Calls**



### Nested Subroutine (Function) Calls

How do we do that with a single LR?




## Stack



### Stack as Object

- Methods
  - PUSH() and POP()
- Data
  - pushed (written) on top of the stack
  - popped (fetched, read) from the top of the stack → LIFO¹)



ZHAW, Computer Engineering

## Stack



### Implementation

- Stack Area (Section)
- Stack Pointer SP
- PUSH { ... }
- POP { ... }
- Direction on ARM
- Alignment

Continuous area of RAM


R13 -> points to last written data value

Decrement SP and store word(s)

Read word(s) and increment SP

"grows" from higher towards lower addresses → full-descending stack

Stack operations are word-aligned




### Stack



30.06.2015


#### Initialization

- Processor fetches initial value of SP (Stack-base) at reset
  - from address 0x0000'0000
- Stack-base is right above the stack area
  - SP is decremented before writing the first word





## ■ Example: PUSH {R0}



SP points to last value that has been written



# Example: POP {R0}

before		after	
R0 <b>0x9999'9999</b>	RAM	R0 <b>0x8765'4321</b>	RAM
Stack-base → 0x2003'0000	0	Stack-base → 0x2003'0000	
0x2002'FFFI	F 0x6B	0x2002'FFFF	0x6B
0x2002'FFFI	E 0x78	0x2002'FFFE	0 <b>x</b> 78
0x2002'FFFI	0x9A	<b>SP</b> 0x2002'FFFD	0 <b>x</b> 9A
0x2002'FFFC	C 0x87	$0x2002$ 'FFFC $\rightarrow 0x2002$ 'FFFC	0x87
0x2002'FFFI	B 0x87	0x2002'FFFB	0x87
0x2002'FFF	A 0x65	0x2002'FFFA	0 <b>x</b> 65
SP 0x2002'FFF9	9 0 <b>x</b> 43	0x2002'FFF9	0 <b>x</b> 43
$0x2002$ 'FFF8 $\rightarrow 0x2002$ 'FFF8	8 0 <b>x21</b>	0x2002'FFF8	0x21



#### PUSH

- registers
  - One or more registers to be stored

  - LR (R14) → M-bit
     → No other high registers
  - Lowest register stored first

```
PUSH {registers}
             reg list
addr = SP - 4*BitCount(M::reg list)
for i = 0 to 7
    if reg_list<i> == '1' then
        Mem[addr, 4] = R[i]
        addr = addr + 4
if (M == '1') then
    Mem[addr] = LR
SP = SP - 4*BitCount(M::reg list)
```

```
00000000 B480 PUSH {R7}

000000002 B43A PUSH {R1,R3,R4,R5}

00000004 B43A PUSH {R1,R3-R5}

00000006 B500 PUSH {LR}

00000008 B580 PUSH {R7,LR}
```

M::reg\_list = 0x03A = 0'0011'1010b




## Storage Order PUSH

- Lowest register
  - stored to lowest address 1)

#### Example

LDR	R1,=0x20010000
MOV	SP,R1
LDR	R2,=0x00112233
LDR	R3,=0x44556677
PUSH	{R2,R3}





#### POP

- registers
  - One or more registers to be restored
  - Low registers
    - → reg\_list =
       one bit per register
  - PC (R15) → P-bit
    - → No other high registers
  - Lowest register reloaded first

```
POP {registers}
             reg_list
addr = SP
for i = 0 to 7
    if reg list<i> == '1' then
        R[i] = Mem[addr, 4]
        addr = addr + 4
if (P == '1') then
    PC = Mem[addr]
SP = SP + 4*BitCount(P::reg list)
```

```
{R7}
00000000 BC80
                   POP
00000002 BC3A
                             {R1,R3,R4,R5}
                   POP
                             {R1,R3-R5}
00000004 BC3A
                   POP
                                               P::reg_list = 0x03A
00000006 BD00
                              \{PC\}
                   POP
                                                 = 0'0011'1010b
00000008 BD80
                             {R7,PC}
                   POP
```




#### ARM Stack

- Only Words  $\rightarrow$  32-bit
- Pushing and popping of half-words and bytes not possible
- I.e. SP mod 4 = 0 → word aligned
- "Number of PUSHs" = "Number of POPs"
- Stack-limit < SP < stack-base</p>
  - Stack size has to fit program requirements

# Nested Subroutines (revisited)



#### Save LR on Stack



Please note: **BX** LR is not required here, as we

directly restore the PC using POP



#### Add to / subtract from SP

- Immediate offset <imm>
- Offset range 0 1020d and 0 508d respectively



load stack pointer plus offset into register

```
ADD <Rd>,SP,#<imm>

15

10101 Rd imm8

<imm> = imm8:00

Rd = SP + <imm>
```

high registers as destination are not supported

allocate (ADD) /
deallocate (SUB)\_
memory
on the stack

SUB SP,SP,#<imm>
15 0
101100001 imm7


<imm> = imm7:00
SP = SP - <imm>



## Add to SP (Register)




load stack pointer plus offset into register



Target → any register except SP bits[6:3] = 1101b → SP

allocate (ADD) memory on the stack



Target  $\rightarrow$  SP bits[7, 2:0] = 1101b  $\rightarrow$  SP



### Instructions with Opcodes previously covered

CMP SP,Rm

CMP Rn, SP

MOV SP,Rm

MOV Rd, SP



## Accessing Memory using SP

- Immediate offset <imm>
- Offset range 0 1020d
- Word transfers

```
LDR (immediate) T2

LDR <Rt>,[SP,#<imm>]

15

10011 Rt imm8

<imm> = imm8:00

Rt = Mem[SP + <imm>]
```



## Using other instructions to implement 1)

PUSH {R2,R3,R6}

00000000 B083	SUB	SP,SP,#12
00000002 9200	STR	R2,[SP]
00000004 9301	STR	R3,[SP,#4]
00000006 9602	STR	R6,[SP,#8]

POP {R2,R3,R6}

8000000	<b>9A</b> 00	LDR	R2,[SP]
000000A	9B01	LDR	R3,[SP,#4]
000000C	9B02	LDR	R6,[SP,#8]
000000E	B003	ADD	SP,SP,#12

## **Assembler Directives**



#### Assembler Directives

- PROC / ENDP
- FUNCTION / ENDFUNC

### Mark start and end of a procedure / function

- Used by debugger (tool)
  - Buttons "step over" and "step out"
- Structure code for reader

## Conclusions



#### Subroutines

- Structured programming
  - → Avoids duplicated code / clear interface
- Call and return on ARM:
  - BL <label> and BX LR / POP {PC}
- Nested subroutines → save LR on stack

#### Stack

- Continuous area of memory → Last-in First-Out
- PUSH und POP
- ARM
  - Full-descending stack
  - SP points to last entry that has been written
  - grows from higher towards lower addresses