Exercise 2: ADC with Keyboard Interrupt

EG-252 Group Design Exercise – Microcontroller Laboratory

Dr K. S. (Joseph) Kim Dr Chris P. Jobling

September 2014

I. Overview

For this lab exercise you are provided a sample ADC assembly program given in the appendix. An electronic version of the program is available on the Blackboard site. The program uses interrupt generated by push buttons to trigger an ADC process on the MC9S08AW60 evaluation board. You are to carry out the following two tasks with this exercise:

- Use the sample program to practice on pushbutton with interrupt mechanism and ADC process with the evaluation board.
- Design an equivalent program in C language which can perform the same keyboard interrupt and ADC processing functions as provided by the example assembly program.

This exercise is worth 8 marks. For this exercise you need only demonstrate your program with the evaluation board to Dr Chris Jobling, Dr Timothy Davies or one of the demonstrators by **Tuesday**, **4 November 2014**.

You can view this document as a web page HTML, PDF or as a Word Document . docx

Appendix

Sample Program in Assembly

```
;* an interrupt is generated, which set LEDs 0:3 to light on.
10
              More interrupts are genereated if SW3 or SW4 are pressed.
12
13
                     INCLUDE
                                     'derivative.inc'; Include derivative-specific definitions
14
15
                  EQU
                                      $2000
    FLASH
16
                                             $0070
    RAM
                        EQU
17
    WATCH
                  EQU
                                      $1802
18
19
                     ORG
                                         RAM
20
                                                  ; Define a variable VAR_D with a size of 1 byte
    LED_on
                   DS.B
                                1
21
22
    ;Start program after reset
23
                     ORG
                                         FLASH
24
    START UP
25
                     LDA
                                         #$00
26
                     STA
                                         WATCH
                                                        ; Turn off the watchdog timer
27
28
    ; Init_GPIO init code
29
                     LDA
                              #$FF
                     STA
                              PTFDD
31
                     MOV
                                                   ; Initialize VAR_D, used to control the LEDs \,
                              #$OF, LED_on
32
                     LDA
                              #$FF
33
                     STA
                              PTDPE
                                               ; Port D is enabled with pull-up
34
                     RSP
                                                                             ; Reset stack pointer
35
36
    ; Enable\ interrupt\ for\ Keyboard\ input
37
                              #$60
                     LDA
38
                                                ; KBI1PE: enable KBI function for pins 5 and 6 only
                     STA
                             KBI1PE
39
                     BSET
                              $02, KBI1SC
                                                ; KBI1SC: KBACK=1, to clear KBI flag
40
                     BSET
                              $01, KBI1SC
                                                ; KBI1SC: KBIE=1, enable KBI
41
42
                     CLI
                                                ; Enable interrupt
43
44
    MAINLOOP
45
                     LDA
                              LED_on
                                                ; Simple loop
46
                     BRA
                                         MAINLOOP
47
48
    ; Interrupt service routine for a keyboard interrupt generated upon the press of a pushbutto
49
    ; with a falling edge (transition from high logic level "1" to low logic level "0")
50
    LED_SWITCH
                     BSET
                              $02, KBI1SC
                                               ; Clear KBI flag
52
                     LDA
                              #8
53
                     STA
                                               ; ADC conversion will start after a number is written
                              ADC1SC1
54
```

ADCLOOP

```
TST
                             ADC1SC1
                                              ; Check the COCO bit (conversion complete flag).
56
                    BPL
                             ADCLOOP
                                              ; if not complete, wait in the ADC loop.
57
                                              ; if complete, read the ADC outcome (digital value)
                    LDA
                             ADC1RL
58
                    STA
                             PTFD
                                              ; display over LED bar
                    RTI
60
61
    ; INT_ VECTOR
62
                    ORG
                             $FFD2
63
                    DC.W
                             LED_SWITCH
64
65
                    ORG
                             $FFFE
66
                    DC.W
                             START_UP
```

View on GitHub