
### To accompany Chapter 4.3 Line Spectra and their Applications Colophon This worksheet can be downloaded as a PDF file. We will step through this worksheet in class. An annotatable copy of the notes for this presentation will be distributed before the second class meeting as Worksheet 9 in the Week 5: Classroom Activities section of the Canvas site. I will also distribute a copy to your personal Worksheets section of the OneNote Class Notebook so that you can add your own notes using OneNote. You are expected to have at least watched the video presentation of Chapter 4.3 of the notes before coming to class. If you haven't watch it afterwards! After class, the lecture recording and the annotated version of the worksheets will be made available through Canvas. Example 3 Compute the exponential Fourier series for the waveform shown below and plot its line spectra.



# What do we know?

Solution to example 3

**Worksheet 11** 

• The pulse duration is T/w. • The recurrence interval T is w times the pulse duration. • w is the ratio of pulse repetition time to the pulse duration – normally called the *duty cycle*.

 $C_k = \frac{1}{2\pi} \int_{-\pi}^{\pi} f(\Omega_0 t) e^{-jk(\Omega_0 t)} d(\Omega_0 t)$ 

The recurrent rectangular pulse is used extensively in digital communication systems. To determine how faithfully such pulses will be transmitted, it is

Given


**Coefficients of the Exponential Fourier Series?** 

necessary to know the frequency components.

• Is the function **even** or **odd**?

• Does the signal have **half-wave symmetry**? • What are the cosequencies of symmetry on the form of the coefficients  $C_k$ ? • What function do we actually need to integrate to compute  $C_k$ ?

**DC Component?** Let k = 0 then perform the integral



 $\Omega_0 = 1 \text{ rad/s}; w = 2; T = 2\pi \text{ s}; T/w = \pi \text{ s}.$ 

 $\Omega_0=1$  rad/s; w=5;  $T=2\pi$  s;  $T/w=2\pi/5$  s.

 $\Omega_0=1$  rad/s; w=10;  $T=2\pi$  s;  $T/w=\pi/5$  s.

 $-6\pi$ 

• Recall pulse width = T/w

w = 2

w = 5

w = 10

**Implications** 

Example 4

Effect of pulse width on frequency spectra

**Exponential Fourier Series?** 

• As the width of the pulse **reduces** the width of the frequency spectra needed to fully describe the signal **increases** • more bandwidth is needed to transmit the pulse.

We will use the provided MATLAB script sinc.mlx to explore these in class. You will also need pulse\_fs.m. See Teams/OneNote for copies of these files.

Try it!

**Proof!** 

**Solution to example 4** 

of unity. This creates a train of impulses  $\delta(t \pm 2\pi k)$ .

and, therefore

Use the result of Example 1 to compute the exponential Fourier series of the impulse train  $\delta(t \pm 2\pi k)$  shown below

 $C_k = \frac{1}{2\pi}$  $f(t) = \frac{1}{2\pi} \sum_{k=-\infty}^{\infty} e^{jk\Omega_0 t}$ From the previous result,  $C_k = \frac{A}{w} \cdot \frac{\sin(k\pi/w)}{k\pi/w}$ and the pulse width was defined as T/w, that is Let us take the previous impulse train as a recurrent pulse with amplitude

 $A = \frac{1}{T/w} = \frac{1}{2\pi/w} = \frac{w}{2\pi}.$ 

 $\frac{2\pi}{w} \times \frac{w}{2\pi} = 1$ 

To solve this we take the previous result and choose amplitude (height) A so that area of pulse is unity. Then we let width go to zero while maintaining the area

 $2\pi$ 

 $4\pi$ 

 $6\pi$ 

 $8\pi$ 

 $\omega t$ 

N

 $\omega t$ 

 $2\pi$ 

 $2\pi$ 

**New coefficents** 

Also, recalling that

The coefficients of the Exponential Fourier Series are now:

-3

 $-2\pi$ 

• We are then left with just one pulse centred around t = 0.

• Line spectrum becomes a continous function.

**Power in Periodic Signals** 

• The frequency difference between harmonics also becomes smaller.

This result is the basis of the Fourier Transform which is coming next.

-2

A

 $\frac{\pi}{}$ 

w

 $-\pi$ 

0

w

 $\pi$ 


and the pulse train is as shown below:

Pulse with unit area

The area of each pulse is then

 $-2\pi$  $-\pi$ ww Area of each pulse is 1

and as  $\pi/w \to 0$  each recurrent pulse becomes a unit impulse, and the pulse train reduces to a unit impulse train.




 $C_n = \frac{w/2\pi}{w} \frac{\sin(k\pi/w)}{k\pi/w} = \frac{1}{2\pi} \frac{\sin(k\pi/w)}{k\pi/w}$ 

## What happens when the pulses to the left and right of the centre pulse become less and less frequent? That is what happens when $T \to \infty$ ? Well? • As $T o \infty$ the fundamental frequency $\Omega_0 o 0$

**Another Interesting Result** 

Consider the pulse train agin:



 $P_{\text{RMS}} = \sqrt{\frac{1}{T} \int_0^T |f(t)|^2 dt} = \sqrt{\sum_{k=-\infty}^{\infty} |C_k|^2}.$ 

 $C_n = \frac{A}{w} \cdot \frac{\sin(k\pi/w)}{k\pi/w}$ 

 $|C_k|^2$ .

 $|C_{-k}|^2 = |C_k^*|^2 = |C_k|^2$ .

Note that most of the power is concentrated at DC and in the first seven harmonic components. That is in the frequency range  $[-14\pi/T, +14\pi/T]$  rad/s.

Distorted sine wave

This can occur in the line voltages of an industrial plant that makes heavy use of nonlineear loads such as electric arc furnaces, solid state relays, motor drives,

Clearly, some of the harmonics for  $k \neq \pm 1$  are nonzero. One way to characterize the distortion is to compute the ratio of average power in all the harmonics that "should not be present", that is for k > 1, to the total average power of the distorted sine wave. The square-root of this ratio is called the *total harmonic* 

 $f_{\rm RMS} = \sqrt{\sum_{k=1}^{\infty} 2|C_k|^2}$ 

Compute the average power of a pulse train for which the pulse width is T/2 (duty cycle 50%). Use the previous result:

In your previous courses you may have come across the definitions of Signal Energy, Average Signal Power and Root Mean Square Power:

 $E = \int_0^T |f(t)|^2 dt$ 

 $P_{\text{av}} = \frac{1}{T} \int_{0}^{T} |f(t)|^{2} dt$   $P_{\text{RMS}} = \sqrt{\frac{1}{T} \int_{0}^{T} |f(t)|^{2} dt}$ 

### **Power Spectrum** The *power spectrum* of signal is the sequence of average powers in each complex harmonic: For real periodic signals the power spectrum is a real even sequence as

In []: A = 1; w = 8; [f,omega] = pulse\_fs(A,w,15);

title('Power Spectrum for pulse width T/8')

imatlab\_export\_fig('print-svg') % Static svg figures.

In [ ]: clear all

cd ../matlab format compact

Power spectrum

In [ ]: stem(omega,abs(f).^2)

ylabel('|C\_k|^2')

etc (E.g. Tata Steel!)

distortion (THD) of the signal.

 $y(t) = H(s)e^{st}$ , where:

By superposition

frequencies.

Illustration

**THD Defined** 

xlabel('\Omega\_0 [rad/s]')

**Total Harmonic Distortion** 

Example 5

as your starting point.


-0.5

0.5

If the signal is real and based on a sine wave (that is  $\mathit{odd}$ ), then  $C_k = 0$  and

Suppose that a signal that is supposed to be a pure sine wave of amplitude A is distorted as shown below

and we can define the THD as the ratio of the RMS value for all the harmonics for K>1 (the distortion) to the RMS of the fundamental which is **Computation of THD** Power Spectrum for Distorted Sine Wave 0.25 0.2 <sup>2</sup> k 0.15 IC 0.1 0.05



This picture below shows the effect of an LTI system on a periodic input in the frequency domain.

**Filtering** A consequence of the previous result is that we can design a system that has a desirable frequency spectrum  $H(jk\Omega_0)$  that retains certain frequencies and cuts off others. We will return to this idea later.

**Summary** • Line spectra • Power in periodic signals • Steady-state response of an LTI system to a periodic signal