VISCA Protocol

Part 1, Camera Return Command

Ack/Completion Message				
	Command Packet	Annotation		
ACK	z0 41 FF	Returned when the command is accepted.		
Completion	z0 51 FF	Returned when the command has been executed.		

z = Camera ID + 8

Part 2 Camera Control Command

Command	Function	Command Packet	Annotation
AddressSet	Broadcast	88 30 01 FF	Address setting
IF_Clear	Broadcast	88 01 00 01 FF	I/F Clear
CommandCancel		8x 21 FF	
CANAR	On	8x 01 04 00 02 FF	P. OMOFF
CAM_Power	Off	8x 01 04 00 03 FF	Power ON/OFF
	Stop	8x 01 04 07 00 FF	
	Tele(Standard)	8x 01 04 07 02 FF	
CAM 7	Wide(Standard)	8x 01 04 07 03 FF	
CAM_Zoom	Tele(Variable)	8x 01 04 07 2p FF	04 \ 74:1\
	Wide(Variable)	8x 01 04 07 3p FF	$p = 0(low) \sim 7(high)$
	Direct	8x 01 04 47 0p 0q 0r 0s FF	pqrs: Zoom Position (0(wide) ~0x4000(tele))
	Stop	8x 01 04 08 00 FF	
	Far(Standard)	8x 01 04 08 02 FF	
CAM_Focus	Near(Standard)	8x 01 04 08 03 FF	
	Direct	8x 01 04 48 0p 0q 0r 0s FF	pqrs: Focus Position
	One Push AF	8x 01 04 18 01 FF	
		pqrs: Zoom Position (0(wide)~ 0x4000(tele)) tuvw: Focus Position	
	Auto	8x 01 04 35 00 FF	
	Indoor	8x 01 04 35 01 FF	
	Outdoor	8x 01 04 35 02 FF	
CAM_WB	OnePush	8x 01 04 35 03 FF	
CAW_WB	Manual	8x 01 04 35 05 FF	
	Outdoor Auto	8x 01 04 35 06 FF	
	Sodium Lamp Auto	8x 01 04 35 07 FF	
	Sodium Auto	8x 01 04 35 08 FF	
CAM_RGain	Reset	8x 01 04 03 00 FF	
	Up	8x 01 04 03 02 FF	Manual Control of R Gain
CAIVI_KOaiii	Down	8x 01 04 03 03 FF	
	Direct	8x 01 04 43 00 00 0p 0q FF	pq: R Gain (0~0xFF)
CAM_Bgain	Reset	8x 01 04 04 00 FF	Manual Control of B Gain

Command	Function	Command Packet	Annotation	
	Up	8x 01 04 04 02 FF		
	Down	8x 01 04 04 03 FF		
	Direct	8x 01 04 44 00 00 0p 0q FF	pq: B Gain (0-0xFF)	
	Full Auto	8x 01 04 39 00 FF	Automatic Exposure mode	
CAM_AE	Manual	8x 01 04 39 03 FF	Manual Control mode	
	Bright	8x 01 04 39 0D FF	Bright mode(Manual control)	
	Reset	8x 01 04 0A 00 FF		
CAM Charter	Up	8x 01 04 0A 02 FF	Shutter Setting	
CAM_Shutter	Down	8x 01 04 0A 03 FF		
	Direct	8x 01 04 4A 00 00 0p 0q FF	pq: Shutter Position (0~0x15)	
	Reset	8x 01 04 0B 00 FF		
CAM Ini-	Up	8x 01 04 0B 02 FF	Iris Setting	
CAM_Iris	Down	8x 01 04 0B 03 FF		
	Direct	8x 01 04 4B 00 00 0p 0q FF	pq: Iris Position (0~0x11)	
	Reset	8x 01 04 0C 00 FF		
CAM C :	Up	8x 01 04 0C 02 FF	Gain Setting	
CAM_Gain	Down	8x 01 04 0C 03 FF		
	Direct	8x 01 04 0C 00 00 0p 0q FF	pq: Gain Positon (0~0x0E)	
	Reset	8x 01 04 0D 00 FF		
CAM Dui-la	Up	8x 01 04 0D 02 FF	Bright Setting	
CAM_Bright	Down	8x 01 04 0D 03 FF		
	Direct	8x 01 04 4D 00 00 0p 0q FF	pq: Bright l Positon ()	
	On	8x 01 04 3E 02 FF	E C (ON/OFF	
	Off	8x 01 04 3E 03 FF	Exposure Compensation ON/OFF	
CAME	Reset	8x 01 04 0E 00 FF		
CAM_ExpComp	Up	8x 01 04 0E 02 FF	Exposure Compensation Amount Setting	
	Down	8x 01 04 0E 03 FF		
	Direct	8x 01 04 4E 00 00 0p 0q FF	pq: ExpComp Position (0~0x0E)	
CAM Doold ight	On	8x 01 04 33 02 FF	BackLight On	
CAM_BackLight	Off	8x 01 04 33 03 FF	BackLight Off	
	Reset	8x 01 04 02 00 FF		
CAM_Aperture	Up	8x 01 04 02 02 FF	Aperture Control	
CAM_Aperture	Down	8x 01 04 02 03 FF		
	Direct	8x 01 04 42 00 00 0p 0q FF	pq: Aperture Gain (0~0x04)	
C11/11/	Reset	8x 01 04 3F 00 0p FF		
CAM_Memory(预置 位)	Set	8x 01 04 3F 01 0p FF	p: Memory Number(=0 to 127) Corresponds to 0 to 9 on the Remote Commander	
14.)	Recall	8x 01 04 3F 02 0p FF	Corresponds to vito y on the remote community	
CAM_ColorGain	Direct	8x 01 04 49 00 00 00 0p FF	(0~0x0E)	
CAM_2D Noise Reduction	Direct	8x 01 04 53 0p FF	(0~0x05)	
CAM_3D Noise Reduction	Direct	8x 01 04 54 0p FF	(0~0x03)	
	Lin	8x 01 06 01 VV WW 03 01 FF		
	Up		VV: Pan speed 0x01 (low speed) to 0x18 (high speed)	
Don tiltDuive	Down	8x 01 06 01 VV WW 03 02 FF	WW: Tilt speed 0x01 (low speed) to 0x14 (high	
Pan_tiltDrive	Left	8x 01 06 01 VV WW 01 03 FF	speed)	
	Right	8x 01 06 01 VV WW 02 03 FF	YYYY: Pan Position(TBD) ZZZZ: Tilt Position(TBD)	
	Upleft	8x 01 06 01 VV WW 01 01 FF		

Command	Function	Command Packet	Annotation
	Upright	8x 01 06 01 VV WW 02 01 FF	
	DownLeft	8x 01 06 01 VV WW 01 02 FF	
	DownRight	8x 01 06 01 VV WW 02 02 FF	
	Stop	8x 01 06 01 VV WW 03 03 FF	
	AbsolutePosition	8x 01 06 02 VV WW 0Y 0Y 0Y 0Y 0Z 0Z 0Z 0Z FF	
	RelativePosition	8x 01 06 03 VV WW 0Y 0Y 0Y 0Y 0Z 0Z 0Z 0Z FF	
	Home	8x 01 06 04 FF	
	Reset	8x 01 06 05 FF	

Part 3 Inquiry Command

t 3 Inquiry Command Command	Command Packet	Return Packet	Annotation
CAM_PowerInq	8x 09 04 00 FF	y0 50 02 FF	On
		y0 50 03 FF	Off(Standby)
CAM_ZoomPosInq	8x 09 04 47 FF	y0 50 0p 0q 0r 0s FF	pqrs: Zoom Position
CAM_FocusModeInq	8x 09 04 38 FF	y0 50 02 FF	Auto Focus Manual Focus
CAM_FocusPosInq	8x 09 04 48 FF	y0 50 03 FF y0 50 0p 0q 0r 0s FF	pqrs: Focus Position
CAIVI_Pocusi osiliq	6X 09 04 46 IT	y0 50 00 FF	Auto
		y0 50 00 FF	Indoor mode
	0.0004.25 FF	y0 50 02 FF	Outdoor mode
CAM_WBModeInq	8x 09 04 35 FF	y0 50 03 FF	OnePush mode
		y0 50 04 FF	ATW
		y0 50 05 FF	Manual
CAM_RGainInq	8x 09 04 43 FF	y0 50 00 00 0p 0q FF	pq: R Gain
CAM_BGainInq	8x 09 04 44 FF	y0 50 00 00 0p 0q FF	pq: B Gain
		y0 50 00 FF	Full Auto
		y0 50 03 FF y0 50 0A FF	Manual Shutter priority
CAM_AEModeInq	8x 09 04 39 FF	y0 50 0B FF	Iris priority
		y0 50 0D FF	Bright
		yo 30 0D 11	Bright
CAM_ShutterPosInq	8x 09 04 4A FF	y0 50 00 00 0p 0q FF	pq: Shutter Position
CAM_IrisPosInq	8x 09 04 4B FF	y0 50 00 00 0p 0q FF	pq: Iris Position
CAM_GainPosiInq	8x 09 04 4C FF	y0 50 00 00 0p 0q FF	pq: Gain Position
CAM_ BrightPosiInq	8x 09 04 4D FF	y0 50 00 00 0p 0q FF	pq: Bright Position
CAM_ExpCompModeInq	8x 09 04 3E FF	y0 50 02 FF	On
		y0 50 03 FF	Off
CAM_ExpCompPosInq	8x 09 04 4E FF	y0 50 00 00 0p 0q FF	pq: ExpComp Position
CAM_ApertureInq	8x 09 04 42 FF	y0 50 00 00 0p 0q FF	pq: Aperture Gain
CAM_MemoryInq SYS_MenuModeInq	8x 09 04 3F FF	y0 50pp FF y0 50 02 FF	pp: Memory number last operated. On
S i S_ivienui/rodeinq	8x 09 06 06 FF	y0 50 02 FF y0 50 03 FF	Off
CAM_LR_ReverseInq	8x 09 04 61 FF	y0 50 03 FF	On
C/ HVI_ER_Reverseing	04 07 04 01 11	v0 50 03 FF	Off
CAM_PictureFlipInq	8x 09 04 66 FF	y0 50 02 FF	On
		y0 50 03 FF	Off
CAM_IDInq	8x 09 04 22 FF	y0 50 0p 0q 0r 0s FF	pqrs: Camera ID
CAM_VersionInq	8x 09 00 02 FF	y0 50 ab cd	
Or IIII_ + Or IIIIIq	0.1 0,7 00 02 11	mn pq rs tu vw FF	0.10.771.0
VideoSystemInq	8x 09 06 23 FF	y0 50 pp FF	pp: 0~18 Video format 0:1080P60 1:1080P50 2:1080I60 3:1080I50 4:1080P25 6:720P60 7:720P50 8:720P30 9:720P25 10:1600*900@60(USB OUTPUT) 11:1440*900@60HZ(USB OUTPUT) 13:1280*800@60HZ(USB OUTPUT) 14:1024*768@60HZ(USB OUTPUT) 15:800*600@60HZ(USB OUTPUT) 16:800*600@30HZ(USB OUTPUT) 17:640*480@60HZ(USB OUTPUT) 18:640*480@30HZ(USB OUTPUT)
IR_Transfer	8x 09 06 1A FF	y0 50 02 FF y0 50 03 FF y0 50 02 FF	On Off On
IR_Receive	8x 09 06 08 FF	y0 50 02 FF	Off
		y0 07 7D 01 04 00 FF	Power ON/OFF
		y0 07 7D 01 04 07 FF	Zoom tele/wide
IR_ReceiveReturn		y0 07 7D 01 04 38 FF	AF On/Off
IX_IXCCCIVEIXCIUIII		y0 07 7D 01 04 33 FF	CAM_Backlight
		y0 07 7D 01 04 3F FF	CAM_Memory
D CLAY C 27	0.000011 EE	y0 07 7D 01 06 01 FF	Pan_tiltDrive
Pan-tiltMaxSpeedInq	8x 09 06 11 FF	y0 50 ww zz FF	ww: Pan Max Speed

				zz: Tilt Max Speed	
-1	0xF670	-30	0xFE50		
-					

	12	1/350		9	f6.8
	11	1/250		10	f5.6
	10	1/180		11	f4.8
	9	1/125		12	f4.0
	8	1/100		13	f3.4
	7	1/90		14	f2.8
	6	1/60		15	f2. 4
	5	1/30		16	f2.0
	4	1/15		17	f1.8
	3	1/8			
	2	/			
	1	/			
	0	/			
	0	0dB		8	16dB
	1	2dB		9	18dB
Gain	2	4dB		10	20dB
	3	6dB	Coin	11	22dB
	4	8dB	Gain	12	24dB
	5	10dB		13	26dB
	6	12dB		14	28dB
	7	14dB			

Zoom Ratio & Zoom Parameter Correspondence List

Ratio	Parameter
x1 (wide)	0x0
x1. 2	0x8D0
x1.5	0x1194
x2	0x1A58
x3	0x2610
x5	0x31D4
x5.8	0x34BC
x6. 9	0x37A4
x8. 2	0x3A98
x9. 9	0x3D8C
x11.8(tele)	0x4000