

Admin

Your system nearing completion -- exciting!

Interrupts

Today

Exceptional control flow

Suspend, jump to different code, then resume

How to do this safely and correctly

Low-level mechanisms

Next lecture

Using interrupts as client

Coordination of activity

Concurrency, multiple handlers, shared data



Blocking I/O

```
while (1) {  
    char ch = keyboard_read_next();  
    update_screen();  
}
```

How long does it take to send a scan code?


11 bits, clock rate 15kHz

How long does it take to update the screen?

What could go wrong?


Blocking I/O

```
while (1) {  
    char ch = keyboard_read_next();  
    update_screen();  
}
```



Blocking I/O

```
while (1) {  
    char ch = keyboard_read_next();  
    update_screen();  
}
```



The Problem

Ongoing, long-running tasks (graphics, simulations, applications) keep CPU occupied, but ...

When an external event arises, need to respond quickly.

It's like baking a chicken ...

- Polling: Checking the thermometer every few minutes
- Interrupts: Wireless thermometer notifying you




Concurrency

How to juggle doing more than one thing at once?

```
while (1) {  
    dequeue scancode from queue  
    update_screen();  
}
```

**whenever scancode arrives,
enqueue it**

scancodes buffered for later processing



Interrupts to the rescue!

Processor pauses current execution, switch to code that handles interrupt, switch back and resume execution

- Asynchronous external event (peripherals, timer)

- Synchronous exception (invalid address, illegal instruction)

Critical for responsive systems, hosted OS

Interrupts are essential and powerful, but getting them right requires using everything you've learned:

- Architecture, assembly, linking, memory, C, peripherals, ...

**code/button-blocking
code/button-interrupt**

Interrupt mechanics

Somewhat analogous to function call

- Suspend currently executing code, save state
- Jump to handler code, process interrupt
- When finished, restore state and resume

Must adhere to conventions to avoid stepping on each other

- Consider: processor state, register use, memory
- Hardware support helps out

C abstraction ...

Asm understanding!

```
update_screen:  
    add sp,sp,-16  
    sd ra,8(sp)  
    sd s0,0(sp)  
    add s0,sp,16  
    jal 0x400006c4 <console_clear>  
  
Interrupt! →  
    lui a0,0x40008  
    add a0,a0,496  
    jal 0x40000224 <co  
    li s1,0  
    j 0x400002cc <up  
    lui a5,0x40022  
    lw a1,-760(a5)  
    lui a0,0x40008  
    add a0,a0,528 # 0x40008210  
    jal 0x40000224 <console_printf>
```

How to go from **update_screen**
to **button_pressed** and back
again?

```
button_pressed:  
    add sp,sp,-16  
    sd ra,8(sp)
```

- 1) pause, preserve state
- 2) jump to handler, execute
- 3) restore state, resume

```
    li a0,1293  
    jal 0x400022d8 <gpio_interrupt_clear>  
    ld ra,8(sp)  
    ld s0,0(sp)  
    add sp,sp,16  
    ret
```

The RISC-V Instruction Set Manual

Volume II: Privileged Architecture

Document Version 20190608-Priv-MSU-Ratified

Editors: Andrew Waterman¹, Krste Asanović^{1,2}

¹SiFive Inc.,

²CS Division, EECS Department, University of California, Berkeley

andrew@sifive.com, krste@berkeley.edu

June 8, 2019

<https://cs107e.github.io/readings/riscv-privileged-20190608-1.pdf>

Terminology

Exception

- Problem arises when executing an instruction
(invalid memory address, illegal instruction)

Trap

- Synchronous transfer of control to trap handler

Interrupt

- External event that occurs asynchronously
- Executing instruction is interrupted, will experience a trap

Processor modes

Machine (most privileged), Supervisor, User (least privileged)


Reset starts in machine (M) mode
(all our code executes in M mode)

Trap usually executes with more privilege
(hardware support to change mode on enter/exit trap handler)


What code is executed on trap?

- **mtvec** CSR stores address of code to jump to

CSRs



<https://cs107e.github.io/readings/riscv-privileged-20190608-1.pdf>



interrupts_global_enable:

```

li a0,1<<11      # set MEIE bit (m-mode external interrupts)
csrs mie,a0        # update mie register
li a0,1<<3        # set MIE bit (global enable m-mode interrupts)
csrs mstatus,a0    # update mstatus register
ret

```

Interrupt, hardware-side

External event triggers interrupt line. Processor response:

- Complete current instruction

- Pause, transfer control

- Save interrupted **pc** in **mepc** CSR, elevate privilege

- Disable further interrupts

- pc = mtvec** (address of handler function)

Software takes over

- Trap handler begins executing

- Must save/restore any registers it uses

- Process interrupt and clear/mark handled


- mret** instruction to restore state and resume

- Restores privilege level, reenables interrupts, **pc = mepc**

Interrupt, software-side

```
__attribute__((interrupt("machine")))
void trap_handler(void)
{
    ....
}
```

How does this attribute change the generated code? Let's find out!



The image shows the Compiler Explorer interface. The top bar includes the Compiler Explorer logo, an 'Add...' button, a 'More' dropdown, and a 'Templates' link. Below the bar is a toolbar with a dropdown menu ('A'), a 'Save/Load' button, a '+ Add new...' dropdown, a 'Vim' button, and a language selector ('C'). The main area contains a text editor with three lines of code:

```
1
2 __attribute__((interrupt("machine"))) void trap_handler(void)
3
```

Install trap handler

```
__attribute__((interrupt("machine"))) void trap_handler(void) {  
    // code to respond to interrupt  
}
```

```
void main(void) {  
    set_mtvec(trap_handler); // store function pointer  
}
```

```
interrupts_set_mtvec:    # assembly  
    csrw mtvec,a0      # mtvec holds address of first insn  
    ret
```

Interrupts (so far)

Hardware support

Processor modes, exceptional control flow

Software config

Install handler, enable interrupts

Exception received, handler must:

Init stack, preserve registers, handle event

Restore and resume

Interrupts (so far)

Top-level interrupts system configuration

- External interrupts enabled mstatus, mie CSRs
- Trap handler address installed in mtvec CSR

Transfer of control to enter/exit interrupt code

- Assembly to preserve registers
- Call into C code
- Assembly to restore registers, resume interrupted code

Next Lecture

Which interrupts are supported and how to configure
(events from gpio, hstimer, uart, ...)

How to dispatch to specific handler per event source

What steps needed to init/enable interrupts

Writing safe interrupt handlers

How to share state without step on each other