



Arm Core Floorplan

- Control: Specifies the operation of the CPU
- Register File: Memory inside the CPU
 - Instructions reference these directly
- ALU: Arithmetic Logic Unit: Arithmetic and bitwise hardware (on the bits)
- Barrel shifter: (shifts bits in a register during instruction execution - Later)
- Instruction Decode: Interprets the the bits in an instruction to determine what the instruction means
- Register Decode: controls the registers in during instruction execution
- Address and Data: Interface to external RAM (like memory dimms)

Single core arm die Floorplan



32-Bit Arm - Registers



- Registers are memory located within the CPU
- Registers are the <u>fastest</u> read and write storage
- Register is word size in length stores 32-bit values
 - Memory is accessed using pointers in registers
- In assembly language the registers have predefined names starting with an r to differentiate them from memory addresses which are labels (address)
- 16 registers: from r0 to r15 (encoded: 0x0 0xf)

External memory 1- Byte **0xFFFFFFF** address 0x00000000 **Capacity:4 GBytes**

CPU Memory Bus = Address + Data

Using AMR-32 Registers

- There are two basic groups of registers, general purpose and special use
- General purpose registers can be used to contain up to 32-bits of data, but you must follow the rules for their use
 - Rules specify how registers are to be used so software can communicate and share the use of registers (later slides)
- Special purpose registers: dedicated hardware use (like r15 the pc) or special use when used with certain instructions (like r13 & r14)
- r15/pc is the program counter that contains the address of an instruction being executed (not exactly ... later)

Special Use Registers program counter

r15/pc

Special Use Registers function call implementation & long branching

r14/lr r13/sp

r12/ip

r11/fp

Preserved registers

Called functions can't change

<u>r10</u>

r8

r7

17

n5


r4

Scratch Registers
First 4 Function Parameters
Function return value
Called functions can change

r3 r2

r0

Assembly and Machine Code




- Machine Language (or code): Set of instructions the CPU executes are encoded in memory using patterns of ones and zeros (like binary numbers)
- Assembly language is a symbolic version of the machine language
- Each assembly statement (called an Instruction)
 - Executes exactly one from a list of simple commands
 - Instructions describe operations (e.g., =, +, -, *)
 - Execution proceeds from low to high memory one instruction at a time unless there is a branch
- One line of arm32 machine code contains one instruction in one word (32 bits)

	Instruction Address	Instruction (4-bytes) contents	Assembly Equivalent
	1040c:	e28db004	add fp, sp, 4
	10410:	e59f0010 Machine	ldr r0, [pc, 16]
	10414:	ebffffb3 Code	bl 102e8 <printf></printf>
`	10418:	e3a00000	mov r0, 0
	1041c:	e24bd004	sub sp, fp, 4

high <- low bytes

Anatomy of an Assembly instruction

- Assembly language instructions specify an operation and the operands to the instruction (arguments of the operation)
- Three basic types of operands
 - Destination: where the result will be stored
 - Source: where data is read from
 - Immediate: an actual value like the 1 in y = x + 1




Meaning of an Instruction

- Operations are abbreviated int opcodes (1– 5 letters)
- Assembly Instructions are specified with a very regular syntax
 - Opcodes are followed by arguments
 - Usually the destination argument is next, then one or more source arguments (this is not strictly the case, but it is generally true)
- Why this order?
- Analogy to C or Java

```
int r0, r1, r2;
r0 = r1 + r2; // c
```

```
r\theta = r1 + r2 add r0, r1, r2 // assembly
```


32-Bit Arm - Registers



Program Execution: A Series of Instructions

- Instructions are retrieved sequentially from memory
- Each instruction executes to completion before the next instruction is completed
- Conceptually the pc (program counter) points at executing instruction
- exceptions: loops, function calls, traps,...

Memory Content in Text segment



Register contents inside the CPU

$$r0 = 1 r1 = 2$$

initial values


$$r0 = 4 r1 = 2$$

$$r0 = 8 r1 = 2$$


$$r0 = 16 \ r1 = 2$$


$$r0 = 16 \ r1 = 14$$

How to Access Memory?



- Operation code: add
 Destination: a
- Operand 1: b
 Operand 2: c
- Aarch32 Instructions are always word size: 32 bits wide
 - Some bits must be used to specify the operation code
 - Some bits must be used to specify the destination
 - Some bits must be used to specify the operands
- Address space is 32 bits wide so put a POINTER in a register






32-Bit Arm is a Load/Store Architecture

All computations (add, subtract, etc.) are performed in the ALU

Arithmetic & Logic Unit (ALU)

Instruction operands and results are only in registers




Load: (also called a Fill)

Copy the contents of a variable from memory into a register.

Store:
(also called a Spill)
Copy the contents of


Copy the contents of a register back into a variable in memory.



Load/Store: Load

int $x[2] = \{0x4321, 0x0\};$ x[1] = x[0];

External memory



Load/Store: Store

```
int x[2] = {0x4321, 0x0};
x[1] = x[0];
```

r15 r14 0x00001010 r13 r12 r11 r10 0x0000100c r9 r8 0x3 writes memory >. **r7** r6 0x00001008 r5 0x4 r4 0x3 r3 0x4321 0x2 r2 r1 + 40x1 0x00001004 x[0]r1 0x1004 points at r0 0x00001000

External memory

Arm Register Summary

- 16 Named registers r0 r15
- The operands of almost all instructions are registers
- To operate on a variable in memory do the following:
 - 1. Load the value(s) from memory into a register
 - 2. Execute the instruction
 - 3. Store the result back into memory (only if needed!)
- Going to/from memory is expensive
 - 4X to 20X+ slower than accessing a register
- Strategy: Keep variables in registers as much as possible

AArch32 Instruction Categories

Data movement to/from memory

- Data Transfer Instructions between memory and registers
 - Load, Store
- Arithmetic and logic
 - Data processing Instructions (registers only)
 - Add, Subtract, Multiply, Shift, Rotate, ...
- Control Flow
 - Compare, Test, If-then, Branch, function calls
- Miscellaneous
 - Traps (OS system calls), Breakpoints, wait for events, interrupt enable/disable, data memory barrier, data synchronization barrier
 - Many others that we will not cover in the class

Arithmetic and logic

Data Movement

Control Flow

Miscellaneous

15

First Look: Copying Values Between Registers - MOV

```
mov r0, r1

// Copies all 32 bits of the
// value in register r1 into
// register r0

register direct "addressing"
register r1

register r1


register r1

register r1


register r1

register r1

register r1
```



mov – Copies Register Content between registers



```
mov Rd, constant // Rd = constant mov Rd, Rm // Rd = Rm
```

(-256) <= imm8 <= 255 + values from "rotating" bits - later

```
mov r1, r5  // r1 = r5

mov r1, 1  // r1 = 1


mov r1, -4  // r1 = -4
```

First Look: Add/Sub Registers


```
add r0, r1, r2 register r1 + register r2


// Adds r1 to r2 and
// stores the result
// in r0

register r0
```



add/sub - Add or Subtract two integers





```
add Rd, Rn, constant // Rd = Rn + constant

sub Rd, Rn, constant // Rd = Rn - constant

add Rd, Rn, Rm // Rd = Rn + Rm

sub Rd, Rn, Rm // Rd = Rn - Rm
```

```
add r1, r2, r3 // r1 = r2 + r3

sub r1, r1, 1 // r1 = r1 - 1; or r1--

add r1, r2, 234 // r1 = r2 + 234
```

Writing a Sequence of Add & Subtract Instructions

 You need to perform the following sequence of integer adds/subtracts

$$a = b + c + d - e;$$

- Since ARM uses a three-operand instruction set, you can only operate on two operands at a time
- So, you need to use one register as an accumulator and create a sequence of add instructions to build up the solution

```
  \begin{array}{cccc}
    r0 & \leftarrow & a \\
    r1 & \leftarrow & b \\
    r2 & \leftarrow & c \\
    r3 & \leftarrow & d \\
    r4 & \leftarrow & e
  \end{array}
```

```
a = b + c + d - e;
r0 = r1 + r2 + r3 - r4;
r0 = ((r1 + r2) + r3) - r4;
r0 = r1 + r2;
r0 = r0 + r3
r0 = r0 - r4
```


```
add r0, r1, r2
add r0, r0, r3
sub r0, r0, r4
```

$$a = (b + c) - 5;$$

 $r0 = (r1 + r2) - 5;$

```
add r0, r1, r2
sub r0, r0, 5
```

Line Layout in an Arm Assembly Source




- Assembly language source text files are line oriented (each ending in a '\n')
- Each line represents a starting address in memory and does one of:
 - 1. Specifies the contents of memory for a variable (segments containing data)
 - 2. Specifies the contents of memory for an instruction (text segment)
 - 3. Assembler directives tell the assembler to do something (for example, change label scope, define a macro, etc.) that does not allocate memory
- Each line is organized into up to four columns
 - Not every column is used on each line
 - Not every line will result in memory being allocated

Labels in Arm Assembly - 1

- 1. Labels (optional); starts in column 1 (often on a line by itself ABOVE the "operation")
 - Only put a label on a line when you need to associate a name (a global variable, a function name, a loop/ branch target, etc.) to that line's location in memory
 - You then refer to the address by name in an instruction
- 2. Operation type 1: assembler directives (all start with a period e.g. .word)
- 3. Operation Type 2: assembly language instructions
- 4. Zero or more operands as required by the instruction or assembler directive
- 5. Comments: C and C++ style; also @ in the place of a C++ comment //

Labels in Arm Assembly - 2



- Remember, a Label associates a name with memory location
- Regular Label:
 - Used with a Function name (label) or all static variables in any of the data segments
- Local Label: Name starts with .L (local label prefix) only usable in the same file
 - 1. Targets for
 - a) branches: if switch, goto, break, continue,
 - b) loops: for, while, do-while
 - 2. Anonymous variables (the address of literal not the address of foo in the following) char *foo = "literal";

Unconditional Branching – Forces Execution to Continue at a Specified Label (goto)

b imm24

imm24 is Relative direction from the branch instruction (in +/- instructions)

Unconditional Branch instruction (branch to only local labels in CSE30)


```
b .Llabel
```

- Causes an unconditional branch (aka goto) to the instruction with the address .Llabel
- .Llabel is called a branch target label (the "target" of a branch instruction)
- Be careful! do not to branch to a function label!
- .Llabel: translates into an number offset being imm24 shifted left two bits (+/- 32 MB)

```
b .Ldone // goto .Ldone :
.Ldone:
add r0, EXIT_SUCCESS // set return value
```

Examples of Unconditional Branching

Unconditional Branch Forward



Not a practical example as this code is unreachable

Backward Branch (Infinite loop)

```
.Lbackward:
    add r1, r2, 4
    sub r1, r2, 4
    add r4, r6, r7
    b .Lbackward
    // not reachable unless
    // there is a label after the .b above
```

Branch target (local label)

- Branches are used to change execution flow using labels as the branch target
- In these example, .Lforward and .Lbackward are the branch target labels
- Branch target labels are placed at the beginning of the line (or above it)
- Caution: Backward branches should only used with loops!

Never Branch to the following instruction: It is not needed!

```
mov r2, 0
b .Lnext // do not do this, not needed
Lnext:
add r1, r2, r3

mov r2, 0
add r1, r2, r3
```

Anatomy of a Conditional Branch: If statement

```
If (r0 == 5) {

/* condition block #1 */

/* branch to "here" */

} else {

/* condition block #2 */


/* fall through to "here" */


}

// resume here
```

- Branch guard: determines when to execute the "condition true block" or the "condition false block"
- In C, when the branch guard (condition test) evaluates <u>non-zero</u> you fall through to the condition true block, otherwise you branch to the condition false (else) block
- Step 1: evaluate the branch guard(s) (involves one or more compares/tests)
- Step 2: If branch guard evaluates to be false
 - branch around the true block and execute the else block
 - otherwise "fall through" and execute the true block
- Block order in C is where the True Block appears above the False block

cmp/cmm - Making Conditional Tests





The values stored in the registers Rn and Rm are not changed
The assembler will automatically substitute cmn for negative immediate values

```
cmp r1, 0 // r1 - 0 and sets flags on the result cmp r1, r2 // r1 - r2 and sets flags on the result
```

Quick Overview of the Condition Bits/Flags



- The CSPR is a special register (like the other registers) in the CPU
- The four bits at the left are called the Condition Code flags
 - Summarize the result of a previous instruction
 - Not all instruction will change the CC bits
- Specifically, Condition Code flags are set by cmm/cmp (and others)

Example: cmp r4, r3

- N (Negative) flag: Set to 1 when the result of r4 r3 is negative, set to 0 otherwise
- **Z (Zero) flag:** Set to 1 when the results of r4 r3 is 0, set to 0 otherwise
- C (Carry bit) flag: Set to 1 when r4 r3 does not have a borrow, set to 0 otherwise
- V flag (oVerflow): Set to 1 when r4 r3 causes an overflow, set to 0 otherwise

Conditional Tests: Implementing ARM Branch guards

imm24 is Relative direction from the branch instruction (in +/- instructions)

cond bsuffix imm24

Branch instruction

bsuffix .Llabel

Use a local label with branch instructions

Condition	Meaning	Flag Checked
BEQ	Equal	Z = 1
BNE	Not equal	Z = 0
BGE	Signed ≥ ("Greater than or Equal")	N = V
BLT	Signed < ("Less Than")	N≠V
BGT	Signed > ("Greater Than")	Z = 0 && N = V
BLE	Signed ≤ ("Less than or Equal")	Z = 1 N ≠ V
BMI	Minus/negative	N = 1
BPL	Plus - positive or zero (non-negative)	N = 0
В	Branch Always (unconditional)	

- Bits in the condition field specify the **conditions** when the branch happens
- If the condition evaluates to be true, next instruction executed is at .Llabel:
- If the condition evaluates to be false, next instruction executed is immediately after the branch
- Unconditional branch is when the condition is "always"

Branch and Loop Guard Strategy

```
cmp r0, 10
ble .Lendif
// True Block
.Lendif:
```

How to implement a branch/loop guard in CSE30

- 1. Use a **cmp/cmm** instruction to set the condition bits
- 2. Follow the cmp/cmm with one or more variants of the conditional branch instruction
 - Conditional branch instructions if evaluate to true (based on the flags set by the cmp) the next instruction will the one at the branch label
 - Otherwise, execution falls through to the instruction that immediately follows the branch
- You may have one or more conditional branches after a single cmp/cmm

Program Flow: Simple If statement, No Else

C source Code	Incorrect Assembly	Correct Assembly
int r0;	cmp r0, 10	cmp r0, 10
if (r0 > 10) {	bgt .Lendif	<pre>ble .Lendif</pre>
// True Block	// True Block	// True Block
}	.Lendif:	.Lendif:

- Realize that in ARM assembly you can only either "fall through" to the next instruction or branch to a specific instruction
- Approach: adjust the conditional test then branch around the true block
- Use a conditional test that specifies the inverse of the condition used in C
 - This preserves C block order

Branch Guard "Adjustment" Table Preserving C Block Order In Assembly

Compare in C	"Inverse" Compare in C	Assembly using Inverse Compare
==	! =	bne
! =	==	beq
>	<=	ble
>=	<	blt
<	>=	bge
<=	>	bgt

```
if (r0 compare 5)
   /* condition true block */
   /* then fall through */
}
```

```
cmp r0, 5
inverse compare .Lelse
// condition true block
// then fall through
.Lendif:
```

Arm Conditional Branching Simple IF no else

C If statement

ARM If statement

```
int r0;
if (r0 == 5) {
    /* condition true block */
    /* then fall through */
}
/* branch around to this code */
```

```
cmp r0, 5
bne .Lendif

/* condition true block */

/* then fall through */


.Lendif:

/* branch around to this code */
```

If r0 == 5 true then *fall through* to the true block If r0 == 5 false then branch *around* the true block

- If statements in ARM
- Step 1: make a conditional test using a cmp instruction
- Step 2: if test evaluates to FALSE, branch around the condition true block with a one
 of the conditional branch instruction

If statement examples – Branch Around the True block!



Branching Avoid: Spaghetti Code ("goto structure")

- Do not use unnecessary branches
- Optimize your use of "fall throughs"
- For example: Do not make a conditional branch around an unconditional branch that immediately follows it

```
Do not do the following:

cmp r0, 0

beq .Lthen
b .Lendif

Two adjacent branches

add r1, r1, 1

Lendif:

add r1, r1, 2
```

```
Do the following:

cmp r0, 0

bne .Lendif

// fall through
add r1, r1, 1

.Lendif:
add r1, r1, 2
```

Program Flow: If with an Else

Approach:

- 1. adjust the conditional test to branch to the False Block
- 2. Fall through to the True Block
- 3. Bottom of the True Block unconditionally branches around the False block

C source Code	Assembly
int r0;	cmp r0, 10
if (r0 > 10) {	ble .Lelse
	/fall through
// true block	// true block
// branch always around the false block	b .Lendif
<pre>} else {</pre>	.Lelse:
//	/ / C-7 1-71-
// false block	// false block
	// fall through
}	.Lendif:

If with an Else Examples

If r0 == 5 false then branch **to** false block


```
if (r0 == 5) {
    /* cond. true block */
    /* branch around false */
} else {
    /* condition false block */
    /* fall through */
}
r1 = 4;
```

If r0 == 5 false then branch to false block

```
cmp r0, 5
   bne .Lelse
   // Fall through
   // cond. true block
     * Now branch around the
     * condition false block
   b .Lendif
Lelse
   // condition false block
   // fall_through
.Lendif:
   mov r1, 4
```

If with an Else Examples

```
Branch condition
  Test (branch guard)
if (r0 < r1) {
    r2 = 1;
   -// branch around else
} else {
   r2 = 0;
   /* fall through */
-r4 = r2 + r4;
```



If statement - C Block Reordering

```
Branch condition
Test (branch guard)

if (r0 == 5) {
    /* condition block #1 */
} else {
    /* condition block #2 */
    /* fall through */
}

condition true block
```

 Block order: (the order the blocks appear in C code) can be changed by inverting the conditional test, swapping the order of the true and false blocks

```
Branch condition
Test (branch guard)

if (r0 != 5) {
    /* condition block #2 */
} else {
    /* condition block #1 */
    /* fall through */
}

condition true block
```

Preserving the same branch guard test

```
if (r0 < r1) { ←
                         Same branch guard test
                                                   cmp r0, r1
                                                   blt .Lelse
   // true block
   r2 = 1;
                                                   // false block
   =// now branch around else
                                                   mov r2, 0
} else {
                                                   b .Lendif // around else
   // false block
                                             .Lelse:
   r2 = 0;
                                                   // true block
   /* fall through */
                                                   mov r2, 1
                                                  /* fall through */
r4 = r2 + r4;
                                             .Lendif:
                                                   add r4, r2, r4
```

Swap the order of true and false blocks

Switch Statement


```
switch (r0) {
case 1:
    // block 1
    break;
case 2:
    // block 2
    break;
default:
    // default 3
    break;
```

```
cmp r0, 1
                 Branch
     beq .Lblk1
                 block
     cmp r0, 2
     beq .Lblk2
     // fall through
     // default 3
     b .Lendsw // break
Lblk1:
     // block 1
     b .Lendsw // break
Lblk2:
     // block 2
     // fall through
     // NO b .Lendsw
 .Lendsw:
```

Bad Style: Branching Upwards (When Not a loop)

Do not Branch "Upwards" unless it is part of a loop (later slides)

- If you cannot easily write the equivalent C code for your assembly code, you may have code that is harder to read than it should be
- Action: adjust your assembly code to have a similar structure as an equivalent version written in C



Review – Short Circuit or Minimal Evaluation

• In evaluation of conditional guard expressions, C uses what is called **short circu**it or **minimal** evaluation

```
if ((x == 5) || (y > 3)) // if x == 5 then y > 3 is not evaluated
```

- Each expression argument is evaluated in sequence from left to right including any side effects (modified using parenthesis), before (optionally) evaluating the next expression argument
- If after evaluating an argument, the value of the entire expression can be determined, then the remaining arguments are NOT evaluated (for performance)

```
if ((a != 0) && func(b))  // if a is 0, func(b) is not called
  // do something
```

Program Flow – If statements && compound tests - 1

```
if ((r0 == 5) && (r1 > 3)) {
    r2 = r5; // true block
    /* fall through */
}
r4 = r3;
```

```
If r0 == 5 false
                     then short
                      circuit branch
    cmp r0, 5
                      around the
    bne .Lendif
                     true block
    cmp r1, 3
    ble .Lendif
    mov r2, r5 // true block
    // fall through
.Lendif:
    mov r4, r3
```

Program Flow – If statements && compound tests - 2

```
if ((r0 == 5) && (r1 > 3))
{
    r2 = r5; // true block
    // branch around else
} else {
    r5 = r2; False block */
    /* fall through */
}
r4 = r3;
```

```
if r0 == 5 false
                                 then short circuit
                                 branch to the
      cmp r0, 5 // test 1
                                 false block
      bne .Lelse
                                 if r1 > 3 false
      cmp r1, 3 // test 2
                                 then branch to
      ble .Lelse
                                 the false block
      mov r2, r5 // true block
      // branch around else
      b .Lendif •
.Lelse:
      mov r5, r2 // false block
      // fall through
  .Lendif:
    mov r4, r3
```

Program Flow – If statements || compound tests - 1

```
if ((r0 == 5) || (r1 > 3)) {
    r2 = r5; // true block
    /* fall through */
}
r4 = r3;
```

```
cmp r0, 5
                        If r0 == 5 true, then
     beq .Lthen
                        branch to true block
                         if r1 > 3 false then
     cmp r1, 3
                         branch around
     ble .Lendif
                         true block
    // fall through
Lthen:
     mov r2, r5 // true block
     /* fall through */
 :Lendif:
     mov r4, r3
```

Program Flow – If statements || compound tests - 2

```
if ((r0 == 5) || (r1 > 3)) {
    r2 = r5; // true block
    /* branch around else */
} else {
    r5 = r2; // false block
    /* fall through */
}
```

```
cmp r0, 5
                       If r0 == 5 true, then
    beq .Lthen
                       branch to the true block
                       if r1 > 3 false then
    cmp r1, 3
                       branch to false block
    ble .Lelse
   // fall through
.Lthen:
    mov r2, r5 // true block
// branch around else
 b .Lendif
Lelse
    mov r5, r2 // false block
// fall through
Lendif:
```

Program Flow – Pre-test and Post-test Loop Guards

- loop guard: code that must evaluate to true before the next iteration of the loop
- If the loop guard test(s) evaluate to true, the body of the loop is executed again
- pre-test loop guard is at the top of the loop
 - If the test evaluates to true, execution falls through to the loop body
 - if the test evaluates to false, execution branches around the loop body


```
do {
    /* block */
    i++;
} while (i < 10);

one or more iterations</pre>
post-test
loop guard
```

- post-test loop guard is at the bottom of the loop
 - If the test evaluates to true, execution branches to the top of the loop
 - If the test evaluates to false, execution falls through the instruction following the loop


Pre-Test Guards - While Loop

```
while (r1 < 10) {
    /* block */
    r1++;
}
r2 = r1;</pre>
```




Pre-Test Guards - While Loop

```
while (r1 < 10) {
    if (r2 != r1) {
        /* block */
    }
    r1++;
}
r2 = r1;</pre>
```




Post-Test Guards - Do While Loop

```
do {
    /* block */
    r1++;
} while (r1 < 10);</pre>
r2 = r1;
```




Post-Test Guards – Do While Loop

```
do {
    if (r2 != r1) {
        /* block */
    }
    r1++;
} while (r1 < 10);</pre>
```




Program Flow – Counting (For) Loop Version 1




A counting loop has three parts:

- 1. Pre-loop setup
- 2. Pre-test loop guard conditions
- 3. Post-loop update




 x

Program Flow – Counting (For) Loop – Version 2



- Alternative:
- move Pre-test loop guard before the loop
- Add post-test loop guard
 - converts to do while
 - removes an unconditional branch



Nested loops

```
for (r3 = 0; r3 < 10; r3++) {
    r0 = 0;
   →do {
       r0 = r0 + r1++;
  -} while (r1 < 10);
   // fall through
   r2 = r2 + r1;
r5 = r0;
```

Nest loop blocks as you would in C or Java

```
mov r3, 0
Lfor:
    cmp r3, 10 // loop guard
    bge .Lendfor
    mov r0, 0
.Ldo:
    add r0, r0, r1
    add r1, r1, 1
    cmp r1, 10 // loop guard
    blt .Ldo
    // fall through
    add r2, r2, r1
    add r3, r3, 1 // loop iteration
    b .Lfor
.Lendfor:
    mov r5, r0
```

Keep loops Properly Nested: Do not branch into the middle of a loop

- It is hard to understand and debug loops when you branch into the middle of a loop
- Keep loops proper nested

.Lloop1: add r1, r1, 1 ►Lloop2: add r2, r2, 1 add r2, r1, r3 cmp r1, 10 blt .Lloop1 Bad practice: branch into loop body beq .Lend1 add r3, r3, 1 cmp r2, 20 ble .Lloop2← :Lend1:

Do not do the following:

Extra Slides

CPU Operational Overview: Executing Machine Code

r15/pc

r15/pc

r15/pc

r15/pc

Everything has a memory address: instructions & data

 Machine code uses addresses for loops, branches, function calls, variables, etc.

1 Fetch

- read the instruction into memory (fetch)
- program counter is automatically incremented (+4) to contain the address of the next instruction in memory Instructions are 32 bits

2 Decode

• **Decodes the instruction** and sets up execution

3 Execute

- CPU completes the execution of the instruction
- Execution may alter the pc to take branches, etc.
- Go to fetch

text segment in memory

```
address contents
                     assembly version
0001042c <inloop>:
  1042c: e3530061
                      cmp r3, 0x61
  10430: ba000002
                      blt 10440 <store>
  10434: e353007a
                      cmp r3, 0x7a
  10438: ca000000
                      bgt 10440 <store>
                      sub r3, r3, #32
  1043c: e2433020
00010440 <store>:
 →10440: e7c13002
                      strb r3, [r1, r2]
  10444: e2822001
                      add r2, r2, 0x1
   10448: e7d03002
                      ldrb r3, [r0, r2]
  1044c: e3530000
                      cmp r3, 0x0
   10450: 1afffff5
                      bne 1042c <inloop>
```

Edited output For output Created by the command

%objdump -d a.out

%objdump -d -S a.out adds source code

Program Execution: Looping in the Execution Flow

- Repeat the series of instructions in a loop means altering the flow of execution
- This is used with if statements and loops
- Below is an infinite loop (br instruction: unconditional branch: "goto"

the address of this instruction has the name .Lloop

Infinite loop C
do {
 r0 = r1 + r1;
 r0 = r0 + r0;
 r0 = r0 + r0;
 r1 = r0 - r1;
} while(1);

```
      Lloop:
      add r0, r1, r1

      add r0, r0, r0

      add r0, r0, r0

      sub r1, r0, r1

      br .Lloop
```

$$r0 = 1 r1 = 2$$

$$r0 = 4 r1 = 2$$

$$r0 = 8 r1 = 2$$

$$r0 = 16 \ r1 = 2$$

$$r0 = 16 \ r1 = 14$$

branch to the instruction at memory location with the label: .Lloop

Branch Target Address (BTA): What Is imm24?

executing instruction

decode instruction

fetch instruction

- Previous slide: phases of execution:
 (1) fetch, (2) decode, (3) execute
- The pc (r15) contains the address of the instruction being fetched, which is two instructions ahead or executing instruction + 8 bytes
- Branch target address (or imm24) is the distance measured in the # of instructions (signed, 2's complement) from the fetch address contained in r15 when executing the branch

```
0001042c <inloop>:
   1042c: e3530061
                      cmp r3, 0x61
 →10430: ba000002
                      blt 10440 <store>
  ▶10434: e353007a
                      cmp r3, 0x7a
  ▶10438: ca000000
                     bgt 10440 <store>
   1043c: e2433020
                      sub r3, r3, #32
                    BTA: + 2 instructions
00010440 <store>:
                    10440: e7c13002
                      add r2, r2, 0x1
   10444: e2822001
                      ldrb r3, [r0, r2]
   10448: e7d03002
                      cmp r3, 0x0
   1044c: e3530000
   10450: 1afffff5
                      bne 1042c <inloop>
```

```
target address = 0x10440
fetch address = 0x10438
distance(bytes) = 0x00008
distance(instructions)= 0x8/(4 bytes/instruction)= 0x2
```

imm24 | 0x 00 00 02

Program Flow – multiple branches, one cmp


```
if ((r0 > 5) {
    /* condition block 1 */
    // branch to endif
} else if (r0 < 5){}
    /* condition block 2 */
    // branch to endif
} else {
    /* condition block 3 */
    // fall through to endif
// endif
r1 = 11;
```

There are many other ways to do this


```
cmp r0, 5
                   special case: multiple
     bgt .Lblk1
                   branches from one cmp
     -blt .Lblk2
     // fall through
     // condition block 3
     b .Lendif
Lblk1:
     // condition block 1
     b .Lendif
→.Lblk2:
     // condition block 2
     b .Lendif
 .Lendif:
     mov r1, 5
```

How are I – Type Constants Encoded in the instruction?

- Aarch32 provides only 8-bits for specifying an immediate constant value
- Without "rotation" immediate values are limited to the range of positive 0-255
- Imm8 expands to 32 bits and does a rotate right to achieve additional constant values (YUCK)



Rot4 - Imm8 Values



- How would 256 be encoded?
 - rotate = 12, imm8 = 1
- Bottom line: the assembler will do this for you
- If you try and use an immediate value that it cannot generate it will give an error
- There is a workaround later

