

#### **Function Calls**

Branch with Link (function call) instruction

bl label

bl imm24


- Function call to the instruction with the address label (no local labels for functions)
  - imm24 number of instructions from pc+8 (24-bits)
  - label any function label in the current file, any function label that is defined as .global in any file that it is linked to, any C function that is not static

Branch with Link Indirect (function call) instruction

blx Rm

blx Rm

- Function call to the instruction whose address is stored in Rm (Rm is a function pointer)
- bl and blx both save the address of the instruction immediately following the bl or blx instruction in register
   lr (link register is also known as r14)
- The contents of the link register is the return address in the calling function
- (1) Branch to the instruction with the label f1
- (2) copies the address of the instruction AFTER the bl in Ir



#### **Function Call Return**

#### Branch & exchange (function return) instruction

bx 1r

bx Rn

// we will always use lr

- Causes a branch to the instruction whose address is stored in register <1r>
  - It copies 1r to the PC
- This is often used to implement a return from a function call (exactly like a C return) when the function is called using either bl label, or blx Rm


Stores this address in 1r this is the address to resume at in the caller

main:

bl f1 


Branch to the instruction whose address is stored in Ir

# **Understanding bl and bx - 1**



But there is a problem we must address here – next slide

# **Understanding bl and bx - 2**



# Understanding bl and blx - 3

```
int a(void)
{
    return 0;
}

int (*func)() = a;

int main(void)
{
    (*func)();
    // not shown
```

But this has the same infinite loop problem when main() returns!

```
.data
func:.word a // func initialized with address of a()
    .text
    .global a
    .type a, %function
         FP_OFF, 4
    .equ
a:
           r0, 0
   mov
   bx
           lr
    .size a, (. - a)
    .global main
    .type main, %function
         FP OFF, 4
    ₌equ
main:
   ldr
       r4, =func
                      // load address of func in r4
   ldr r4, [r4] // load contents of func in r4
   blx
       r4
                       // we lose the lr for main!
   // not shown
   bx
           lr
                       // infinite loop!
```


# Preserving and Restoring Registers on the stack - 1

Operation	Pseudo Instruction	Operation
Push registers Function Entry	push {reg list}	<pre>sp = sp - 4 × #registers Copy registers to mem[sp]</pre>
Pop registers Function Exit	pop {reg list}	Copy mem[sp] to registers, sp = sp + 4 × #registers

#### push (multiple register str to memory operation)

# high memory before stack pointer registers registers stack pointer low memory

#### push (multiple register 1dr from memory operation)




#### **Preserving and Restoring Registers on the Stack - 2**

Operation	Pseudo Instruction	Operation
Push registers Function Entry	push {reg list}	<pre>sp = sp - 4 × #registers Copy registers to mem[sp]</pre>
Pop registers Function Exit	pop {reg list}	Copy mem[sp] to registers, sp = sp + 4 × #registers

• {reg list} is a list of registers in numerically increasing order, left to right


- Registers cannot be:
  - 1. duplicated in the list
  - 2. listed out of increasing numeric order (left to right)
- Register ranges can be specified {r4, r5, r8-r10, fp, lr}
- Never! push/pop r12, r13, or r15
  - the top two registers on the stack must always be fp, 1r // ARM function spec later slides

# push: Multiple Register Save to the stack




- push copies the contents of the {reg list} to stack segment memory
- push subtracts (# of registers saved) \* (4 bytes) from the sp to allocate space on the stack
  - sp = sp (# registers\_saved \* 4)
- this must always be true: sp % 8 == 0

# pop: Multiple Register Restore from the stack



- pop copies the contents of stack segment memory to the {reg list}
- pop <u>adds:</u> (# of registers restored) \* (4 bytes) to <u>sp</u> to <u>deallocate</u> space on the stack
  - sp = sp + (# registers restored \* 4)
- Remember: {reg list} must be the same in both the push and the corresponding pop

# Consequences of inconsistent push and pop operands



 Ir gets contents of saved r8, likely causing a segmentation fault when the bx Ir is executed at function exit

# **Registers: Rules For Use**

Register	Function Call Use	Function Body Use	Save before use Restore before return	
r0	arg1 and return value	scratch registers	No	
r1-r3	arg2 to arg4	scratch registers	No	
r4-r10	preserved registers	contents preserved across function calls	Yes	
r11 / fp	stack frame pointer	Use to locate variables on the stack	Yes	
r12 / ip	may used by assembler with large text file	can be used as a scratch if really needed	No	
r13 / sp	stack pointer	stack space allocation	Yes	
r14 / lr	link register	contains return address for function calls	Yes	
r15	Do not use Do not use		No	

# **Return Value and Passing Parameters to Functions**

(Four parameters or less)

Register	Function Call Use	Function Body Use	Save before use Restore before return	
r0	arg1 and return value	scratch registers	No	
r1-r3	arg2 to arg4	scratch registers	No	

• Where r0, r1, r2, r3 are arm registers, the function declaration is (first four arguments):

$$r0 = function(r0, r1, r2, r3)$$
 // 32-bit return

- Each parameter and return value is limited to data that can fit in 4 bytes or less
- Calling function:
  - · copy up to the first four parameters into these four registers before calling a function
  - MUST assume that the called function will alter the contents of all four registers: r0-r3
  - In terms of C runtime support, these registers contain the copies given to the called function
  - C allows the copies to be changed in any way by the called function
- Called function:
  - you receive the first four parameters in these four registers (r0 r3)

# **Return Value and Passing Parameters to Functions**

(Four parameters or less)


Register	Function Call Use	Function Body Use	Save before use Restore before return	
r0	arg1 and return value	g1 and return value scratch registers		
r1-r3	arg2 to arg4	scratch registers	No	


• Where r0, r1, r2, r3 are arm registers, the function declaration is (first four arguments):


- For parameters, whose size is larger than 4 bytes, pass a pointer to the parameter (we will cover this later)
- One arg value per register! NO arrays across multiple registers
  - · chars, shorts and ints are directly stored
  - Structs (not always), and arrays (always) are passed via a pointer
  - Pointers passed as output parameters contain an address that points at the stack, BSS, data, or heap

# **Register Arguments and Return Values**

- When passing or returning values from a function you must do the following:
- Make sure that the values in the registers r0-r3 are in their properly aligned position in the register based on data type
- 2. Upper bytes in byte and halfword values in registers r0-r3 when passing arguments and returning values are
  - a. zero filled for unsigned values
  - b. sign extended for signed values







# What it means to be a Temporary/argument register

```
int a(void)
{
    // not shown
}
int main(void)
{
    int r0 = 0;
    int r1 = 1;
    int r2 = 2;
    int r3 = 3;
    r0 = a();
    // in C r1 and r3 would have the same values
    // after the call
```

```
// main()
// code not shown
mov r0, 0
mov r1, 1
mov r2, 2
mov r3, 3
bl a
// r0 = return value
// r1-r3 values are unknown as a() has right to change them as it wants
```

#### **Preserved Registers**


Register	Function Call Use	Function Body Use	Save before use Restore before return	
r4-r10	preserved registers	contents preserved across function calls	Yes	
r11/fp	stack frame pointer	Use to locate variables on the stack	Yes	
r13/sp	stack pointer	stack space allocation	Yes	
r14/lr	link register	contains return address for function calls	Yes	

- Any value you have in a preserved register before a function call will still be there after the function returns (Contents are "preserved" across function calls)
- If the function wants to use a preserved register it must:
  - 1. Save the value contained in the register at function entry
  - 2. Use the register in the body of the function
  - 3. Restore the original saved value to the register at function exit (before returning to the caller)
- You use a preserved register when a function makes calls another function and you have:
  - 1. Local variables allocated to be in registers
  - 2. Parameters passed to you (in r0-r3) that you need to continue to use after calling another function

#### Minimum Stack Frame (Arm Arch32 Procedure Call Standards)

Minimal frame: allocating at function entry: push {fp, lr}


Minimum stack frame



- sp always points at top element in the stack (lowest byte address)
- fp always points at the bottom element in the stack
  - Bottom element is always the saved 1r (contains the return address of caller)
  - A saved copy of callers fp is always the next element below the Ir
  - fp will be used later when referencing stack variables
- Minimal frame: deallocating at function exit: pop {fp, lr}
- On function entry: sp must be 8-byte aligned (sp % 8 == 0)

# First Look: A typical Stack Frame

- Saved Ir and fp of the caller (so function calls work)
- Save values for any preserved registers this function will change
- Space (FRMADD) for local variables is allocated on the stack right below the lowest pushed register




# **Function Prologue and Epilogue**

```
.global myfunc
                       myfunc, %function
               .type
                      FP OFF, 4
                                            // fp distance to sp after push
               .equ
                      FRAMDD, 8
                                            // number of bytes for local stack vars
               .equ
           myfunc:
  Function
                       {fp, lr}
               push
                                  // push (save) fp and lr on stack
  Prologue
                      fp, sp, FP_OFF  // set fp at bottom of stack
               add
    creates
                                            // allocate FRMADD bytes for local vars
                       sp, sp, -FRMADD
               add
stack frame
                                            // by moving sp
                  // your code here
  Function
               sub
                       sp, fp, FP_OFF  // deallocate local variables by moving sp
  Epilogue
                                // pop (restore) fp and lr from stack
                      {fp, lr}
               pop
  removes
               bx
                                            // return to caller
                       lr
stack frame
               .size myfunc, (. - myfunc)
```

- Only one prologue right after the function label (name)
- Only one epilogue at the bottom of the function right above the .size directive

## Minimum Stack Frame (Arm Arch32 Procedure Call Standards)




```
int b(void)
{
    return 0;
}
int a(void)
{
    b();
    return 0;
}
int main(void)
{
    a();
    a();
```

```
main() = 10480 (lr) | Stack address | 90300 ← fp | 902fc ← sp
```

```
b:
                     103f4:
                                 push {fp, lr}
                    103f8:
                                 add fp, sp, 4
                    103fc:
                                 mov r0, 0
                    10400:
                                 sub sp, fp, 4
                    10404:
                                 pop {fp, lr}
                     10408:
                                 bx lr
                 a:
                                 push {fp, lr}
                     1040c:
                     10410:
                                 add fp, sp, 4
                     10414:
                                 bl 103f4 <b>
                    10418:
                                 mov r0, 0
                     1041c:
                                 sub sp, fp, 4
                    10420:
                                 pop {fp, lr}
                    10424:
                                 bx lr
                 main:
                   → 10428:
                                 push {fp, lr}
Memory address
                     1042c:
                                 add fp, sp, 4
                    10430:
                                 bl 1040c <a>
                     10434:
                                 bl 1040c <a>
                 // not shown
```


```
int b(void)
{
    return 0;
}
int a(void)
{
    b();
    return 0;
}
int main(void)
{
    a();
    a();
```



```
b:
   103f4:
               push {fp, lr}
               add fp, sp, 4
   103f8:
               mov r0, 0
   103fc:
   10400:
               sub sp, fp, 4
   10404:
               pop {fp, lr}
   10408:
               bx lr
a:
               push {fp, lr} ←
   1040c:
   10410:
               add fp, sp, 4
               bl 103f4 <b>
   10414:
   10418:
               mov r0, 0
               sub sp, fp, 4
   1041c:
   10420:
               pop {fp, lr}
   10424:
               bx lr
                             1r:
                             10434
main:
   10428:
               push {fp, lr}
   1042c:
               add fp, sp, 4
   10430:
               bl 1040c <a>
               bl 1040c <a>
   10434:
// not shown
```

X

```
int b(void)
{
    return 0;
}
int a(void)
{
    b();
    return 0;
}
int main(void)
{
    a();
    a();
```



```
b:
   103f4:
               push {fp, lr} ←
   103f8:
               add fp, sp, 4
               mov r0, 0
   103fc:
   10400:
               sub sp, fp, 4
   10404:
               pop {fp, lr}
   10408:
               bx lr
                           10418
a:
               push {fp, lr} ←
   1040c:
               add fp, sp, 4
   10410:
               bl 103f4 <b>__
   10414:
   10418:
               mov r0, 0
               sub sp, fp, 4
   1041c:
   10420:
               pop {fp, lr}
   10424:
               bx lr
                             lr:
                             10434
main:
   10428:
               push {fp, lr}
   1042c:
               add fp, sp, 4
   10430:
                bl 1040c <a>
               bl 1040c <a>
   10434:
// not shown
```

X

lr:


10418


```
int b(void)
{
    return 0;
}
int a(void)
{
    b();
    return 0;
}
int main(void)
{
    a();
    a();
```

```
Stack address
          10480 (Ir)
                     90300
main() -
          90308 fp
                     902fc
           10434 Ir
                     902f8
   a().
                     902f4
          90300 fp
           10418 lr
                     902f0 ←fp
   b()
           902f8 fp
                     902ec ←sp
```


```
b:
   103f4:
                push {fp, lr} ←
   103f8:
                add fp, sp, 4
                mov r0, 0
   103fc:
   10400:
                sub sp, fp, 4
  V10404:
               ⇒pop {fp, l<u>r}</u>
   10408:
                bx lr
                           10418
a:
                push {fp, lr} ←
   1040c:
                add fp, sp, 4
   10410:
                bl 103f4 <b>__
   10414:
   10418:
                mov r0, 0
                sub sp, fp, 4
   1041c:
   10420:
                pop {fp, lr}
   10424:
                bx lr
                              lr:
                              10434
main:
   10428:
                push {fp, lr}
   1042c:
                add fp, sp, 4
   10430:
                bl 1040c <a>
                bl 1040c <a>
   10434:
// not shown
```

```
int b(void)
{
    return 0;
}
int a(void)
{
    b();
    return 0;
}
int main(void)
{
    a();
    a();
```






26 X



X

#### Function Prologue: Allocating the Stack Frame -1



#### Function Prologue: Allocating the Stack Frame - 2 Prologue Step 3 of 3


- Space for local variables is allocated on the stack right below the lowest pushed register
- Add memory to the stack frame for local variables by moving the sp towards low memory
- The amount moved is the total size of all local variables in bytes plus memory alignment padding

FRMADD = total local var space (bytes) + padding

Allocate the space after the register push by


```
add sp, sp, -FRMADD
```

 fp (frame pointer) is used as a pointer (base register) to access all stack variables — later slides




```
push {fp, lr} // push (save) fp and lr on stack
add fp, sp, FP_OFF // set fp for this function
add sp, sp, -FRMADD // allocate FRMADD bytes for local vars
// by moving sp
```

# Function Epilogue: Deallocating the Stack Frame - 1




Use fp as a pointer to find local variables on the stack





Move SP back to where it was after the push in the prologue. So, pop works properly (this also deallocates the local variables)

```
sub sp, fp, FP_OFF // deallocate local variables by moving sp
pop {fp, lr} // pop (restore) fp and lr from stack
bx lr // return to caller
```

Why You must move SP before POP in the Epilogue









```
sub sp, fp, FP_OFF // deallocate local variables by moving sp pop {fp, lr} // pop (restore) fp and lr from stack bx lr // return to caller
```

**Function Epilogue: Deallocating the Stack Frame** 




Move SP back to where it was after the push in the prologue. So, pop works properly (this also deallocates the local variables)



Use pop to restore the registers to the values they had at function entry

```
sub sp, fp, FP_OFF // deallocate local variables by moving sp pop {fp, lr} // pop (restore) fp and lr from stack bx lr // return to caller
```

#### **How to Set FP**



## Reference Table: Global Variable access

var	global variable address into r0 (Iside)		global variable contents into r0 (rside)			contents of r0 into global variable	
x	ldr	r0, =x		-	=x [r0]	ldr str	r1, =x r0, [r1]
*x		r0, =x r0, [r0]	ldr r	່າ0,	=x [r0] [r0]	ldr ldr str	r1, =x r1, [r1] r0, [r1]
**X	ldr	r0, =x r0, [r0] r0, [r0]	ldr r ldr r	.0, .0,	=x [r0] [r0] [r0]	ldr ldr ldr str	r1, =x r1, [r1] r1, [r1] r0, [r1]
stderr	ldr	r0, =stderr			=stderr [r0]	<pre><do are="" doing="" know="" not="" really="" unless="" what="" write="" you=""></do></pre>	
.Lstr	ldr	r0, =.Lstr		-	=.Lstr [r0]	<re< td=""><td>ad only&gt;</td></re<>	ad only>

```
.bss // from libc
stderr:.space 4 // FILE *
```

```
.data
x: .data y //x = &y
```

```
.section .rodata
.Lstr: .string "HI\n"
```

stdin, stdout and stderr are global variables

# **Assembler Directives: Label Scope Control (Normal Labels only)**

- .extern printf
- .extern fgets
- .extern strcpy
- .global fbuf

#### .extern <label>

- Imports label (function name, symbol or a static variable name);
- · An address associated with the label from another file can be used by code in this file

#### .global <label>

- Exports label (or symbol) to be visible outside the source file boundary (other assembly or c source)
- label is either a function name or a global variable name
- Only use with function names or static variables
- Without .global, labels are usually (depends on the assembler) local to the file

Passing global variables as a parameter: fprintf()


```
    r0 = function(r0, r1, r2, r3)
        fprintf(stderr, "arg2", arg3, arg4)
    create a literal string for arg2 which tells fprintf() how to interpret the remaining arguments
    stdin, stdout, stderr are all global variable and are part of libc
    these names are their lside (label names)
    get their contents and pass that to fprintf(), fread(), fwrite()
```

```
.extern fprintf //declare fprintf
#include <stdio.h>
                                                  .section .rodata // note the dots "."
#include <stdlib.h>
                                           .Lfst: .string "c=%d\n"
int
                  We are going to
main(void)
                  put these
                                          // part of the text segment below
                  variables in
   int a = 2;
                                                         r2, 2 // int a = 2;
                                                  mov
   int b = 3; ___
                 temporary
                                                         r3, 3 // int b = 3;
                                                  mov
                  registers
   int c;
                                                         r2, r2, r3 // arg 3: int c = a + b;
                                                  add
   c = a + b;
                                                         r0, =stderr // get stderr address
                                                  1dr
   fprintf(stderr,"c=%d\n", c);
                                  three passed
                                                         r0, [r0] // arg 1: get stderr contents
                                                  ldr
                                  args in this
                                                          r1, =.Lfst // arg 2: =literal address
                                                  ldr
                          r2
            rO,
                   r1,
                                  use of fprintf
                                                          fprintf
                                                  bl
    return EXIT SUCCESS;
```

# **Example: using preserved registers for local variables**

```
#include <stdio.h>
#include <stdlib.h>
                     You must assume that
int
                     both getchar() and
main(void)
                     putchar() alter r0-r3
    int c; // use r0
    int count = 0; // use r4
            r0
    while ((c = getchar()) != EOF) {
        putchar(c);
        count++;
                          r0
                 r0
    printf("Echo count: %d\n", count);
    return EXIT SUCCESS;
```

```
.extern getchar
                    .extern putchar
                   .section .rodata
                   .string "Echo count: %d\n"
            .Lst:
                    .text
                    .type
                           main, %function
                    .global main
                           EOF,
                    .equ
                                         -1
                    .equ FP_OFF,
                                         12
                    .equ EXIT SUCCESS, 0
           main:
                    push
                           {r4, r5, fp, lr}
Push two registers to
                           fp, sp, FP OFF
                   add
keep stack 8-byte
                           r4, 0 //r4 = count
                   mov
aligned (sp \% 8 == 0)
           /* while loop code will go here */
                          r0, EXIT SUCCESS
                   mov
                   sub
                           sp, fp, FP OFF
                          {r4, r5, fp, lr}
                    pop
                           lr
                    bx
                   .size main, (. - main)
```



#### **Accessing Pointers (argv) in ARM assembly**

```
argv[0] = ./cipher
    .extern printf
                                                                           argv[1] = -e
    .extern stderr
                                                                           argv[2] = -b
    .section .rodata
.Lstr: .string "argv[%d] = %s\n"
                                                                           argv[3] = in/B00K
                                                need to save r1 as
    .text
    .qlobal main
                 // main(r0=argc, r1=argv)
                                                we are calling a
                                                                               r0-r3 lost due to fprintf call
           main, %function
    .type
                                                function - fprintf
           FP_OFF,
                       20
    •equ
main:
           {r4-r7, fp, lr}
                                                                                      "argv[%d] = %s\n"
    push
           fp, sp, FP_OFF
    add
                                                                 Registers
            r7, r1
                            // save ardv!
    mov
                                                           r7
            r4, =stderr
                            // get the address of stderr
    ldr
                                                                                       NULL
           r4, [r4]
                            // get the contents of stderr
                                                           r6
   ldr
                                                                   indx
                                                                                     argv[3]
            r5, =.Lstr
                           // get the address of .Lstr
                                                                                                   in/book
    ldr
                                                                                     argv[2]
            r6, 0
                            // set indx = 0;
    mov
                                                                                     argv[1]
                                                                                                      -b
                                                                file * stderr
// see next slide
                                                                                     argv[0]
                                                           r3
                                                                                                      -e
.Ldone:
            r0, 0
                                                           r2
    mov
                                                                                                   ./cipher
    sub
           sp, fp, FP_OFF
                                                                  **argv
            {r4-r7, fp, lr}
    pop
            lr
    bx
                                                            r0
                                                                   argc
```

fprintf(stderr, "argv[%d] = %s\n", indx, \*argv);

39

% \*/cipher -e -b in/B00K

### Accessing Pointers (argv) in ARM assembly

```
argv[0] = ./cipher
                                                             argv[1] = -e
.Lloop:
                                                             argv[2] = -b
   // fprintf(stderr, "argv[%d] = %s\n", indx, *argv)
                                                             argv[3] = in/B00K
   ldr
           r3, [r7] // arg 4: *argv
           r3, 0
                          // check *argv == NULL
   cmp
                                                                 r0-r3 lost due to fprintf call
           Ldone
                          // if so done
   beq
                        // arg 3: indx
           r2, r6
   mov
                  // arg 2: "argv[%d] = %s\n"
           r1, r5
   mov
                                                                             "arqv[%d] = %s\n"
           r0, r4
                          // arg 1: stderr
   mov
                                                          Registers
   bl
           fprintf
                                                    r7
                                                                              NULL
           r6, r6, 1
                           // indx++ for printing
   add
                                                    r6
                                                            indx
   add
                           // argv++ pointer
           r7, r7, 4
                                                                            argv[3]
                                                                                        in/book
           .Lloop
                                                    r5
   h
                                                                            argv[2]
.Ldone:
                                                                            argv[1]
                                                                                          -b
                                                    r4
                                                         file * stderr
                             observe the
                                                                            argv[0]
                                                    r3
                                                                                           -e
                             different
                                                    r2
                             increment sizes
                                                                                        ./cipher
                                                    r1
                                                           **argv
                                                     r0
                                                            argc
```

% ./cipher -e -b in/B00K

40 X

## **Allocating Space For Locals on the Stack**


- Space for local variables is allocated on the stack right below the lowest pushed register
  - Move the sp towards low memory by the total size of all local variables in bytes plus padding

FRMADD = total local var space (bytes) + padding

· Allocate the space after the register push by

Requirement: on function entry, sp is always 8-byte aligned
 sp % 8 == 0

- Padding (as required):
  - 1. Additional space between variables on the stack to meet memory alignment requirements
  - 2. Additional space so the frame size is evenly divisible by 8
- fp (frame pointer) is used as a pointer (base register) to access all stack variables — later slides




#### **Review Variables: Size**

#### Integer types

- char (unspecified default)
- int (signed default)
- Floating Point
  - float, double
- · Optional Modifiers for each base type
  - short [int]
  - long [int, double]
  - signed [char, int]
  - unsigned [char, int]
  - const: variable read only
- char type
  - One byte in a byte addressable memory
  - Be careful char is unsigned on arm and signed on other HW like intel

C Data Type	AArch-32 contiguous Bytes	printf specification
unsigned char	1	%с
signed char	1	%с
short int	2	%hd
unsigned short int	2	%hu
int	4	%d / %i
unsigned int	4	%u
long int	4	%ld
long long int	8	%11d
float	4	%f
double	8	%lf
long double	8	%Lf
pointer *	4	%р

#### **Local Variables on the stack**



```
.text
              main, %function
      .tvpe
      .global main
      .equ
              FP OFF,
                          12
              FRMADD,
                           8
      .equ
   main:
               {r4, r5, fp, lr}
       push
               fp, sp, FP OFF
       add
       add
               sp, sp, -FRMADD
   // but we are not done yet!
// when FRMADD values fail to assemble
        ldr r3, =-FRMADD
```

- In this example we are allocating two variables on the stack
- When writing assembly functions, in many situations you may choose allocate these to registers instead


- Add space on the stack for each local
  - we will allocate space in same order the locals are listed the C function shown from high to low stack address

add sp, sp, r3

- gcc compiler allocates from low to high stack addresses
- · Order does not matter for our use

**Accessing Stack Variables: Introduction** 

```
int main(void)
{
    int c;
    int count = 0;
    // rest of code
}
```



low memory 4-byte words

• use the ldr/str instructions

To Access data stored in the stack


- Use register fp with offset (distance in bytes) addressing (use either register offset or immediate offset)
- No matter what address the stack frame is at, fp always points at saved lr, so you can find a local stack variable by using an offset address from the contents of fp

Variable	distance from fp	Read variable	Write Variable
int c	-16	ldr r0, [fp, -16]	str r0, [fp, -16]
int count	-20	ldr r0, [fp, -20]	str r0, [fp, -20]


```
.text
    .type
            main, %function
    .global main
           FP OFF,
   .equ
                      12
           FRMADD,
                       8
   .equ
main:
            {r4, r5, fp, lr}
    push
            fp, sp, FP_OFF
    add
            sp, sp, -FRMADD
    add
// but we are not done yet!
```

# **Stack Frame Design – Local Variables**

- When writing an ARM equivalent for a C program, for CSE30 we will not re-arrange the order of the variables to optimize space (covered in the compiler course)
- Arrays start at a 4-byte boundary (even arrays with only 1 element)
  - Exception: double arrays [] start at an 8-byte boundary
  - struct arrays are aligned to the requirements of largest member
- Single chars (and shorts) can be grouped together in same 4-byte word (following the alignment for the short)
- Padding may be required (see next slide)




Rule: When the function is entered the stack is already 8-byte aligned



## **Stack Variables: Padding**

 Variable padding – start arrays at 4byte boundary and leave unused space at end (high side address) before the variable higher on the stack



 Frame padding – add space below the last local variable to keep 8-byte alignment




```
Ir to caller
                                     callers fp
                                                     FP_OFF
        8-byte aligned
                                      saved r5
                               12
     32 bytes
    Total frame
                                      saved r4
              ξр
                                4
                                       count
                            1 + 3 pad
                                           buf
                                      frame pad
                                                       sp
                                   .text
                                               main, %function
                                      .type
int main(void)
                                      .global main
                                              FP OFF.
                                     .equ
                                                           12
    int c;
                                                           16
                                              FRMADD,
                                     .equ
    int count = 0;
                                 main:
    char buf[] = "hi";
                                               {r4, r5, fp, lr}
                                      push
    // rest of code
                                               fp, sp, FP_OFF
                                      add
}
                                               sp, sp, -FRMADD
                                      add
                                 // but we are not done yet!
```

X

Accessing Stack Variables, the hard way.


```
int main(void)
{
    int c;
    int count = 0;
    char buf[] = "hi";
    // rest of code
}
```

```
.text
    .tvpe
            main, %function
    .global main
   .equ
           FP OFF,
                      12
           FRMADD,
                      16
   .equ
main:
            {r4, r5, fp, lr}
    push
    add
            fp, sp, FP OFF
            sp, sp, -FRMADD
    add
// but we are not done yet!
```




char buf[] by usage with ASCII chars we will use strb (or make it unsigned char)


Variable	distance from fp	Read variable	Write Variable
int c	16	ldr r0, [fp, -16]	str r0, [fp, -16]
int count	20	ldr r0, [fp, -20]	str r0, [fp, -20]
char buf[0]	24	ldrb r0, [fp, -24]	strb r0, [fp, -24]
char buf[1]	23	ldrb r0, [fp, -23]	strb r0, [fp, -23]
char buf[2]	22	ldrb r0, [fp, -22]	strb r0, [fp, -22]



- Calculating offsets is a lot of work to get it correct
- · It is also hard to debug
- There is a better way!


#### **Best Practice: Assembler Generated FP Distance Table**





- 1. For each stack variable create a .equ symbol whose value is the distance in bytes from the FP after the prologue
- 2. After the last variable add a name PAD for the size of the frame padding (if any). if no padding, PAD will be set to the same value as the variable above it
- 3. The value of the symbol is an expression that calculates the distance from the FP based on the distance of the variable above it on the stack. The first variable will use SP\_OFF as the starting distance
  - **.equ VAR**, size\_of var + variable\_padding + previous\_var\_symbol // previous\_var\_symbol distance of the var above
- 4. Calculate the size of the local variable area that needs to be added to the sp in bytes

  FRMADD = distance PAD minus distance of the SP to the FP (FP OFF) after the prologue push



Variable	distance from fp	Address on Stack	Read variable	Write Variable
int c	С	add r0, fp, -C	ldr r0, [fp, -C]	str r0, [fp, -C]
int count	COUNT	add r0, fp, -COUNT	ldr r0, [fp, -COUNT]	str r0, [fp, -COUNT]
char buf[0]	BUF	add r0, fp, -BUF	ldrb r0, [fp, -BUF]	strb r0, [fp, -BUF]
char buf[1]	BUF-1	add r0, fp, -BUF+1	ldrb r0, [fp, -BUF+1]	strb r0, [fp, -BUF+1]
char buf[2]	BUF-2	add r0, fp, -BUF+2	ldrb r0, [fp, -BUF+2]	strb r0, [fp, -BUF+2]

```
Initializing and Accessing Stack variables
                                                                                                    Ir to caller
                                                                                                     callers fp
      .section .rodata
                                                                     Total frame size
 .Lmess: .string "%d %d %s\n"
                                                                         8-byte aligned
                                                                                                     saved r5
                                                                                               12
      .extern printf
                                                                                                     saved r4
                                                                              fр
                                                                                   fр
                                                                                         fр
main:
                                                                                                       count
             {r4, r5, fp, lr}
    push
                                    passes
                                                                                            1 + 3
             fp, sp, FP OFF
    add
                                   contents of
             sp, sp, -FRMADD
    add
                                   stack var C
                                                                                               4
                                                                                                      frame pad
    // nothing to do for C
                                   and
             r2, 0
    mov
                                   COUNT
                                                   int main(int argc, char **argv)
             r2, [fp, -COUNT]
    str
             r2, [fp, -BUF+2]
                                                       int c;
    strb
                                                                           pass stack address
                                                       int count = 0;
             r2, 'h'
    mov
                                                       char buf[] = "hi";
             r2, [fp, -BUF]
    strb
                                                                                                    ./a.out
                                                       printf("%d %d %s\n", c, count, buf);
              r2, 'i'
    mov
                                                                                                    -136572160 0 hi
                                                        // rest of code
              r2, [fp, -BUF+1]
    strb
                                                                  Address on Stack
                                                                                       Read variable
             r0, =.Lmess /
                                 // arg1
                                                         distance
    ldr
                                              Variable
                                                         from fp
    ldr
             r1, [fp, -C]
                                 // arg2
                                             int c
                                                           C
                                                                 add r0, fp, -C
                                                                                   ldr r0, [fp, -C]
                                                                                                        str r0, [fp, -C]
    ldr
             r2, [fp, -COUNT] // arg3
                                                         COUNT
                                                                 add r0, fp, -COUNT
    add
             r3, fp, -BUF
                                 // arg4
                                             int count
                                                                                   ldr r0, [fp, -COUNT]
                                                                                                        str r0, [fp, -COUNT]
```

char buf[0]

char buf[1]

char buf[2]

**BUF** 

BUF-1

BUF-2

add r0, fp, -BUF

add r0, fp, -BUF+1

add r0, fp, -BUF+2

ldrb r0, [fp, -BUF]

ldrb r0, [fp, -BUF+1]

ldrb r0, [fp, -BUF+2]

passes address of a stack variable buf

printf

bl

FP\_OFF

FRMADD

Write Variable

strb r0, [fp, -BUF]


strb r0, [fp, -BUF+1]


strb r0, [fp, -BUF+2]

sp

buf







2 + FP OFF

2 + C

.equ

.equ


.equ

S,

Write the variables in C

fp

- Draw a picture of the stack frame
- Write the code to generate the offsets
- create the distance table to the variables



.equ	FP_UFF,	12
.equ	С,	1 + FP_OFF
.equ	S,	3 + C
.equ	Β,	8 + S
.equ	PTR,	4 + B
.equ	PAD,	0 + PTR
.equ	FRMADD,	PAD - FP_OFF
// FRMA	DD = 28 -	12 = 16

Variable	distance from fp	Address on Stack	Read variable	Write Variable
signed char c	С	add r0, fp, -C	ldrsb r0, [fp, -C]	strsb r0, [fp, -C]
signed short s	S	add r0, fp, -S	ldrsh r0, [fp, -S]	strsh r0, [fp, -S]
unsigned char b[0]	В	add r0, fp, -B	ldrb r0, [fp, -B]	strb r0, [fp, -B]
unsigned char *ptr	PTR	add r0, fp, -PTR	ldr r0, [fp, -PTR]	str r0, [fp, -PTR]

```
int sum(int j, int k)
{
    return j + k;
}
void testp(int j, int k, int (*func)(int, int), int *i)
{
    *i = func(j,k);
    return;
}
int main()
{
    int i;
    int (*pf)(int, int) = sum; // pf could be in a register

    testp(1, 2, pf, &i);
    printf("%d\n", i);
    return EXIT_SUCCESS;
}
Output Parameters (like i) you
pass a pointer to them, must be on the stack!
```

 $\mathsf{x}$ 

```
int main()
{
   int i; // NOTICE: i must be on stack as you pass the address!
   int (*pf)(int, int) = sum; // pf could be in a register

   testp(1, 2, pf, &i);
   printf("%d\n", i);
   return EXIT_SUCCESS;
}
```

```
Ir to caller

8-phre aligned

(*pf)()

4

frame pad

page 4

frame pad

page 4

frame pad

page 4

frame pad

page 5

page 5

page 6

page 6

page 6

page 6


page 6

page 7

page 7
```


. Lı	.sectio mess: .st	n .rodat ring "%d	
	.extern	printf	
	.text	p. 1	
	.global	main	
	.type	main, %	function
	<b>.</b> equ	FP_OFF,	4
	<b>.</b> equ	Ι,	4 + FP_0FF
	<b>.</b> equ	,	4 + I
	₌equ	PAD,	0 + PF
	•equ	FRMADD,	PAD-FP_0FF
//	FRMADD =	12 - 4 =	8

Variable	distance from fp	Address on Stack	Read variable	Write Variable	
int i	I	add r0, fp, -I	ldr r0, [fp, -I]	str r0, [fp, -I]	
int (*pf)()	PF	add r0, fp, -PF	ldr r0, [fp, -PF]	str r0, [fp, -PF]	



Variable	distance from fp	Address on Stack	Read variable	Write Variable	
int i	I	add r0, fp, -I	ldr r0, [fp, -I]	str r0, [fp, -I]	
int (*pf)()	PF	add r0, fp, -PF	ldr r0, [fp, -PF]	str r0, [fp, -PF]	


```
void
testp(int j, int k, int (*func)(int, int), int *i)
{
    *i = func(j, k);
    return;
}
```



```
int
sum(int j, int k)
{
    return j + k;
}
```

```
.global sum
.type sum, %function
.equ FP_OFF, 4
sum:
   push {fp, lr}
   add fp, sp, FP_OFF
   add r0, r0, r1

   sub sp, fp, FP_OFF
   pop {fp, lr}
   bx lr
.size sum, (. - sum)
```




Passing More Than Four Arguments – At the point of Call

r0 = function(r0, r1, r2, r3, arg5, arg6, ... argn)

arg1, arg2, arg3, arg4, ...


- Approach: Increase stack frame size to include space for args# > 4
  - Arg5 and above are in <u>caller's stack frame</u> at the bottom of the stack
- Arg5 is always at the bottom (at sp), arg6 and greater are above it
- One arg value per slot! NO arrays across multiple slots
  - · chars, shorts and ints are directly stored
  - Structs (not always), and arrays (always) are passed via a pointer
- Output parameters contain an address that points at the stack, BSS, data, or heap
- Prior to any function call (and obviously at the start of the called function):
  - 1. sp must point at arg5
  - 2. sp and therefore arg5 must be at an 8-byte boundary,
  - 3. Add padding to force arg5 alignment if needed is placed above the last argument the called function is expecting



## **Passing More Than Four Arguments – At the point of Call**

r0 = function(r0, r1, r2, r3, arg5, arg6, ... argn)arg1, arg2, arg3, arg4, ...

- Called functions have the right to change stack args just like they can change the register args!
  - Caller must always assume all args including ones on the stack are changed by the caller
- Calling function prior to making the call you must
  - 1. Evaluate first four args: place the resulting values in r0-r3
  - 2. Evaluate Arg 5 and greater and place the resulting values on the stack




## Passing More Than Four Arguments – At the point of Call

```
r0 = function(r0, r1, r2, r3, arg5, arg6, ... argn)

arg1, arg2, arg3, arg4, ...
```

- Approach: Extend the stack frame to include enough space for stack arguments for the called function that has the greatest number of args
  - 1. Examine every function call in the body of a function
  - 2. Find the function call with greatest arg count, this determines space needed for outgoing args
  - 3. Add the greatest arg count space as needed to the frame layout
  - 4. Adjust PAD as required to keep the sp 8-byte aligned



59

# **Determining Size of the Passed Parameter Area on The Stack**

- Find the function called by main with the largest number of parameters
- That function determines the size of the Passed Parameter allocation on the stack

```
int main(void)
{
    /* code not shown */
    a(g, h);

    /* code not shown */
    sixsum(a1, a2, a3, a4, a5, a6);

    /* code not shown */

    b(q, w, e, r);
    /* code not shown */
}
```


largest arg count is 6 allocate space for 6 - 4 = 2 arg slots

### **<u>Calling Function Stack Frame:</u>** Pass ARG 5 and higher

#### **Rules: At point of call**

- 1. OARG5 must be pointed at by sp
- 2. SP must be 8-byte aligned at function call

```
int cnt;
r0 = func(r0, r1, r2, r3, OARG5, OARG6);
```



Variable	distance from fp	Address on Stack	Read variable	Write Variable
int cnt	CNT	add r0, fp, -CNT	ldr r0, [fp, -CNT]	str r0, [fp, -CNT]
int oarg6	OARG6	add r0, fp, -OARG6	ldr r0, [fp, -OARG6]	str r0, [fp, -OARG6]
int oarg5	OARG5	add r0, fp, -OARG5	ldr r0, [fp, -OARG5]	str r0, [fp, -OARG5]


# **Called Function: Retrieving Args From the Stack**

r0 = func(r0, r1, r2, r3, ARG5, ARG6);

- At function start and before the push{} the sp is at an 8-byte boundary
- Args > 4 in <u>caller's stack frame</u> and arg 5 always starts at fp+4
  - Additional args are higher up the stack, with one "slot" every 4bytes

.equ ARGN, 
$$(N-4)*4$$
 // where n must be > 4

- This "algorithm" for finding args was designed to enable variable arg count functions like printf("conversion list", arg0, ... argn);
- No limit to the number of args (except running out of stack space)



#### Rule:

Called functions always access stack args using a positive offset to the fp

# **Called Function: Retrieving Args From the Stack**

```
.equ FP_OFF, 4
.equ C, 4 + FP_OFF
.equ INDX, 4 + C
.equ PAD, 0 + INDX
.equ FRMADD, PAD - FP_OFF
// below are distances into the caller's stack frame
.equ ARG6, 8
.equ ARG5, 4
```

r0 = func(r0, r1, r2, r3, r4, ARG5, ARG6);

#### Rule:

**Called functions** always access stack args using a **positive offset to the fp** 

<u> </u>	oning a poon		- t ti.i i-p				
	Variable or Argument	distance from fp	Address on Stack		Read variable	Write Variable	
	int arg6	ARG6	add r0, fp, ARG6	ldr	r0, [fp, ARG6]	str r0, [fp, ARG6]	Observe the positive
	int arg5	ARG5	add r0, fp, ARG5	ldr	r0, [fp, ARG5]	str r0, [fp, ARG5] 💠	offsets
	int c	С	add r0, fp, -C	ldr	r0, [fp, -C]	str r0, [fp, -C]	
	int count	INDX	add r0, fp, -INDX	ldr	r0, [fp, -INDX]	str r0, [fp, -INDX]	v

Ir to caller

callers fp

Frame PAD

oarg6

oarg5

Ir to callers

callers fp

indx

Frame PAD

ARG6

INDX

ARG5

calling

stack

frame

called

stack

frame

**functions** 

**functions** 

# **Example: Passing Stack Args, Calling Function**


```
int sum(int j, int k)
    return j + k;
      arg1
                      arg3
                             arg4
                                         arg5
              arg2
                                                           arg6
void
testp(int j, int k, int l, int m, int (*func)(int, int), int *i)
    *i = func(j,k) + func(l, m); // notice two func() calls
    return;
}
int main()
    int i; // NOTICE: i must be on stack as you pass the address!
    int (*pf)(int, int) = sum; // pf could be in a register
    testp(1, 2, 3, 4, pf, &i);
    printf("%d\n", i);
    return EXIT_SUCCESS;
```

# **Example: Passing Stack Args, Calling Function**


```
int main()
{
   int i; // NOTICE: i must be on stack as you pass the address!
   int (*pf)(int, int) = sum; // pf could be in a register

   testp(1, 2, 3, 4, pf, &i);
   printf("%d\n", i);
   return EXIT_SUCCESS;
}
   equ FP_OFF, 4
```


```
.equ FP_OFF, 4
.equ I, 4 + FP_OFF
.equ PF, 4 + I
.equ PAD, 0 + PF
.equ OARG6, 4 + PAD
.equ OARG5 4 + OARG6
.equ FRMADD, OARG5 - FP_OFF
// FRMADD = 20 - 4 = 16
```



Variable or Argument	distance from fp	Address on Stack	Read variable	Write Variable
int i	I	add r0, fp, -I	ldr r0, [fp, -I]	str r0, [fp, -I]
int (*pf)()	PF	add r0, fp, -PF	ldr r0, [fp, -PF]	str r0, [fp, -PF]
int oarg6	OARG6	add r0, fp, -OARG6	ldr r0, [fp, -OARG6]	str r0, [fp, -OARG6]
int oarg5	OARG5	add r0, fp, -OARG5	ldr r0, [fp, -OARG5]	str r0, [fp, -OARG5]



Variable or Argument	distance from fp	Address on Stack	Read variable	Write Variable
int i	I	add r0, fp, -I	ldr r0, [fp, -I]	str r0, [fp, -I]
int (*pf)()	PF	add r0, fp, -PF	ldr r0, [fp, -PF]	str r0, [fp, -PF]
int oarg6	OARG6	add r0, fp, -OARG6	ldr r0, [fp, -OARG6]	str r0, [fp, -OARG6]
int oarg5	OARG5	add r0, fp, -OARG5	ldr r0, [fp, -OARG5]	str r0, [fp, -OARG5]



	Argument	distance	Address on Stack	Read variable	Write Variable
	int *i	ARG6	add r0, fp, ARG6	ldr r0, [fp, ARG6]	str r0, [fp, ARG6]
67	int (*pf)()	ARG5	add r0, fp, ARG5	ldr r0, [fp, ARG5]	str r0, [fp, ARG5]

# **Extra Slides**

# By following the saved fp, you can find each stack frame

