1 RISC-y Conversions

- 1.1 Convert the different RISC-V commands into their hex form or convert the hex form into RISC-V. The instructions are in order of when they would be executed.
 - (a) 0x005004B3
 - (b) lw t5, 17(t6)
 - (c) sll s9, x9, t0
 - (d) 0x03CE2283
 - (e) jalr a0, x11, 8
 - (f) ori t1, t2, 5
 - (g) lui a7, 0xCF61C

2 Instruction Format Design

Prof. Wawrzynek decides to design a new ISA for his ternary neural network accelerator. He only needs to perform 7 different operations with his ISA: xor, add, lw, sw, lui, addi, and blt. He decides that each instruction should be 17 bits wide, as he likes the number 17. There are no funct7 or funct3 fields in this new ISA.

- 2.1 What is the minimum number of bits required for the opcode field?
- 2.2 Suppose Prof. Wawrzynek decides to make the opcode field 6 bits. If we would like to support instructions with 3 register fields, what is the maximum number of registers we could address?

- 2.3 Given that the opcode field is 6 bits wide and each register field is 2 bits wide in the 17 bit instruction, answer the following questions:
 - (a) Using the assumptions stated in the above description, how many bits are left for the immediate field for the instruction blt (Assume it takes opcode, rs1, rs2, and imm as inputs)?
 - (b) Let n be your answer in part (a). Suppose that blt's branch immediate is in units of instructions (i.e. an immediate of value 1 means branching 1 instruction away). What is the maximum number of bits a blt instruction can jump forward from the current pc using these assumptions? Write your answer in terms of n.
 - (c) Using the assumptions stated in the description, what is the most negative immediate that could be used in the addi instruction (Assume it takes opcode, rs1, rd, and imm as inputs)?
 - (d) For LUI, we need opcode, rd, and imm as inputs. Using the assumptions stated in the description, how many bits can we use for the immediate value?

3 Advanced RISC-V

3.1 You are given the following RISC-V code:

```
Loop: andi t2 t1 1
srli t3 t1 1
bltu t1 a0 Loop
jalr s0 s1 MAX_POS_IMM
```

- (a) What is the value of the byte offset that would be stored in the immediate field of the bltu instruction?
- (b) What is the binary encoding of the bltu instruction? Please use hexadecimal to represent your answer.
- As a curious 61C student, you question why there are so many possible opcodes, but only 47 instructions. Thus, your propose a revision to the standard 32-bit RISC-V instruction formats where each instruction has a unique opcode (which still is 7 bits). You believe this justifies taking out the funct3 field from the R, I, S, and SB instructions, allowing you to allocate bits to other instruction fields except the opcode field.
 - (a) What is the largest number of registers that can now be supported in hardware?
 - (b) With the new register size, how far can a jal instruction jump to (in halfwords)?
 - (c) Assume register s0 = 0x1000 0000, s1 = 0x4000 0000, PC = 0xA000 0000. Let's analyze the instruction jalr s0, s1, MAX_POS_IMM where MAX_POS_IMM is the maximum possible positive immediate for jalr. Using the register sizes defined above, what are the values in registers s0, s1, and pc after the instruction executes?