Matlab Code for Pulse Width Modulation and Pulse Position Modulation

```
fm=25;
w=2*pi;
f=300;
overSampRate=650;
fs=overSampRate*f;
cycle=50;
t=0:1/fs:0.1;
%%Message Signal
xm = sin(w*fm*t);
subplot(4,1,1);
plot(t,xm);
title('Message Signal');
%%Carrier Pulse Signal
xc=2*sawtooth(800*t);
subplot(4,1,2);
plot(t,xc);
title('Carrier Pulse Signal');
%%Pulse Width Modulation
for i= 1:length(t)
    if xc(i) \le xm(i)
        pw(i) = 1;
    else
        pw(i) = 0;
    end
end
subplot(4,1,3);
plot(t,pw);
title('Pulse Width Modulated wave');
%%Pulse Position Modulation
pp(1)=0;
for i=2:length(t)
    if pw(i) == pw(i-1)
        pp(i) = 0;
    elseif pw(i) < pw(i-1)
        pp(i)=1;
    end
end
subplot(4,1,4)
plot(t,pp)
title('Pulse Position Modulated wave');
```

