# Processor Programming Reference (PPR) for AMD Family 17h Model 60h, Revision A1 Processors

# **Legal Notices**

# © 2020 Advanced Micro Devices, Inc. All rights reserved.

The information contained herein is for informational purposes only, and is subject to change without notice. While every precaution has been taken in the preparation of this document, it may contain technical inaccuracies, omissions and typographical errors, and AMD is under no obligation to update or otherwise correct this information. Advanced Micro Devices, Inc. makes no representations or warranties with respect to the accuracy or completeness of the contents of this document, and assumes no liability of any kind, including the implied warranties of noninfringement, merchantability or fitness for particular purposes, with respect to the operation or use of AMD hardware, software or other products described herein. No license, including implied or arising by estoppel, to any intellectual property rights is granted by this document. Terms and limitations applicable to the purchase or use of AMD's products are as set forth in a signed agreement between the parties or in AMD's Standard Terms and Conditions of Sale.

#### Trademarks:

AMD, the AMD Arrow logo, and combinations thereof are trademarks of Advanced Micro Devices, Inc.

AGESA is a trademark of Advanced Micro Devices, Inc.

AMD Virtualization is a trademark of Advanced Micro Devices, Inc.

AMD-V is a trademark of Advanced Micro Devices, Inc.

Adobe is a registered trademark of Adobe.

DirectX is a registered trademark of Microsoft Corporation.

HDMI is a trademark of HDMI Licensing, LLC.

Infinity Fabric is a trademark of Advanced Micro Devices, Inc.

Linux is a registered trademark of Linus Torvalds.

Microsoft is a registered trademark of Microsoft Corporation.

OpenCL is a trademark of Apple, Inc. used by permission by Khronos Group, Inc.

OpenGL is a registered trademark of Hewlett Packard Enterprise.

PCI Express is a registered trademark of PCI-SIG Corporation.

PCIe is a registered trademark of PCI-SIG Corporation.

Windows is a registered trademark of Microsoft Corporation.

Other product names used in this publication are for identification purposes only and may be trademarks of their respective companies.

Reverse engineering or disassembly is prohibited.

USE OF THIS PRODUCT IN ANY MANNER THAT COMPLIES WITH THE MPEG ACTUAL OR DE FACTO VIDEO AND/OR AUDIO STANDARDS IS EXPRESSLY PROHIBITED WITHOUT ALL NECESSARY LICENSES UNDER APPLICABLE PATENTS. SUCH LICENSES MAY BE ACQUIRED FROM VARIOUS THIRD PARTIES INCLUDING, BUT NOT LIMITED TO, IN THE MPEG PATENT PORTFOLIO, WHICH LICENSE IS AVAILABLE FROM MPEG LA, L.L.C., 6312 S. FIDDLERS GREEN CIRCLE, SUITE 400E, GREENWOOD VILLAGE, COLORADO 80111.

# **List of Chapters**

- 1 Overview
- 2 Core Complex (CCX)
- 3 Reliability, Availability, and Serviceability (RAS) Features
- 4 System Management Unit (SMU)
- 5 Advanced Platform Management Link (APML)
- **6** SB Temperature Sensor Interface (SB-TSI)

List of Namespaces List of Definitions Memory Map - MSR Memory Map - Main Memory

# **Table of Contents**

Over	view		
1.1	Intended Audience		
1.2	Reference Documents		
	1.2.1 Documentation Conventions		
1.3	Adobe® Reader		
	1.3.1 Adobe® Reader Configuration		
	1.3.1.1 Open Hyperlink Document in New Window		
	1.3.1.2 Show Toolbars		
	1.3.1.3 Show "Previous View" and "Next View" Buttons		
	1.3.2 Adobe® Reader Usage		
	1.3.2.1 Searching a Multiple Volume PPR		
	1.3.2.2 Cross-References and Hyperlinks		
	1.3.2.3 Expand Current Bookmark		
1.4	Conventions		
	1.4.1 Numbering		
	1.4.2 Arithmetic And Logical Operators		
	1.4.2.1 Operator Precedence and Associativity		
	1.4.3 Register Mnemonics		
	1.4.3.1 Logical Mnemonic		
	1.4.3.2 Physical Mnemonic		
	1.4.4 Register Format		
	1.4.4.1 A Register is a group of Register Instances		
	1.4.4.2 Register Physical Mnemonic, Title, and Name		
	1.4.4.3 Full Width Register Attributes		
	1.4.4.4 Register Description		
	1.4.4.5 Register Instance Table		
	1.4.4.5.1 Content Ordering in a Row		
	1.4.4.5.2 Multiple Instances Per Row		
	1.4.4.5.3 MSR Access Method		
	1.4.4.5.3.1 MSR Per-Thread Example		
	1.4.4.5.3.2 MSR Range Example		
	1.4.4.5.4 BAR Access Method		
	1.4.4.5.4.1 BAR as a Register Reference		
	1.4.4.5.5 PCICFG Access Method		
	1.4.4.5.5.1 PCICFG Bus Implied to be 00h		
	1.4.4.5.6 Data Port Access Method		
	1.4.4.6 Register Field Format		
	1.4.4.7 Simple Register Field Format		
	1.4.4.8 Complex Register Field Format		
	1.4.4.9 Field Name is Reserved		
	1.4.4.10 Field Access Type		
	1.4.4.10.1 Conditional Access Type Expression		
	1.4.4.11 Field Reset		
	1.4.4.12 Field Initialization		
	1.4.4.13 Field Check		
	1.4.4.14 Field Valid Values		
1.5	Definitions		
1.6	Changes Between Revisions and Product Variations		
	1.6.1 Revision Conventions		
1.7	Package		

1.7.1 Package type	
.8 Processor Overview	
1.8.1 Features	
Core Complex (CCX)	
2.1 Processor x86 Core	
2.1.1 Core Functional Information	
2.1.2 Core Definitions	
2.1.3 Secure Virtual Machine Mode (SVM)	
2.1.3.1 BIOS support for SVM Disable	
2.1.3.1.1 Enable AMD Virtualization™	
2.1.3.1.2 Disable AMD Virtualization <sup>TM</sup>	
2.1.3.1.3 Disable AMD Virtualization™, with a user supplied ke	y
2.1.4 Memory Encryption	
2.1.5 Effective Frequency	
2.1.6 Address Space	
2.1.6.1 Virtual Address Space	
2.1.6.2 Physical Address Space	
2.1.6.3 System Address Map	
2.1.6.3.1 Memory Access to the Physical Address Space	
2.1.6.3.1.1 Determining Memory Type	
2.1.7 Configuration Space	
2.1.7.1 MMIO Configuration Coding Requirements	
2.1.7.2 MMIO Configuration Ordering	
2.1.7.3 Processor Configuration Space	
2.1.8 PCI Configuration Legacy Access	
2.1.9 System Software Interaction With SMT Enabled	
2.1.10 Register Sharing	
2.1.11 Timers	
2.1.12 Interrupts	
2.1.12.1 System Management Mode (SMM)	
2.1.12.1.1 SMM Overview	
2.1.12.1.2 Mode and Default Register Values	
2.1.12.1.3 SMI Sources And Delivery	
2.1.12.1.4 SMM Initial State	
2.1.12.1.5 SMM Save State	
2.1.12.1.6 System Management State	
2.1.12.1.7 Exceptions and Interrupts in SMM	
2.1.12.1.8 The Protected ASeg and TSeg Areas	
2.1.12.1.9 SMM Special Cycles	
2.1.12.1.10 Locking SMM	
2.1.12.2 Local APIC	
2.1.12.2.1 Local APIC Functional Description	
2.1.12.2.1.1 Detecting and Enabling	
2.1.12.2.1.2 APIC Register Space	
2.1.12.2.1.3 ApicId Enumeration Requirements	
2.1.12.2.1.4 Physical Destination Mode	
2.1.12.2.1.5 Logical Destination Mode	
2.1.12.2.1.6 Interrupt Delivery	
2.1.12.2.1.7 Vectored Interrupt Handling	
2.1.12.2.1.8 Interrupt Masking	
2.1.12.2.1.9 Spurious Interrupts	
• • • • • • • • • • • • • • • • • • • •	
2.1.12.2.1.10 Spurious Interrupts Caused by Timer Tick Interrupt	

3.1.4.2

**Error Simulation** 

	2.1.12.2.1.2	12 Inter-Processor Interrupts
	2.1.12.2.1.1	_
	2.1.12.2.1.3	
	2.1.12.2.1.1	
	2.1.12.2.2	8
		PUID Instruction
	2.1.13.1	CPUID Instruction Functions
	2.1.14 N	ISR Registers
	2.1.14.1	MSRs - MSR0000_xxxx
	2.1.14.2	MSRs - MSRC000_0xxx
	2.1.14.2.1	MSRs - MSRC000_2xxx
	2.1.14.3	MSRs - MSRC001_0xxx
	2.1.14.4	MSRs - MSRC001_1xxx
	2.1.15 P	erformance Monitor Counters
	2.1.15.1	RDPMC Assignments
	2.1.15.2	Large Increment per Cycle Events
	2.1.15.3	
	2.1.15.3.1	
	2.1.15.3.2	· , ,
		IC and BP Events
	2.1.15.3.4	
		EX (SC) Events
	2.1.15.3.6	
	2.1.15.4	L3 Cache Performance Monitor Counters L3 Cache PMC Events
	2.1.15.4.1	I 3 Cache PIVIC EVENTS
- 11	2.1.16 In	nstruction Based Sampling (IBS)
	2.1.16 In Ibility, Avail	nstruction Based Sampling (IBS) <b>ability, and Serviceability (RAS) Features</b>
<b>Relia</b> 3.1	2.1.16 In <b>bility, Avail</b> Machine (	nstruction Based Sampling (IBS) <b>ability, and Serviceability (RAS) Features</b> Check Architecture
	2.1.16 In the state of the stat	nstruction Based Sampling (IBS) <b>ability, and Serviceability (RAS) Features</b> Check Architecture  Overview
	2.1.16 In <b>bility, Avail</b> Machine (3.1.1 C) 3.1.1.1	nstruction Based Sampling (IBS) <b>ability, and Serviceability (RAS) Features</b> Check Architecture  Overview  Legacy Machine Check Architecture
	2.1.16 In bility, Avail Machine (3.1.1 C 3.1.1.1 3.1.1.2	nstruction Based Sampling (IBS)  ability, and Serviceability (RAS) Features Check Architecture Overview  Legacy Machine Check Architecture Machine Check Architecture Extensions
	2.1.16 In <b>bility, Avail</b> Machine (3.1.1 C) 3.1.1.1	nstruction Based Sampling (IBS)  ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information
	2.1.16 In bility, Avail Machine (3.1.1 C 3.1.1.1 3.1.1.2	nstruction Based Sampling (IBS)  ability, and Serviceability (RAS) Features Check Architecture Overview  Legacy Machine Check Architecture Machine Check Architecture Extensions
	2.1.16 In <b>bility, Avail</b> Machine 6 3.1.1 C 3.1.1.1 3.1.1.2 3.1.1.3	nstruction Based Sampling (IBS)  ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information
	2.1.16 In bility, Avail Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3 3.1.1.3.1 3.1.1.3.2	nstruction Based Sampling (IBS)  ability, and Serviceability (RAS) Features Check Architecture Overview  Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management
	2.1.16 In bility, Avail Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3 3.1.1.3.1 3.1.1.3.2	nstruction Based Sampling (IBS)  ability, and Serviceability (RAS) Features Check Architecture Overview  Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information  Error Management Fault Management Machine Check Registers
	2.1.16 In bility, Avail Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3 3.1.1.3.1 3.1.1.3.2 3.1.2 M	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management
	2.1.16 In bility, Avail Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3 3.1.1.3.1 3.1.1.3.2 3.1.2 M 3.1.2.1	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Machine Check Registers Global Registers Machine Check Banks
	2.1.16 In Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3.1 3.1.1.3.2 3.1.2 M 3.1.2.1 3.1.2.2 3.1.2.2 3.1.2.2	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Machine Check Registers Global Registers Machine Check Banks Legacy MCA Registers
	2.1.16 In bility, Avail Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3.1 3.1.1.3.2 3.1.2 M 3.1.2.1 3.1.2.2 3.1.2.2 3.1.2.2 3.1.2.2 3.1.2.2.1 3.1.2.2.2	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Machine Check Registers Global Registers Machine Check Banks Legacy MCA Registers Legacy MCA MSRs
	2.1.16 In bility, Avail Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3.1 3.1.1.3.2 3.1.2 M 3.1.2.1 3.1.2.2 3.1.2.2 3.1.2.2.1 3.1.2.2.2 3.1.2.2.3 3.1.2.2.3	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Machine Check Registers Global Registers Machine Check Banks Legacy MCA Registers Legacy MCA MSRs MCAX Registers
	2.1.16 In bility, Avail Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3.1 3.1.1.3.2 3.1.2 M 3.1.2.1 3.1.2.2 3.1.2.2 3.1.2.2.1 3.1.2.2.2 3.1.2.2.3 3.1.2.2.4	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Machine Check Registers Global Registers Machine Check Banks Legacy MCA Registers Legacy MCA MSRs MCAX Registers MCAX MSRs
	2.1.16 In Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3.1 3.1.1.3.2 3.1.2 In 3.1.2.2 3.1.2.1 3.1.2.2 3.1.2.2.1 3.1.2.2.2 3.1.2.2.3 3.1.2.2.4 3.1.2.3	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Global Registers Global Registers Machine Check Banks Legacy MCA Registers Legacy MCA MSRs MCAX Registers MCAX MSRs Access Permissions
	2.1.16 In Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3.1 3.1.1.3.2 3.1.2 M 3.1.2.1 3.1.2.2 3.1.2.2 3.1.2.2.1 3.1.2.2.2 3.1.2.2.3 3.1.2.2.4 3.1.2.3 3.1.3 M	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Machine Check Registers Global Registers Machine Check Banks Legacy MCA Registers Legacy MCA MSRs MCAX Registers MCAX MSRs Access Permissions Machine Check Errors
	2.1.16 In bility, Avail Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3.1 3.1.1.3.2 3.1.2 M 3.1.2.1 3.1.2.2 3.1.2.2 3.1.2.2.1 3.1.2.2.2 3.1.2.2.3 3.1.2.2.4 3.1.2.3 3.1.3 M 3.1.3.1	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Machine Check Registers Global Registers Machine Check Banks Legacy MCA Registers Legacy MCA MSRs MCAX Registers MCAX MSRs Access Permissions Machine Check Errors Error Severities
	2.1.16 In bility, Avail Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3.1 3.1.1.3.2 3.1.2.1 3.1.2.2 3.1.2.2.1 3.1.2.2.2 3.1.2.2.3 3.1.2.2.4 3.1.2.3 3.1.3 N 3.1.3.1 3.1.3.2	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Machine Check Registers Global Registers Machine Check Banks Legacy MCA Registers Legacy MCA MSRs MCAX Registers MCAX Registers MCAX MSRs Access Permissions Machine Check Errors Error Severities Exceptions and Interrupts
	2.1.16 In bility, Avail Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3 3.1.1.3.2 3.1.2 M 3.1.2.1 3.1.2.2 3.1.2.2.1 3.1.2.2.2 3.1.2.2.3 3.1.2.2.4 3.1.2.3 3.1.3 M 3.1.3.1 3.1.3.2 3.1.3.3	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Machine Check Registers Global Registers Machine Check Banks Legacy MCA Registers Legacy MCA MSRs MCAX Registers MCAX Registers MCAX MSRs Access Permissions Machine Check Errors Error Severities Exceptions and Interrupts Error Codes
	2.1.16 In Machine (3.1.1 C) 3.1.1.1 (3.1.1.2 3.1.1.3.1 3.1.1.3.2 3.1.2.1 3.1.2.2 3.1.2.2.1 3.1.2.2.2 3.1.2.2.3 3.1.2.2.4 3.1.2.3 3.1.3 N 3.1.3.1 3.1.3.2 3.1.3.3 3.1.3.4	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Global Registers Global Registers Machine Check Banks Legacy MCA Registers Legacy MCA MSRs MCAX Registers MCAX Registers MCAX MSRs Access Permissions Machine Check Errors Error Severities Exceptions and Interrupts Error Codes Extended Error Codes
	2.1.16 In bility, Avail Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3.1 3.1.1.3.2 3.1.2.1 3.1.2.2 3.1.2.2 3.1.2.2.1 3.1.2.2.2 3.1.2.2.3 3.1.2.2.4 3.1.2.3 3.1.3 M 3.1.3.1 3.1.3.2 3.1.3.1 3.1.3.2 3.1.3.4 3.1.3.5	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Machine Check Registers Global Registers Machine Check Banks Legacy MCA Registers Legacy MCA MSRs MCAX Registers MCAX MSRs Access Permissions Machine Check Errors Error Severities Exceptions and Interrupts Error Codes Extended Error Codes DOER and SEER State
	2.1.16 In bility, Avail Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3.1 3.1.1.3.2 3.1.2.1 3.1.2.2 3.1.2.2.1 3.1.2.2.2 3.1.2.2.3 3.1.2.2.4 3.1.2.3 3.1.3.1 3.1.3.1 3.1.3.1 3.1.3.2 3.1.3.1 3.1.3.2 3.1.3.4 3.1.3.5 3.1.3.6	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Machine Check Registers Global Registers Machine Check Banks Legacy MCA Registers Legacy MCA MSRs MCAX Registers MCAX MSRs Access Permissions Machine Check Errors Error Severities Exceptions and Interrupts Error Codes Extended Error Codes DOER and SEER State MCA Overflow Recovery
	2.1.16 In bility, Avail Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3.1 3.1.1.3.2 3.1.2.1 3.1.2.2 3.1.2.2.1 3.1.2.2.2 3.1.2.2.3 3.1.2.2.4 3.1.2.3 3.1.3.1 3.1.3.2 3.1.3.1 3.1.3.2 3.1.3.1 3.1.3.2 3.1.3.4 3.1.3.5 3.1.3.6 3.1.3.7	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Machine Check Registers Global Registers Machine Check Banks Legacy MCA Registers Legacy MCA MSRs MCAX Registers MCAX Registers MCAX MSRs Access Permissions Machine Check Errors Error Severities Exceptions and Interrupts Error Codes Extended Error Codes DOER and SEER State MCA Overflow Recovery MCA Recovery
	2.1.16 In bility, Avail Machine (3.1.1 C) 3.1.1.1 3.1.1.2 3.1.1.3.1 3.1.1.3.2 3.1.2.1 3.1.2.2 3.1.2.2.1 3.1.2.2.2 3.1.2.2.3 3.1.2.2.4 3.1.2.3 3.1.3.1 3.1.3.1 3.1.3.2 3.1.3.1 3.1.3.2 3.1.3.4 3.1.3.5 3.1.3.6 3.1.3.7	ability, and Serviceability (RAS) Features Check Architecture Overview Legacy Machine Check Architecture Machine Check Architecture Extensions Use of MCA Information Error Management Fault Management Machine Check Registers Global Registers Machine Check Banks Legacy MCA Registers Legacy MCA MSRs MCAX Registers MCAX MSRs Access Permissions Machine Check Errors Error Severities Exceptions and Interrupts Error Codes Extended Error Codes DOER and SEER State MCA Overflow Recovery

5

6

6.1.1

Definitions

5.4.2.1.1 5.4.2.1.2 5.4.2.2 5.4.2.2.1 SBI Phys	ACK/NAK Mechanism Bus Timeouts
5.4.2.1.1 5.4.2.1.2 5.4.2.2 5.4.2.2.1 SBI Phys	ACK/NAK Mechanism Bus Timeouts Error Recovery SBI Bus Reset sical Interface
5.4.2.1.1 5.4.2.1.2 5.4.2.2 5.4.2.2.1	ACK/NAK Mechanism Bus Timeouts Error Recovery SBI Bus Reset
5.4.2.1.1 5.4.2.1.2 5.4.2.2	ACK/NAK Mechanism Bus Timeouts Error Recovery
5.4.2.1.1 5.4.2.1.2	ACK/NAK Mechanism Bus Timeouts
5.4.2.1.1	ACK/NAK Mechanism
5.4.2.1	Error Detection
	SBI Error Detection and Recovery
	SBI Modified Block Write-Block Read Process Call
SBI Prot	
	Processor States
5.3.1.1	Physical Layer Characteristics
5.3.1	SBI Processor Pins
	cessor Information
	I2C Support
	SMBus Protocol Support
	Characteristics
	Definitions
	- · · · · · · · · · · · · · · · · · · ·
	orm Management Link (APML)
	Registers
	9
	L3 Cache CS
	IF
	LS
	MCA Banks
	Decoding Error Type
	Mapping of Banks to Blocks
	Implemented Machine Check Bank Registers
3.2.1	Implemented Machine Check Banks
	Check Architecture Implementation
3.1.5.7	Machine Check Error Handling
3.1.5.6	Recognizing Error Type
3.1.5.5	Determining Bank Type
3.1.5.4	Determining Bank Count
3.1.5.3	Machine Check Initialization
3.1.5.2	Communicating MCAX Support
3.1.5.1	Recognizing MCAX Support
3.1.5	Software Guidelines
	3.1.5.1 3.1.5.2 3.1.5.3 3.1.5.4 3.1.5.5 3.1.5.6 3.1.5.7 Machine 3.2.1 3.2.2 3.2.3 3.2.4 3.2.5 3.2.5.1 3.2.5.2 3.2.5.3 3.2.5.4 3.2.5.5 3.2.5.6 3.2.5.7 3.2.5.8 3.2.5.7 3.2.5.8 3.2.5.10 em Manage SMU Re Thermal 4.2.1 anced Platf Overview 5.1.1 SBI Bus 5.2.1 5.2.2 SBI Proc 5.3.1 5.3.1 5.3.2 SBI Proc 5.4.1

6.2	SB-TSI Protocol
0.2	20-12111000001

- 6.2.1 SB-TSI Send/Receive Byte Protocol
- 6.2.1.1 SB-TSI Address Pointer
- 6.2.2 SB-TSI Read/Write Byte Protocol
- 6.2.3 Alert Behavior
- 6.2.4 Atomic Read Mechanism
- 6.2.5 SB-TSI Temperature and Threshold Encodings
- 6.2.6 SB-TSI Temperature Offset Encoding
- 6.3 SB-TSI Physical Interface
  - 6.3.1 SB-TSI SMBus Address
  - 6.3.2 SB-TSI Bus Timing
  - 6.3.3 SB-TSI Bus Electrical Parameters
  - 6.3.4 Pass-FET Option
- 6.4 SB-TSI Registers

# **List of Figures**

Figure 1: Adobe® Reader Hyperlink Opens New Window Configuration Figure 2: Adobe® Reader Select Between Opened Files Adobe® Reader Show Toolbars Configuration Figure 3: Figure 4: Adobe® Reader Prev/Next Buttons Figure 5: Adobe® Reader Searching a Multiple Volume PPR Figure 6: Adobe® Reader Expand Current Bookmark Button Figure 7: Register Physical Mnemonic, Title, and Name Figure 8: Full Width Register Attributes Figure 9: Register Description Figure 10: Register Instance Table: Content Ordering in a Row

Figure 11: Register Instance Table: MSR Example

Figure 12: Register Instance Table: MSR Range Example
Figure 13: Register Instance Table: BAR as Register Reference
Figure 14: Register Instance Table: Bus Implied to be 00h
Figure 15: Register Instance Table: Data Port Select

Figure 16: Simple Register Field Example

Figure 17: Register Field Sub-Row for {Reset,AccessType,Init,Check}

Figure 18: Register Field Sub-Row for Description
Figure 19: Register Field Sub-Row for Valid Value Table
Figure 20: Register Field Sub-Row for Valid Bit Table

Figure 21: Register Sharing Domains Figure 22: Instance Parameters

Figure 23: SBI Transmission Protocol Figure 24: Pass FET Implementation

Figure 25: RTS Thermal Management Example Figure 26: SB-TSI Thermal Management Example

Figure 27: Alert Assertion Diagram
Figure 28: Pass FET Implementation

Table 50:

MCA STATUS FP

# **List of Tables**

Table 1: Reference Documents Listing Arithmetic and Logical Operator Definitions Table 2: Table 3: **Function Definitions** Table 4: Operator Precedence and Associativity Table 5: Register Mnemonic Definitions Table 6: Logical Mnemonic Definitions Table 7: Physical Mnemonic Definitions Table 8: AccessType Definitions Table 9: **Reset Type Definitions** Table 10: **Init Type Definitions Definitions** Table 11: Table 12: Package Definitions Table 13: PCI Device ID Assignments. Table 14: **Definitions** Table 15: SMM Initial State Table 16: SMM Save State Table 17: ICR Valid Combinations Table 18: **PMC** Definitions Table 19: Machine Check Terms and Acronyms Table 20: Legacy MCA MSR Layout MCAX MSR Layout Table 21: MCAX Implementation-Specific Register Layout Table 22: **Error Overwrite Priorities** Table 23: Table 24: Error Scope Hierarchy Table 25: Error Code Types Error code: transaction type (TT) Table 26: Error codes: cache level (LL) Table 27: Table 28: Error codes: memory transaction type (RRRR) Blocks Capable of Supporting MCA Banks Table 29: Mapping of Blocks to MCA\_IPID[HwId] and MCA\_IPID[McaType] Table 30: Table 31: Legacy MCA Registers MCAX Registers Table 32: Table 33: Core MCA Bank to Block Mapping Table 34: Non-core MCA Bank to Block Mapping Table 35: MCA STATUS LS Table 36: MCA ADDR LS Table 37: MCA\_SYND\_LS Table 38: MCA\_STATUS\_IF Table 39: MCA\_ADDR\_IF Table 40: MCA SYND IF MCA\_STATUS\_L2 Table 41: Table 42: MCA ADDR L2 MCA SYND L2 Table 43: Table 44: MCA STATUS DE Table 45: MCA ADDR DE MCA\_SYND\_DE Table 46: Table 47: MCA\_STATUS\_EX Table 48: MCA ADDR EX MCA SYND EX Table 49:

Table 51:	MCA_ADDR_FP
Table 52:	MCA_SYND_FP
Table 53:	MCA_STATUS_L3
Table 54:	MCA_ADDR_L3
Table 55:	MCA_SYND_L3
Table 56:	MCA_STATUS_CS
Table 57:	MCA_ADDR_CS
Table 58:	MCA_SYND_CS
Table 59:	MCA_STATUS_PIE
Table 60:	MCA_ADDR_PIE
Table 61:	MCA_SYND_PIE
Table 62:	MCA_STATUS_UMC
Table 63:	MCA_ADDR_UMC
Table 64:	MCA_SYND_UMC

Table 65: List of Acronyms and Terms used in Thermal (THM)

Table 66: APML Definitions
Table 67: SB-TSI Definitions

Table 68: SB-TSI CPU Temperature and Threshold Encoding Examples

Table 69: SB-TSI Temperature Offset Encoding Examples

Table 70: SB-TSI Address Encodings

#### 1 Overview

#### 1.1 Intended Audience

This document provides the processor behavioral definition and associated design notes. It is intended for platform designers and for programmers involved in the development of BIOS functions, drivers, and operating system kernel modules.

#### 1.2 Reference Documents

Table 1: Reference Documents Listing

Term	Description
docAPM1	AMD64 Architecture Programmer's Manual Volume 1: Application Programming, order# 24592.
docAPM2	AMD64 Architecture Programmer's Manual Volume 2: System Programming, order# 24593.
docAPM3	AMD64 Architecture Programmer's Manual Volume 3: Instruction-Set Reference, order# 24594.
docAPM4	AMD64 Architecture Programmer's Manual Volume 4: 128-Bit and 256-Bit Media Instructions,
	order# 26568.
docAPM5	AMD64 Architecture Programmer's Manual Volume 5: 64-Bit Media and x87 Floating-Point
	Instructions, order# 26569.
docACPI	Advanced Configuration and Power Interface (ACPI) Specification. <a href="http://www.acpi.info">http://www.acpi.info</a> .
docASF	Alert Standard Format Specification. <a href="http://dmtf.org/standards/asf">http://dmtf.org/standards/asf</a> .
docATA	AT Attachment with Packet Interface. <a href="http://www.t13.org">http://www.t13.org</a> .
docDP	VESA DisplayPort Standard. <a href="http://www.vesa.org/vesa-standards">http://www.vesa.org/vesa-standards</a> .
docIOMMU	AMD I/O Virtualization Technology Specification, order# 48882.
docI2C	I2C Bus Specification. <a href="http://www.nxp.com/documents/user_manual/UM10204.pdf">http://www.nxp.com/documents/user_manual/UM10204.pdf</a>
docJEDEC	JEDEC Standards. <a href="http://www.jedec.org">http://www.jedec.org</a> .
docPCIe	PCI Express® Specification. <a href="http://www.pcisig.org">http://www.pcisig.org</a> .
docPCIlb	PCI Local Bus Specification. <a href="http://www.pcisig.org">http://www.pcisig.org</a> .
docRevG	Revision Guide for AMD Family 17h Models 60h-6Fh Processors
docSATA	Serial ATA Specification. <a href="http://www.sata-io.org">http://www.sata-io.org</a> .
docSDHC	Secure Digital Host Controller Standard Specification. <a href="https://www.sdcard.org">https://www.sdcard.org</a> .
docAM4	Socket AM4 Processor Functional Data Sheet, order# 55509.
docSFP6	AMD FP6 Processor Functional Data Sheet, order# 56177.
docSMB	System Management Bus (SMBus) Specification. <a href="http://www.smbus.org">http://www.smbus.org</a> .
docUSB	Universal Serial Bus Specification. <a href="http://www.usb.org">http://www.usb.org</a> .

# 1.2.1 **Documentation Conventions**

When referencing information found in external documents listed in Reference Documents, the "=>" operator is used. This notation represents the item to be searched for in the reference document. For example:

docExDoc => Header1 => Header2

is to have the reader use the search facility when opening referenced document "docExDoc" and search for "Header2". "Header2" may appear more than once in "docExDoc", therefore, referencing the one that follows "Header1". In that case, the easiest way to get to Header2 is to use the search to locate Header1, then again to locate "Header2".

#### 1.3 Adobe® Reader

This section describes how to configure and use Adobe® Reader for the PPR PDFs.

Adobe Reader is the recommended tool for viewing PPR pdfs and can be downloaded at <a href="https://get.adobe.com/reader/">https://get.adobe.com/reader/</a>.

# 1.3.1 Adobe® Reader Configuration

This section describes how to configure Adobe Reader for the PPR PDFs.

# 1.3.1.1 Open Hyperlink Document in New Window

The Open Hyperlink Document in New Window setting opens a new window for a hyperlink, instead of opening the hyperlink document in the same window.

• Only when deselected are previously opened files visible in the Windows® pull-down menu.

#### Edit->Preferences:

- Documents
  - Open Settings:
    - Deselect: Open cross-document links in same window




Figure 1: Adobe® Reader Hyperlink Opens New Window Configuration

Figure 2 shows how when hyperlinking from volume 2 to volume 1, that volume 2 is left open. The check indicates the foreground window.




Figure 2: Adobe® Reader Select Between Opened Files

#### 1.3.1.2 Show Toolbars

If Toolbars is not shown:

- View->Show/Hide->Toolbar Items->Show Toolbars
- The toolbar is needed to see the "Previous View" and "Next View" buttons.



Figure 3: Adobe® Reader Show Toolbars Configuration

# 1.3.1.3 Show "Previous View" and "Next View" Buttons

If the "Previous View" (left arrow) and "Next View" (right arrow) buttons are not shown:

• Right click on toolbar-> Page Navigation-> select "Previous View" and "Next View" items.



Figure 4: Adobe® Reader Prev/Next Buttons

# 1.3.2 Adobe® Reader Usage

This section describes how to use Adobe Reader for the PPR PDFs.

NOTE: PDF's are distributed in zip format. In order to search and hyperlink between PDF volumes, the zip contents must be extracted to a folder.

### 1.3.2.1 Searching a Multiple Volume PPR

The PPR is a multiple PDF document and searching all PDFs is performed as follows:

- The zip of PDF files must be extracted to a directory where the search will be performed. A sesarch across multiple PDF files can not be performed from within a zip of PDF's.
- Open search by selecting Edit -> Advanced Search (Shift+Ctrl+F)
- Select "All PDF Documents in" and select "Browse for Location...", which opens the "Browse For Folder" window.
- In the "Browse For Folder" window, select the folder that contains the PPR PDFs that need to be searched, and select OK.




Figure 5: Adobe® Reader Searching a Multiple Volume PPR

# 1.3.2.2 Cross-References and Hyperlinks

A cross-reference is a link to a location within the same PDF. A hyperlink is a link to a location within a different PDF.

- For cross-references, use "Previous View" to return from the current location to the previous location.
- Hyperlinks between documents leave the current location unchanged in the PDF that contained the hyperlink.
- In order for hyperlinks to work properly the zip of PDF's must be extracted to a directory. Hyperlinks will not function within a zip of PDF's.

#### 1.3.2.3 Expand Current Bookmark

The bookmark pane can highlight the current bookmark associated with the viewer pane by selecting the "expand current bookmark" button, as shown below.




Figure 6: Adobe® Reader Expand Current Bookmark Button

#### 1.4 Conventions

# 1.4.1 Numbering

- Binary numbers: Binary numbers are indicated either by appending a "b" at the end (e.g., 0110b) or by verilog syntax (e.g., 4'b0110).
- Hexadecimal numbers: Hexadecimal numbers are indicated by appending an "h" to the end (e.g., 45F8h) or by verilog syntax (e.g., 16'h45F8).
- Decimal numbers: A number is decimal if not specified to be binary or hex.
- Exception: Physical register mnemonics are implied to be hex without the h suffix.
- Underscores in numbers: Underscores are used to break up numbers to make them more readable. They do not imply any operation (e.g., 0110\_1100).

#### 1.4.2 Arithmetic And Logical Operators

In this document, formulas generally follow Verilog conventions for logic equations.

Table 2: Arithmetic and Logical Operator Definitions

Operator	Definition
{}	Concatenation. Curly brackets are used to indicate a group of bits that are concatenated together.
	Each set of bits is separated by a comma (e.g., {Addr[3:2], Xlate[3:0]} represents a 6-bit values;
	the two MSBs are Addr[3:2] and the four LSBs are Xlate[3:0]).
	Bitwise OR (e.g., 01b   10b == 11b).
	Logical OR (e.g., 01b    10b == 1b). It treats a multi-bit operand as 1 if >= 1 and produces a 1-bit
	result.
&	Bitwise AND (e.g., 01b & 10b == 00b).
&&	Logical AND (e.g., 01b && 10b == 1b). It treats a multi-bit operand as 1 if >= 1 and produces a 1-
	bit result.

٨	Bitwise exclusive-OR (e.g., $01b \land 10b == 11b$ ). Sometimes used as "raised to the power of" as well, as indicated by the context in which it is used (e.g., $2^2 == 4$ ).		
~	Bitwise NOT (also known as one's complement). (e.g., ~10b == 01b).		
!	Logical NOT (e.g., !10b == 0b). It treats a multi-bit operand as 1 if >= 1 and produces a 1-bit result.		
<, <=, >,	Relational. Less than, Less than or equal, greater, greater than or equal, equal, and not		
>=, ==, !=	equal.		
+, -, *, /, %	Arithmetic. Addition, subtraction, multiplication, division, and modulus.		
<<	Bitwise left shift. Shift left first operand by the number of bits specified by the 2nd operand (e.g., 01b << 01b == 10b).		
>>	Bitwise right shift. Shift right first operand by the number of bits specified by the 2nd operand (e.g., 10b >> 01b == 01b).		
?:	Ternary conditional (e.g., condition? value if true: value if false).		

*Table 3: Function Definitions* 

Term	Description	
ABS	ABS(integer expression): Remove sign from signed value.	
FLOOR	FLOOR(integer expression): Rounds real number down to nearest integer.	
CEIL	CEIL(real expression): Rounds real number up to nearest integer.	
MIN	MIN(integer expression list): Picks minimum integer or real value of comma separated list.	
MAX	MAX(integer expression list): Picks maximum integer or real value of comma separated list.	
COUNT	COUNT(integer expression): Returns the number of binary 1's in the integer.	
ROUND	ROUND(real expression): Rounds to the nearest integer; halfway rounds away from zero.	
UNIT	UNIT(register field reference): Input operand is a register field reference that contains a valid values table	
	that defines a value with a unit (e.g., clocks, ns, ms, etc). This function takes the value in the register field	
	and returns the value associated with the unit (e.g., If the field had a valid value definition where 1010b was	
	defined as 5 ns). Then if the field had the value of 1010b, then UNIT() would return the value 5.	
POW	POW(base, exponent): POW(x,y) returns the value x to the power of y.	

# 1.4.2.1 Operator Precedence and Associativity

This document follows C operator precedence and associativity. The following table lists operator precedence (highest to lowest). Their associativity indicates in what order operators of equal precedence in an expression are applied. Parentheses are also used to group subexpressions to force a different precedence; such parenthetical expressions can be nested and are evaluated from inner to outer (e.g., " $X = A \parallel B \& C$ " is the same as " $X = A \parallel (B \& C)$ ").

Table 4: Operator Precedence and Associativity

Operator	Description	Associativity
!, ~	Logical negation/bitwise complement	right to left
*, /, %	Multiplication/division/modulus	left to right
+, -	Addition/subtraction	left to right
<<,>>>	Bitwise shift left, Bitwise shift right	left to right
< , <=, >,	Relational operators	left to right
>=, ==, !=		
&	Bitwise AND	left to right
٨	Bitwise exclusive OR	left to right
	Bitwise inclusive OR	left to right
&&	Logical AND	left to right

	Logical OR	left to right
?:	Ternary conditional	right to left

# 1.4.3 Register Mnemonics

A register mnemonic is a short name that uniquely refers to a register, either all instances of that register, some instances, or a single instance.

Every register instance can be expressed in 2 forms, logical and physical, as defined below.

*Table 5: Register Mnemonic Definitions* 

Term	Description	
logical mnemonic	The register mnemonic format that describes the register functionally, what namespace to	
	which the register belongs, a name for the register that connotes its function, and optionally,	
	named parameters that indicate the different function of each instance (e.g.,	
	Link::Phy::PciDevVendIDF3). See 1.4.3.1 [Logical Mnemonic].	
physical mnemonic	vsical mnemonic The register mnemonic that is formed based on the physical address used to access the	
	register (e.g., D18F3x00). See 1.4.3.2 [Physical Mnemonic].	

#### 1.4.3.1 Logical Mnemonic

The logical mnemonic format consists of a register namespace, a register name, and optionally a register instance specifier (e.g., register namespace::register name register instance specifier).

For Unb::PciDevVendIDF3:

- The register namespace is Unb, which is the UNB IP register namespace.
- The register name is PciDevVendIDF3, which reads as PCICFG device and vendor ID in Function 3.
- There is no register instance specifier because there is just a single instance of this register.

For Dct::Phy::CalMisc2\_dct[1:0]\_chiplet[BCST,3:0]\_pad[BCST,11:0]:

- The register namespace is Dct::Phy, which is the DCT PHY register namespace.
- The register name is CalMisc2, which reads as miscellaneous calibration register 2.
- The register instance specifier is \_dct[1:0]\_chiplet[BCST,3:0]\_pad[BCST,11:0], which indicates that there are 2 DCTPHY instances, each IP for this register has 5 chiplets (0-3 and BCST), and for each chiplet 13 pads (0-11 and BCST). This register has 130 instances. (2\*5\*13)

*Table 6: Logical Mnemonic Definitions* 

Term	Description	
register namespace	A namespace for which the register name must be unique. A register namespace	
	indicates to which IP it belongs and an IP may have multiple namespaces. A	
	namespace is a string that supports a list of "::" separated names. The convention is	
	for the list of names to be hierarchical, with the most significant name first and the	
	least significant name last (e.g., Link::Phy::Rx is the RX component in the Link	
	PHY).	
register name	A name that cannotes the function of the register.	
register instance specifier	The register instance specifier exists when there is more than one instance for a	
	register. The register instance specifier consists of one or more register instance	
	parameter specifier (e.g., The register instance specifier	
	_dct[1:0]_chiplet[BCST,3:0]_pad[BCST,11:0] consists of 3 register instance	
	parameter specifiers, _dct[1:0], _chiplet[BCST,3:0], and _pad[BCST,11:0]).	

register instance parameter	A register instance parameter specifier is of the form _register parameter	
specifier	name[register parameter value list] (e.g., The register instance parameter specifier	
	_dct[1:0] has a register parameter name of dct (The DCT PHY instance name) and	
	a register parameter value list of "1:0" or 2 instances of DCT PHY).	
register parameter name	A register parameter name is the name of the number of instances at some level of	
	the logical hierarchy (e.g., The register parameter name dct specifies how many	
	instances of the DCT PHY exist).	
register parameter value list	The register parameter value list is the logical name for each instance of the	
	register parameter name (e.g., For _dct[1:0], there are 2 DCT PHY instances, with	
	the logical names 0 and 1, but it should be noted that the logical names 0 and 1 can	
	correspond to physical values other than 0 and 1). It is the purpose of the	
	AddressMappingTable to map these register parameter values to physical address	
	values for the register.	

# 1.4.3.2 Physical Mnemonic

The physical register mnemonic format varies by the access method. The following table describes the supported physical register mnemonic formats.

*Table 7: Physical Mnemonic Definitions* 

Term	Description	
PCICFG	The PCICFG, or PCI defined configuration space, physical register mnemonic format	
	is of the form DXFYxZZZ.	
BAR	The BAR, or base address register, physical register mnemonic format is of the form	
	PREFIXxZZZ.	
MSR	The MSR, or x86 model specific register, physical register mnemonic format is of the	
	form MSRXXXX_XXXX, where XXXX_XXXX is the hexadecimal MSR number.	
	This space is accessed through x86 defined RDMSR and WRMSR instructions.	
PMC	The PMC, or x86 performance monitor counter, physical register mnemonic format is	
	any of the forms {PMCxXXX, L2IPMCxXXX, NBPMCxXXX}, where XXX is the	
	performance monitor select.	
CPUID	The CPUID, or x86 processor identification state, physical register mnemonic format	
	is of the form CPUID FnXXXX_XXXX_EiX[_xYYY], where XXXX_XXXX is the	
	hex value in the EAX and YYY is the hex value in ECX.	

# 1.4.4 Register Format

A register is a group of register instances that have the same field format (same bit indices and field names).

# 1.4.4.1 A Register is a group of Register Instances

All instances of a register:

- Have the same:
  - Field bit indices and names
  - Field titles, descriptions, valid values.
  - Register title
  - Register description
- Fields may have different: (instance specific)
  - Access Type. See 1.4.4.10 [Field Access Type].
  - Reset. See 1.4.4.11 [Field Reset].

- Init. See 1.4.4.12 [Field Initialization].
- Check. See 1.4.4.13 [Field Check].

# 1.4.4.2 Register Physical Mnemonic, Title, and Name

A register definition is identified by a table that starts with a heavy bold line. The information above the bold line in order is:

- 1. The physical mnemonic of the register.
  - A register that has multiple instances, may have instances that have different access methods, each with it's own physical mnemonic format.
  - In the event that there are multiple physical mnemonic formats, the physical mnemonic format chosen is the most commonly used physical mnemonic.
  - The physical mnemonic is not intended to represent the physical mnemonics of all instances of the register. It is only a visual aid to identify a register when scanning down a list, for readers that prefer to find registers by physical mnemonic. If "..." occurs in the physical mnemonic, the range is first ... last. There is no implication as to how many instances exist between first and last. See 1.4.4.5 [Register Instance Table].
- 2. The register title in brackets.
- 3. The register name in parenthesis.

Physical Mn	nemonic Title Name
MSR000	00_0010[Time Stamp Counter] (TSC)
Read-wr	ite,Volatile. Reset: 0000_0000_0000_0000h.
Core::X86::	Msr::TSC_lthree[1:0]_core[3:0]_thread[1:0]; MSR00000010
Bits	Description
63:0	TSC: time stamp counter. Read-write, Volatile. Reset: 0. The TSC increments at the P0 frequency. The TSC counts at the same rate in all P-states, all C states, S0, or S1. A read of this MSR in guest mode is affected by Core::X86::Msr::TscRateMsr. The value (TSC/TSCRatio) is the TSC P0 frequency based
	value (as if TSCRatio == 1.0) when (TSCRatio != 1.0).

*Figure 7: Register Physical Mnemonic, Title, and Name* 

#### 1.4.4.3 Full Width Register Attributes

The first line that follows the bold line contains the attributes that apply to all fields of the register. This row is rendered as a convenience to the reader and replicates content that exists in the register field.

- AccessType: If all non-reserved fields of a register have the same access type, then the access type is rendered in this row.
  - The supported access types are specified by 1.4.4.10 [Field Access Type].
  - The example figure shows that the access type "Read-write, Volatile" applies to all non-reserved fields of the register.
- Reset: If all non-reserved fields of a register have a constant reset and are all the same type (Warm, Cold, Fixed), then the full width register reset is rendered in this row. The example figure shows the reset "0000\_0000\_0000\_0000h". See 1.4.4.11 [Field Reset].
  - The value zero (0) is assumed for display purposes for all reserved fields.
- If none of the above content is rendered, then this row of the register is not rendered.

MSR000	ASR0000_0010 [Time Stamp Counter] (TSC)		
Read-write, Volatile. Reset: 0000_0000_0000_0000h.			
Core::X86::N	Msr::TSC_lthree[1:0]_core[3:0]_thread[1:0]; MSR00000010		
Bits	Description		
63:0	<b>TSC</b> : <b>time stamp counter</b> . Read-write, Volatile. Reset: 0. The TSC increments at the P0 frequency. The		
	TSC counts at the same rate in all P-states, all C states, S0, or S1. A read of this MSR in guest mode is		
	affected by Core::X86::Msr::TscRateMsr. The value (TSC/TSCRatio) is the TSC P0 frequency based		

Figure 8: Full Width Register Attributes

value (as if TSCRatio == 1.0) when (TSCRatio != 1.0).

#### 1.4.4.4 Register Description

The register description is optional and appears after the "full width register attributes" row and before the "register instance table" rows. The register description can be one or more paragraphs.

Temet vention 15   Device, vention in	PciDevVendIDF3 [Devi	ce/Vendor II	1
---------------------------------------	----------------------	--------------	---

Read-onl	y. Reset: 0000_1022h.	
A register	r description.	
That can	be multiple paragraphs.	
Link::Phy::T	x::PciDevVendIDF3; D18F3x00	
Bits	Description	
31:16	DeviceID: device ID. Read-only. Reset: Fixed,0000h.	
15:0	VendorID: vendor ID. Read-only. Reset: Fixed,1022h. Init: 1234h.	

Figure 9: Register Description

#### 1.4.4.5 Register Instance Table

The zero or more rows of 8-pt font before the Bits/Description row is the register instance table.

The register instance table can generally be described as follows:

- Each row describes the access method of one or more register instances.
- If a row describes two or more instances, then the logical instance range, left to right, corresponds to the physical range, left to right.
- The absence of register instance rows indicates that the register exists for documentation purposes, and no access method is described for the register.

Because there are multiple access methods for all the registers, each of the following subsections describes an aspect of the register instance table in isolation.

#### 1.4.4.5.1 Content Ordering in a Row

Content in a register instance table row is ordered as follows:

- The text up to the first semicolon is the logical mnemonic.
  - See 1.4.3.1 [Logical Mnemonic].
- The text after the first semicolon is the physical mnemonic.
  - See 1.4.3.2 [Physical Mnemonic].

• Optionally, content after the physical mnemonic provides additional information about the access method for the register instances in the row.

# BXXD00F0x000 (NB\_VENDOR\_ID)

Read-only. Reset: 1022h.
Vendor ID Register
IOHC::NB_VENDOR_ID_aliasHOS[T; BXXD00F0x00 <mark>0; BXX=IOHC::NB_BUS_NUM_CNTL_aliasSMN[NB_BUS_NUM]</mark>
IOHC::NB_VENDOR_ID_aliasSMN; NBCFGx00000000; NBCFG=13B0_0000h

Figure 10: Register Instance Table: Content Ordering in a Row

# 1.4.4.5.2 Multiple Instances Per Row

Multiple instances in a row is represented by a single dimension "range" in the logical mnemonic and the physical mnemonic.

The single dimension order of instances is the same for both the logical and physical mnemonic. The first logical mnemonic is associated with the first physical mnemonic, so forth for the 2nd, up until the last.

- Brackets indicates a list, most significant to least significant.
- The ":" character indicates a continuous range between 2 values.
- The "," character separates non-contiguous values.
- There are some cases where more than one logical mnemonic maps to a single physical mnemonic.

Note that it is implied that the MSR {lthree,core,thread} parameters are not part of a range.

#### Example:

NAMESP::REGNAME inst[BLOCK[5:0],BCST] aliasHOST; FFF1x00000088 x[000[B:6] 0001,00000000]

- There are 7 instances.
- NAMESP is the namespace.
- 6 instances are represented by the sub-range 000[B:6] 0001.
- \_instBCST corresponds to FFF1x00000088\_x00000000.
- \_inst BLOCK 0 corresponds to FFF1x00000088\_x00060001.
- .
- \_inst BLOCK 5 corresponds to FFF1x00000088\_x000B0001.

#### 1.4.4.5.3 MSR Access Method

The MSR parameters {lthree,core,thread} are implied by the identity of the core on which the RDMSR/WRMSR is being executed, and therefore are not represented in the physical mnemonic.

#### MSRs that are:

- per-thread have the {lthree,core,thread} parameters.
- per-core do not have the thread parameter.
- per-L3 do not have the {core,thread} parameters.
- common to all L3's do not have the {lthree,core,thread} parameters.

#### 1.4.4.5.3.1 MSR Per-Thread Example

An MSR that is per-thread has all three {lthree,core,thread} parameters and all instances have the same physical mnemonic.

	$MSR0000_{-}$	0010 [Time	Stamp (	Counter] (	(TSC)
--	---------------	------------	---------	------------	-------

Read-wri	ite,Volatile. Reset: 0000_0000_0000_0000h.
Core::X86::N	Msr::TSC_lthree[1:0]_core[3:0]_thread[1:0];[MSR00000010]
Bits	Description
63:0	TSC: time stamp counter. Read-write, Volatile. Reset: 0. The TSC increments at the P0 frequency. The
	TSC counts at the same rate in all P-states, all C states, S0, or S1. A read of this MSR in guest mode is
	affected by Core::X86::Msr::TscRateMsr. The value (TSC/TSCRatio) is the TSC P0 frequency based
	value (as if TSCRatio == 1.0) when (TSCRatio != 1.0).

Figure 11: Register Instance Table: MSR Example

#### 1.4.4.5.3.2 MSR Range Example

An MSR can exist as a range for a parameter other than the {lthree,core,thread} parameters.

In the following example the n parameter is a range. The \_n0 value corresponds to MSR0000\_0201, and so on.

# MSR0000\_0201 [Variable-Size MTRRs Mask] (MtrrVarMask)

Reset: 0000_0000_0000_0000h.	
Core::X86::Msr::MtrrVarMask_n[7:0]_lthree[1:0]_core[3:0]; MSR0000_020[[F,D,B,9,7,5,3,1]]	

Figure 12: Register Instance Table: MSR Range Example

#### 1.4.4.5.4 BAR Access Method

The BAR access method is indicated by a physical mnemonic that has the form PREFIXxNUMBER.

• Example: APICx0000. The BAR prefix is "APIC".

The BAR prefix represents either a constant or an expression that consists of a register reference.

#### 1.4.4.5.4.1 BAR as a Register Reference

A relocatable BAR is when the base of an IP is not a constant.

• The prefix NTBPRIBAR0 represents the base of the IP, the value of which comes from the register NBIFEPFNCFG::BASE ADDR 1 aliasHOST instNBIF0 func1[BASE ADDR].

#### NTBPRIBAR0x00000 (NTB\_SMU\_PCTRL0)

Reset: 0000_0000h.
NTB::NTB_SMU_PCTRL0_aliasHOSTPRI_NTBPRIBAR0x00000;
NTBPRIBARO-NBIFEPFNCFG::BASE_ADDR_1_aliasHOST_instNBIF0_func1[BASE_ADDR]
NTB::NTB_SMU_PCTRL0_aliasHOSTSEC; NTBSECBAR0x100000; NTBSECBAR0=NBIFEPFNCFG::BASE ADDR 1 aliasHOST instNBIF2 func1[BASE ADDR]
NTB::NTB_SMU_PCTRL0_aliasSMN; NTBx00000000; NTB=0400_0000h

Figure 13: Register Instance Table: BAR as Register Reference

# 1.4.4.5.5 PCICFG Access Method

The PCICFG access method is indicated by a physical mnemonic that has the form DXXFXxNUMBER. There are 2 cases:

- Bus omitted and implied to be 00h.
- Bus represented as BXX and indicates that the bus is indicated by a register field.

#### Example:

- Example: D18F0x000. (The bus, when omitted, is implied to be 00h)
- Example: BXXD0F0x000. (The bus as an expression that includes a register reference)

### 1.4.4.5.5.1 PCICFG Bus Implied to be 00h

#### Example:

• The absence of a B before the D14 implies that the bus is 0.

FCH::ITF::LPC::PciDevVendID\_aliasHOST; D14F3x000

Figure 14: Register Instance Table: Bus Implied to be 00h

#### 1.4.4.5.6 Data Port Access Method

A data port requires that the data port select be written before the register is accessed via the data port.

### Example:

- The data port select value follows the "\_x".
- The data port select register follows the "DataPortWrite=".

```
DF::FabricBlockInstanceCount_inst[PIE0,BCST]_aliasHOST; D18F0x040_x[00050001,00000000]; DataPortWrite=DF::FabricConfigAccessControl
DF::FabricBlockInstanceCount_inst[PIE0,BCST]_aliasSMN; DFF0x000000040_x[00050001,00000000]; DFF0=0001_C000h;
DataPortWrite=DF::FabricConfigAccessControl
```

Figure 15: Register Instance Table: Data Port Select

#### 1.4.4.6 Register Field Format

The register field definition are all rows that follow the Bits/Description row. Each field row represents the definition of a bit range, with the bit ranges ordered from most to least significant. There are 2 columns, with the left column defining the field bit range, and the right column containing the field definition.

There are 2 field definition formats, simple and complex. If the description can be described in the simple one paragraph format then the simple format is used, else the complex format is used.

# 1.4.4.7 Simple Register Field Format

The simple register format compresses all content into a single paragraph with the following implied order:

- 1. Field name (required)
  - Allowed to be Reserved. See 1.4.4.9 [Field Name is Reserved].
  - "FFXSE" in the example figure.
- 2. Field title
  - "fast FXSAVE/FRSTOR enable" in the example figure.
- 3. Field Access Type. See 1.4.4.10 [Field Access Type].
  - In the example figure the access type is "Read-write".

- 4. Field Reset. See 1.4.4.11 [Field Reset].
  - In the example figure the reset is warm reset and "0".
- 5. Field Init. See 1.4.4.12 [Field Initialization].
- 6. Field Check. See 1.4.4.13 [Field Check].
- 7. Field Valid Values, if the valid values are single bit (e.g., 0=, 1=). See 1.4.4.14 [Field Valid Values].
  - In the example figure the 1= definition begins with "Enables" and ends with "mechanism".
  - In the example figure there is no 0= definition.
- 8. Field description, if it is a single paragraph.
  - In the example figure the field description begins with "This is" and ends with "afterwards".

All fields that don't exist are omitted.

14 FFXSE fast FXSAVE/FRSTOR enable Read-write Reset: 0 1=Enables the fast FXSAVE/FRSTOR mechanism. A 64-bit operating system may enable the fast FXSAVE/FRSTOR mechanism if (Core::X86::Cpuid::FeatureExtIdEdx[FFXSR] == 1). This bit is set once by the operating system and its value is not changed afterwards.

Figure 16: Simple Register Field Example

#### 1.4.4.8 Complex Register Field Format

Content that can't be expressed in the single paragraph format is broken out to a separate sub-row (a definition column row).

Additional sub-rows are added in the following order:

- 1. Complex expression for {Reset,AccessType,Init,Check}.
- 2. Instance specific {Reset,AccessType,Init,Check} values.
- 3. Description, if more than 1 paragraph.
- 4. Valid values, if more than 0=/1=. Or a Valid bit table. (see figure)

The following figure highlights a complex access type specification.

63:0 APerfReadOnly: read-only actual core clocks counter. Reset: 0. This register increments in proportion to the actual number of core clocks cycles while the core is in C0. See Core::X86::Msr::MPerfReadOnly. This register is not affected by writes to Core::X86::Msr::APERF.

AccessType: Core::X86::Msr::HWCR[EffFreqReadOnlyLock]? Read-only,Volatile: Readwrite,Volatile.

Figure 17: Register Field Sub-Row for {Reset,AccessType,Init,Check}

The following figure highlights a complex description specification.

4 INVDWBINVD: INVD to WBINVD conversion. Read-write. Reset: 1. Check: 1. 1=Convert INVD to WBINVD.

**Description**: This bit is required to be set for normal operation when any of the following are true:

- · An L2 is shared by multiple threads.
- · An L3 is shared by multiple cores.
- CC6 is enabled.
- Probe filter is enabled.

Figure 18: Register Field Sub-Row for Description

The following figure highlights a complex valid value table, used either when the field is more than 1 bit or when the definition is more than a single sentence.

2:1	CpuWdtTimeBase: CPU watchdog timer time base. Read-write. Reset: 0. Specifies the time base for the timeout period specified in CpuWdtCountSel.					
	ValidValues:					
	Value Description					
	00b 1.31ms					
	01b 1.28us 10b Reserved (5ns)					
	11b	Reserved				

Figure 19: Register Field Sub-Row for Valid Value Table

The following figure highlights a valid bit table which is used when each bit has a specific function.

	<u> </u>				
55:52	Reserved.				
51:48	SliceMask. Read-write. Reset: 0.				
1	ValidValues:				
	Bit Description				
	[0] L3 Slice 0 mask.				
[1] L3 Slice 1 mask.		L3 Slice 1 mask.			
	[2]	L3 Slice 2 mask.			
	[3]	L3 Slice 3 mask.			

Figure 20: Register Field Sub-Row for Valid Bit Table

#### 1.4.4.9 Field Name is Reserved

When a register field name is Reserved, and it does not explicitly specify an access type, then the implied access type is "Reserved-write-as-read".

- The Reserved-write-as-read access type is:
  - Reads must not depend on the read value.
  - Writes must only write the value that was read.

# 1.4.4.10 Field Access Type

The AccessType keyword is optional and specifies the access type for a register field. The access type for a field is a comma separated list of the following access types.

*Table 8: AccessType Definitions* 

Term	Description			
Read-only	Readable; writes are ignored.			
Read-write	Readable and writable.			
Read	Readable; must be associated with one of the following {Write-once, Write-1-only, Write-1-to-			
	clear, Error-on-write}.			
Write-once	Capable of being written once; all subsequent writes have no effect. If not associated with Read,			

	then reads are undefined.					
Write-only	Writable. Reads are undefined.					
Write-1-only	Writing a 1 sets to a 1; Writing a 0 has no effect. If not associated with Read, then reads are undefined.					
Write-1-to-clear	Writing a 1 clears to a 0; Writing a 0 has no effect. If not associated with Read, then reads are undefined.					
Write-0-only	Writing a 0 clears to a 0; Writing a 1 has no effect. If not associated with Read, then reads are undefined.					
Error-on-read	Error occurs on read.					
Error-on-write	Error occurs on write.					
Error-on-write-0	Error occurs on bitwise write of 0.					
Error-on-write-1	Error occurs on bitwise write of 1.					
Inaccessible	Not readable or writable (e.g., Hide? Inaccessible: Read-Write).					
Configurable	Indicates that the access type is configurable as described by the documentation.					
Unpredictable	The behavior of both reads and writes is unpredictable.					
Reserved-write-	Reads are undefined. Must always write 1.					
as-1						
Reserved-write-	Reads are undefined. Must always write 0.					
as-0						
Volatile	Indicates that a register field value may be modified by hardware, firmware, or microcode when fetching the first instruction and/or might have read or write side effects. No read may depend on the results of a previous read and no write may be omitted based on the value of a previous read or write.					

# 1.4.4.10.1 Conditional Access Type Expression

The ternary operator can be used to express an access type that is conditional on an expression that can contain any of the following:

- A register field value
- A constant
- · A definition

#### **1.4.4.11** Field Reset

The Reset keyword is optional and specifies the value for a register field at the time that hardware exits reset, before firmware initialization initiates.

Unless preceded by one of the following prefixes, the reset value is called warm reset and the value is applied at both warm and cold reset.

*Table 9: Reset Type Definitions* 

Type	Description			
Cold	Cold reset. The value is applied only at cold reset.			
Fixed	The value applies at all time.			

#### 1.4.4.12 Field Initialization

The Init keyword is optional and specifies an initialization recommendation for a register field.

If present, then there is an optional prefix that specifies the owner of the initialization. See Table 10 [Init Type Definitions].

• Example: Init: BIOS,2'b00. //A initialization recommendation for a field to be programmed by BIOS.

*Table 10: Init Type Definitions* 

Type	Description			
BIOS	Initialized by AMD provided AMD Generic Encapsulated Software Architecture (AGESA™)			
	x86 software.			
SBIOS	Initialized by OEM or IBV provided x86 software, also called Platform BIOS.			
OS	Initialized by OS or Driver.			

#### 1.4.4.13 Field Check

The Check keyword is optional and specifies the value that is recommended for firmware/software to write for a register field. It is a recommendation, not a requirement, and may not under all circumstances be what software programs.

# 1.4.4.14 Field Valid Values

A register can optionally have either a valid values table or a valid bit table:

- A valid values table specifies the definition for specific field values.
- A valid bit table specifies the definition for specific field bits.

#### 1.5 Definitions

Table 11: Definitions

Table 11. Definitions						
Term	Description					
AGESA™	AMD Generic Encapsulated Software Architecture.					
APP	Accelerated Processor Platform.					
APU	Accelerated Processing Unit.					
APML	Advanced Platform Management Link.					
BatteryPower	The system is running from a limited energy or battery power source or otherwise undocked from					
	a continuous power supply. Setting using this definition may be required to change during run					
	time.					
BCD	Binary Coded Decimal number format.					
BCS	Base Configuration Space.					
BIST	Built-In Self-Test. Hardware within the processor that generates test patterns and verifies t					
	they are stored correctly (in the case of memories) or received without error (in the case of links).					
Boot VID	Boot Voltage ID. This is the VDD and VDDNB voltage level that the processor requests from the					
	external voltage regulator during the initial phase of the cold boot sequence.					
C-states	These are ACPI defined core power states. C0 is operational. All other C-states are low-power					
	states in which the processor is not executing code. See docACPI.					
COF	Current operating frequency of a given clock domain.					
Cold reset	PWROK is de-asserted and RESET_L is asserted.					
DID	Divisor Identifier. Specifies the post-PLL divisor used to reduce the COF.					
Doubleword	A 32-bit value.					
DW	Doubleword.					
ECS	Extended Configuration Space.					
EDC	Electrical design current. Indicates the maximum current the voltage rail can demand for a short,					

	thermally insignificant time.						
ECH	The integrated platform subsystem that contains the IO interfaces and bridges them to the system						
FCH	BIOS. Previously included in the Southbridge.						
FDS	Functional Data Sheet. There is one FDS for each package type. See docAM4 or docSFP6.  Frequency Identifier. Specifies the PLL frequency multiplier for a given clock domain.						
FID	Frequency Identifier. Specifies the PLL frequency multiplier for a given clock domain.  An internal free running timer used by many power management features.						
FreeRunSampleTim	An internal free running timer used by many power management features.						
er							
GB	Gbyte or Gigabyte; 1,073,741,824 bytes.						
GT/s	Giga-Transfers per second. Hardware Thermal Control.						
HTC	Ü i						
HTC-active state	Hardware-controlled lower-power, lower performance state used to reduce temperature.						
IFCM	Isochronous flow-control mode, as defined in the link specification.						
IO configuration	Access to configuration space though IO ports CF8h and CFCh.						
IP	In electronic design, a semiconductor Intellectual Property, IP, or IP block is a reusable unit of						
	logic, cell, or integrated circuit layout design that is the intellectual property of one party.						
KB	Kbyte or Kilobyte; 1024 bytes.						
Master abort	This is a PCI-defined term that is applied to transactions on other than PCI buses. It indicates that						
	the transaction is terminated without affecting the intended target; reads return all 1s; write are						
	discarded; the master abort error code is returned in the response, if applicable; master abort error						
MB	bits are set if applicable.						
MMIO	Megabyte; 1024 KB.  Memory Manned Input Output range. This is physical address space that is manned to the IO.						
IVIIVIIO	Memory-Mapped Input-Output range. This is physical address space that is mapped to the IC functions such as the IO links or MMIO configuration.						
MMIO	Access to configuration space through memory space.						
configuration							
Node	A node, is an integrated circuit device that includes one to 8 cores (one or two Core Complexes).						
OW	Octword. An 128-bit value.						
Processor	A package containing one or more Nodes. See Node.						
QW	Quadword. A 64-bit value.						
RX	Receiver.						
REFCLK	Reference clock. Refers to the clock frequency (100 MHz) or the clock period (10 ns) depending						
Chutdar	on the context used.						
Shutdown	A state in which the affected core waits for either INIT, RESET, or NMI. When shutdown state is entered, a shutdown special cycle is sent on the IO links.						
SMAF	System Management Action Field. This is the code passed from the SMC to the processors in						
	STPCLK assertion messages.						
SMC	System Management Controller. This is the platform device that communicates system						
	management state information to the processor through an IO link, typically the system IO hub.						
Speculative event	A performance monitor event counter that counts all occurrences of the event even if the event						
	occurs during speculative code execution.						
TDC	Thermal Design Current.						
TDP	Thermal Design Power. A power consumption parameter that is used in conjunction with thermal						
	specifications to design appropriate cooling solutions for the processor.						
Token	A scheduler entry used in various DF queues to track outstanding requests.						
TOM	Top of Memory.						
TOM2	Top of extended Memory.						
TX	Transmitter.						
UMI	Unified Media Interface. The link between the processor and the FCH.						
VDD	Main power supply to the processor core logic.						
VID	Voltage level identifier.						

Warm reset	RESET_L is asserted only (while PWROK stays high).			
XBAR	Cross bar; command packet switch.			
<b>PCIe</b> ®	PCI Express.			
PCS	Physical Coding Sublayer.			

# 1.6 Changes Between Revisions and Product Variations

#### 1.6.1 Revision Conventions

The processor revision is specified by CPUID\_Fn00000001\_EAX (FamModStep) or CPUID\_Fn80000001\_EAX (FamModStepExt). This document uses a revision letter instead of specific model numbers. Where applicable, the processor stepping is indicated after the revision letter. All behavior marked with a revision letter apply to future revisions unless they are superseded by a change in a later revision. See the revision guide in 1.2 [Reference Documents] for additional information about revision determination.

#### 1.7 Package

# 1.7.1 Package type

The following packages are supported.

Table 12: Package Definitions

Term	Description					
AM4	Desktop, single die, single socket. For client desktop platform (uPGA) DDR4. AM4 =					
	(Core::X86::Cpuid::BrandId[PkgType] == 02h).					
FP6	Notebook package for direct solder boards (uPGA). FP6 =					
	(Core::X86::Cpuid::BrandId[PkgType] == 00h).					

#### 1.8 Processor Overview

#### 1.8.1 Features

The Family 17h Models 60h-67h addition to AMD's offering of Accelerated Processing Units (APU). This System-On-a-Chip (SoC) has been created to meet the needs of energy efficient, performance rich solution laptop and mainstream desktop computing environments based on the x86 CPU architecture for 9th Generation APUs. It features AMD's Infinity Fabric<sup>TM</sup> (Scalable Data Fabric or SDF) for these market segments maximizing bandwidth utilization across the system with minimal latencies to boost overall system performance. The SoC is a solution that includes integrated IO, graphics, multimedia, and memory interfaces, where no supporting chipset is necessary, resulting in a lower Bill of Materials (BoM) cost.

- Package:
  - FP6 Mainstream Notebook class package.
  - AM4 Desktop class package.
- 4.5W-55W Thermal Design Power (TDP) Ordering Part Numbers (OPN) available for energy limited mobile solutions.
- Central Processing Units (CPU):

- Up to 2 Core Complexes (CCX) with up to 4 CUs per CCX, where each CU may run in single-thread mode (1T) or two-thread SMT mode (2T), for a total of up to 8T per Complex and 16T total.
- 512KiB of L2 per CU, for a total of 4MiB L2.
- 4MB L3 size per CCX. Total 8MB L3.
- Integrated Graphics.
- Multimedia Hub (MMHUB):
  - Video Controller.
  - Audio Co-Processor:
    - Audio DSP for low power audio playback (Azalea).
    - High Definition Audio.
  - Display Controller:
    - Supports maximum 4 independent display timings simultaneously.
- Scalable Data Fabric.
- Memory interface:
  - 2 Unified Memory Controllers (UMC), supporting two x64b DRAM channels for DDR4 or four x32b DDR channels for LPDDR4.
- System Management Unit (SMU):
  - Platform Security Processor and System Management Unit.
  - Thermal monitoring.
  - Power gating.
- NBIO:
  - 1 IOHUB.
  - 7x16 and 3x16 PCIe® controllers.
  - Support for OBFF and LTR end-to-end.
- FCH:
  - ACPI.
  - CLKGEN/CGPLL.
  - GPIOs (varying number depending on muxing).
  - Low Pin Count (LPC) interface.
  - Real-Time Clock (RTC).
  - SMBus (2 ports).
  - eSPI.
  - UART (2 ports).
- Ethernet complex:
  - 2 Ethernet ports.
- SATA:
  - 4 Port SATA.
  - Two SATA controllers supporting x2 lanes of SATA Gen1/Gen2/Gen3.
- USB:
  - 2 ports of USB3.1 Gen2 with integrated Type-C Switch with DP Alt Mode support.
  - 2 ports of USB3.1 Gen2.
  - 4 port of USB2.0.
- PHY for USB Type-C with integrated DP Alt Mode Switching.

The table, Table 13 [PCI Device ID Assignments.], shows the Family 17h, Models 60h-6Fh PCI Vendor ID and Device ID assignments. Graphics uses the ATI Vendor ID of 1002h, the others use the AMD Vendor ID of 1022h.

*Table 13: PCI Device ID Assignments.* 

Vendor ID	Device ID	Bus	Device	Function	Component
1022h	1448h	0	24	0	Data Fabric: Device 18h; Function 0
1022h	1449h	0	24	1	Data Fabric: Device 18h; Function 1

1022h	144Ah	0	24	2	Data Fabric: Device 18h; Function 2
1022h	144Bh	0	24	3	Data Fabric: Device 18h; Function 3
1022h	144Ch	0	24	4	Data Fabric: Device 18h; Function 4
1022h	144Dh	0	24	5	Data Fabric: Device 18h; Function 5
1022h	144Eh	0	24	6	Data Fabric: Device 18h; Function 6
1022h	144En	0	24	7	Data Fabric: Device 18h; Function 7
1022h	1630h	0	0	0	Root Complex
1022h	1631h	0	0	2	IOMMU
1022h	1632h	0	1	0	PCIe® Dummy Host Bridge
1022h	1633h	0	1	1	PCIe® GPP Bridge 0
1022h	1633h	0	1	2	PCIe® GPP Bridge 1
1022h	1633h	0	1	3	PCIe® GPP Bridge 2
1022h	1632h	0	2	0	PCIe® Dummy Host Bridge
1022h	1634h	0	2	1	PCIe® GPP Bridge 0
1022h	1634h	0	2	2	PCIe® GPP Bridge 1
1022h	1634h	0	2	3	PCIe® GPP Bridge 2
1022h	1634h	0	2	4	PCIe® GPP Bridge 3
1022h	1634h	0	2	5	PCIe® GPP Bridge 4
1022h	1634h	0	2	6	PCIe® GPP Bridge 5
1022h	1634h	0	2	7	PCIe® GPP Bridge 6
1022h	1632h	0	8	0	PCIe® Dummy Host Bridge
1022h	1635h	0	8	1	Internal PCIe® GPP Bridge 0 to Bus A
1022h	1635h	0	8	2	Internal PCIe® GPP Bridge 0 to Bus A  Internal PCIe® GPP Bridge 1 to Bus B
1022h	1635h	0	8	3	Internal PCIe® GPP Bridge 2 to Bus C
1022h	1455h	A	0	0	PCIe® Dummy Function
1022h	1639h	A	0	3	USB3.1 (USB0)
1022h	1639h	A	0	4	USB3.1 (USB1)
1022h	15E2h	A	0	5	Audio Processor (ACP)
1022h	15E2h	A	0	6	Audio Processor (ACF)  Audio Processor – HD Audio Controller
102211	13E3H	A	U	0	(Standalone AZ)
1022h	1455h	В	0	0	PCIe® Dummy Function
1022h	7901h	В	0	0	SATA AHCI Mode with MS Driver support
1022h	7904h	В	0	0	SATA AHCI Mode with AMD driver support
1022h	790Bh	0	20	0	SMBus Controller
1022h	7916h	В	0	1	SATA Controller; SATA Raid/AHCI Mode
1022h	7917h	В	0	1	SATA Controller: SATA Raid AHCI Mode for
102211	751711		O	_	second vendor
1022h	1641h	В	0	2	10 GbE Controller Port 0 (XGBE0)
1022h	1641h	В	0	3	10 GbE Controller Port 1 (XGBE1)
1022h	1455h	C	0	0	PCIe® Dummy Function
1022h	1644h	C	0	2	I2S/AC'97 Audio
1002h	1636h	A	0	0	Internal GPU (GFX)
1002h	1637h	A	0	1	Display HD Audio Controller (GFXAZ)
100411	100/11	11	J		Display IID Hadio Conduction (GI AMZ)

Note: In Table 13 [PCI Device ID Assignments.], programmable bus numbers are labeled A and B. Buses with different labels cannot be assigned the same bus number.

Note: Vendor ID 1002h is used for Internal GPU (1636h) and Display HD Audio Controller (1637h).

# 2 Core Complex (CCX)

# 2.1 Processor x86 Core

# 2.1.1 Core Functional Information

# 2.1.2 Core Definitions

*Table 14: Definitions* 

Table 14: Definitions					
Term	Description				
CCX	Core Complex where more than one core shares L3 resources.				
Core	The instruction execution unit of the processor when the term Core is used in a x86 core context.				
CoreCOF	Core current operating frequency in MHz. CoreCOF = (Core::X86::Msr::PStateDef[CpuFid[7:0]]/Core::X86::Msr::PStateDef[CpuDfsId])*200. A				
	nominal frequency reduction can occur if spread spectrum clocking is enabled.				
CPL	Current Privilege Level of the running task when the term CPL is used in a x86 core context.				
CpuCoreNum	Specifies the core number.				
IBS	Instruction based sampling.				
IO configuration	Access to configuration space through IO ports CF8h and CFCh.				
IORR	IO range register.				
L1 cache	The level 1 caches (instruction cache and the data cache).				
L2 cache	The level 2 caches.				
L3	Level 3 Cache. The L3 term is also in Addrmaps to enumerate CCX units.				
L3 cache	Level 3 Cache.				
Linear (virtual)	The address generated by a core after the segment is applied.				
address	The address generated by a core after the segment is applied.				
LINT	Local interrupt.				
Logical address	The address generated by a core before the segment is applied.				
LVT	Local vector table. A collection of APIC registers that define interrupts for local events (e.g., APIC[530:500] [Extended Interrupt [3:0] Local Vector Table]).				
MTRR	Memory-type range register. The MTRRs specify the type of memory associated with various				
	memory ranges.				
NTA	Non-Temporal Access.				
PTE	Page table entry.				
SMI	System management interrupt.				
Speculative event	A performance monitor event counter that counts all occurrences of the event even if the event				
	occurs during speculative code execution.				
SVM	Secure virtual machine.				
BSC	Boot strap core. Core 0 of the BSP.				
BSP	Boot strap processor.				
Canonical-address	An address in which the state of the most-significant implemented bit is duplicated in all the remaining higher-order bits, up to bit[63].				
CMP	Specifies the core number.				

#GP	A general-protection exception.		
#GP(0)	Notation indicating a general-protection exception (#GP) with error code of 0.		
NBC	NBC = (CPUID Fn00000001_EBX[LocalApicId[3:0]]==0). Node Base Core. The lowest		
	numbered core in the node.		
SMM	System Management Mode.		
SMT	Simultaneous multithreading. See Core::X86::Cpuid::CoreId[ThreadsPerCore].		
Thread	One architectural context for instruction execution.		
WDT	Watchdog timer. A timer that detects activity and triggers an error if a specified period of time		
	expires without the activity.		
X2APICEN	x2 APIC is enabled. X2APICEN = (Core::X86::Msr::APIC_BAR[ApicEn] &&		
	Core::X86::Msr::APIC_BAR[x2ApicEn]).		

# 2.1.3 Secure Virtual Machine Mode (SVM)

Support for SVM mode is indicated by Core::X86::Cpuid::FeatureExtIdEcx[SVM].

# 2.1.3.1 BIOS support for SVM Disable

The BIOS should include the following user setup options to enable and disable AMD Virtualization™ technology.

#### 2.1.3.1.1 Enable AMD Virtualization<sup>TM</sup>

- Core::X86::Msr::VM\_CR[SvmeDisable] = 0.
- Core::X86::Msr::VM\_CR[Lock] = 1.
- Core::X86::Msr::SvmLockKey[SvmLockKey] = 0000\_0000\_0000\_0000h.

#### 2.1.3.1.2 Disable AMD Virtualization<sup>TM</sup>

- Core::X86::Msr::SvmLockKey[SvmLockKey] = 0000\_0000\_0000\_0000h.
- Core::X86::Msr::VM\_CR[SvmeDisable] = 1.
- Core::X86::Msr::VM\_CR[Lock] = 1.

The BIOS may also include the following user setup options to disable AMD Virtualization technology.

#### 2.1.3.1.3 Disable AMD Virtualization™, with a user supplied key

- Core::X86::Msr::VM CR[SymeDisable] = 1.
- Core::X86::Msr::VM\_CR[Lock] = 1.
- Core::X86::Msr::SvmLockKey[SvmLockKey] programmed with value supplied by user. This value should be stored in NVRAM.

### 2.1.4 Memory Encryption

For details of the memory encryption, see docAPM2 section Secure Encrypted Virtualization. See docAPM2 section Enabling Memory Encryption Extensions for details about enabling memory encryption extensions.

# 2.1.5 Effective Frequency

The effective frequency interface allows software to discern the average, or effective, frequency of a given core over a

configurable window of time. This provides software a measure of actual performance rather than forcing software to assume the current frequency of the core is the frequency of the last P-state requested. Core::X86::Msr::MPERF is incremented by hardware at the P0 frequency while the core is in C0. Core::X86::Msr::APERF increments in proportion to the actual number of core clocks cycles while the core is in C0.

The following procedure calculates effective frequency using Core::X86::Msr::MPERF and Core::X86::Msr::APERF:

- 1. At some point in time, write 0 to both MSRs.
- 2. At some later point in time, read both MSRs.
- 3. Effective frequency = (value read from Core::X86::Msr::APERF / value read from Core::X86::Msr::MPERF) \* P0 frequency.

#### Additional notes:

- The amount of time that elapses between steps 1 and 2 is determined by software.
- It is software's responsibility to disable interrupts or any other events that may occur in between the Write of Core::X86::Msr::MPERF and the Write of Core::X86::Msr::APERF in step 1 or between the Read of Core::X86::Msr::MPERF and the Read of Core::X86::Msr::APERF in step 2.
- The behavior of Core::X86::Msr::MPERF and Core::X86::Msr::APERF may be modified by Core::X86::Msr::HWCR[EffFreqCntMwait].
- The effective frequency interface provides +/- 50MHz accuracy if the following constraints are met:
  - Effective frequency is read at most one time per millisecond.
  - When Reading or Writing Core::X86::Msr::MPERF and Core::X86::Msr::APERF software executes only MOV instructions, and no more than 3 MOV instructions, between the two RDMSR or WRMSR instructions.
  - Core::X86::Msr::MPERF and Core::X86::Msr::APERF are invalid if an overflow occurs.

### 2.1.6 Address Space

#### 2.1.6.1 Virtual Address Space

The processor supports 48-bit address bits of virtual memory space (256 TB) as indicated by Core::X86::Cpuid::LongModeInfo.

#### 2.1.6.2 Physical Address Space

The processor supports a 48-bit physical address space. See Core::X86::Cpuid::LongModeInfo. The processor master aborts the following upper-address transactions (to address PhysAddr):

• Link or core requests with non-zero PhysAddr[63:48].

#### 2.1.6.3 System Address Map

The processor defines a reserved memory address region starting at FFFD\_0000\_0000h and extending up to FFFF\_FFFF. System software must not map memory into this region. Downstream host accesses to the Reserved address region results in a page fault. Upstream system device accesses to the reserved address region results in an undefined operation.

#### 2.1.6.3.1 Memory Access to the Physical Address Space

All memory accesses to the physical address space from a core are sent to its associated Data Fabric (DF). All memory accesses from a link are routed through the DF. An IO link access to physical address space indicates to the DF the cache attribute (Coherent or Non-coherent, based on bit[0] of the Sized Read and Write commands).

A core access to physical address space has two important attributes that must be determined before issuing the access to the NB: the memory type (e.g., WB, WC, UC; as described in the MTRRs) and the access destination (DRAM or MMIO).

If the memory map maps a region as DRAM that is not populated with real storage behind it, then that area of DRAM must be mapped as UC memtype.

This mechanism is managed by the BIOS and does not require any setup or changes by system software.

### 2.1.6.3.1.1 Determining Memory Type

The memory type for a core access is determined by the highest priority of the following ranges that the access falls in: 1=Lowest priority.

- 1. The memory type as determined by architectural mechanisms.
  - See the docAPM2 chapter titled "Memory System", sections "Memory-Type Range Registers" and "Page-Attribute Table Mechanism".
  - See the docAPM2 chapter titled "Nested Paging", section "Combining Memory Types, MTRRs".
  - See Core::X86::Msr::MTRRdefType, Core::X86::Msr::MtrrVarBase, Core::X86::Msr::MtrrVarMask, Core::X86::Msr::MtrrFix\_64K and Core::X86::Msr::MtrrFix\_16K\_0 through Core::X86::Msr::MtrrFix\_4K\_7.
- 2. TSeg & ASeg SMM mechanism. (see Core::X86::Msr::SMMAddr and Core::X86::Msr::SMMMask)
- 3. CR0[CD]: If (CR0[CD] == 1) then MemType = CD.
- 4. MMIO configuration space, APIC space.
  - MMIO APIC space and MMIO config space must not overlap.
  - MemType = UC.
- 5. If ("In SMM Mode"&& ~((Core::X86::Msr::SMMMask[AValid] && "The address falls within the ASeg region") || (Core::X86::Msr::SMMMask[TValid] && "The address falls within the TSeg region"))) then MemType = CD.

#### 2.1.7 Configuration Space

PCI-defined configuration space was originally defined to allow up to 256 bytes of register space for each function of each device; these first 256 bytes are called base configuration space (BCS). It was expanded to support up to 4096 bytes per function; bytes 256 through 4095 are called extended configuration space (ECS).

The processor includes configuration space registers located in both BCS and ECS. Processor configuration space is accessed through bus 0, devices 18h to 1Fh, where device 18h corresponds to node 0 and device 1Fh corresponds to node 7. See 2.1.7.3 [Processor Configuration Space].

Configuration space is accessed by the processor through two methods as follows:

- IO-space configuration: IO instructions to addresses CF8h and CFCh.
  - Enabled through IO::IoCfgAddr[ConfigEn], which allows access to BCS.
  - Use of IO-space configuration can be programmed to generate GP faults through Core::X86::Msr::HWCR[IoCfgGpFault].
  - SMI trapping for these accesses is specified by Core::X86::Msr::SMI\_ON\_IO\_TRAP\_CTL\_STS and Core::X86::Msr::SMI\_ON\_IO\_TRAP.
- MMIO configuration: configuration space is a region of memory space.
  - The base address and size of this range is specified by Core::X86::Msr::MmioCfgBaseAddr. The size is controlled by the number of configuration-space bus numbers supported by the system. Accesses to this range are converted configuration space as follows:
  - Address[31:0] = {0h, bus[7:0], device[4:0], function[2:0], offset[11:0]}.

The BIOS may use either configuration space access mechanism during boot. Before booting the OS, BIOS must disable

IO access to ECS, enable MMIO configuration and build an ACPI defined MCFG table. BIOS ACPI code must use MMIO to access configuration space.

### 2.1.7.1 MMIO Configuration Coding Requirements

MMIO configuration space accesses must use the uncacheable (UC) memory type. Instructions used to read MMIO configuration space are required to take the following form: mov eax/ax/al, any\_address\_mode;

Instructions used to write MMIO configuration space are required to take the following form: mov any\_address\_mode, eax/ax/al;

No other source/target registers may be used other than eax/ax/al.

In addition, all such accesses are required not to cross any naturally aligned DW boundary. Access to MMIO configuration space registers that do not meet these requirements result in undefined behavior.

### 2.1.7.2 MMIO Configuration Ordering

Since MMIO configuration cycles are not serializing in the way that IO configuration cycles are, their ordering rules relative to posted may result in unexpected behavior.

Therefore, processor MMIO configuration space is designed to match the following ordering relationship that exists naturally with IO-space configuration: if a core generates a configuration cycle followed by a posted write cycle, then the posted write is held in the processor until the configuration cycle completes. As a result, any unexpected behavior that might have resulted if the posted-write cycle were to pass MMIO configuration cycle is avoided.

### 2.1.7.3 Processor Configuration Space

Accesses to unimplemented registers of implemented functions are ignored: Writes dropped; Reads return 0. Accesses to unimplemented functions also ignored: Writes are dropped; however, Reads return all F's. The processor does not log any master abort events for accesses to unimplemented registers or functions.

Accesses to device numbers of devices not implemented in the processor are routed based on the configuration map registers. If such requests are master aborted, then the processor can log the event.

### 2.1.8 PCI Configuration Legacy Access

### IOx0CF8 [IO-Space Configuration Address] (IO::IoCfgAddr)

Read-write. Reset: 0000\_0000h.

IO::IoCfgAddr, and IO::IoCfgData are used to access system configuration space, as defined by the PCI specification. IO::IoCfgAddr provides the address register and IO::IoCfgData provides the data port. Software sets up the configuration address by writing to IO::IoCfgAddr. Then, when an access is made to IO::IoCfgData, the processor generates the corresponding configuration access to the address specified in IO::IoCfgAddr. See 2.1.7 [Configuration Space].

IO::IoCfgAddr may only be accessed through aligned, DW IO Reads and Writes; otherwise, the accesses are passed to the appropriate IO link. Accesses to IO::IoCfgAddr and IO::IoCfgData received from an IO link are treated as all other IO transactions received from an IO link. IO::IoCfgAddr and IO::IoCfgData in the processor are not accessible from an IO link.

_aliasIO	; IOx0CF8; IO=0000_0000h		
Bits	Description		
31	<b>ConfigEn: configuration space enable</b> . Read-write. Reset: 0. 0=IO Read and Write accesses are passed to the		
	appropriate IO link and no configuration access is generated. 1=IO Read and Write accesses to IO::IoCfgData are		
	translated into configuration cycles at the configuration address specified by this register.		
30:28	Reserved.		
27:24	<b>ExtRegNo:</b> extended register number. Read-write. Reset: 0h. ExtRegNo provides bits[11:8] and RegNo		
	provides bits[7:2] of the byte address of the configuration register.		
23:16	<b>BusNo: bus number</b> . Read-write. Reset: 00h. Specifies the bus number of the configuration cycle.		
15:11	<b>Device: device number</b> . Read-write. Reset: 00h. Specifies the device number of the configuration cycle.		
10:8	<b>Function</b> . Read-write. Reset: 0h. Specifies the function number of the configuration cycle.		
7:2	RegNo: register address. Read-write. Reset: 00h. See IO::IoCfgAddr[ExtRegNo].		
1:0	Reserved.		

IOx0CFC [IO-Space Configuration Data Port] (IO::IoCfgData)		
Read-v	write. Reset: 0000_0000h.	
_aliasIO; IOx0CFC; IO=0000_0000h		
Bits	Bits Description	
31:0 <b>Data</b> . Read-write. Reset: 0000_0000h. See IO::IoCfgAddr.		

### 2.1.9 System Software Interaction With SMT Enabled

If Core::X86::Cpuid::CoreId[ThreadsPerCore] > 0, then SMT is enabled in all cores in the system. When SMT is enabled, the resources of each core are dynamically balanced among the hardware threads executing on that core. The number of hardware threads (hereafter "threads") supported by a single core when SMT is enabled is reported in Core::X86::Cpuid::CoreId[ThreadsPerCore]. System software that is SMT-aware may take advantage of the knowledge that core resources are being shared among multiple threads when scheduling tasks to be run by each thread on each core. System software that is not SMT-aware sees each thread as an independent core.

### 2.1.10 Register Sharing




Figure 21: Register Sharing Domains

### MSR0000\_0010 [Time Stamp Counter] (TSC)

	Read-write, Volatile. Reset: 0000 0000 0000 0000h.		
Core::X86::1	Msr::TS <mark>C_lthree[1:0]_core[3:0]_thread[1:0],</mark> MSR00000010		
Bits	Bits Description		
	TSC: time stamp counter. Read-write, Volatile. Reset: 0. The TSC increments at the P0 frequency. The		
	TSC counts at the same rate in all P-states, all C states, S0, or S1. A read of this MSR in guest mode is		
	affected by Core::X86::Msr::TscRateMsr. The value (TSC/TSCRatio) is the TSC P0 frequency based		

Figure 22: Instance Parameters

Instances of core registers are designated as lthree[n:0]\_core[n:0]\_thread[1:0]. Core registers may be shared at various levels of hierarchy as one register instance per node, per L3 complex, per core or per thread. The absence of the instance parameter \_thread[1:0] signifies that there is not a specific instance of said register per thread and thus the register is shared between thread[1] and thread[0]. Similarly, the absence of the instance parameter \_core[n:0] signifies that there is not a specific instance of said register per core and thus the register is shared by all cores in that L3 complex, and so on. The absence of instance parameters indicate there is one shared register at the node level. Software must coordinate writing to shared registers with other threads in the same sharing hierarchy level.

### 2.1.11 Timers

Each core includes the following timers. These timers do not vary in frequency regardless of the current P-state or C-state.

- Core::X86::Msr::TSC; the TSC increments at the rate specified by the P0 Pstate.
- The APIC timer (Core::X86::Apic::TimerInitialCount and Core::X86::Apic::TimerCurrentCount), which increments at the rate of 2xCLKIN; the APIC timer may increment in units of between 1 and 8.

### 2.1.12 Interrupts

### 2.1.12.1 System Management Mode (SMM)

System management mode (SMM) is typically used for system control activities such as power management. These activities are typically transparent to the operating system.

### **2.1.12.1.1 SMM Overview**

SMM is entered by a core on the next instruction boundary after a system management interrupt (SMI) is received and recognized. A core may be programmed to broadcast a special cycle to the system, indicating that it is entering SMM mode. The core then saves its state into the SMM memory state save area and jumps to the SMI service routine (or SMI handler). The pointer to the SMI handler is specified by MSRs. The code and data for the SMI handler are stored in the SMM memory area, which may be isolated from the main memory accesses.

The core returns from SMM by executing the RSM instruction from the SMI handler. The core restores its state from the SMM state save area and resumes execution of the instruction following the point where it entered SMM. The core may be programmed to broadcast a special bus cycle to the system, indicating that it is exiting SMM mode.

### 2.1.12.1.2 Mode and Default Register Values

The software environment after entering SMM has the following characteristics:

- Addressing and operation is in Real mode.
  - A far jump, call or return in the SMI handler can only address the lower 1M of memory, unless the SMI handler first switches to protected mode.
  - If (Core::X86::Msr::SMM\_BASE[SmmBase] >= 0010\_0000h) then:
    - The value of the CS selector is undefined upon SMM entry.
    - The undefined CS selector value should not be used as the target of a far jump, call, or return.
- 4-Gbyte segment limits.
- Default 16-bit operand, address, and stack sizes (instruction prefixes can override these defaults).
- Control transfers that do not override the default operand size truncate the EIP to 16 bits.
- Far jumps or calls cannot transfer control to a segment with a base address requiring more than 20 bits, as in Real mode segment-base addressing, unless a change is made into protected mode.
- Interrupt vectors use the Real mode interrupt vector table.
- The IF flag in EFLAGS is cleared (INTR is not recognized).
- The TF flag in EFLAGS is cleared.
- The NMI and INIT interrupts are masked.
- Debug register DR7 is cleared (debug traps are disabled).

The SMM base address is specified by Core::X86::Msr::SMM\_BASE[SmmBase]. Important offsets to the base address pointer are:

- Core::X86::Msr::SMM\_BASE[SmmBase] + 8000h: SMI handler entry point.
- Core::X86::Msr::SMM\_BASE[SmmBase] + FE00h FFFFh: SMM state save area.

### 2.1.12.1.3 SMI Sources And Delivery

The processor accepts SMIs as link-defined interrupt messages only. The core/node destination of these SMIs is a function of the destination field of these messages. However, the expectation is that all such SMI messages are specified to be delivered globally (to all cores of all nodes).

There are also several local events that can trigger SMIs. However, these local events do not generate SMIs directly. Each of them triggers a programmable IO cycle that is expected to target the SMI command port in the IO hub and trigger a global SMI interrupt message back to the coherent fabric.

Local sources of SMI events that generate the IO cycle specified in Core::X86::Msr::SmiTrigIoCycle are:

- In the core, as specified by:
  - Core::X86::Msr::McExcepRedir.
  - Core::X86::Msr::SMI\_ON\_IO\_TRAP.
- All local APIC LVT registers programmed to generate SMIs.

The status for these is stored in Core::X86::Smm::LocalSmiStatus.

### **2.1.12.1.4 SMM Initial State**

After storing the save state, execution starts at Core::X86::Msr::SMM\_BASE[SmmBase] + 08000h. The SMM initial state is specified in the following table.

Table 15: SMM Initial State

Register	SMM Initial State
CS	SmmBase[19:4]
DS	0000h
ES	0000h

FS	0000h
GS	0000h
SS	0000h
General-Purpose Registers	Unmodified.
EFLAGS	0000_0002h
RIP	0000_0000_0000_8000h
CR0	Bits[0,2,3,31] cleared (PE, EM, TS, and PG); remainder is unmodified.
CR4	0000_0000_0000_0000h
GDTR	Unmodified.
LDTR	Unmodified.
IDTR	Unmodified.
TR	Unmodified.
DR6	Unmodified.
DR7	0000_0000_0000_0400h
EFER	All bits are cleared except bit[12] (SVME) which is unmodified.

### 2.1.12.1.5 SMM Save State

In the following table, the offset field provides the offset from the SMM base address specified by Core::X86::Msr::SMM\_BASE[SmmBase].

Table 16: SMM Save State

Offset	Size	Conten	ts	Access
FE00h	Word	ES	Selector	Read-only
FE02h	6 Bytes	1	Reserved	
FE08h	Quadword	1	Descriptor in memory format	
FE10h	Word	CS	Selector	Read-only
FE12h	6 Bytes	]	Reserved	
FE18h	Quadword	]	Descriptor in memory format	
FE20h	Word	SS	Selector	Read-only
FE22h	6 Bytes	1	Reserved	
FE28h	Quadword	1	Descriptor in memory format	
FE30h	Word	DS	Selector	Read-only
FE32h	6 Bytes	]	Reserved	
FE38h	Quadword	1	Descriptor in memory form	
FE40h	Word	FS	Selector	Read-only
FE42h	2 Bytes	]	Reserved	
FE44h	Doublewor d		FS Base {16'b[47], 47:32}(note 1)	
FE48h	Quadword	1	Descriptor in memory format	
FE50h	Word	GS	Selector	Read-only
FE52h	2 Bytes	1	Reserved	
FE54h	Doublewor d		GS Base {16'b[47], 47:32}(note 1)	
FE58h	Quadword	1	Descriptor in memory format	
FE60h	4 Bytes	GDTR	Reserved	Read-only
FE64h	Word	1	Limit	

FE66h	2 Bytes		Reserved	
FE68h	Quadword		Descriptor in memory format	
FE70h	Word	LDTR	Selector	Read-only
FE72h	Word		Attributes	Ţ.
FE74h	Doublewor d		Limit	
FE78h	Quadword		Base	
FE80h	4 Bytes	IDTR	Reserved	Read-only
FE84h	Word		Limit	Ţ
FE86h	2 Bytes		Reserved	
FE88h	Quadword		Base	
FE90h	Word	TR	Selector	Read-only
FE92h	Word		Attributes	
FE94h	Doublewor d		Limit	
FE98h	Quadword		Base	
FEA0h	Quadword	IO_RES	TART_RIP	
FEA8h	Quadword	IO_RES	TART_RCX	
FEB0h	Quadword	IO_RES	TART_RSI	
FEB8h	Quadword	IO_RES	TART_RDI	
FEC0h	Doublewor d	Core::X	86::Smm::TrapOffset [SMM IO Trap Offset]	Read-only
FEC4	Doublewor d	Core::X	86::Smm::LocalSmiStatus	Read-only
FEC8h	Byte	Core::X	86::Smm::IoRestart	Read-write
FEC9h	Byte	Core::X	86::Smm::AutoHalt	Read-write
FECAh	Byte	Core::X	86::Smm::NmiMask	Read-write
FECBh	5 Bytes	Reserve	d	
FED0h	Quadword	EFER		Read-only
FED8h	Quadword	Core::X	86::Smm::SvmState	Read-only
FEE0h	Quadword	Guest V	MCB physical address	Read-only
FEE8h	Quadword	SVM Vi	rtual Interrupt Control	Read-only
FEF0h	16 Bytes	Reserve	d	
FEFCh	Doublewor d	Core::X	86::Smm::SmmRevID	Read-only
FF00h	Doublewor d	Core::X	86::Smm::SmmBase	Read-write
FF04h	28 Bytes	Reserve	d	
FF20h	Quadword	Guest PA	AT	Read-only
FF28h	Quadword	Host EF	ER (note 2)	
FF30h	Quadword	Host CR	4 (note 2)	
FF38h	Quadword	Nested (	CR3 (note 2)	
FF40h	Quadword	Host CR	10 (note 2)	
FF48h	Quadword	CR4		
FF50h	Quadword	CR3		
FF58h	Quadword	CR0		
FF60h	Quadword	DR7		Read-only
FF68h	Quadword	DR6		
FF70h	Quadword	RFLAG	Read-write	
FF78h	Quadword	RIP		Read-write

FF80h	Quadword	R15	
FF88h	Quadword	R14	
FF90h	Quadword	R13	
FF98h	Quadword	R12	
FFA0h	Quadword	R11	
FFA8h	Quadword	R10	
FFB0h	Quadword	R9	
FFB8h	Quadword	R8	
FFC0h	Quadword	RDI	Read-write
FFC8h	Quadword	RSI	
FFD0h	Quadword	RBP	
FFD8h	Quadword	RSP	
FFE0h	Quadword	RBX	
FFE8h	Quadword	RDX	
FFF0h	Quadword	RCX	
FFF8h	Quadword	RAX	
3. T		·	

### Notes:

- 1. This notation specifies that bit[47] is replicated in each of the 16 MSBs of the DW (sometimes called sign extended). The 16 LSBs contain bits[47:32].
- 2. Only used for an SMI in guest mode with nested paging enabled.

The SMI save state includes most of the integer execution unit. Not included in the save state are: the floating point state, MSRs, and CR2. In order to be used by the SMI handler, these must be saved and restored. The save state is the same, regardless of the operating mode (32-bit or 64-bit).

### 2.1.12.1.6 System Management State

The following are offsets in the SMM save state area.

### SMMxFEC0 [SMM IO Trap Offset] (Core::X86::Smm::TrapOffset)

Read-only, Volatile. Reset: 0000 0000h.

If the assertion of SMI is recognized on the boundary of an IO instruction, Core::X86::Smm::TrapOffset contains information about that IO instruction. For example, if an IO access targets an unavailable device, the system can assert SMI and trap the IO instruction. Core::X86::Smm::TrapOffset then provides the SMI handler with information about the IO instruction that caused the trap. After the SMI handler takes the appropriate action, it can reconstruct and then reexecute the IO instruction from SMM. Or, more likely, it can use Core::X86::Smm::IoRestart to cause the core to reexecute the IO instruction immediately after resuming from SMM.

CACCUI	ate the 10 montherior miniculatery after resuming from owner.		
Bits	its Description		
31:16 <b>Port</b> : <b>trapped IO port address</b> . Read-only, Volatile. Reset: 0000h. This provides the address of the IO			
	instruction.		
15:12	BPR: IO breakpoint match. Read-only, Volatile. Reset: 0h.		
11	<b>TF</b> : <b>EFLAGS TF value</b> . Read-only, Volatile. Reset: 0.		
10:7	Reserved.		
6	SZ32: size 32 bits. Read-only, Volatile. Reset: 0. 1=Port access was 32 bits.		
5	SZ16: size 16 bits. Read-only, Volatile. Reset: 0. 1=Port access was 16 bits.		
4	SZ8: size 8 bits. Read-only, Volatile. Reset: 0. 1=Port access was 8 bits.		
3	REP: repeated port access. Read-only, Volatile. Reset: 0.		
2	STR: string-based port access. Read-only, Volatile. Reset: 0.		
1	V: IO trap word valid. Read-only, Volatile. Reset: 0. 0=The other fields of this offset are not valid. 1=The core		
	entered SMM on an IO instruction boundary; all information in this offset is valid.		

0 **RW**: port access type. Read-only, Volatile. Reset: 0. 0=IO Write (OUT instruction). 1=IO Read (IN instruction).

### SMMxFEC4 [Local SMI Status] (Core::X86::Smm::LocalSmiStatus)

Read-only, Volatile. Reset: 0000\_0000h.

This offset stores status bits associated with SMI sources local to the core. For each of these bits, 1=The associated mechanism generated an SMI.

mecha	mechanism generated an SMI.		
Bits	Description		
31:9	Reserved.		
8	MceRedirSts: machine check exception redirection status. Read-only, Volatile. Reset: 0. This bit is associated		
with the SMI source specified in Core::X86::Msr::McExcepRedir[RedirSmiEn].			
7:4	Reserved.		
3:0	<b>IoTrapSts</b> : <b>IO trap status</b> . Read-only, Volatile. Reset: 0h. Each of these bits is associated with each of the		
	respective SMI sources specified in Core::X86::Msr::SMI_ON_IO_TRAP.		

### SMMxFEC8 [IO Restart Byte] (Core::X86::Smm::IoRestart)

Read-write. Reset: 00h.

If the core entered SMM on an IO instruction boundary, the SMI handler may write this to FFh. This causes the core to re-execute the trapped IO instruction immediately after resuming from SMM. The SMI handler should only write to this byte if Core::X86::Smm::TrapOffset[V] == 1; otherwise, the behavior is undefined.

If a second SMI is asserted while a valid IO instruction is trapped by the first SMI handler, the core services the second SMI prior to re-executing the trapped IO instruction. Core::X86::Smm::TrapOffset[V] == 0 during the second entry into SMM, and the second SMI handler must not rewrite this byte.

If there is a simultaneous SMI IO instruction trap and debug breakpoint trap, the processor first responds to the SMI and postpones recognizing the debug exception until after resuming from SMM. If debug registers other than DR6 and DR7 are used while in SMM, they must be saved and restored by the SMI handler. If Core::X86::Smm::IoRestart is set to FFh when the RSM instruction is executed, the debug trap does not occur until after the IO instruction is re-executed.

Bits	Description
7:0	RST: SMM IO Restart Byte. Read-write. Reset: 00h.

### SMMxFEC9 [Auto Halt Restart Offset] (Core::X86::Smm::AutoHalt)

Read-	Read-write. Reset: 00h.		
Bits	Bits Description		
7:1	Reserved.		
0	<b>HLT</b> : <b>halt restart</b> . Read-write. Reset: 0. 0=Entered SMM on a normal x86 instruction boundary. 1=Entered		
	SMM from the Halt state. Upon SMM entry, this bit indicates whether SMM was entered from the Halt state.		
	Before returning from SMM, this bit can be written by the SMI handler to specify whether the return from SMM		
	should take the processor back to the Halt state or to the instruction-execution state specified by the SMM state		
	save area (normally, the instruction after the halt). Clearing this bit the returns to the instruction specified in the		
	SMM save state. Setting this bit returns to the halt state. If the return from SMM takes the processor back to the		
	Halt state, the HLT instruction is not refetched and re-executed. However, the Halt special bus cycle is broadcast		
	and the processor enters the Halt state.		

### SMMxFECA [NMI Mask] (Core::X86::Smm::NmiMask)

Read-write. Reset: 00h.		
Bits	Description	
7:1	Reserved.	
0	NmiMask: NMI Mask. Read-write. Reset: 0. 0=NMI not masked. 1=NMI masked. Specifies whether NMI was	
	masked upon entry to SMM.	

### SMMxFED8 [SMM SVM State] (Core::X86::Smm::SvmState)

Read-o	Read-only, Volatile. Reset: 0000_0000_0000_0000h.			
This o	This offset stores the SVM state of the processor upon entry into SMM.			
Bits	Descripti	on		
63:4	Reserved.			
3	HostEflag	gesIF: host EFLAGS IF. Read-only, Volatile. Reset: 0.		
2:0	SvmState	SvmState. Read-only, Volatile. Reset: 0h.		
	ValidValues:			
	Value	Value Description		
	0h	Oh SMM entered from a non-guest state.		
	1h	1h Reserved.		
	2h	2h SMM entered from a guest state.		
	5h-3h Reserved.			
	6h SMM entered from a guest state with nested paging enabled.			
	7h	Reserved.		

SMMxFEFC [SMM Revision Identifier] (Core::X86::Smm::SmmRevID)
---

Read-	Read-only. Reset: 0003_0064h.		
This o	This offset stores the SVM state of the processor upon entry into SMM.		
Bits	Description		
31:18	Reserved.		
17	<b>BRL</b> . Read-only. Reset: 1. 1=Base relocation supported.		
16	IOTrap. Read-only. Reset: 1. 1=IO trap supported.		
15:0	Revision. Read-only. Reset: 0064h.		

### SMMxFE00 [SMM Base Address] (Core::X86::Smm::SmmBase)

	,		
Read-	Read-write, Volatile. Reset: 0000_0000_0000_0000h.		
This o	offset stores the base of the SMM-State of the processor upon entry into SMM.		
Bits	Description		
63.32	Reserved.		
00.02	reserved.		

### 2.1.12.1.7 Exceptions and Interrupts in SMM

When SMM is entered, the core masks INTR, NMI, SMI, and INIT interrupts. The core clears the IF flag to disable INTR interrupts. To enable INTR interrupts within SMM, the SMM handler must set the IF flag to 1.

Generating an INTR interrupt can be used for unmasking NMI interrupts in SMM. The core recognizes the assertion of NMI within SMM immediately after the completion of an IRET instruction. Once NMI is recognized within SMM, NMI recognition remains enabled until SMM is exited, at which point NMI masking is restored to the state it was in before entering SMM.

While in SMM, the core responds to STPCLK interrupts, as well as to all exceptions that may be caused by the SMI handler.

### 2.1.12.1.8 The Protected ASeg and TSeg Areas

These ranges are controlled by Core::X86::Msr::SMMAddr and Core::X86::Msr::SMMMask; see those registers for details.

### 2.1.12.1.9 SMM Special Cycles

Special cycles can be initiated on entry and exit from SMM to acknowledge to the system that these transitions are occurring. These are controlled by Core::X86::Msr::HWCR[RsmSpCycDis,SmiSpCycDis].

### 2.1.12.1.10 Locking SMM

The SMM registers (Core::X86::Msr::SMMAddr and Core::X86::Msr::SMMMask) can be locked from being altered by setting Core::X86::Msr::HWCR[SmmLock]. SBIOS must lock the SMM registers after initialization to prevent unexpected changes to these registers.

### 2.1.12.2 **Local APIC**

Family 17h, Model 60h supports the APIC interrupt controller and the X2APIC interrupt controllers. See 2.1.12.2.2 [Local APIC Registers] for the APIC registers and Core::X86::Msr::APIC\_ID through Core::X86::Msr::ExtendedInterruptLvtEntries for the X2APIC registers.

### 2.1.12.2.1 Local APIC Functional Description

The local APIC contains logic to receive interrupts from a variety of sources and to send interrupts to other local APICs, as well as registers to control its behavior and report status. Interrupts can be received from:

- IO devices including the IO hub (IO APICs)
- Other local APICs (inter-processor interrupts)
- APIC timer
- Thermal events
- Performance counters
- Legacy local interrupts from the IO hub (INTR and NMI)
- APIC internal errors

The APIC timer, thermal events, performance counters, local interrupts, and internal errors are all considered local interrupt sources, and their routing is controlled by local vector table entries. These entries assign a message type and vector to each interrupt, allow them to be masked, and track the status of the interrupt.

IO and inter-processor interrupts have their message type and vector assigned at the source and are unaltered by the local APIC. They carry a destination field and a mode bit that together determine which local APIC(s) accepts them. The destination mode (DM) bit specifies if the interrupt request packet should be handled in physical or logical destination mode.

### 2.1.12.2.1.1 Detecting and Enabling

The presence of APIC is detected via Core::X86::Cpuid::FeatureIdEdx[APIC], and the presence of X2APIC is detected via Core::X86::Cpuid::FeatureIdEcx[X2APIC].

The local APIC is enabled via Core::X86::Msr::APIC\_BAR[ApicEn]. The X2APIC is enabled via Core::X86::Msr::APIC\_BAR[x2ApicEn]. Reset forces the APIC and X2APIC disabled.

### 2.1.12.2.1.2 APIC Register Space

### MMIO APIC space:

- Memory mapped to a 4 KB range. The memory type of this space is the UC memory type. The base address of this range is specified by {Core::X86::Msr::APIC\_BAR[ApicBar[47:12]],000h}.
- The mnemonic is defined to be APICxXXX; where XXX is the byte address offset from the base address starting

with APICx020 through APICx530 (Core::X86::Apic::ApicId - Core::X86::Apic::ExtendedInterruptLvtEntries).

- Treated as normal memory space when APIC is disabled, as specified by Core::X86::Msr::APIC\_BAR[ApicEn]. MSR X2APIC space:
  - The local APIC register space in x2APIC mode.
  - MMIO APIC registers in x2APIC mode is defined by the register from MSR0000\_0802 to MSR0000\_08[53:50] (Core::X86::Msr::APIC\_ID through Core::X86::Msr::ExtendedInterruptLvtEntries).
  - If (Core::X86::Msr::APIC\_BAR[x2ApicEn] == 0) then GP-read-write.
  - RDMSR/WRMSR will occur in program order.

### 2.1.12.2.1.3 ApicId Enumeration Requirements

Note: Family 17h processors do not require contiguous ApicId assignments. Operating systems are expected to use Core::X86::Cpuid::SizeId[ApicIdSize], the number of least significant bits in the Initial APIC ID that indicate core ID within a processor, in constructing per-core CPUID masks. Core::X86::Cpuid::SizeId[ApicIdSize] determines the maximum number of cores (MNC) that the processor could theoretically support, not the actual number of cores that are actually implemented or enabled on the processor, as indicated by Core::X86::Cpuid::SizeId[NC].

### 2.1.12.2.1.4 Physical Destination Mode

The interrupt is only accepted by the local APIC whose Core::X86::Apic::ApicId[ApicId] matches the destination field of the interrupt. Physical mode allows up to 255 APICs to be addressed individually.

### 2.1.12.2.1.5 Logical Destination Mode

A local APIC accepts interrupts selected by Core::X86::Apic::LocalDestination and the destination field of the interrupt using either cluster or flat format as configured by Core::X86::Apic::DestinationFormat[Format].

If flat destinations are in use, bits[7:0] of Core::X86::Apic::LocalDestination[Destination] are checked against bits[7:0] of the arriving interrupt's destination field. If any bit position is set in both fields, the local APIC is a valid destination. Flat format allows up to 8 APICs to be addressed individually.

If cluster destinations are in use, bits[7:4] of Core::X86::Apic::LocalDestination[Destination] are checked against bits[7:4] of the arriving interrupt's destination field to identify the cluster. If all of bits[7:4] match, then bits[3:0] of Core::X86::Apic::LocalDestination[Destination] and the interrupt destination are checked for any bit positions that are set in both fields to identify processors within the cluster. If both conditions are met, the local APIC is a valid destination. Cluster format allows 15 clusters of 4 APICs each to be addressed.

### 2.1.12.2.1.6 Interrupt Delivery

SMI, NMI, INIT, Startup, and External interrupts are classified as non-vectored interrupts.

When an APIC accepts a non-vectored interrupt, it is handled directly by the processor instead of being queued in the APIC. When an APIC accepts a fixed or lowest-priority interrupt, it sets the bit in Core::X86::Apic::InterruptRequest corresponding to the vector in the interrupt. For local interrupt sources, this comes from the vector field in that interrupt's local vector table entry. The corresponding bit in Core::X86::Apic::TriggerMode is set if the interrupt is level-triggered and cleared if edge-triggered. If a subsequent interrupt with the same vector arrives when the corresponding bit in Core::X86::Apic::InterruptRequest[RequestBits] is already set, the two interrupts are collapsed into one. Vectors 15-0 are reserved.

### 2.1.12.2.1.7 Vectored Interrupt Handling

Core::X86::Apic::TaskPriority and Core::X86::Apic::ProcessorPriority each contain an 8-bit priority divided into a main priority (bits[7:4]) and a priority sub-class (bits[3:0]). The task priority is assigned by software to set a threshold priority at which the processor is interrupted.

The processor priority is calculated by comparing the main priority (bits[7:4]) of Core::X86::Apic::TaskPriority[Priority] to bits[7:4] of the 8-bit encoded value of the highest bit set in Core::X86::Apic::InService. The processor priority is the higher of the two main priorities.

The processor priority is used to determine if any accepted interrupts (indicated by

Core::X86::Apic::InterruptRequest[RequestBits]) are high enough priority to be serviced by the processor. When the processor is ready to service an interrupt, the highest bit in Core::X86::Apic::InterruptRequest[RequestBits] is cleared, and the corresponding bit is set in Core::X86::Apic::InService[InServiceBits].

When the processor has completed service for an interrupt, it performs a Write to Core::X86::Apic::EndOfInterrupt, clearing the highest bit in Core::X86::Apic::InService[InServiceBits] and causing the next-highest interrupt to be serviced. If the corresponding bit in Core::X86::Apic::TriggerMode[TriggerModeBits] is set, a Write to Core::X86::Apic::EndOfInterrupt is performed on all APICs to complete service of the interrupt at the source.

### 2.1.12.2.1.8 Interrupt Masking

Interrupt masking is controlled by the Core::X86::Apic::ExtendedApicControl. If

Core::X86::Apic::ExtendedApicControl[IerEn] is set, Core::X86::Apic::InterruptEnable are used to mask interrupts. Any bit in Core::X86::Apic::InterruptEnable[InterruptEnableBits] that is clear indicates the corresponding interrupt is masked. A masked interrupt is not serviced and the corresponding bit in Core::X86::Apic::InterruptRequest[RequestBits] remains set.

### 2.1.12.2.1.9 Spurious Interrupts

In the event that the task priority is set to or above the level of the interrupt to be serviced, the local APIC delivers a spurious interrupt vector to the processor, as specified by Core::X86::Apic::SpuriousInterruptVector.

Core::X86::Apic::EndOfInterrupt occurs.

### 2.1.12.2.1.10 Spurious Interrupts Caused by Timer Tick Interrupt

A typical interrupt is asserted until it is serviced. An interrupt is de-asserted when software clears the interrupt status bit within the interrupt service routine. Timer tick interrupt is an exception, since it is de-asserted regardless of whether it is serviced or not.

The processor is not always able to service interrupts immediately (i.e., when interrupts are masked by clearing EFLAGS.IM).

If the processor is not able to service the timer tick interrupt for an extended period of time, the INTR caused by the first timer tick interrupt asserted during that time is delivered to the local APIC in ExtInt mode and latched, and the subsequent timer tick interrupts are lost. The following cases are possible when the processor is ready to service interrupts:

- An ExtInt interrupt is pending, and INTR is asserted. This results in timer tick interrupt servicing. This occurs 50 percent of the time.
- An ExtInt interrupt is pending, and INTR is de-asserted. The processor sends the interrupt acknowledge cycle, but when the PIC receives it, INTR is de-asserted, and the PIC sends a spurious interrupt vector. This occurs 50 percent of the time.

There is a 50 percent probability of spurious interrupts to the processor.

### 2.1.12.2.1.11 Lowest-Priority Interrupt Arbitration

Fixed and non-vectored interrupts are accepted by their destination APICs without arbitration.

Delivery of lowest-priority interrupts requires all APICs to arbitrate to determine which one accepts the interrupt. If Core::X86::Apic::SpuriousInterruptVector[FocusDisable] is clear, then the focus processor for an interrupt always accepts the interrupt. A processor is the focus of an interrupt if it is already servicing that interrupt (corresponding bit in Core::X86::Apic::InService[InServiceBits] is set) or if it already has a pending request for that interrupt (corresponding bit in Core::X86::Apic::InterruptRequest[RequestBits] is set). If Core::X86::Apic::ExtendedApicControl[IerEn] is set, the interrupt must also be enabled in Core::X86::Apic::InterruptEnable[InterruptEnableBits] for a processor to be the focus processor. If there is no focus processor for an interrupt, or focus processor checking is disabled, then each APIC calculates an arbitration priority value, stored in Core::X86::Apic::ArbitrationPriority, and the one with the lowest result accepts the interrupt.

The arbitration priority value is calculated by comparing Core::X86::Apic::TaskPriority[Priority] with the 8-bit encoded value of the highest bit set in Core::X86::Apic::InterruptRequest[RequestBits] (IRRVec) and the 8-bit encoded value of the highest bit set Core::X86::Apic::InService[InServiceBits] (ISRVec). If Core::X86::Apic::ExtendedApicControl[IerEn] is set the IRRVec and ISRVec are based off the highest enabled interrupt. The main priority bits[7:4] are compared as follows:

```
if ((TaskPriority[Priority[7:4]] >= InterruptRequest[IRRVec[7:4]])
&&(TaskPriority[Priority[7:4]] > InService[ISRVec[7:4]])) {
ArbitrationPriority[Priority] = TaskPriority[Priority]
} elsif { (InterruptRequest[IRRVec[7:4]] > InService[ISRVec[7:4]])
ArbitrationPriority[Priority] = {InterruptRequest[IRRVec[7:4]],0h}
} else {
ArbitrationPriority[Priority] = {InService[ISRVect[7:4]],0h}
}
```

### 2.1.12.2.1.12 Inter-Processor Interrupts

The Core::X86::Apic::InterruptCommandLow and Core::X86::Apic::InterruptCommandHigh provide a mechanism for generating interrupts in order to redirect an interrupt to another processor, originate an interrupt to another processor, or allow a processor to interrupt itself. A Write to register Core::X86::Apic::InterruptCommandLow causes an interrupt to be generated with the properties specified by the Core::X86::Apic::InterruptCommandLow and Core::X86::Apic::InterruptCommandHigh fields.

Message type (bits[10:8]) == 011b (Remote Read) is deprecated.

Not all combinations of ICR fields are valid. Only the following combinations are valid: Note: x indicates a don't care.

Table	17.	ICD	val: a	Combinations
iable.	1/:	ICK	vana	<b>Combinations</b>

Message Type	Trigger Mode	Level	Destination Shorthand
Fixed	Edge	X	X
	Level	Assert	X
Lowest Priority, SMI,	Edge	X	Destination or all
NMI, INIT			excluding self
	Level	Assert	Destination or all
			excluding self

Startup	X	X	Destination or all
			excluding self

### 2.1.12.2.1.13 APIC Timer Operation

The local APIC contains a 32-bit timer, controlled by Core::X86::Apic::TimerLvtEntry,

Core::X86::Apic::TimerInitialCount, and Core::X86::Apic::TimerDivideConfiguration. The processor bus clock is divided by the value in Core::X86::Apic::TimerDivideConfiguration[Div[3:0]] to obtain a time base for the timer. When Core::X86::Apic::TimerInitialCount[Count] is written, the value is copied into Core::X86::Apic::TimerCurrentCount. Core::X86::Apic::TimerCurrentCount[Count] is decremented at the rate of the divided clock. When the count reaches 0, a timer interrupt is generated with the vector specified in Core::X86::Apic::TimerLvtEntry[Vector]. If Core::X86::Apic::TimerLvtEntry[Mode] specifies periodic operation, Core::X86::Apic::TimerCurrentCount[Count] is reloaded with the Core::X86::Apic::TimerInitialCount[Count] value, and it continues to decrement at the rate of the divided clock. If Core::X86::Apic::TimerLvtEntry[Mask] is set, timer interrupts are not generated.

### 2.1.12.2.1.14 Generalized Local Vector Table

All LVTs (Core::X86::Apic::ThermalLvtEntry to Core::X86::Apic::LVTLINT, and

Core::X86::Apic::ExtendedInterruptLvtEntries) support a generalized message type as follows:

- 000b=Fixed
- 010b=SMI
- 100b=NMI
- 111b=ExtINT
- All other messages types are Reserved.

### 2.1.12.2.1.15 State at Reset

At power-up or reset, the APIC is hardware disabled (Core::X86::Msr::APIC\_BAR[ApicEn] == 0) so only SMI, NMI, INIT, and ExtInt interrupts may be accepted.

The APIC can be software disabled through Core::X86::Apic::SpuriousInterruptVector[APICSWEn]. The software disable has no effect when the APIC is hardware disabled.

When a processor accepts an INIT interrupt, the APIC is reset as at power-up, with the exception that:

- Core::X86::Apic::ApicId is unaffected.
- Pending APIC register writes complete.

### 2.1.12.2.2 Local APIC Registers

APICx020 [APIC ID] (Core::X86::Apic::ApicId)			
Read-	Read-only.		
_lthree[1	::0]_core[3:0]_thread[1:0]; APICx020; APIC={Core::X86::Msr:::APIC_BAR[ApicBar[47:12]] , 000h}		
Bits	Description		
	<b>ApicId</b> : <b>APIC ID</b> . Read-only. Reset: XXh. The reset value varies based on core number. See 2.1.12.2.1.3 [ApicId		
	Enumeration Requirements].		
23:0	Reserved.		

APICx030 [APIC Version] (Core::X86::Apic::ApicVersion)
Read-only.
lthree[1:0] core[3:0] thread[1:0]: APICx030: APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]]_000h}

Bits	Description			
31	ExtApicSpace: extended APIC register space present. Read-only. Reset: 1. 1=Indicates the presence of			
	extended APIC register space starting at Core::X86::Apic::ExtendedApicFeature.			
30:25	Reserved.			
24	DirectedEoiSupport: directed EOI support. Read-only. Reset: Fixed,0. 0=Directed EOI capability not			
	supported.			
23:16	<b>MaxLvtEntry</b> . Read-only. Reset: XXh. Specifies the number of entries in the local vector table minus one.			
15:8	Reserved.			
7:0	<b>Version</b> . Read-only. Reset: 10h. Indicates the version number of this APIC implementation.			

### APICx080 [Task Priority] (Core::X86::Apic::TaskPriority)

Read-	Read-write. Reset: 0000_0000h.		
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; APICx080; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}		
Bits	Description		
31:8	Reserved.		
7:0	<b>Priority</b> . Read-write. Reset: 00h. This field is assigned by software to set a threshold priority at which the core is		
	interrupted.		

### APICx090 [Arbitration Priority] (Core::X86::Apic::ArbitrationPriority)

Read-only, Volatile. Reset: 0000_0000h.		
_lthree[1:0]_core[3:0]_thread[1:0]; APICx090; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}		
Bits	Bits Description	
31:8	31:8 Reserved.	
7:0	7:0 <b>Priority</b> . Read-only, Volatile. Reset: 00h. Indicates the current priority for a pending interrupt, or a task or	
	interrupt being serviced by the core. The priority is used to arbitrate between cores to determine which accepts a	
lowest-priority interrupt request.		

### APICx0A0 [Processor Priority] (Core::X86::Apic::ProcessorPriority)

Read-	Read-only, Volatile. Reset: 0000_0000h.		
_lthree[1	l:0]_core[3:0]_thread[1:0]; APICx0A0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}		
Bits	Description		
31:8	Reserved.		
7:0	<b>Priority</b> . Read-only, Volatile. Reset: 00h. Indicates the core's current priority servicing a task or interrupt, and is		
	used to determine if any pending interrupts should be serviced. It is the higher value of the task priority value and		
	the current highest in-service interrupt.		

### APICx0B0 [End of Interrupt] (Core::X86::Apic::EndOfInterrupt)

· · · · · · · · · · · · · · · · ·
Write-only

This register is written by the software interrupt handler to indicate the servicing of the current interrupt is complete. \_lthree[1:0]\_core[3:0]\_thread[1:0]; APICx0B0; APIC={Core::X86::Msr::APIC\_BAR[ApicBar[47:12]], 000h}

	- 1 <u> </u>
Bits	Description
31.0	Reserved

### APICx0C0 [Reserved] (Core::X86::Apic::RemoteRead)

The Tono Go [Teoler year] (Government Appendix and Teoler year)		
Read-only. Reset: 0000_0000h.		
Remote Read is deprecated.		
_lthree[1:0]_core[3:0]_thread[1:0]; APICx0C0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}		
Bits Description		
31:0 Reserved.		

### APICx0D0 [Logical Destination] (Core::X86::Apic::LocalDestination)

- 8	- '	1		
Read-write, Volatile. Rese	et: 0000_0000h.			
_lthree[1:0]_core[3:0]_thread[1:0]	; APICx0D0; APIC={Core::2	K86::Msr::APIC_BA	AR[ApicBar[47:12]] , 000h	}

Bits	Description	
31:24	<b>Destination</b> . Read-write, Volatile. Reset: 00h. This APIC's destination identification. Used to determine which	
	interrupts should be accepted.	
23:0	Reserved.	

APIC	APICx0E0 [Destination Format] (Core::X86::Apic::DestinationFormat)					
Read-v	Read-write. Reset: F000_0000h.					
Only s	upported i	n xAPIC mode.				
_lthree[1	:0]_core[3:0]_	thread[1:0]; APICx0E0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}				
Bits	Descripti	on				
31:28	Format.	Read-write. Reset: Fh. Controls which format to use when accepting interrupts with a logical destination				
	mode.					
	ValidValues:					
	Value Description					
	Oh Cluster destinations are used.					
	Eh-1h Reserved.					
	Fh Flat destinations are used.					
27:0	7:0 Reserved.					

### APICx0F0 [Spurious-Interrupt Vector] (Core::X86::Apic::SpuriousInterruptVector)

	- 1 - 1 1 /		
Reset:	0000_00FFh.		
_lthree[1:0]_core[3:0]_thread[1:0]; APICx0F0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}			
Bits	Bits Description		
31:10	Reserved.		
9	<b>FocusDisable</b> . Read-write. Reset: 0. 1=Disable focus core checking during lowest-priority arbitrated interrupts.		
8	<b>APICSWEn: APIC software enable</b> . Read-write, Volatile. Reset: 0. 0=SMI, NMI, INIT, LINT[1:0], and Startup		
	interrupts may be accepted; pending interrupts in Core::X86::Apic::InService and		
	Core::X86::Apic::InterruptRequest are held, but further fixed, lowest-priority, and ExtInt interrupts are not		
	accepted. All LVT entry mask bits are set and cannot be cleared.		
7:0	<b>Vector</b> . Read-write, Volatile. Reset: FFh. The vector that is sent to the core in the event of a spurious interrupt.		

### APICx1[0...7]0 [In-Service] (Core::X86::Apic::InService)

### APICx1[8...F]0 [Trigger Mode] (Core::X86::Apic::TriggerMode)

being serviced by the core.

Read-only, Volatile. Reset: 0000_0000h.
The trigger mode registers provide a bit per interrupt to indicate the assertion mode of each interrupt. The first 16
TriggerModeBits of the each thread's APIC[1F0:180] registers are Reserved.
[lthree[1:0] core[3:0] thread[1:0] n0; APICx180; APIC={Core::X86::Msr::APIC BAR[ApicBar[47:12]], 000h}

\_lthree[1:0]\_core[3:0]\_thread[1:0]\_n1; APICx190; APIC={Core::X86::Msr::APIC\_BAR[ApicBar[47:12]] , 000h}

\_lthree[1:0]\_core[3:0]\_thread[1:0]\_n2; APICx1A0; APIC={Core::X86::Msr::APIC\_BAR[ApicBar[47:12]], 000h}

1:0

Reserved.

_lthree[	_lthree[1:0]_core[3:0]_thread[1:0]_n3; APICx1B0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}		
_lthree[1:0]_core[3:0]_thread[1:0]_n4; APICx1C0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}			
_lthree[1:0]_core[3:0]_thread[1:0]_n5; APICx1D0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}			
_lthree[	_lthree[1:0]_core[3:0]_thread[1:0]_n6; APICx1E0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}		
_lthree[	_lthree[1:0]_core[3:0]_thread[1:0]_n7; APICx1F0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}		
Bits	Bits Description		
31:0	31:0 <b>TriggerModeBits</b> . Read-only, Volatile. Reset: 0000_0000h. The corresponding trigger mode bit is updated when		
	an interrupt is accepted. 1=Level-triggered interrupt. 0=Edge-triggered interrupt.		

### APICx2[0...7]0 [Interrupt Request] (Core::X86::Apic::InterruptRequest)

Read-only. Reset: 0000_0000h.
The interrupt request registers provide a bit per interrupt to indicate that the corresponding interrupt has been accepted
by the APIC. The first 16 RequestBits of the first Core::X86::Apic::InterruptRequest register are Reserved.
_lthree[1:0]_core[3:0]_thread[1:0]_n0; APICx200; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}
_lthree[1:0]_core[3:0]_thread[1:0]_n1; APICx210; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
_lthree[1:0]_core[3:0]_thread[1:0]_n2; APICx220; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
_lthree[1:0]_core[3:0]_thread[1:0]_n3; APICx230; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
_lthree[1:0]_core[3:0]_thread[1:0]_n4; APICx240; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
_lthree[1:0]_core[3:0]_thread[1:0]_n5; APICx250; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
_lthree[1:0]_core[3:0]_thread[1:0]_n6; APICx260; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
[!three[1:0]_core[3:0]_thread[1:0]_n7; APICx270; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
Bits Description
31:0 <b>RequestBits</b> . Read-only. Reset: 0000_0000h. The corresponding request bit is set when the an interrupt is
accepted by the APIC.

### APICx280 [Error Status] (Core::X86::Apic::ErrorStatus)

Writes to this register trigger an update of the register state. The value written by software is arbitrary. Each write causes the internal error state to be loaded into this register, clearing the internal error state. Consequently, a second write prior to the occurrence of another error causes the register to be overwritten with cleared data.

lthree[1:0]\_core[3:0]\_thread[1:0]; APICx280; APIC={Core::X86::Msr::APIC\_BAR[ApicBar[47:12]], 000h} Bits Description 31:8 Reserved. IllegalRegAddr: illegal register address. Read-write. Reset: 0. This bit indicates that an access to a nonexistent register location within this APIC was attempted. Can only be set in xAPIC mode. RcvdIllegalVector: received illegal vector. Read-write. Reset: 0. This bit indicates that this APIC has received a 6 message with an illegal vector (00h to 0Fh for fixed and lowest priority interrupts). **SentIllegalVector**. Read-write. Reset: 0. This bit indicates that this APIC attempted to send a message with an 5 illegal vector (00h to 0Fh for fixed and lowest priority interrupts). Reserved. 4 3 **RcvAcceptError**: **receive accept error**. Read-write. Reset: 0. This bit indicates that a message received by this APIC was not accepted by this or any other APIC. 2 **SendAcceptError**. Read-write. Reset: 0. This bit indicates that a message sent by this APIC was not accepted by any APIC.

### APICx300 [Interrupt Command Low] (Core::X86::Apic::InterruptCommandLow)

Reset: 0000_0000h.		
_lthree[1	l:0]_core[3:0]_thread[1:0]; APICx300; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}	
Bits	Description	
31:20	Reserved.	
19:18	DestShrthnd: destination shorthand. Read-write. Reset: 0h.	
	<b>Description</b> : Provides a quick way to specify a destination for a message.	
	If all including self or all excluding self is used, then destination mode is ignored and physical is automatically	
	used.	

	ValidVal	ues:	
	Value	Description	
	0h	No shorthand (Destination field).	
	1h	Self.	
	2h	All including self.	
	3h	All excluding self (This sends a message with a destination encoding of all 1s, so if lowest priority is	
		used the message could end up being reflected back to this APIC).	
17:16	RemoteR	RdStat. Read-only. Reset: 0h.	
	ValidValues:		
	Value	Description	
	0h	Read was invalid.	
	1h	Delivery pending.	
	2h	Delivery complete and access was valid.	
	3h	Reserved.	
15	TM: trig	<b>ger mode</b> . Read-write. Reset: 0. 0=Edge triggered. 1=Level triggered. Indicates how this interrupt is	
	triggered.		
14		ead-write. Reset: 0. 0=De-asserted. 1=Asserted.	
13	Reserved		
12		<b>rupt delivery status</b> . Read-only. Reset: 0. 0=Idle. 1=Send pending. In xAPIC mode this bit is set to	
		hat the interrupt has not yet been accepted by the destination core(s). Software may repeatedly Write	
		6::Apic::InterruptCommandLow without polling the DS bit; all requested IPIs are delivered.	
11		tination mode. Read-write. Reset: 0. 0=Physical. 1=Logical.	
10:8	8 71		
	ValidVal		
	Value	Description	
	0h	Fixed	
	1h	Lowest Priority.	
	2h	SMI	
	3h	Reserved.	
	4h	NMI	
	5h	INIT	
	6h	Startup	
	7h	External interrupt.	
7:0	Vector. R	lead-write. Reset: 00h. The vector that is sent for this interrupt source.	

### APICx310 [Interrupt Command High] (Core::X86::Apic::InterruptCommandHigh)

11110	interrupt communa riign] (coremroom previmerrupt communariign)
Read-write. Reset: 0000_0000h.	
_lthree[1	:0]_core[3:0]_thread[1:0]; APICx310; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
Bits	Description
31:24	<b>DestinationField</b> . Read-write. Reset: 00h. The destination encoding used when
	Core::X86::Apic::InterruptCommandLow[DestShrthnd] is 00b.
23:0	Reserved.

### APICx320 [LVT Timer] (Core::X86::Apic::TimerLvtEntry)

Reset: 0001_0000h.	
_lthree[1	:0]_core[3:0]_thread[1:0]; APICx320; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
Bits	Description
31:18	Reserved.
17	<b>Mode</b> . Read-write. Reset: 0. 0=One-shot. 1=Periodic.
16	Mask. Read-write. Reset: 1. 0=Not masked. 1=Masked.

15:13	Reserved.
12	<b>DS</b> : <b>interrupt delivery status</b> . Read-only, Volatile. Reset: 0. 0=Idle. 1=Send pending. (Indicates that the interrupt
	has not yet been accepted by the core.)
11	Reserved.
10:8	<b>MsgType</b> : message type. Read-write. Reset: 0h. See2.1.12.2.1.14 [Generalized Local Vector Table].
7:0	<b>Vector</b> . Read-write. Reset: 00h. Interrupt vector number.

### APICx330 [LVT Thermal Sensor] (Core::X86::Apic::ThermalLvtEntry)

Reset: 0001_0000h.	
_lthree[1	:0]_core[3:0]_thread[1:0]; APICx330; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
Bits	Description
31:17	Reserved.
16	Mask. Read-write. Reset: 1. 0=Not masked. 1=Masked.
15:13	Reserved.
12	<b>DS</b> : <b>interrupt delivery status</b> . Read-only, Volatile. Reset: 0. 0=Idle. 1=Send pending. (Indicates that the interrupt
	has not yet been accepted by the core.)
11	Reserved.
10:8	<b>MsgType</b> : <b>message type</b> . Read-write. Reset: 0h. See2.1.12.2.1.14 [Generalized Local Vector Table].
7:0	<b>Vector</b> . Read-write. Reset: 00h. Interrupt vector number.

### APICx340 [LVT Performance Monitor] (Core::X86::Apic::PerformanceCounterLvtEntry)

Docot.	0001	0000h.	
neset.	$\mathcal{M}\mathcal{M}\mathcal{M}$	www.	

Interrupts for this local vector table are caused by overflows of:

- Core::X86::Msr::PERF\_LEGACY\_CTL(Performance Event Select [3:0]).
- Core::X86::Msr::PERF\_CTL(Performance Event Select [5:0]).

_iuiree[1	:0]_coie[5:0]_tillead[1:0]; APICx540; APIC={Coie::X66::MSI::APIC_BAR[ApiCBal[47:12]] , 000ii}
Bits	Description
31:17	Reserved.
16	Mask. Read-write. Reset: 1. 0=Not masked. 1=Masked.
15:13	Reserved.
12	<b>DS</b> : <b>interrupt delivery status</b> . Read-only, Volatile. Reset: 0. 0=Idle. 1=Send pending. (Indicates that the interrupt
	has not yet been accepted by the core.)
11	Reserved.
10:8	<b>MsgType</b> : <b>message type</b> . Read-write. Reset: 0h. See2.1.12.2.1.14 [Generalized Local Vector Table].
7:0	<b>Vector</b> . Read-write. Reset: 00h. Interrupt vector number.

### APICx3[5...6]0 [LVT LINT[1:0]] (Core::X86::Apic::LVTLINT)

	1 11 /
Reset: 0001_0000h.	
_lthree[1	:0]_core[3:0]_thread[1:0]_n0; APICx350; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
_lthree[1	:0]_core[3:0]_thread[1:0]_n1; APICx360; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}
Bits	Description
31:17	Reserved.
16	Mask. Read-write. Reset: 1. 0=Not masked. 1=Masked.
15	<b>TM</b> : <b>trigger mode</b> . Read-write. Reset: 0. 0=Edge. 1=Level.
14	<b>RmtIRR</b> . Read-only, Volatile. Reset: 0. If trigger mode is level, remote Core::X86::Apic::InterruptRequest is set
	when the interrupt has begun service. Remote Core::X86::Apic::InterruptRequest is cleared when the end of
	interrupt has occurred.
13	Reserved.
12	<b>DS</b> : <b>interrupt delivery status</b> . Read-only, Volatile. Reset: 0. 0=Idle. 1=Send pending. (Indicates that the interrupt
	has not yet been accepted by the core.)
11	Reserved.

10:8	<b>MsgType</b> : message type. Read-write. Reset: 0h. See2.1.12.2.1.14 [Generalized Local Vector Table].
7:0	Vector. Read-write. Reset: 00h. Interrupt vector number.

### APICx370 [LVT Error] (Core::X86::Apic::ErrorLvtEntry)

71110	ADTO [LIVE ETTOS] (COTEMATOR PREMERTOR VEHICLE)
Reset: 0001_0000h.	
_lthree[1	1:0]_core[3:0]_thread[1:0]; APICx370; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
Bits	Description
31:17	Reserved.
16	Mask. Read-write. Reset: 1. 0=Not masked. 1=Masked.
15:13	Reserved.
12	<b>DS</b> : <b>interrupt delivery status</b> . Read-only, Volatile. Reset: 0. 0=Idle. 1=Send pending. (Indicates that the interrupt
	has not yet been accepted by the core.)
11	Reserved.
10:8	<b>MsgType</b> : <b>message type</b> . Read-write. Reset: 0h. See 2.1.12.2.1.14 [Generalized Local Vector Table].
7:0	<b>Vector</b> . Read-write. Reset: 00h. Interrupt vector number.

### APICx380 [Timer Initial Count] (Core::X86::Apic::TimerInitialCount)

Read-	write, Volatile. Reset: 0000_0000h.
_lthree[1	L:0]_core[3:0]_thread[1:0]; APICx380; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
Bits	Description
31:0	<b>Count</b> . Read-write, Volatile. Reset: 0000_0000h. The value copied into the current count register when the timer
	is loaded or reloaded.

### APICx390 [Timer Current Count] (Core::X86::Apic::TimerCurrentCount)

Read-only, Volatile. Reset: 0000_0000h.	
_lthree[1:0]_core[3:0]_thread[1:0]; APICx390; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}	
Bits	Description
31:0	<b>Count</b> . Read-only, Volatile. Reset: 0000_0000h. The current value of the counter.

### APICx3E0 [Timer Divide Configuration] (Core::X86::Apic::TimerDivideConfiguration)

Read-	write. Rese	et: 0000_0000h.
_lthree[1	:0]_core[3:0]_	_thread[1:0]; APICx3E0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}
Bits	Descripti	on
31:4	Reserved.	
3:0	Div[3:0].	Read-write. Reset: 0h. Div[2] is unused.
	ValidValu	ues:
	Value	Description
	0h	Divide by 2.
	1h	Divide by 4.
	2h	Divide by 8.
	3h	Divide by 16.
	7h-4h	Reserved.
	8h	Divide by 32.
	9h	Divide by 64.
	Ah	Divide by 128.
	Bh	Divide by 1.
	Fh-Ch	Reserved.

### APICx400 [Extended APIC Feature] (Core::X86::Apic::ExtendedApicFeature)

Read-only. Reset: 0004_0007h.
_lthree[1:0]_core[3:0]_thread[1:0]; APICx400; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}
Bits Description

31:24	Reserved.
23:16	<b>ExtLvtCount</b> : <b>extended local vector table count</b> . Read-only. Reset: 04h. This specifies the number of extended
	LVT registers (Core::X86::Apic::ExtendedInterruptLvtEntries) in the local APIC.
15:3	Reserved.
2	<b>ExtApicIdCap: extended APIC ID capable</b> . Read-only. Reset: 1. 1=The processor is capable of supporting an
	8-bit APIC ID, as controlled by Core::X86::Apic::ExtendedApicControl[ExtApicIdEn].
1	SeoiCap: specific end of interrupt capable. Read-only. Reset: 1. 1=The
	Core::X86::Apic::SpecificEndOfInterrupt is present.
0	<b>IerCap: interrupt enable register capable.</b> Read-only. Reset: 1. This bit indicates that the
	Core::X86::Apic::InterruptEnable are present. See2.1.12.2.1.8 [Interrupt Masking].

### APICx410 [Extended APIC Control] (Core::X86::Apic::ExtendedApicControl)

Read-write. Reset: 0000_0000h.	
_lthree[1	L:0]_core[3:0]_thread[1:0]; APICx410; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}
Bits	Description
31:3	Reserved.
2	ExtApicIdEn: extended APIC ID enable. Read-write. Reset: 0. 1=Enable 8-bit APIC ID;
	Core::X86::Apic::ApicId[ApicId] supports an 8-bit value; an interrupt broadcast in physical destination mode
	requires that the IntDest[7:0] == 1111_1111b (instead of XXXX_1111b); a match in physical destination mode
	occurs when $(IntDest[7:0] == ApicId[7:0])$ instead of $(IntDest[3:0] == ApicId[3:0])$ .
1	SeoiEn. Read-write. Reset: 0. 1=Enable SEOI generation when a write to
	Core::X86::Apic::SpecificEndOfInterrupt is received.
0	<b>IerEn</b> . Read-write. Reset: 0. 1=Enable writes to the interrupt enable registers.

### APICx420 [Specific End Of Interrupt] (Core::X86::Apic::SpecificEndOfInterrupt)

TH TOX 420 [Specific Life Of Interrupt] (Core		
Read-write. Reset: 0000_0000h.		
	lthree[1	l:0]_core[3:0]_thread[1:0]; APICx420; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
	Bits	Description
	31:8	Reserved.
	7:0	<b>EoiVec:</b> end of interrupt vector. Read-write. Reset: 00h. A write to this field causes an end of interrupt cycle to
		be performed for the vector specified in this field. The behavior is undefined if no interrupt is pending for the
		specified interrupt vector.

### APICx4[8...F]0 [Interrupt Enable] (Core::X86::Apic::InterruptEnable)

111 10x4[01] V [Interrupt Enable] (Ovie2001pieinterruptEnable)		
Read-write. Reset: FFFF_FFFFh.		
_lthree[1:0]_core[3:0]_thread[1:0]_n0; APICx480; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}		
[!three[1:0]_core[3:0]_thread[1:0]_n1; APICx490; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}		
[!three[1:0]_core[3:0]_thread[1:0]_n2; APICx4A0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}		
[!three[1:0]_core[3:0]_thread[1:0]_n3; APICx4B0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}		
_lthree[1:0]_core[3:0]_thread[1:0]_n4; APICx4C0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}		
_lthree[1:0]_core[3:0]_thread[1:0]_n5; APICx4D0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}		
_tthree[1:0]_core[3:0]_thread[1:0]_n6; APICx4E0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}		
[!three[1:0]_core[3:0]_thread[1:0]_n7; APICx4F0; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}		
Bits Description		
31:0 <b>InterruptEnableBits</b> . Read-write. Reset: FFFF_FFFFh. The interrupt enable bits can be used to enable each of		
the 256 interrupts.		

### APICx5[0...3]0 [Extended Interrupt Local Vector Table] (Core::X86::Apic::ExtendedInterruptLvtEntries)

Reset: 0001\_0000h.

Assignments conventions:

- APIC500 provides a local vector table entry for IBS.
- APIC510 provides a local vector table entry for error thresholding. See Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset].
- APIC520 provides a local vector table entry for Deferred errors. See MCi\_CONFIG[DeferredIntType].

_lthree[1	:0]_core[3:0]_thread[1:0]_n0; APICx500; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]], 000h}
_lthree[1	:0]_core[3:0]_thread[1:0]_n1; APICx510; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
_lthree[1	:0]_core[3:0]_thread[1:0]_n2; APICx520; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
_lthree[1	:0]_core[3:0]_thread[1:0]_n3; APICx530; APIC={Core::X86::Msr::APIC_BAR[ApicBar[47:12]] , 000h}
Bits	Description
31:17	Reserved.
16	Mask. Read-write. Reset: 1. 0=Not masked. 1=Masked.
15:13	Reserved.
12	<b>DS</b> : <b>interrupt delivery status</b> . Read-only, Volatile. Reset: 0. 0=Idle. 1=Send pending. (Indicates that the interrupt
	has not yet been accepted by the core.)
11	Reserved.
10:8	<b>MsgType</b> : <b>message type</b> . Read-write. Reset: 0h. See2.1.12.2.1.14 [Generalized Local Vector Table].
7:0	<b>Vector</b> . Read-write. Reset: 00h. Interrupt vector number.

### 2.1.13 CPUID Instruction

Processor feature capabilities and configuration information are provided through the CPUID instruction. The information is accessed by (1) selecting the CPUID function setting EAX and optionally ECX for some functions, (2) executing the CPUID instruction, and (3) reading the results in the EAX, EBX, ECX, and EDX registers. The syntax CPUID FnXXXXXXXXX\_EiX[\_xYYY] refers to the function where EAX == X, and optionally ECX == Y, and the registers specified by EiX. EiX can be any single register such as {EAX, EBX, ECX, and EDX}, or a range of registers, such as E[C,B,A]X. Undefined function numbers return 0's in all 4 registers.

Unless otherwise specified, single-bit feature fields are encoded as: 1=Feature is supported by the processor. 0=Feature is not supported by the processor. CPUID functions not listed are Reserved.

### 2.1.13.1 **CPUID Instruction Functions**

CPU	CPUID_Fn00000000_EAX [Processor Vendor and Largest Standard Function Number]	
(Co	re::X86::Cpuid::LargFuncNum)	
Read	d-only. Reset: Fixed,0000_0010h.	
_lthre	ee[1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000000_EAX	
Bits	S Description	
31:0	0 <b>LFuncStd</b> : <b>largest standard function</b> . Read-only. Reset: Fixed,0000_0010h. The largest CPUID standard	
	function input value supported by the processor implementation.	

# CPUID\_Fn0000000\_EBX [Processor Vendor (ASCII Bytes [3:0])] (Core::X86::Cpuid::ProcVendEbx) Read-only. Reset: Fixed,6874\_7541h. Core::X86::Cpuid::ProcVendEbx and Core::X86::Cpuid::ProcVendExtEbx return the same value. \_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn0000000\_EBX Bits Description

	2 to the part of t
31:0	<b>Vendor</b> . Read-only. Reset: Fixed,6874_7541h. ASCII Bytes [3:0] ("h t u A") of the string "AuthenticAMD".
<b>CPUI</b>	D_Fn00000000_ECX [Processor Vendor (ASCII Bytes [11:8])] (Core::X86::Cpuid::ProcVendEcx)
Dood	only Decet Fixed 444D, 41Ch

CPUI	D_Filo0000000_ECX [F10cessor vendor (ASCII Bytes [11.0])] (CoreAooCpiliaF10c vendEcx)
Read-	only. Reset: Fixed,444D_4163h.
Core:	:X86::Cpuid::ProcVendEcx and Core::X86::Cpuid::ProcVendExtEcx return the same value.
_lthree[	1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000000_ECX
Bits	Description
31:0	<b>Vendor</b> . Read-only. Reset: Fixed,444D_4163h. ASCII Bytes [11:8] ("D M A c") of the string "AuthenticAMD".

CPUID_Fn00000000_EDX [Processor Vendor (ASCII Bytes [7:4])] (Core::X86::Cpuid::ProcVendEdx)	
Read-only. Reset: Fixed,6974_6E65h.	

Core::X86::Cpuid::ProcVendEdx and Core::X86::Cpuid::ProcVendExtEdx return the same value.	
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000000_EDX	
Bits Description	
31:0	<b>Vendor</b> . Read-only. Reset: Fixed,6974_6E65h. ASCII Bytes [7:4] ("i t n e") of the string "AuthenticAMD".

### CPUID\_Fn00000001\_EAX [Family, Model, Stepping Identifiers] (Core::X86::Cpuid::FamModStep)

### Read-only.

Core::X86::Cpuid::FamModStep and Core::X86::Cpuid::FamModStepExt return the same value.

Family: Is an 8-bit value and is defined as: Family[7:0]=({0000b,BaseFamily[3:0]}+ExtendedFamily[7:0]).

• E.g., If BaseFamily[3:0] == Fh and ExtendedFamily[7:0] == 08h, then Family[7:0] = 17h.

Model: Is an 8-bit value and is defined as: Model[7:0]={ExtendedModel[3:0],BaseModel[3:0]}.

- E.g., If ExtendedModel[3:0] == 1h and BaseModel[3:0] == 8h, then Model[7:0] = 18h.
- Model numbers vary with product.

Model numbers are are assigned a letter, 0h = "A", 1h = "B", and so on. Model and Stepping form the Revision. E.g., A1.

_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000001_EAX	
Bits	Description
31:28	Reserved.
27:20	ExtFamily: extended family. Read-only. Reset: 08h. See Family above.
19:16	ExtModel: extended model. Read-only. Reset: 6h. See Model above.
15:12	Reserved.
11:8	BaseFamily. Read-only. Reset: Fh. See Family description above.
7:4	BaseModel. Read-only. Reset: Xh. Model numbers vary with product.
3:0	<b>Stepping</b> . Read-only. Reset: 1h. Processor stepping (revision) for a specific model.

### CPUID\_Fn00000001\_EBX [LocalApicId, LogicalProcessorCount, CLFlush] (Core::X86::Cpuid::FeatureIdEbx)

Read-	Read-only.		
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000001_EBX			
Bits	Description		
31:24	LocalApicId. Read-only. Reset: XXh. Initial local APIC physical ID.		
23:16	<b>LogicalProcessorCount</b> : <b>logical processor count</b> . Read-only. Reset: Fixed,(Core::X86::Cpuid::SizeId[NC] + 1).		
	Specifies the number of threads in the processor as Core::X86::Cpuid::SizeId[NC] + 1.		
15:8	CLFlush. Read-only. Reset: Fixed,08h. CLFLUSH size in quadwords.		
7:0	Reserved.		

### CPUID\_Fn00000001\_ECX [Feature Identifiers] (Core::X86::Cpuid::FeatureIdEcx)

	·	
Read-only.		
These	values can be over-written by Core::X86::Msr::CPUID_Features.	
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000001_ECX		
Bits	Description	
31	Reserved.	
30	RDRAND. Read-only. Reset: Fixed,1. RDRAND instruction support.	
29	<b>F16C</b> . Read-only. Reset: Fixed,1. Half-precision convert instruction support.	
28	AVX. Read-only. Reset: Fixed,1. AVX instruction support.	
27	<b>OSXSAVE</b> . Read-only. Reset: X. 1=The OS has enabled support for XGETBV/XSETBV instructions to query	
	processor extended states. OS enabled support for XGETBV/XSETBV.	
26	<b>XSAVE</b> . Read-only. Reset: Fixed,1. 1=Support provided for the XSAVE, XRSTOR, XSETBV, and XGETBV	
	instructions and the XFEATURE_ENABLED_MASK register. XSAVE (and related) instruction support.	
25	AES: AES instruction support. Read-only. Reset: X. AES instruction support.	

24	Reserved.
23	POPCNT. Read-only. Reset: Fixed,1. POPCNT instruction.
22	MOVBE. Read-only. Reset: Fixed,1. MOVBE instruction support.
21	<b>X2APIC</b> . Read-only. Reset: Fixed,1. x2APIC capability.
20	SSE42. Read-only. Reset: Fixed,1. SSE4.2 instruction support.
19	SSE41. Read-only. Reset: Fixed,1. SSE4.1 instruction support.
18:14	Reserved.
13	CMPXCHG16B. Read-only. Reset: Fixed,1. CMPXCHG16B instruction.
12	FMA. Read-only. Reset: Fixed,1. FMA instruction support.
11:10	Reserved.
9	SSSE3. Read-only. Reset: Fixed,1. Supplemental SSE3 extensions.
8:4	Reserved.
3	Monitor. Read-only. Reset: !Core::X86::Msr::HWCR[MonMwaitDis]. Monitor/Mwait instructions.
2	Reserved.
1	PCLMULQDQ. Read-only. Reset: X. PCLMULQDQ instruction support.
0	SSE3. Read-only. Reset: Fixed,1. SSE3 extensions.

### CPUID\_Fn00000001\_EDX [Feature Identifiers] (Core::X86::Cpuid::FeatureIdEdx)

CPUL	D_Fn00000001_EDX [Feature Identifiers] (Core::X86::Cpuid::FeatureIdEdx)		
Read-	Read-only.		
These values can be over-written by Core::X86::Msr::CPUID_Features.			
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000001_EDX			
	Description		
31:29	Reserved.		
28	<b>HTT</b> . Read-only. Reset: Fixed,(Core::X86::Cpuid::SizeId[NC] != 0). 0=Single thread product		
	(Core::X86::Cpuid::SizeId[NC] == 0). 1=Multi thread product (Core::X86::Cpuid::SizeId[NC] != 0). Hyper-		
	threading technology.		
27	Reserved.		
26	SSE2. Read-only. Reset: Fixed,1. SSE2: SSE2 extensions.		
25	SSE. Read-only. Reset: Fixed,1. SSE extensions.		
24	<b>FXSR</b> . Read-only. Reset: Fixed,1. FXSAVE and FXRSTOR instructions.		
23	MMX. Read-only. Reset: Fixed,1. MMX instructions		
22:20	Reserved.		
19	CLFSH. Read-only. Reset: Fixed,1. CLFLUSH instruction.		
18	Reserved.		
17	<b>PSE36</b> . Read-only. Reset: Fixed,1. Page-size extensions.		
16	<b>PAT</b> . Read-only. Reset: Fixed,1. Page attribute table.		
15	CMOV. Read-only. Reset: Fixed,1. Conditional move instructions, CMOV, FCOMI, FCMOV.		
14	MCA. Read-only. Reset: Fixed,1. Machine check architecture, MCG_CAP.		
13	<b>PGE</b> . Read-only. Reset: Fixed,1. Page global extension, CR4.PGE.		
12	MTRR. Read-only. Reset: Fixed,1. Memory-type range registers.		
11	SysEnterSysExit. Read-only. Reset: Fixed,1. SYSENTER and SYSEXIT instructions.		
10	Reserved.		
9	<b>APIC</b> : advanced programmable interrupt controller (APIC) exists and is enabled. Read-only. Reset: X.		
	Core::X86::Msr::APIC_BAR[ApicEn].		
8	CMPXCHG8B. Read-only. Reset: Fixed,1. CMPXCHG8B instruction.		
7	MCE. Read-only. Reset: Fixed,1. Machine check exception, CR4.MCE.		
6	PAE. Read-only. Reset: Fixed,1. Physical-address extensions (PAE).		
5	MSR. Read-only. Reset: Fixed,1. AMD model-specific registers (MSRs), with RDMSR and WRMSR		
	instructions.		

4	TSC. Read-only. Reset: Fixed,1. Time Stamp Counter, RDTSC/RDTSCP instructions, CR4.TSD.
3	<b>PSE</b> . Read-only. Reset: Fixed,1. Page-size extensions (4 MB pages).
2	<b>DE</b> . Read-only. Reset: Fixed,1. Debugging extensions, IO breakpoints, CR4.DE.
1	VME. Read-only. Reset: Fixed,1. Virtual-mode enhancements.
0	<b>FPU</b> . Read-only. Reset: Fixed,1. x87 floating point unit on-chip.

### CPUID\_Fn00000005\_EAX [Monitor/MWait] (Core::X86::Cpuid::MonMWaitEax)

01 01.	== noovoos=ni [niomeoi/ni // me] (coreviioovopmuv/niom/i // me=mi)	
Read-only. Reset: Fixed,0000_0040h.		
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000005_EAX	
Bits	Description	
31:16	Reserved.	
15:0	MonLineSizeMin. Read-only. Reset: Fixed,0040h. Smallest monitor-line size in bytes.	

### CPUID\_Fn00000005\_EBX [Monitor/MWait] (Core::X86::Cpuid::MonMWaitEbx)

Read-	Read-only. Reset: Fixed,0000_0040h.	
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000005_EBX	
Bits	Description	
31:16	Reserved.	
15:0	MonLineSizeMax. Read-only. Reset: Fixed,0040h. Largest monitor-line size in bytes.	

### CPUID\_Fn00000005\_ECX [Monitor/MWait] (Core::X86::Cpuid::MonMWaitEcx)

	,	
Read-	Read-only. Reset: Fixed,0000_0003h.	
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000005_ECX		
Bits	Description	
31:2	Reserved.	
1	IBE. Read-only. Reset: Fixed,1. Interrupt break-event.	
0	<b>EMX</b> . Read-only. Reset: Fixed,1. Enumerate MONITOR/MWAIT extensions.	

### CPUID\_Fn00000005\_EDX [Monitor/MWait] (Core::X86::Cpuid::MonMWaitEdx)

Read-	Read-only. Reset: Fixed,0000_0011h.	
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000005_EDX		
Bits	Description	
31:8	Reserved.	
7:4	<b>MWaitC1SubStates</b> . Read-only. Reset: Fixed,1h. Number of C1 sub-cstates supported by MWAIT.	
3:0	<b>MWaitC0SubStates</b> . Read-only. Reset: Fixed,1h. Number of C0 sub-cstates supported by MWAIT.	

### CPUID\_Fn0000006\_EAX [Thermal and Power Management] (Core::X86::Cpuid::ThermalPwrMgmtEax)

Read-	Read-only. Reset: Fixed,0000_0004h.			
_lthree[1	L:0]_core[3:0]_thread[1:0]; CPUID_Fn00000006_EAX			
Bits	Description			
31:3	Reserved.			
2	<b>ARAT</b> : always running APIC timer. Read-only. Reset: Fixed,1. 1=Indicates support for APIC timer always			
	running feature.			
1:0	Reserved.			

### CPUID\_Fn0000006\_EBX [Thermal and Power Management] (Core::X86::Cpuid::ThermalPwrMgmtEbx)

	[ [		
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000006_EBX			
Bits	Description		
31:0	Reserved.		

### CPUID\_Fn00000006\_ECX [Thermal and Power Management] (Core::X86::Cpuid::ThermalPwrMgmtEcx)

Read-only. Reset: Fixed,0000\_0001h.

These	These values can be over-written by Core::X86::Msr::CPUID_PWR_THERM.			
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000006_ECX			
Bits	Description			
31:1	Reserved.			
0	EffFreq: effective frequency interface. Read-only. Reset: Fixed,1. 1=Indicates presence of			
	Core::X86::Msr::MPERF and Core::X86::Msr::APERF.			

### CPUID\_Fn00000006\_EDX [Thermal and Power Management] (Core::X86::Cpuid::ThermalPwrMgmtEdx)

		 •	 	,
_lthree[1	1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000006_EDX			
Bits	Description			
31:0	Reserved.			

### $CPUID\_Fn00000007\_EAX\_x00\ [Structured\ Extended\ Feature\ Identifiers]$

(Core::X86::Cpuid::StructExtFeatIdEax0)

(	······································		
Read-only. Reset: Fixed,0000_0000h.			
_lthree[1	l:0]_core[3:0]_thread[1:0]; CPUID_Fn00000007_EAX_x00		
Bits	Description		
31:0	<b>StructExtFeatIdMax</b> . Read-only. Reset: Fixed,0000_0000h. The largest CPUID Fn0000_0007 sub-function		
	supported by the processor implementation.		

## CPUID\_Fn0000007\_EBX\_x00 [Structured Extended Feature Identifiers] (Core::X86::Cpuid::StructExtFeatIdEbx0)

(	mion option of activities (			
	only. Reset: Fixed,219C_91A9h.			
	:0]_core[3:0]_thread[1:0]; CPUID_Fn00000007_EBX_x00			
Bits	Description			
31:30	Reserved.			
29	<b>SHA</b> . Read-only. Reset: Fixed,1. 1=SHA Extensions available.			
28:25	Reserved.			
24	<b>CLWB</b> . Read-only. Reset: Fixed,1. Cache line write back.			
23	CLFSHOPT. Read-only. Reset: Fixed,1. Optimized Cache Line Flush.			
22:21	Reserved.			
20	<b>SMAP</b> . Read-only. Reset: Fixed,1. Secure Mode Access Prevention is supported.			
19	ADX. Read-only. Reset: Fixed,1. ADCX and ADOX are present.			
18	RDSEED. Read-only. Reset: Fixed,1. RDSEED is present.			
17:16	Reserved.			
15	<b>PQE</b> . Read-only. Reset: Fixed,1. The processor supports Cache Allocation Technology.			
14:13	Reserved.			
12	<b>PQM</b> . Read-only. Reset: Fixed,1. Platform QoS Monitoring.			
11:9	Reserved.			
8	<b>BMI2</b> . Read-only. Reset: Fixed,1. Bit manipulation group 2 instruction support.			
7	<b>SMEP</b> . Read-only. Reset: Fixed,1. Supervisor Mode Execution protection.			
6	Reserved.			
5	AVX2. Read-only. Reset: Fixed,1. AVX extension support.			
4	Reserved.			
3	<b>BMI1</b> . Read-only. Reset: Fixed,1. Bit manipulation group 1 instruction support.			
2:1	Reserved.			
0	<b>FSGSBASE</b> . Read-only. Reset: Fixed,1. FS and GS base read write instruction support.			

### CPUID\_Fn00000007\_ECX\_x00 [Structured Extended Feature Identifier]

(Core::X86::Cpuid::StructExtFeatIdEcx0)

Read-only. Reset: Fixed,0040\_0004h.

_lthree[1	_tthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn00000007_ECX_x00		
Bits	Description		
31:23	Reserved.		
22	<b>RDPID</b> . Read-only. Reset: Fixed,1. Read Processor ID instruction support.		
21:3	Reserved.		
2	<b>UMIP</b> . Read-only. Reset: Fixed,1. User Mode Instruction Prevention enable.		
1:0	Reserved.		

### $CPUID\_Fn00000007\_EDX\_x00\ [Structured\ Extended\ Feature\ Identifiers]$

(Core::X86::Cpuid::StructExtFeatIdEdx0)

Reset:	0000_0000h.				
_lthree[1	l:0]_core[3:0]_thread[1:0]; CPUID_Fn00000007_EDX_x00				
Bits	Description				
31:0	Reserved.				

### CPUID\_Fn0000000B\_EAX\_x00 [Extended Topology Enumeration] (Core::X86::Cpuid::ExtTopEnumEax0)

Read-only. Enable: (Core::X86::Cpuid::ExtTopEnumEbx0 > 0).

CPUID Fn0000\_000B\_E[D,C,B,A]X\_x[2:0] specifies the hierarchy of logical cores from the SMT level through the processor socket level.

Software determines the presence of CPUID Fn0000\_000B if (CPUID Fn0000\_000B\_EBX\_x0[31:0] != 0). Software reads CPUID Fn0000\_000B\_E[C,B,A]X for ascending values of ECX until (CPUID

 $Fn0000\_000B\_EBX[LogProcAtThisLevel] == 0).$ 

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn0000000B\_EAX\_x00

Bits	Description
31:5	Reserved.
4:0	<b>CoreMaskWidth</b> . Read-only. Number of bits to shift ExtendedApicId right to get unique topology ID of the next
	level type.
	Reset: SMT ? 01h : 00h.

### CPUID\_Fn0000000B\_EBX\_x00 [Extended Topology Enumeration] (Core::X86::Cpuid::ExtTopEnumEbx0)

Read-	only.
_lthree[1	1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000B_EBX_x00
Bits	Description
31:16	Reserved.
15:0	LogProcAtThisLevel. Read-only. Number of threads in a core.
	Reset: SMT ? 2: 0001h.

### CPUID Fn0000000B ECX x00 [Extended Topology Enumeration] (Core::X86::Cpuid::ExtTopEnumEcx0)

CI CI	elb_indutudub_leni_kto [Ektended lopology Endmerddon] (edietiindott epunditekt)							
Read-o	ad-only. Reset: Fixed,0000_0100h. Enable: (Core::X86::Cpuid::ExtTopEnumEbx0 > 0).							
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000B_ECX_x00							
Bits	Description							
31:16	Reserved.							
15:8	LevelType. Read-only. Reset: Fixed,01h.							
	ValidValues:							
	Value Description							
	00h Invalid							
	01h	01h Thread						
	02h	02h Processor						
	FFh-	Reserved.						
	03h							

03h

7:0	EcxVal.	Read-only.	Reset:	Fixed.00h.	ECX input value.
-----	---------	------------	--------	------------	------------------

### CPUID Fn0000000B EAX x01 [Extended Topology Enumeration] (Core::X86::Cpuid::ExtTopEnumEax1)

01 01	== no o o o o o == == == == == == == == == =	
Read-only. Enable: (Core::X86::Cpuid::ExtTopEnumEbx1 > 0).  _lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000B_EAX_x01		
31:5	Reserved.	
4:0	CoreMaskWidth. Read-only. ExtendedApicId right shift value.	
	Reset: SMT ? 7 : 6.	

### CPUID\_Fn0000000B\_EBX\_x01 [Extended Topology Enumeration] (Core::X86::Cpuid::ExtTopEnumEbx1)

Read-	Read-only.	
_lthree[1	three[1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000B_EBX_x01	
Bits	Bits Description	
31:16	Reserved.	
15:0	LogProcAtThisLevel. Read-only. Reset: XXXXh. Number of logical cores in processor socket.	

### CPUID\_Fn0000000B\_ECX\_x01 [Extended Topology Enumeration] (Core::X86::Cpuid::ExtTopEnumEcx1)

CPUII	CPUID_FIN0000000B_ECX_x01 [Extended Topology Enumeration] (Core::x86::Cpuid::ExtTopEnumEcx1)			
Read-o	Read-only. Reset: Fixed,0000_0201h. Enable: (Core::X86::Cpuid::ExtTopEnumEbx1 > 0).			
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000B_ECX_x01			
Bits	Bits Description			
31:16	:16 Reserved.			
15:8	LevelType. Read-only. Reset: Fixed,02h.			
	ValidValues:			
	Value	Description		
	00h	Invalid		
	01h	Thread		
	02h	Processor		
	FFh-	Reserved.		

7:0 **EcxVal**. Read-only. Reset: Fixed,01h. ECX input value.

### CPUID\_Fn0000000B\_EAX\_x02 [Extended Topology Enumeration] (Core::X86::Cpuid::ExtTopEnumEax2)

Read-only. Reset: Fixed,0000\_0000h. Enable: (Core::X86::Cpuid::ExtTopEnumEbx2 > 0).

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn000000B\_EAX\_x02

Bits Description

31:5	Reserved.
4:0	<b>CoreMaskWidth</b> . Read-only. Reset: Fixed,00h. Zero indicates no more levels.

### CPUID\_Fn000000B\_EBX\_x02 [Extended Topology Enumeration] (Core::X86::Cpuid::ExtTopEnumEbx2)

Read-only. Reset: 0000_0000hlthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000B_EBX_x02		
		Bits
31:16	Reserved.	
15:0	LogProcAtThisLevel. Read-only. Reset: 0000h. Zero indicates no more levels.	

### CPUID\_Fn0000000B\_ECX\_x02 [Extended Topology Enumeration] (Core::X86::Cpuid::ExtTopEnumEcx2)

Read-only. Reset: Fixed,0000_0002h. Enable: (Core::X86::Cpuid::ExtTopEnumEbx2 > 0).			
_lthree[1	:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000B_ECX_x02		
Bits	Bits Description		
31:16	Reserved.		
15:8 LevelType, Read-only, Reset: Fixed.00h, Zero indicates no more levels.			

	ues:	
	Value	Description
	00h	Invalid
	01h	Thread
	02h	Processor
	FFh-	Reserved.
	03h	
7:0 <b>EcxVal</b> . Read-only. Reset: Fixed,02h. ECX input value.		Read-only. Reset: Fixed,02h. ECX input value.

### CPUID\_Fn0000000B\_EDX [Extended Topology Enumeration] (Core::X86::Cpuid::ExtTopEnumEdx)

Read-	only.			
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000B_EDX			
Bits	Bits Description			
31:0	ExtendedLocalApicId: extended APIC ID. Read-only. Reset: XXXX_XXXXh. Extended APIC_ID.			

### CPUID\_Fn000000D\_EAX\_x00 [Processor Extended State Enumeration]

(Core::X86::Cpuid::ProcExtStateEnumEax00)

Read-only. Reset: Fixed,0000\_0007h.

lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn0000000D\_EAX\_x00

### Bits Description

31:0 **XFeatureSupportedMask[31:0]**. Read-only. Reset: Fixed,0000\_0007h. Each set bit indicates the corresponding bit in register XCR0[31:0] is settable.

### ValidValues:

Bit	Name	Description
[0]	X87	X87 Support.
[1]	SSE	128-bit SSE Support.
[2]	AVX	256-bit AVX support.
[31:3]		Reserved.

### CPUID\_Fn000000D\_EBX\_x00 [Processor Extended State Enumeration]

(Core::X86::Cpuid::ProcExtStateEnumEbx00)

	*			
Read-	Read-only, Volatile.			
_lthree[1	:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000D_EBX_x00			
Bits	Description			
31:0	XFeatureEnabledSizeMax. Read-only, Volatile. Reset: XXXX_XXXXh.			
	<b>Description</b> : Size in bytes of an uncompacted XSAVE/XRSTOR area for all features enabled in the XCR0			
	register.			
	IF (XCR0[AVX] == 1)			
	Return EBX = 0000_0340h // legacy header + X87/SSE + AVX size			
	ELSIF (XCR0[SSE] == 1)			
	Return EBX=0000_0240h // legacy header + X87/SSE size			
	ELSIF (XCR0[X87] == 1)			
	Return EBX = 0000_0240h			
END				

### CPUID\_Fn0000000D\_ECX\_x00 [Processor Extended State Enumeration]

(Core::X86::Cpuid::ProcExtStateEnumEcx00)

Read-	Read-only. Reset: Fixed,0000_0400h.		
_lthree[1	1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000D_ECX_x00		
Bits	Bits Description		
24.0	<b>XFeatureSupportedSizeMax</b> . Read-only. Reset: Fixed,0000_0400h. Size of legacy header + X87/SSE + AVX.		

### CPUID\_Fn000000D\_EDX\_x00 [Processor Extended State Enumeration] (Core::X86::Cpuid::ProcExtStateEnumEdx00)

(0010	(Mileon Sparator recent action)		
Read-only. Reset: Fixed,0000_0000h.			
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000D_EDX_x00		
Bits	Bits Description		
31:0 <b>XFeatureSupportedMask[63:32]</b> . Read-only. Reset: Fixed,0000_0000h. Each set bit indicates the correspon			
	bit in register XCR0[63:32] is settable.		

### CPUID\_Fn000000D\_EAX\_x01 [Processor Extended State Enumeration]

(Core::X86::Cpuid::ProcExtStateEnumEax01)

_	···				
Read-	Read-only. Reset: Fixed,0000_000Fh.				
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn000000D_EAX_x01					
Bits	ts Description				
31:4	4 Reserved.				
3	XSAVES. Read-only. Reset: Fixed,1. XSAVES,XRSTORS, and XSS supported.				
2	<b>XGETBV</b> . Read-only. Reset: Fixed,1. XGETBV with ECX = 1 supported.				
1	<b>XSAVEC</b> . Read-only. Reset: Fixed,1. XSAVEC and compact XRSTOR supported.				
0	<b>XSAVEOPT</b> . Read-only. Reset: Fixed,1. XSAVEOPT is available.				

### CPUID\_Fn000000D\_EBX\_x01 [Processor Extended State Enumeration]

(Core::X86::Cpuid::ProcExtStateEnumEbx01)

lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn0000000D\_EBX\_x01

	Bits	Description
	31:0	<b>XFeatureEnabledSizeMax</b> . Read-only, Volatile. Reset: XXXX_XXXh. Value is 512 + ((XCR0[AVX])? 256:
- 1		

Read-only, Volatile.

ValidValu	ValidValues:						
Value	Description						
0000_0	_0 Reserved.						
23Fh-							
0000_0							
000h							
0000_0	Legacy header + FPU/SSE size; (XCR0[AVX] == 0)						
240h							
0000_0	Reserved.						
33Fh-							
0000_0							
241h							
0000_0	Legacy header + FPU/SSE + AVX size; (XCR0[AVX] == 1)						
340h							
FFFF_F	Reserved.						
FFFh-							
0000_0							
341h							

### CPUID\_Fn000000D\_ECX\_x01 [Processor Extended State Enumeration]

(Core::X86::Cpuid::ProcExtStateEnumEcx01)

Read-only. Reset: Fixed,0000_0000h.					
_tthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000D_ECX_x01					
Bits Description					
31:0 Reserved.					

CPUID\_Fn000000D\_EDX\_x01 [Processor Extended State Enumeration]

(Core::X86::Cpuid::ProcExtStateEnumEdx01)

Read-only. Reset: Fixed,0000\_0000h.

lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn0000000D\_EDX\_x01

Bits Description

31:0 Reserved.

CPUID\_Fn000000D\_EAX\_x02 [Processor Extended State Enumeration]

(Core::X86::Cpuid::ProcExtStateEnumEax02)

Read-only. Reset: Fixed,0000\_0100h.

lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn0000000D\_EAX\_x02

Bits | Description

31:0 **YmmSaveStateSize**. Read-only. Reset: Fixed,0000\_0100h. YMM save state byte size.

CPUID\_Fn000000D\_EBX\_x02 [Processor Extended State Enumeration]

(Core::X86::Cpuid::ProcExtStateEnumEbx02)

Read-only. Reset: Fixed,0000 0240h.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn0000000D\_EBX\_x02

Bits Description

31:0 **YmmSaveStateOffset**. Read-only. Reset: Fixed,0000\_0240h. YMM save state byte offset.

CPUID\_Fn000000D\_ECX\_x02 [Processor Extended State Enumeration]

(Core::X86::Cpuid::ProcExtStateEnumEcx02)

Read-only. Reset: Fixed,0000 0000h.

lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn0000000D\_ECX\_x02

Bits Description

31:0 Reserved.

CPUID\_Fn000000D\_EDX\_x02 [Processor Extended State Enumeration]

(Core::X86::Cpuid::ProcExtStateEnumEdx02)

Read-only. Reset: Fixed.0000 0000h.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn0000000D\_EDX\_x02

Bits Description

31:0 | Reserved.

CPUID\_Fn0000000F\_EAX\_x00 [Resource Director Technology Monitor Capability]

(Core::X86::Cpuid::RsrcDirTechMonCapEax0)

Read-only. Reset: Fixed,0000\_0000h.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn0000000F\_EAX\_x00

Bits Description

31:0 Reserved.

CPUID\_Fn0000000F\_EBX\_x00 [Resource Director Technology Monitor Capability]

(Core::X86::Cpuid::RsrcDirTechMonCapEbx0)

Read-only. Reset: Fixed,0000 00FFh.

lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn0000000F\_EBX\_x00

Bits Description

31:0 **RmidMaxRange**. Read-only. Reset: Fixed,0000\_00FFh. RMID maximum within this processor for all types.

CPUID Fn0000000F ECX x00 [Resource Director Technology Monitor Capability]

(Core::X86::Cpuid::RsrcDirTechMonCapEcx0)

Read-only. Reset: Fixed,0000 0000h.

Reserved.

_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000F_ECX_x00				
Bits	Description			
31:0	Reserved.			

## CPUID\_Fn0000000F\_EDX\_x00 [Resource Director Technology Monitor Capability] (Core: X86: Cpuid: RsrcDirTechMonCapEdx0)

(Core	.AooCpuluRsi CDII Technoli Capituxo)						
Read-only. Reset: Fixed,0000_0002h.							
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000F_EDX_x00							
Bits	Description						
31:2	31:2 Reserved.						
1	L3CacheRDT. Read-only. Reset: Fixed,1. L3 Cache RDT Monitoring.						

## CPUID\_Fn000000F\_EAX\_x01 [Resource Director Technology L3 Monitor Capability] (Core::X86::Cpuid::RsrcDirTechMonCapEax1)

Read-only. Reset: Fixed,0000_0000h.							
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000F_EAX_x01							
Bits	Bits Description						
31:0 Reserved.							

## CPUID\_Fn0000000F\_EBX\_x01 [Resource Director Technology L3 Monitor Capability] (Core::X86::Cpuid::RsrcDirTechMonCapEbx1)

Read-only. Reset: Fixed,0000_0040h.					
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000F_EBX_x01					
Bits Description 31:0 ConverFactor. Read-only. Reset: Fixed,0000 0040h. Conversion Factor.					

## CPUID\_Fn0000000F\_ECX\_x01 [Resource Director Technology L3 Monitor Capability] (Core::X86::Cpuid::RsrcDirTechMonCapEcx1)

Read-	Read-only. Reset: Fixed,0000_00FFh.					
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000F_ECX_x01					
Bits	s Description					
31:0	31:0 <b>RmidMaxRange</b> . Read-only. Reset: Fixed,0000_00FFh. RMID Maximum Range of this resourse.					

## CPUID\_Fn0000000F\_EDX\_x01 [Resource Director Technology L3 Monitor Capability] (Core::X86::Cpuid::RsrcDirTechMonCapEdx1)

Read-	nd-only. Reset: Fixed,0000_0007h.				
_lthree[1	lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn0000000F_EDX_x01				
Bits Description					
31:3	Reserved.				
2	L3CacheLocalBndwdthMon. Read-only. Reset: Fixed,1. L3 Local Bandwidth monitoring.				
<ul> <li>L3CacheTotalBndwdthMon. Read-only. Reset: Fixed,1. L3 Total Bandwidth monitoring.</li> <li>L3CacheOccpncyMon. Read-only. Reset: Fixed,1. L3 occupancy monitoring.</li> </ul>					

## CPUID\_Fn00000010\_EAX\_x00 [Resource Director Technology Allocation Enumeration] (Core::X86::Cpuid::RsrcDirTechAllocEnumEax0)

Read-only. Reset: Fixed,0000_0000h. Enable: (Core::X86::Cpuid::RsrcDirTechAllocEnumEbx0 > 0).
Software determines the presence of CPUID Fn0000_0010 if (CPUID Fn0000_0010_EBX_x0[31:0] != 0). Software
Reads CPUID Fn0000_0010_E[D,C,B,A]X for ascending values of ECX until (CPUID
Fn0000 0010 EBX[LogProcAtThisLevel] == 0

_lthree[1	:0]	_core	3:0	]_thread[1:0];	CPUID	_Fn00000010_	_EAX	_x00
				_				

	Description
31:0	Reserved.

## CPUID\_Fn00000010\_EBX\_x00 [Resource Director Technology Allocation Enumeration] (Core::X86::Cpuid::RsrcDirTechAllocEnumEbx0)

(	······································	
Read-	Read-only. Reset: 0000_0002h.	
_lthree[1	:0]_core[3:0]_thread[1:0]; CPUID_Fn00000010_EBX_x00	
Bits	Description	
31:3	Reserved.	
2	L2CacheAllocTech. Read-only. Reset: 0. L2 Cache Allocation Technology.	
1	L3CacheAllocTech. Read-only. Reset: 1. L3 Cache Allocation Technology.	
0	Reserved.	

## CPUID\_Fn00000010\_ECX\_x00 [Resource Director Technology Allocation Enumeration] (Core::X86::Cpuid::RsrcDirTechAllocEnumEcx0)

Read-only. Reset: Fixed,0000\_0000h. Enable: (Core::X86::Cpuid::RsrcDirTechAllocEnumEbx0 > 0).
\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn00000010\_ECX\_x00

Bits Description

31:0 Reserved.

## CPUID\_Fn00000010\_EDX\_x00 [Resource Director Technology Allocation Enumeration] (Core::X86::Cpuid::RsrcDirTechAllocEnumEdx0)

Read-only. Reset: Fixed,0000\_0000h. Enable: (Core::X86::Cpuid::RsrcDirTechAllocEnumEbx0 > 0).

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn0000010\_EDX\_x00

Bits Description

31:0 Reserved.

## CPUID\_Fn00000010\_EAX\_x01 [Resource Director Technology L3 Allocation Enumeration] (Core::X86::Cpuid::RsrcDirTechAllocEnumEax1)

Read-only. Enable: (Core::X86::Cpuid::RsrcDirTechAllocEnumEbx1 > 0).

\_\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn00000010\_EAX\_x01

Bits Description

31:5 Reserved.

4:0 CapacityMask. Read-only. Reset: Fixed,0Fh. Capacity bitmask length.

## CPUID\_Fn00000010\_EBX\_x01 [Resource Director Technology L3 Allocation Enumeration] (Core::X86::Cpuid::RsrcDirTechAllocEnumEbx1)

 Read-only. Reset: 0000\_0000h.

 \_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn00000010\_EBX\_x01

 Bits Description

 31:0 AllocUnits. Read-only. Reset: 0000\_0000h. Allocation Units.

## CPUID\_Fn00000010\_ECX\_x01 [Resource Director Technology L3 Allocation Enumeration] (Core::X86::Cpuid::RsrcDirTechAllocEnumEcx1)

Read-only. Reset: Fixed,0000\_0004h. Enable: (Core::X86::Cpuid::RsrcDirTechAllocEnumEbx1 > 0).

\_lthree[::0]\_core[3:0]\_thread[1:0]; CPUID\_Fn0000010\_ECX\_x01

Bits Description

31:3 Reserved.

2 CDP. Read-only. Reset: Fixed,1. Code and data prioritization.

1:0 Reserved.

## CPUID\_Fn00000010\_EDX\_x01 [Resource Director Technology L3 Allocation Enumeration] (Core::X86::Cpuid::RsrcDirTechAllocEnumEdx1)

Read-only. Reset: Fixed,0000\_000Fh. Enable: (Core::X86::Cpuid::RsrcDirTechAllocEnumEbx1 > 0).

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn00000010\_EDX\_x01

### Bits Description

31:16	Reserved.
15:0	HCS. Read-only. Reset: Fixed,000Fh. Highest COS supported.

### CPUID\_Fn80000000\_EAX [Largest Extended Function Number] (Core::X86::Cpuid::LargExtFuncNum)

Read-only. Reset: Fixed,8000\_0020h.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn80000000\_EAX

### Bits Description

31:0 **LFuncExt**: **largest extended function**. Read-only. Reset: Fixed,8000\_0020h. The largest CPUID extended function input value supported by the processor implementation.

### CPUID\_Fn80000000\_EBX [Processor Vendor (ASCII Bytes [3:0])] (Core::X86::Cpuid::ProcVendExtEbx)

Read-only. Reset: Fixed,6874 7541h.

Core::X86::Cpuid::ProcVendEbx and Core::X86::Cpuid::ProcVendExtEbx return the same value.

lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn80000000\_EBX

### Bits Description

31:0 **Vendor**. Read-only. Reset: Fixed,6874\_7541h. ASCII Bytes [3:0] ("h t u A") of the string "AuthenticAMD".

### CPUID\_Fn80000000\_ECX [Processor Vendor (ASCII Bytes [11:8])] (Core::X86::Cpuid::ProcVendExtEcx)

Read-only. Reset: Fixed,444D\_4163h.

Core::X86::Cpuid::ProcVendEcx and Core::X86::Cpuid::ProcVendExtEcx return the same value.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn80000000\_ECX

### Bits Description

31:0 **Vendor**. Read-only. Reset: Fixed,444D\_4163h. ASCII Bytes [11:8] ("D M A c") of the string "AuthenticAMD".

### CPUID\_Fn80000000\_EDX [Processor Vendor (ASCII Bytes [7:4])] (Core::X86::Cpuid::ProcVendExtEdx)

Read-only. Reset: Fixed,6974 6E65h.

Core::X86::Cpuid::ProcVendEdx and Core::X86::Cpuid::ProcVendExtEdx return the same value.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn80000000\_EDX

### Bits | Description

31:0 **Vendor**. Read-only. Reset: Fixed,6974\_6E65h. ASCII Bytes [7:4] ("i t n e") of the string "AuthenticAMD".

### CPUID\_Fn80000001\_EAX [Family, Model, Stepping Identifiers] (Core::X86::Cpuid::FamModStepExt)

Read-only.

Core::X86::Cpuid::FamModStep and Core::X86::Cpuid::FamModStepExt return the same value. See

Core::X86::Cpuid::FamModStep.

lthree[1:0] core[3:0] thread[1:0]; CPUID Fn80000001 EAX

Rite	Description
DIIS	17686111011011

31:28 Reserved.

27:20 **ExtFamily**: **extended family**. Read-only. Reset: 08h. See Core::X86::Cpuid::FamModStep description of Family.

19:16 **ExtModel**: **extended model**. Read-only. Reset: 6h. See Core::X86::Cpuid::FamModStep description of ExtModel.

15:12 Reserved.

11:8 **BaseFamily**. Read-only. Reset: Fh. See Core::X86::Cpuid::FamModStep description of Family.

7:4 **BaseModel**. Read-only. Reset: Xh. Model numbers vary with product.

3:0 **Stepping**. Read-only. Reset: 1h. Processor stepping (revision) for a specific model.

### CPUID\_Fn80000001\_EBX [BrandId Identifier] (Core::X86::Cpuid::BrandId)

### Read-only.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn80000001\_EBX

### Bits Description

31:28 **PkgType**: package type. Read-only. Reset: Xh. Specifies the package type.

ValidValues:

	Value	Description
	0h	FP6
	1h	Reserved.
	2h	AM4
	Fh-3h	Reserved.
27:0	Reserved.	,

	Fh-3h   Reserved.
27:0	Reserved.
CPIII	D_Fn80000001_ECX [Feature Identifiers] (Core::X86::Cpuid::FeatureExtIdEcx)
Read-	
	values can be over-written by Core::X86::Msr::CPUID_ExtFeatures.
	1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000001_ECX
	Description
31	Reserved.
30	AdMskExtn: address mask extension support for instruction breakpoint. Read-only. Reset: Fixed,1. Indicates
	support for address mask extension (to 32 bits and to all 4 DRs) for instruction breakpoints.
29	<b>MwaitExtended</b> . Read-only. Reset: !Core::X86::Msr::HWCR[MonMwaitDis]. 1=MWAITX and MONITORX
	capability is supported.
28	<b>PerfCtrExtLLC:</b> Last Level Cache performance counter extensions. Read-only. Reset: Fixed,1. 1=Indicates
	support for Core::X86::Msr::ChL3PmcCfg and Core::X86::Msr::ChL3Pmc L3 performance counter extensions.
	L3 performance counter extensions support. See 2.1.15.4 [L3 Cache Performance Monitor Counters] and 2.1.15
	[Performance Monitor Counters].
27	<b>PerfTsc</b> . Read-only. Reset: Fixed,0. Performance time-stamp counter supported.
26	<b>DataBreakpointExtension</b> . Read-only. Reset: Fixed,1. 1=Indicates data breakpoint support for
	Core::X86::Msr::DR0_ADDR_MASK, Core::X86::Msr::DR1_ADDR_MASK,
	Core::X86::Msr::DR2_ADDR_MASK and Core::X86::Msr::DR3_ADDR_MASK.
25	Reserved.
24	<b>PerfCtrExtDF: data fabric performance counter extensions support</b> . Read-only. Reset: Fixed,1. 1=Indicates
	support for Core::X86::Msr::DF_PERF_CTL and Core::X86::Msr::DF_PERF_CTR.
23	<b>PerfCtrExtCore</b> : <b>core performance counter extensions support</b> . Read-only. Reset: Fixed,1. 1=Indicates
	support for Core::X86::Msr::PERF_CTL and Core::X86::Msr::PERF_CTR. See See 2.1.15.3 [Core Performance
	Monitor Counters] and 2.1.15 [Performance Monitor Counters].
22	<b>TopologyExtensions: topology extensions support</b> . Read-only. Reset: Fixed,1. 1=Indicates support for
	Core::X86::Cpuid::CachePropEax0 and Core::X86::Cpuid::ExtApicId.
21:18	
17	TCE. Read-only. Reset: Fixed,1. Translation cache extension.
16	<b>FMA4</b> . Read-only. Reset: Fixed,0. Four-operand FMA instruction support.
15	<b>LWP</b> . Read-only. Reset: Fixed,0. Lightweight profiling support.
14	Reserved.
13	WDT. Read-only. Reset: Fixed,1. Watchdog timer support.
12	SKINIT. Read-only. Reset: Fixed,1. SKINIT and STGI support.
11	XOP. Read-only. Reset: Fixed,0. Extended operation support.
10	IBS. Read-only. Reset: Fixed,1. Instruction Based Sampling.
9	OSVW. Read-only. Reset: Fixed,1. OS Visible Work-around support.
8	ThreeDNowPrefetch. Read-only. Reset: Fixed,1. Prefetch and PrefetchW instructions.
7	MisAlignSse. Read-only. Reset: Fixed,1. Misaligned SSE Mode.
6	<b>SSE4A</b> . Read-only. Reset: Fixed,1. EXTRQ, INSERTQ, MOVNTSS, and MOVNTSD instruction support.
5	<b>ABM</b> : advanced bit manipulation. Read-only. Reset: Fixed,1. LZCNT instruction support.
4	AltMovCr8. Read-only. Reset: Fixed,1. LOCK MOV CR0 means MOV CR8.
3	ExtApicSpace. Read-only. Reset: Fixed,1. Extended APIC register space.
2	SVM: Secure Virtual Mode feature. Read-only. Reset: Fixed,1. Indicates support for: VMRUN, VMLOAD,

	VMSAVE, CLGI, VMMCALL, and INVLPGA.
	<b>CmpLegacy</b> . Read-only. Reset: Fixed,(Core::X86::Cpuid::SizeId[NC] > 0). 0=Single core product (Core::X86::Cpuid::SizeId[NC] != 0). 1=Multi core product (Core::X86::Cpuid::SizeId[NC] != 0). Core multi-
	processing legacy mode.
0	<b>LahfSahf</b> . Read-only. Reset: Fixed,1. LAHF and SAHF instruction support in 64-bit mode.

### CPUID\_Fn80000001\_EDX [Feature Identifiers] (Core::X86::Cpuid::FeatureExtIdEdx)

CPUL	D_Fn80000001_EDX [Feature Identifiers] (Core::X86::Cpuid::FeatureExtIdEdx)		
Read-	Read-only.		
	These values can be over-written by Core::X86::Msr::CPUID_ExtFeatures.		
	:0]_core[3:0]_thread[1:0]; CPUID_Fn80000001_EDX		
	Description		
31	<b>ThreeDNow</b> . Read-only. Reset: Fixed,0. 3DNow! instructions.		
30	<b>ThreeDNowExt</b> . Read-only. Reset: Fixed,0. AMD extensions to 3DNow! instructions.		
29	LM. Read-only. Reset: Fixed,1. Long Mode.		
28	Reserved.		
27	RDTSCP. Read-only. Reset: Fixed,1. RDTSCP instruction.		
26	<b>Page1GB</b> . Read-only. Reset: Fixed,1. 1-GB large page support.		
25	<b>FFXSR</b> . Read-only. Reset: Fixed,1. FXSAVE and FXRSTOR instruction optimizations.		
24	<b>FXSR</b> . Read-only. Reset: Fixed,1. FXSAVE and FXRSTOR instructions.		
23	MMX. Read-only. Reset: Fixed,1. MMX instructions.		
22	<b>MmxExt</b> . Read-only. Reset: Fixed,1. AMD extensions to MMX instructions.		
21	Reserved.		
20	NX. Read-only. Reset: Fixed,1. No-execute page protection.		
19:18	Reserved.		
17	<b>PSE36</b> . Read-only. Reset: Fixed,1. Page-size extensions.		
16	<b>PAT</b> . Read-only. Reset: Fixed,1. Page attribute table.		
15	CMOV. Read-only. Reset: Fixed,1. Conditional move instructions, CMOV, FCOMI, FCMOV.		
14	MCA. Read-only. Reset: Fixed,1. Machine check architecture, MCG_CAP.		
13	<b>PGE</b> . Read-only. Reset: Fixed,1. Page global extension, CR4.PGE.		
12	MTRR. Read-only. Reset: Fixed,1. Memory-type range registers.		
11	SysCallSysRet. Read-only. Reset: Fixed,1. SYSCALL and SYSRET instructions.		
10	Reserved.		
9	APIC: advanced programmable interrupt controller (APIC) exists and is enabled. Read-only. Reset: X.		
	Reset is Core::X86::Msr::APIC_BAR[ApicEn].		
8	CMPXCHG8B. Read-only. Reset: Fixed,1. CMPXCHG8B instruction.		
7	MCE. Read-only. Reset: Fixed,1. Machine Check Exception, CR4.MCE.		
6	<b>PAE</b> . Read-only. Reset: Fixed,1. Physical-address extensions (PAE).		
5	MSR. Read-only. Reset: Fixed,1. Model-specific registers (MSRs), with RDMSR and WRMSR instructions.		
4	<b>TSC</b> . Read-only. Reset: Fixed,1. Time stamp counter, RDTSC/RDTSCP instructions, CR4.TSD.		
3	<b>PSE</b> . Read-only. Reset: Fixed,1. Page-size extensions (4 MB pages).		
2	<b>DE</b> . Read-only. Reset: Fixed,1. Debugging extensions, IO breakpoints, CR4.DE.		
1	VME. Read-only. Reset: Fixed,1. Virtual-mode enhancements.		
0	<b>FPU</b> . Read-only. Reset: Fixed,1. x87 floating point unit on-chip.		

## CPUID\_Fn80000002\_EAX [Processor Name String Identifier (Bytes [3:0])] (Core::X86::Cpuid::ProcNameStr0Eax)

(CoreXooCptiid1 rochaineoti vLax)	
Read-only.	
Is an alias of Core::X86::Msr::ProcNameString_n0.	
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000002_EAX	
Bits Description	

31:24	<b>ProcNameByte3</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n0[CpuNameString3]. Processor name,
	byte3.
23:16	<b>ProcNameByte2</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n0[CpuNameString2]. Processor name,
	byte2.
15:8	<b>ProcNameByte1</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n0[CpuNameString1]. Processor name,
	h-v-1
	byte1.
7:0	ProcNameByte0. Read-only. Reset: Core::X86::Msr::ProcNameString_n0[CpuNameString0]. Processor name,

# CPUID\_Fn80000002\_EBX [Processor Name String Identifier (Bytes [7:4])] (Core::X86::Cpuid::ProcNameStr0Ebx)

Read-only.	
Is an alias of Core::X86::Msr::ProcNameString_n0.	
_lthree[1:0]_core[3:0]_	thread[1:0]; CPUID_Fn80000002_EBX
Bits Description	on .
31:24 ProcNam	eByte7. Read-only. Reset: Core::X86::Msr::ProcNameString_n0[CpuNameString7]. Processor name,
byte 7.	
23:16 <b>ProcNam</b>	eByte6. Read-only. Reset: Core::X86::Msr::ProcNameString_n0[CpuNameString6]. Processor name,
byte 6.	
15:8 ProcNam	eByte5. Read-only. Reset: Core::X86::Msr::ProcNameString_n0[CpuNameString5]. Processor name,
byte 5.	
7:0 <b>ProcNam</b>	eByte4. Read-only. Reset: Core::X86::Msr::ProcNameString_n0[CpuNameString4]. Processor name,
byte 4.	

# CPUID\_Fn80000002\_ECX [Processor Name String Identifier (Bytes [11:8])] (Core::X86::Cpuid::ProcNameStr0Ecx)

_	1	
Read-	only.	
Is an a	Is an alias of Core::X86::Msr::ProcNameString_n1.	
_lthree[1	:0]_core[3:0]_thread[1:0]; CPUID_Fn80000002_ECX	
Bits	Description	
31:24	ProcNameByte11. Read-only. Reset: Core::X86::Msr::ProcNameString_n1[CpuNameString3]. Processor name,	
	byte 11.	
23:16	ProcNameByte10. Read-only. Reset: Core::X86::Msr::ProcNameString_n1[CpuNameString2]. Processor name,	
	byte 10.	
15:8	<b>ProcNameByte9</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n1[CpuNameString1]. Processor name,	
	byte 9.	
7:0	<b>ProcNameByte8</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n1[CpuNameString0]. Processor name,	
	byte 8.	

# CPUID\_Fn80000002\_EDX [Processor Name String Identifier (Bytes [15:12])] (Core::X86::Cpuid::ProcNameStr0Edx)

(Core::xoo::Cpilid::ProcNallieStroEdx)		
Read-only.		
Is an alias of Core::X86::Msr::ProcNameString_n1.		
_tthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000002_EDX		
Bits Description		
31:24 <b>ProcNameByte15</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n1[CpuNameString7]. Processor name,		
byte 15.		
23:16 <b>ProcNameByte14</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n1[CpuNameString6]. Processor name,		
byte 14.		
15:8 <b>ProcNameByte13</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n1[CpuNameString5]. Processor name,		
byte 13.		
7:0 <b>ProcNameByte12</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n1[CpuNameString4]. Processor name,		

byte 12.

# CPUID\_Fn80000003\_EAX [Processor Name String Identifier (Bytes [19:16])]

#### (Core::X86::Cpuid::ProcNameStr1Eax)

$\mathbf{p}_{c}$	ead		nl	<b>T</b> 7
Πt	au	-υ	ш	٧.

Is an alias of Core::X86::Msr::ProcNameString\_n2.

lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn80000003\_EAX

# Bits Description

- 31:24 **ProcNameByte19**. Read-only. Reset: Core::X86::Msr::ProcNameString\_n2[CpuNameString3]. Processor name, byte 19.
- 23:16 **ProcNameByte18**. Read-only. Reset: Core::X86::Msr::ProcNameString\_n2[CpuNameString2]. Processor name, byte 18.
- 15:8 **ProcNameByte17**. Read-only. Reset: Core::X86::Msr::ProcNameString\_n2[CpuNameString1]. Processor name, byte 17.
- 7:0 **ProcNameByte16**. Read-only. Reset: Core::X86::Msr::ProcNameString\_n2[CpuNameString0]. Processor name, byte 16.

# CPUID\_Fn80000003\_EBX [Processor Name String Identifier (Bytes [23:20])]

## (Core::X86::Cpuid::ProcNameStr1Ebx)

#### Read-only.

Is an alias of Core::X86::Msr::ProcNameString\_n2.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn80000003\_EBX

L	_iunee[i	.oj_core[5.v]_uneau[1.v], Cr OID_Priovovovo_EBX	
	Bits	Description	
	31:24	<b>ProcNameByte23</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n2[CpuNameString7]. Processor name,	
		byte 23.	
	23:16	<b>ProcNameByte22</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n2[CpuNameString6]. Processor name,	
		byte 22.	
	15:8	<b>ProcNameByte21</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n2[CpuNameString5]. Processor name,	
- 11			

byte 21.

7:0 **ProcNameByte20**. Read-only. Reset: Core::X86::Msr::ProcNameString\_n2[CpuNameString4]. Processor name, byte 20.

# CPUID\_Fn80000003\_ECX [Processor Name String Identifier (Bytes [27:24])]

#### (Core::X86::Cpuid::ProcNameStr1Ecx)

#### Read-only.

Is an alias of Core::X86::Msr::ProcNameString\_n3.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn80000003\_ECX

#### Bits Description

- 31:24 **ProcNameByte27**. Read-only. Reset: Core::X86::Msr::ProcNameString\_n3[CpuNameString3]. Processor name, byte 27.
- 23:16 **ProcNameByte26**. Read-only. Reset: Core::X86::Msr::ProcNameString\_n3[CpuNameString2]. Processor name, byte 26.
- 15:8 **ProcNameByte25**. Read-only. Reset: Core::X86::Msr::ProcNameString\_n3[CpuNameString1]. Processor name, byte 25.
- 7:0 **ProcNameByte24**. Read-only. Reset: Core::X86::Msr::ProcNameString\_n3[CpuNameString0]. Processor name, byte 24.

# CPUID\_Fn80000003\_EDX [Processor Name String Identifier (Bytes [31:28])]

# (Core::X86::Cpuid::ProcNameStr1Edx)

Read-only.

Is an alias of Core::X86::Msr::ProcNameString\_n3.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn80000003\_EDX

Bits	Description
31:24	<b>ProcNameByte31</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n3[CpuNameString7]. Processor name,
	byte 31.
23:16	<b>ProcNameByte30</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n3[CpuNameString6]. Processor name,
	byte 30.
15:8	<b>ProcNameByte29</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n3[CpuNameString5]. Processor name,
	byte 29.
7:0	<b>ProcNameByte28</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n3[CpuNameString4]. Processor name,
	byte 28.

# CPUID\_Fn80000004\_EAX [Processor Name String Identifier (Bytes [35:32])] (Core::X86::Cpuid::ProcNameStr2Eax)

_	-	
Read-	only.	
Is an a	Is an alias of Core::X86::Msr::ProcNameString_n4.	
_lthree[1	:0]_core[3:0]_thread[1:0]; CPUID_Fn80000004_EAX	
Bits	Description	
31:24	<b>ProcNameByte35</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n4[CpuNameString3]. Processor name,	
	byte 35.	
23:16	<b>ProcNameByte34</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n4[CpuNameString2]. Processor name,	
	byte 34.	
15:8	<b>ProcNameByte33</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n4[CpuNameString1]. Processor name,	
	byte 33.	
7:0	<b>ProcNameByte32</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n4[CpuNameString0]. Processor name,	
	byte 32.	

# CPUID\_Fn80000004\_EBX [Processor Name String Identifier (Bytes [39:36])] (Core::X86::Cpuid::ProcNameStr2Ebx)

Read-	only.	
Is an a	Is an alias of Core::X86::Msr::ProcNameString_n4.	
_lthree[1	:0]_core[3:0]_thread[1:0]; CPUID_Fn80000004_EBX	
Bits	Description	
31:24	<b>ProcNameByte39</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n4[CpuNameString7]. Processor name,	
	byte 39.	
23:16	<b>ProcNameByte38</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n4[CpuNameString6]. Processor name,	
	byte 38.	
15:8	<b>ProcNameByte37</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n4[CpuNameString5]. Processor name,	
	byte 37.	
7:0	<b>ProcNameByte36</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n4[CpuNameString4]. Processor name,	
	byte 36.	

# CPUID\_Fn80000004\_ECX [Processor Name String Identifier (Bytes [43:40])]

(Core	::X86::Cpuid::ProcNameStr2Ecx)	
Read-	Read-only.	
Is an a	Is an alias of Core::X86::Msr::ProcNameString_n5.	
_lthree[1	:0]_core[3:0]_thread[1:0]; CPUID_Fn80000004_ECX	
Bits	Description	
31:24	<b>ProcNameByte43</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n5[CpuNameString3]. Processor name,	
	byte 43.	
23:16	<b>ProcNameByte42</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n5[CpuNameString2]. Processor name,	
	byte 42.	
15:8	<b>ProcNameByte41</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n5[CpuNameString1]. Processor name,	
	byte 41.	

7:0	<b>ProcNameByte40</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n5[CpuNameString0]. Processor name,
	byte 40.

# CPUID\_Fn80000004\_EDX [Processor Name String Identifier (Bytes [47:44])] (Core::X86::Cpuid::ProcNameStr2Edx)

(0010	5010oureparture 1001.tumeou == un.)		
Read-	Read-only.		
Is an a	lias of Core::X86::Msr::ProcNameString_n5.		
_lthree[1	:0]_core[3:0]_thread[1:0]; CPUID_Fn80000004_EDX		
Bits	Description		
31:24	<b>ProcNameByte47</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n5[CpuNameString7]. Processor name,		
	byte 47.		
23:16	<b>ProcNameByte46</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n5[CpuNameString6]. Processor name,		
	byte 46.		
15:8	<b>ProcNameByte45</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n5[CpuNameString5]. Processor name,		
	byte 45.		
7:0	<b>ProcNameByte44</b> . Read-only. Reset: Core::X86::Msr::ProcNameString_n5[CpuNameString4]. Processor name,		
	byte 44.		

# CPUID\_Fn80000005\_EAX [L1 TLB 2M/4M Identifiers] (Core::X86::Cpuid::L1Tlb2M4M)

Read-	Read-only.			
This function provides the processor's first level cache and TLB characteristics for each core.				
_lthree[1	1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000005_EAX			
Bits	Description			
31:24	L1DTlb2and4MAssoc: data TLB associativity for 2 MB and 4 MB pages. Read-only. Reset: Fixed,FFh. See			
	Core::X86::Cpuid::L1DcId[L1DcAssoc].			
23:16	L1DTlb2and4MSize: data TLB number of entries for 2 MB and 4 MB pages. Read-only. Reset: Fixed,64.			
	The value returned is for the number of entries available for the 2 MB page size; 4 MB pages require two 2 MB			
	entries, so the number of entries available for the 4 MB page size is one-half the returned value.			
15:8	L1ITlb2and4MAssoc: instruction TLB associativity for 2 MB and 4 MB pages. Read-only. Reset: Fixed,FFh.			
	See Core::X86::Cpuid::L1DcId[L1DcAssoc].			
7:0	L1ITlb2and4MSize: instruction TLB number of entries for 2 MB and 4 MB pages. Read-only. Reset:			
	Fixed,64. The value returned is for the number of entries available for the 2 MB page size; 4 MB pages require			
	two 2 MB entries, so the number of entries available for the 4 MB page size is one-half the returned value.			

# CPUID\_Fn80000005\_EBX [L1 TLB 4K Identifiers] (Core::X86::Cpuid::L1Tlb4K)

Read-only.			
See Core::X86::Cpuid::L1Tlb2M4M.			
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000005_EBX			
Bits Description			
1:24 <b>L1DTlb4KAssoc</b> . Read-only. Reset: Fixed,FFh. Data TLB associativity for 4 KB pages. See			
Core::X86::Cpuid::L1DcId[L1DcAssoc].			
23:16 <b>L1DTlb4KSize</b> . Read-only. Reset: Fixed,64. Data TLB number of entries for 4 KB pages.			
15:8 <b>L1ITlb4KAssoc</b> . Read-only. Reset: Fixed,FFh. Instruction TLB associativity for 4 KB pages. See			
Core::X86::Cpuid::L1DcId[L1DcAssoc].			
<b>L1ITlb4KSize</b> . Read-only. Reset: Fixed,64. Instruction TLB number of entries for 4 KB pages.			

#### CPUID Fn800000005 FCX [L1 Data Cache Identifiers] (Core: X86::Cnuid::L1DcId)

CPOID_F11000000005_ECA [L1 Data Cache Identifiers] (Core::A00::Cpuid::L1Dctd)				
Read-only.				
This function provides first level cache characteristics for each core.				
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000005_ECX				
Bits Description				
31:24 <b>L1DcSize</b> . Read-only. Reset: Fixed,32. L1 data cache size in KB.				

ValidValues:

Value Description

23:16	:16 L1DcAssoc. Read-only. Reset: Fixed,8. L1 data cache associativity.				
	ValidValues:				
	Value	Description			
	00h	Reserved			
	01h	1 way (direct mapped)			
	02h	2 way			
	03h	3 way			
	FEh-	<value> way</value>			
	04h				
	FFh	Fully associative			
15:8	8 L1DcLinesPerTag. Read-only. Reset: Fixed,01h. L1 data cache lines per tag.				
7:0	L1DcLin	eSize. Read-only. Reset: Fixed,64. L1 data cache line size in bytes.			

CPUI	CPUID_Fn80000005_EDX [L1 Instruction Cache Identifiers] (Core::X86::Cpuid::L1IcId)				
Read-o	Read-only.				
This fu	This function provides first level cache characteristics for each core.				
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000005_EDX				
Bits	Descripti	on			
31:24	L1IcSize	. Read-only. Reset: Fixed,32. L1 instruction cache size KB.			
23:16	L1IcAsso	c. Read-only. Reset: Fixed,8. L1 instruction cache associativity.			
	ValidValu	ues:			
	Value	Description			
	00h	Reserved			
	01h	1 way (direct mapped)			
	02h	2 way			
	03h	3 way			
	04h	4 way			
	FEh-	<value> way</value>			
	05h				
	FFh	Fully associative			
15:8	8 <b>L1IcLinesPerTag</b> . Read-only. Reset: Fixed,01h. L1 instruction cache lines per tag.				
7:0	the L1IcLineSize. Read-only. Reset: Fixed,64. L1 instruction cache line size in bytes.				

CPUI	CPUID_Fn80000006_EAX [L2 TLB 2M/4M Identifiers] (Core::X86::Cpuid::L2Tlb2M4M)			
Read-	Read-only.			
This fo	ınction pro	ovides the processor's second level cache and TLB characteristics for each core.		
_lthree[1	:0]_core[3:0]_	_thread[1:0]; CPUID_Fn80000006_EAX		
Bits	Descripti	on		
31:28	L2DTlb2	and4MAssoc: L2 data TLB associativity for 2 MB and 4 MB pages. Read-only. Reset: Xh.		
	ValidValues:			
	Value	Description		
	3h-0h	Reserved.		
	4h	4 ways		
	Fh-5h	Reserved.		
27:16	L2DTlb2and4MSize: L2 data TLB number of entries for 2 MB and 4 MB pages. Read-only. Reset:			
	Fixed,204	8. The value returned is for the number of entries available for the 2 MB page size; 4 MB pages require		
	two 2 ME	B entries, so the number of entries available for the 4 MB page size is one-half the returned value.		

15:12 **L2ITlb2and4MAssoc**: **L2 instruction TLB associativity for 2 MB and 4 MB pages**. Read-only. Reset: Fixed,6.

	5h-0h	Reserved.	]
	6h	8 ways	1
	Fh-7h	Reserved.	]

11:0 **L2ITlb2and4MSize**: **L2** instruction TLB number of entries for 2 MB and 4 MB pages. Read-only. Reset: Fixed,1024. The value returned is for the number of entries available for the 2 MB page size; 4 MB pages require two 2 MB entries, so the number of entries available for the 4 MB page size is one-half the returned value.

#### CPUID Fn80000006 EBX [L2 TLB 4K Identifiers] (Core::X86::Cpuid::L2Tlb4K)

# Read-only.

This function provides the processor's second level cache and TLB characteristics for each core.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn80000006\_EBX

#### **Bits** Description

31:28 **L2DTlb4KAssoc**. Read-only. Reset: 6h. L2 data TLB associativity for 4 KB pages.

#### ValidValues:

11 11 11 11 11		
	Value	Description
	5h-0h	Reserved.
	6h	8 ways
	Fh-7h	Reserved.

27:16 **L2DTlb4KSize**. Read-only. Reset: Fixed,2048. L2 data TLB number of entries for 4 KB pages.

15:12 **L2ITlb4KAssoc**. Read-only. Reset: Fixed,6. L2 instruction TLB associativity for 4 KB pages.

#### ValidValues:

vana varaes.	
Value	Description
5h-0h	Reserved.
6h	8 ways
Fh-7h	Reserved.

11:0 **L2ITlb4KSize**. Read-only. Reset: Fixed,1024. L2 instruction TLB number of entries for 4 KB pages.

# CPUID\_Fn80000006\_ECX [L2 Cache Identifiers] (Core::X86::Cpuid::L2CacheId)

#### Read-only.

This function provides second level cache characteristics for each core.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn80000006\_ECX

#### **Bits Description**

31:16 **L2Size**. Read-only. Reset: Fixed,0200h. L2 cache size in KB.

# ValidValues:

Value	Description
00FFh-	Reserved.
0000h	
0100h	256 KB
01FFh-	Reserved.
0101h	
0200h	512 KB
03FFh-	Reserved.
0201h	
0400h	1 MB
07FFh-	Reserved.
0401h	
0800h	2 MB
FFFFh-	Reserved.
0801h	

15:12 **L2Assoc**. Read-only. Reset: Fixed,6. L2 cache associativity.

Fh-Ah

Reserved.

Va	ValidValues:	
,	Value	Description
	0h	Disabled.
	1h	1 way (direct mapped)
	2h	2 ways
	3h	Reserved.
	4h	4 ways
	5h	Reserved.
	6h	8 ways
	7h	Reserved.
	8h	16 ways
	9h	Reserved.
	Ah	32 ways
	Bh	48 ways
	Ch	64 ways
	Dh	96 ways
	Eh	128 ways
	Fh	Fully associative
11:8 L2	:8 <b>L2LinesPerTag</b> . Read-only. Reset: Fixed,1h. L2 cache lines per tag.	
7:0 L2	2LineSi	ze. Read-only. Reset: Fixed,64. L2 cache line size in bytes.

<b>CPUII</b>	CPUID_Fn80000006_EDX [L3 Cache Identifiers] (Core::X86::Cpuid::L3CacheId)				
Read-c	Read-only.				
This fu	This function provides third level cache characteristics shared by all cores of a processor.				
_lthree[1:	:0]_core[3:0]_	thread[1:0]; CPUID_Fn80000006_EDX			
Bits	Descripti	on			
31:18	L3Size: L	<b>.3 cache size</b> . Read-only. Reset: XXXXh. The L3 cache size in 512 KB units.			
	ValidValu	ies:			
	Value	Description			
	0000h	Disabled.			
	3FFFh-	( <value> *0.5) MB</value>			
	0001h				
17:16	Reserved.				
15:12	L3Assoc.	Read-only. Reset: Fixed,9h. There are insufficient available encodings to represent all possible L3			
	associativ	ities. Please refer to Core::X86::Cpuid::CachePropEbx3[CacheNumWays].			
	ValidValues:				
	Value Description				
	8h-0h	Reserved.			
	9h	Invalid, not reported here.			

#### CPUID\_Fn80000007\_EAX [Reserved] (Core::X86::Cpuid::ProcFeedbackCap)

11:8 L3LinesPerTag. Read-only. Reset: Fixed,1h. L3 cache lines per tag.
7:0 L3LineSize. Read-only. Reset: Fixed,64. L3 cache line size in bytes.

	= = ! i( i i)	
Read-only. Reset: Fixed,0000_0000h.		
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000007_EAX		
Bits	Description	
31:0	Reserved.	

# CPUID\_Fn80000007\_EBX [RAS Capabilities] (Core::X86::Cpuid::RasCap)

Read-	Read-only.		
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000007_EBX		
Bits	Description		
31:4	Reserved.		
3	<b>ScalableMca</b> . Read-only. Reset: Fixed,1. 0=Scalable MCA is not supported. 1=Scalable MCA is supported. See		
	3.1.1.2 [Machine Check Architecture Extensions] and MCA_CONFIG[McaX] for the respective bank.		
2	<b>HWA</b> . Read-only. Reset: Fixed,0. Hardware assert supported.		
1	SUCCOR: Software uncorrectable error containment and recovery capability. Read-only. Reset: X. The		
	processor supports software containment of uncorrectable errors through context synchronizing data poisoning		
	and deferred error interrupts; MSR Core::X86::Msr::McaIntrCfg, MCA_STATUS[Deferred] and		
	MCA_STATUS[Poison] exist.		
0	McaOverflowRecov: MCA overflow recovery support. Read-only. Reset: Fixed,1. 0=MCA overflow		
	conditions require software to shutdown the system. 1=MCA overflow conditions (MCi_STATUS[Overflow] ==		
	1) are not fatal; software may safely ignore such conditions. See 3.1 [Machine Check Architecture].		

# Read-only. Reset: Fixed,0000\_00007\_ECX | https://document.org/linearing/li

CPUI	D_Fn80000007_EDX [Advanced Power Management Information] (Core::X86::Cpuid::ApmInfoEdx)	
Read-only.		
	This function provides advanced power management feature identifiers.	
	:0]_core[3:0]_thread[1:0]; CPUID_Fn80000007_EDX	
	Description	
31:15	Reserved.	
14	RAPL. Read-only. Reset: Fixed,1. Running average power limit.	
13	ConnectedStandby. Read-only. Reset: Fixed,1. Connected Standby.	
12	<b>ProcPowerReporting</b> . Read-only. Reset: Fixed,0. Core power reporting interface supported.	
11	<b>ProcFeedbackInterface: processor feedback interface.</b> Read-only. Reset: Fixed,0. 1=Indicates support for	
	processor feedback interface; Core::X86::Cpuid::ProcFeedbackCap.	
10	EffFreqRO: read-only effective frequency interface. Read-only. Reset: Fixed,1. Indicates presence of	
	Core::X86::Msr::MPerfReadOnly and Core::X86::Msr::APerfReadOnly.	
9	<b>CPB</b> : <b>core performance boost</b> . Read-only. Reset: X. 1=Indicates presence of Core::X86::Msr::HWCR[CpbDis]	
	and support for core performance boost.	
8	<b>TscInvariant</b> : <b>TSC invariant</b> . Read-only. Reset: Fixed,1. The TSC rate is invariant.	
7	HwPstate: hardware P-state control. Read-only. Reset: Fixed,1. Core::X86::Msr::PStateCurLim,	
	Core::X86::Msr::PStateCtl and Core::X86::Msr::PStateStat exist.	
6	OneHundredMHzSteps. Read-only. Reset: Fixed,0. 100 MHz multiplier Control.	
5	Reserved.	
4	TM. Read-only. Reset: Fixed,1. Hardware thermal control (HTC).	
3	TTP. Read-only. Reset: Fixed,1. THERMTRIP.	
2	VID: Voltage ID control. Read-only. Reset: Fixed,0. Function replaced by HwPstate.	
1	FID: Frequency ID control. Read-only. Reset: Fixed,0. Function replaced by HwPstate.	
0	<b>TS</b> . Read-only. Reset: Fixed,1. Temperature sensor.	

# CPUID\_Fn80000008\_EAX [Long Mode Address Size Identifiers] (Core::X86::Cpuid::LongModeInfo) Read-only. Reset: Fixed,0000\_3030h. This provides information about the maximum physical and linear address width supported by the processor.

_lthree[1	:0]_core[3:0]_	thread[1:0]; CPUID_Fn80000008_EAX
Bits	Descripti	on
31:24	Reserved.	
23:16	<b>GuestPhysAddrSize</b> . Read-only. Reset: Fixed,00h. Maximum guest physical byte address size in bits.	
	ValidValu	ues:
	Value	Description
	00h	The maximum guest physical address size defined by PhysAddrSize.
	FFh-	The maximum guest physical address size defined by GuestPhysAddrSize.
	01h	
15:8	LinAddr	Size. Read-only. Reset: Fixed,30h. Maximum linear byte address size in bits.
7:0	PhysAdd	<b>rSize</b> . Read-only. Reset: Fixed,30h. Maximum physical byte address size in bits.

# CPUID\_Fn80000008\_EBX [Extended Feature Extensions ID EBX] (Core::X86::Cpuid::FeatureExtIdEbx)

	D_FH00000000_EDA [Extended Feature Extensions ID EDA] (CoreAooCpuidFeatureExtruEox)		
	Read-only.		
	::0]_core[3:0]_thread[1:0]; CPUID_Fn80000008_EBX		
	Description		
	Reserved.		
24	SSBD: Speculative Store Bypass Disable. Read-only. Reset: Fixed,1.		
23	<b>PPIN: PPIN support</b> . Read-only. Reset: X. 0=PPIN capability is not supported; Core::X86::Msr::PPIN_CTL and		
	Core::X86::Msr::PPIN are treated as RAZ. 1=Indicates that Protected Processor Inventory Number (PPIN)		
	capability can be enabled for privileged system inventory agent to Read PPIN from Core::X86::Msr::PPIN. Protected Processor Inventory Number support.		
22.20	Reserved.		
19	IbrsProvidesSameModeProtection. Read-only. Reset: 1. IBRS provides Same Mode Protection.		
18	<b>IbrsPreferred</b> . Read-only. Reset: 1. 1=IBRS is preferred over software solution.		
17	<b>StibpAlwaysOn</b> . Read-only. Reset: 0. Single Thread Indirect Branch Prediction Mode has Enhanced Performance and May be left Always On.		
16	Reserved.		
15	STIBP. Read-only. Reset: 1. Single Thread Indirect Branch Prediction.		
14	IBRS. Read-only. Reset: 1. Indirect Branch Restricted Speculation.		
13	INT_WBINVD. Read-only. Reset: 1. Interruptible WBINVD,WBNOINVD		
12	IBPB. Read-only. Reset: 1. Indirect Branch Prediction Barrier.		
11:10	Reserved.		
9	<b>WBNOINVD</b> . Read-only. Reset: 1. WBNOINVD writes all modified cache lines in the internal caches of the		
	processor back to memory leaving the line valid (clean) in the internal caches.		
8	MCOMMIT: memory commit. Read-only. Reset: 0. Memory commit instruction support.		
7	Reserved.		
6	MBE. Read-only. Reset: Fixed,1. Memory Bandwidth Enforcement.		
5	Reserved.		
4	<b>RDPRU</b> : <b>read processor register at user level</b> . Read-only. Reset: Fixed,1. RDPRU instruction allows reading		
	MPERF and APERF at user level.		
3	Reserved.		
2	<b>RstrFpErrPtrs</b> . Read-only. Reset: Fixed,1. 1=FXSAVE, XSAVE, FXSAVEOPT, XSAVEC, XSAVES always		
	save error pointers and FXRSTOR, XRSTOR, XRSTORS always restore error pointers is supported.		
1	InstRetCntMsr: instructions retired count support. Read-only. Reset: Fixed,1.		
	1=Core::X86::Msr::IRPerfCount supported.		
0	<b>CLZERO:</b> Clear Zero Instruction. Read-only. Reset: Fixed,1. CLZERO instruction zero's out the 64 byte cache		
	line specified in RAX. Note: CLZERO instruction operations are cache-line aligned and RAX[5:0] is ignored.		

# CPUID\_Fn80000008\_ECX [Size Identifiers] (Core::X86::Cpuid::SizeId)

Read-	l-only.		
This p	This provides information about the number of threads supported by the processor.		
_lthree[1	:0]_core[3:0]_	_thread[1:0]; CPUID_Fn80000008_ECX	
Bits	Descripti	on	
31:18	Reserved	•	
17:16	PerfTscS	ize: performance time-stamp counter size. Read-only. Reset: Fixed,0h.	
15:12	ApicIdSize: APIC ID size. Read-only. The number of bits in the initial Core::X86::Apic::ApicId[ApicId] value		
	that indic	ate thread ID within a package.	
	Reset: SM	MT ? 7 : 6.	
	ValidValues:		
	Value	Description	
	5h-0h	Reserved.	
	6h	Up to 64 threads.	
	7h	Up to 128 threads.	
	Fh-8h	Reserved.	
11:8	Reserved		
7:0	NC: num	<b>ber of threads - 1</b> . Read-only. Reset: XXh. The number of threads in the package is NC + 1 (e.g., if NC	
	== 0, ther	n there is one thread).	

#### CPUID\_Fn80000008\_EDX [Feature Extended Size Edx] (Core::X86::Cpuid::FeatureExtSizeEdx)

	i		
Read-	Read-only. Reset: Fixed,0001_0000h.		
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000008_EDX		
Bits	Description		
31:24	Reserved.		
23:16	RdpruMax. Read-only. Reset: Fixed,01h. RDPRU Instruction max input supported.		
15:0	Reserved.		

#### CPUID\_Fn8000000A\_EAX [SVM Revision and Feature Identification] (Core::X86::Cpuid::SvmRevFeatIdEax)

Read-only. Reset: Fixed,0000_0001h. Enable: Core::X86::Cpuid::FeatureExtIdEcx[SVM].		
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn8000000A_EAX		
Bits	Description	
31:8	Reserved.	
7:0	SvmRev. Read-only. Reset: Fixed,01h. SVM revision.	

#### CPUID\_Fn8000000A\_EBX [SVM Revision and Feature Identification] (Core::X86::Cpuid::SvmRevFeatIdEbx)

Read-only, Volatile. Reset: 0000\_8000h. Enable: Core::X86::Cpuid::FeatureExtIdEcx[SVM].

This provides SVM revision and feature information.
\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn8000000A\_EBX

Bits Description

31:0 NASID: number of address space identifiers (ASID). Read-only, Volatile. Reset: 0000\_8000h.

# CPUID\_Fn8000000A\_EDX [SVM Revision and Feature Identification] (Core::X86::Cpuid::SvmRevFeatIdEdx)

Read-	Read-only. Reset: Fixed,0013_B4FFh. Enable: Core::X86::Cpuid::FeatureExtIdEcx[SVM].		
This p	This provides SVM feature information.		
_lthree[1	L:0]_core[3:0]_thread[1:0]; CPUID_Fn8000000A_EDX		
Bits	Description		
31:21	Reserved.		
20	GuestSpecCtrl. Read-only. Reset: Fixed,1. 1=Indicates support for Guest SPEC_CTRL.		
19:18	Reserved.		
17	GMET. Read-only. Reset: Fixed,1. Guest Mode Execute Trap.		
16	vGIF. Read-only. Reset: Fixed,1. Virtualized GIF.		

15	V_VMSAVE_VMLOAD. Read-only. Reset: Fixed,1. Virtualized VMLOAD and VMSAVE.
14	Reserved.
13	<b>AVIC</b> : <b>AMD virtual interrupt controller</b> . Read-only. Reset: Fixed,1. 1=Support indicated for SVM mode
	virtualized interrupt controller; Indicates support for Core::X86::Msr::AvicDoorbell.
12	PauseFilterThreshold. Read-only. Reset: Fixed,1. PAUSE filter threshold.
11	Reserved.
10	PauseFilter. Read-only. Reset: Fixed,1. Pause intercept filter.
9:8	Reserved.
7	<b>DecodeAssists</b> . Read-only. Reset: Fixed,1. Decode assists.
6	FlushByAsid. Read-only. Reset: Fixed,1. Flush by ASID.
5	VmcbClean. Read-only. Reset: Fixed,1. VMCB clean bits.
4	<b>TscRateMsr:</b> MSR based TSC rate control. Read-only. Reset: Fixed,1. 1=Indicates support for TSC ratio
	Core::X86::Msr::TscRateMsr.
3	NRIPS. Read-only. Reset: Fixed,1. NRIP Save.
2	SVML. Read-only. Reset: Fixed,1. SVM lock.
1	LbrVirt. Read-only. Reset: Fixed,1. LBR virtualization.
0	<b>NP</b> . Read-only. Reset: Fixed,1. Nested Paging.

# CPUID\_Fn80000019\_EAX [L1 TLB 1G Identifiers] (Core::X86::Cpuid::L1Tlb1G)

= = i		
Read-only.		
This function provides first level TLB characteristics for 1-GB pages.		
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000019_EAX		
Bits Description		
31:28 L1DTlb1GAssoc: L1 data TLB associativity for 1-GB pages. Read-only. Reset: Fixed,Fh. See		
Core::X86::Cpuid::L2CacheId[L2Assoc].		
27:16 <b>L1DTlb1GSize</b> . Read-only. Reset: Fixed,64. L1 data TLB number of entries for 1-GB pages.		
15:12 <b>L1ITlb1GAssoc</b> . Read-only. Reset: Fixed,Fh. L1 instruction TLB associativity for 1-GB pages. See		
Core::X86::Cpuid::L2CacheId[L2Assoc].		
11:0 <b>L1ITlb1GSize</b> . Read-only. Reset: Fixed,64. L1 instruction TLB number of entries for 1-GB pages.		

# CPUID\_Fn80000019\_EBX [L2 TLB 1G Identifiers] (Core::X86::Cpuid::L2Tlb1G)

Read-only. Reset: Fixed,0000_0000h.	
This provides 1-GB paging information. The associativity fields are defined by Core::X86::Cpuid::L2Tlb2M4M,	
Core::X86::Cpuid::L2Tlb4K, Core::X86::Cpuid::L2CacheId and Core::X86::Cpuid::L3CacheId.	
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000019_EBX	
Bits Description	
31:28 <b>L2DTlb1GAssoc</b> . Read-only. Reset: Fixed,0h. L2 data TLB associativity for 1-GB pages. See	
Core::X86::Cpuid::L2CacheId[L2Assoc].	
27:16 <b>L2DTlb1GSize</b> . Read-only. Reset: Fixed,000h. L2 data TLB number of entries for 1-GB pages.	
15:12 <b>L2ITlb1GAssoc</b> . Read-only. Reset: Fixed,0h. L2 instruction TLB associativity for 1-GB pages. See	
Core::X86::Cpuid::L2CacheId[L2Assoc].	
11:0 <b>L2ITlb1GSize</b> . Read-only. Reset: Fixed,000h. L2 instruction TLB number of entries for 1-GB pages.	

# CPUID\_Fn8000001A\_EAX [Performance Optimization Identifiers] (Core::X86::Cpuid::PerfOptId)

Read-	Read-only. Reset: Fixed,0000_0006h.	
This f	This function returns performance related information.	
_lthree[1	:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001A_EAX	
Bits	Description	
31:3	Reserved.	
	<b>FP256</b> . Read-only. Reset: Fixed,1. 256-bit AVX instructions are executed with full-width internal operations and	
	pipelines rather than decomposing them into internal 128-bit suboperations.	

ValidValues:

- MOVU. Read-only. Reset: Fixed,1. MOVU SSE instructions are more efficient and should be preferred to SSE MOVL/MOVH. MOVUPS is more efficient than MOVLPS/MOVHPS. MOVUPD is more efficient than MOVLPD/MOVHPD.
- **FP128**. Read-only. Reset: Fixed,0. 128-bit SSE (multimedia) instructions are executed with full-width internal operations and pipelines rather than decomposing them into internal 64-bit suboperations.

# CPUID\_Fn8000001B\_EAX [Instruction Based Sampling Identifiers] (Core::X86::Cpuid::IbsIdEax)

CFUI	D_FilovovoviD_EAX [filst action based Sampling Identifiers] (CoreXooCpuidiosidEax)	
Read-only.		
This function returns IBS feature information.		
_lthree[1	:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001B_EAX	
Bits	Description	
31:11	Reserved.	
10	<b>IbsOpData4</b> . Read-only. Reset: Fixed,0. IBS op data 4 MSR supported.	
9	<b>IbsFetchCtlExtd</b> : <b>IBS fetch control extended MSR supported</b> . Read-only. Reset: Fixed,1. Indicates support for	
	Core::X86::Msr::IC_IBS_EXTD_CTL.	
8	<b>OpBrnFuse</b> : <b>fused branch micro-op indication supported</b> . Read-only. Reset: Fixed,1. Indicates support for	
	Core::X86::Msr::IBS_OP_DATA[IbsOpBrnFuse].	
7	RipInvalidChk: invalid RIP indication supported. Read-only. Reset: Fixed,1. Indicates support for	
	Core::X86::Msr::IBS_OP_DATA[IbsRipInvalid].	
6	OpCntExt: IbsOpCurCnt and IbsOpMaxCnt extend by 7 bits. Read-only. Reset: Fixed,1. Indicates support	
	for Core::X86::Msr::IBS_OP_CTL[IbsOpCurCnt[26:20],IbsOpMaxCnt[26:20]].	
5	<b>BrnTrgt</b> . Read-only. Reset: Fixed,1. Branch target address reporting supported.	
4	<b>OpCnt</b> . Read-only. Reset: Fixed,1. Op counting mode supported.	
3	RdWrOpCnt. Read-only. Reset: Fixed,1. Read/Write of op counter supported.	
2	<b>OpSam</b> . Read-only. Reset: Fixed,1. IBS execution sampling supported.	
1	FetchSam. Read-only. Reset: 1. IBS fetch sampling supported.	
0	IBSFFV. Read-only. Reset: Fixed,1. IBS feature flags valid.	

CPUI	CPUID_Fn8000001D_EAX_x00 [Cache Properties (DC)] (Core::X86::Cpuid::CachePropEax0)		
Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].			
		d::CachePropEax0 reports topology information for the DC.	
		_thread[1:0]; CPUID_Fn8000001D_EAX_x00	
	Descripti		
31:26	Reserved		
25:14		ringCache: number of logical processors sharing cache. Read-only. Reset: XXXh. The number of	
	logical pr	ocessors sharing this cache is NumSharingCache + 1.	
13:10	Reserved	•	
9	FullyAss	ociative: fully associative cache. Read-only. Reset: Fixed,0. 1=Cache is fully associative.	
8	SelfInitia	llization: cache is self-initializing. Read-only. Reset: Fixed,1. 1=Cache is self initializing; cache does	
	not need	software initialization.	
7:5	CacheLevel: cache level. Read-only. Reset: Fixed,1h. Identifies the cache level.		
	ValidValues:		
	Value	Description	
	0h	Reserved.	
	1h	Level 1	
	2h	Level 2	
	3h	Level 3	
	7h-4h	Reserved.	
4:0	CacheTy	pe: cache type. Read-only. Reset: Fixed,01h. Identifies the type of cache.	

	Value	Description
	00h	Null; no more caches.
	01h	Data cache.
	02h	Instruction cache.
	03h	Unified cache.
	1Fh-04h	Reserved.

# CPUID\_Fn8000001D\_EAX\_x01 [Cache Properties (IC)] (Core::X86::Cpuid::CachePropEax1)

01 01	2_1 housest 15perues (10)] (corehouredener 15p2mir)		
Read-	Read-only. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].		
Core::	Core::X86::Cpuid::CachePropEax1 reports topology information for the IC. See Core::X86::Cpuid::CachePropEax0.		
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001D_EAX_x01		
Bits	Description		
31:26	Reserved.		
25:14	NumSharingCache: number of logical processors sharing cache. Read-only. Reset: XXXh. See		
	Core::X86::Cpuid::CachePropEax0[NumSharingCache].		
13:10	Reserved.		
9	FullyAssociative: fully associative cache. Read-only. Reset: Fixed,0. See		
	Core::X86::Cpuid::CachePropEax0[FullyAssociative].		
8	SelfInitialization: cache is self-initializing. Read-only. Reset: Fixed,1. See		
	Core::X86::Cpuid::CachePropEax0[SelfInitialization].		
7:5	CacheLevel: cache level. Read-only. Reset: Fixed,1h. Identifies the cache level. See		
	Core::X86::Cpuid::CachePropEax0[CacheLevel].		
4:0	CacheType: cache type. Read-only. Reset: Fixed,02h. See Core::X86::Cpuid::CachePropEax0[CacheType].		

# CPUID\_Fn8000001D\_EAX\_x02 [Cache Properties (L2)] (Core::X86::Cpuid::CachePropEax2)

Read-only. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].	
Core::X86::Cpuid::CachePropEax2 reports topology information for the L2. See Core::X86::Cpuid::CachePropEax0.	
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001D_EAX_x02	
Bits	Description
31:26	Reserved.
25:14	NumSharingCache: number of logical processors sharing cache. Read-only. Reset: XXXh.
	Core::X86::Cpuid::CachePropEax0[NumSharingCache].
13:10	Reserved.
9	FullyAssociative: fully associative cache. Read-only. Reset: Fixed,0.
	Core::X86::Cpuid::CachePropEax0[FullyAssociative].
8	SelfInitialization: cache is self-initializing. Read-only. Reset: Fixed,1.
	Core::X86::Cpuid::CachePropEax0[SelfInitialization].
7:5	CacheLevel: cache level. Read-only. Reset: Fixed,2h. Identifies the cache level.
	Core::X86::Cpuid::CachePropEax0[CacheLevel].
4:0	CacheType: cache type. Read-only. Reset: Fixed,03h. Core::X86::Cpuid::CachePropEax0[CacheType].

# CPUID\_Fn8000001D\_EAX\_x03 [Cache Properties (L3)] (Core::X86::Cpuid::CachePropEax3)

Read-	Read-only. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].	
Core::	Core::X86::Cpuid::CachePropEax3 reports topology information for the L3.	
_lthree[1	:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001D_EAX_x03	
Bits	Description	
31:26	Reserved.	
25:14	NumSharingCache: number of logical processors sharing cache. Read-only. Reset: XXXh. The number of	
	logical processors sharing this cache is NumSharingCache + 1.	
13:10	Reserved.	
9	<b>FullyAssociative</b> : <b>fully associative cache</b> . Read-only. Reset: Fixed,0.	

	Core::X86::Cpuid::CachePropEax0[FullyAssociative].
8	SelfInitialization: cache is self-initializing. Read-only. Reset: Fixed,1.
	Core::X86::Cpuid::CachePropEax0[SelfInitialization].
7:5	CacheLevel: cache level. Read-only. Reset: Fixed,3h. Identifies the cache level.
	Core::X86::Cpuid::CachePropEax0[CacheLevel].
4:0	CacheType: cache type. Read-only. Reset: Fixed,03h. Core::X86::Cpuid::CachePropEax0[CacheType].

#### CPUID Fn8000001D EAX x04 [Cache Properties Null] (Core::X86::Cpuid::CachePropEax4)

01 01	or ore == novovore == novo (out of the print	
Read-only. Reset: Fixed,0000_0000h. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].		
Core::X86::Cpuid::CachePropEax4 reports done/null. See Core::X86::Cpuid::CachePropEax0.		
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001D_EAX_x04	
Bits	Description	
31:5	Reserved.	
4:0	CacheType: cache type. Read-only. Reset: Fixed,00h. Core::X86::Cpuid::CachePropEax0[CacheType].	

#### CPUID\_Fn8000001D\_EBX\_x00 [Cache Properties (DC)] (Core::X86::Cpuid::CachePropEbx0)

Read-	only. Reset: Fixed,01C0_003Fh. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].		
Core::	Core::X86::Cpuid::CachePropEbx0 reports topology information for the DC. See Core::X86::Cpuid::CachePropEax0.		
_lthree[1	L:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001D_EBX_x00		
Bits	Description		
31:22	<b>CacheNumWays: cache number of ways</b> . Read-only. Reset: Fixed,007h. Cache number of ways is		
	CacheNumWays + 1.		
21:12	CachePhysPartitions: cache physical line partitions. Read-only. Reset: Fixed,000h. Cache partitions is		
	CachePhysPartitions + 1.		
11:0	CacheLineSize: cache line size in bytes. Read-only. Reset: Fixed,03Fh. Cache line size in bytes is		
	CacheLineSize + 1		

#### CPUID\_Fn8000001D\_EBX\_x01 [Cache Properties (IC)] (Core::X86::Cpuid::CachePropEbx1)

#### CPUID\_Fn8000001D\_EBX\_x02 [Cache Properties (L2)] (Core::X86::Cpuid::CachePropEbx2)

Read-	Read-only. Reset: Fixed,01C0_003Fh. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].	
Core::	Core::X86::Cpuid::CachePropEbx2 reports topology information for the L2. See Core::X86::Cpuid::CachePropEax0.	
_lthree[1	L:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001D_EBX_x02	
Bits	Description	
31:22	CacheNumWays: cache number of ways. Read-only. Reset: Fixed,007h. See	
	Core::X86::Cpuid::CachePropEbx0[CacheNumWays].	
21:12	CachePhysPartitions: cache physical line partitions. Read-only. Reset: Fixed,000h. See	
	Core::X86::Cpuid::CachePropEbx0[CachePhysPartitions].	
11:0	CacheLineSize: cache line size in bytes. Read-only. Reset: Fixed,03Fh. See	
	Core::X86::Cpuid::CachePropEbx0[CacheLineSize].	

#### CPUID\_Fn8000001D\_EBX\_x03 [Cache Properties (L3)] (Core::X86::Cpuid::CachePropEbx3)

Read-only. Reset: Fixed,03C0_003Fh. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].	
Core::	X86::Cpuid::CachePropEbx3 reports topology information for the L3. See Core::X86::Cpuid::CachePropEax0.
_lthree[1	:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001D_EBX_x03
Bits	Description
31:22	CacheNumWays: cache number of ways. Read-only. Reset: Fixed,00Fh. See
	Core::X86::Cpuid::CachePropEbx0[CacheNumWays].
21:12	CachePhysPartitions: cache physical line partitions. Read-only. Reset: Fixed,000h. See
	Core::X86::Cpuid::CachePropEbx0[CachePhysPartitions].
11:0	CacheLineSize: cache line size in bytes. Read-only. Reset: Fixed,03Fh. See
	Core::X86::Cpuid::CachePropEbx0[CacheLineSize].

#### CPUID\_Fn8000001D\_EBX\_x04 [Cache Properties Null] (Core::X86::Cpuid::CachePropEbx4)

Read-only. Reset: Fixed,0000 0000h. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions]. Core::X86::Cpuid::CachePropEax4 reports done/null. See Core::X86::Cpuid::CachePropEax0. lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn8000001D\_EBX\_x04 Bits Description

# 31:0 Reserved.

#### CPUID\_Fn8000001D\_ECX\_x00 [Cache Properties (DC)] (Core::X86::Cpuid::CachePropEcx0)

Read-only. Reset: Fixed,0000\_003Fh. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions]. Core::X86::Cpuid::CachePropEcx0 reports topology information for the DC. See Core::X86::Cpuid::CachePropEax0. lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn8000001D\_ECX\_x00 Bits Description

CacheNumSets: cache number of sets. Read-only. Reset: Fixed,0000\_003Fh. Cache number of sets is 31:0 CacheNumSets + 1.

#### CPUID\_Fn8000001D\_ECX\_x01 [Cache Properties (IC)] (Core::X86::Cpuid::CachePropEcx1)

Read-only. Reset: Fixed,0000 003Fh. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions]. Core::X86::Cpuid::CachePropEcx1 reports topology information for the IC. See Core::X86::Cpuid::CachePropEax0. lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn8000001D\_ECX\_x01 Rite Description

Dits	Description
31:0	<b>CacheNumSets:</b> cache number of sets. Read-only. Reset: Fixed,0000_003Fh. See
	Core::X86::Cpuid::CachePropEcx0[CacheNumSets].

#### CPUID\_Fn8000001D\_ECX\_x02 [Cache Properties (L2)] (Core::X86::Cpuid::CachePropEcx2)

Read-only. Reset: Fixed,0000 03FFh. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions]. Core::X86::Cpuid::CachePropEcx2 reports topology information for the L2. See Core::X86::Cpuid::CachePropEax0.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn8000001D\_ECX\_x02

Bits	Description

31:0 | CacheNumSets: cache number of sets. Read-only. Reset: Fixed,0000\_03FFh. See Core::X86::Cpuid::CachePropEcx0[CacheNumSets].

#### CPUID\_Fn8000001D\_ECX\_x03 [Cache Properties (L3)] (Core::X86::Cpuid::CachePropEcx3)

Read-only. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].

Core::X86::Cpuid::CachePropEcx3 reports topology information for the L3.

lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn8000001D\_ECX\_x03

#### Bits Description

31:0 CacheNumSets: cache number of sets. Read-only. Reset: 0000 XXXXh. See

Core::X86::Cpuid::CachePropEcx0[CacheNumSets].

# ValidValues

vanu vanues:		
Value	Description	
0000_1	Reserved.	

FFEh-	
0000_0	
000h	
0000_1	8192 L3 Cache Sets.
FFFh	
0000_3	Reserved.
FFEh-	
0000_2	
000h	
0000_3	16384 L3 Cache Sets.
FFFh	
FFFF_F	Reserved.
FFFh-	
0000_4	
000h	

#### CPUID Fn8000001D ECX x04 [Cache Properties Null] (Core::X86::Cpuid::CachePropEcx4)

Read-only. Reset: Fixed,0000\_0000h. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].

Core::X86::Cpuid::CachePropEax3 reports done/null. See Core::X86::Cpuid::CachePropEax0.

lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn8000001D\_ECX\_x04

#### Bits Description

31:0 **CacheNumSets**. Read-only. Reset: Fixed,0000\_0000h. Cache number of sets.

#### CPUID\_Fn8000001D\_EDX\_x00 [Cache Properties (DC)] (Core::X86::Cpuid::CachePropEdx0)

Read-only. Reset: Fixed,0000\_0000h. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].

Core::X86::Cpuid::CachePropEdx0 reports topology information for the DC. See Core::X86::Cpuid::CachePropEax0.

lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn8000001D\_EDX\_x00

# Bits Description

31:2 Reserved.

- **CacheInclusive**: **cache inclusive**. Read-only. Reset: Fixed,0. 0=Cache is not inclusive of lower cache levels. 1=Cache is inclusive of lower cache levels.
- WBINVD: Write-Back Invalidate/Invalidate. Read-only. Reset: Fixed,0. 0=WBINVD/INVD invalidates all lower level caches of non-originating cores sharing this cache. 1=WBINVD/INVD not ensured to invalidate all lower level caches of non-originating cores sharing this cache.

#### CPUID\_Fn8000001D\_EDX\_x01 [Cache Properties (IC)] (Core::X86::Cpuid::CachePropEdx1)

Read-only. Reset: Fixed,0000 0000h. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].

Core::X86::Cpuid::CachePropEdx1 reports topology information for the IC. See Core::X86::Cpuid::CachePropEax0.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn8000001D\_EDX\_x01

Bits   Description
--------------------

- 31:2 Reserved.
  - **CacheInclusive**: **cache inclusive**. Read-only. Reset: Fixed,0. See

Core::X86::Cpuid::CachePropEdx0[CacheInclusive].

WBINVD: Write-Back Invalidate/Invalidate. Read-only. Reset: Fixed,0. 0=WBINVD/INVD invalidates all lower level caches of non-originating cores sharing this cache. 1=WBINVD/INVD may not invalidate all lower level caches of non-originating cores sharing this cache. See Core::X86::Cpuid::CachePropEdx0[WBINVD].

#### CPUID\_Fn8000001D\_EDX\_x02 [Cache Properties (L2)] (Core::X86::Cpuid::CachePropEdx2)

Read-only. Reset: Fixed,0000 0002h. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].

Core::X86::Cpuid::CachePropEdx2 reports topology information for the L2. See Core::X86::Cpuid::CachePropEax0.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn8000001D\_EDX\_x02

#### Bits Description

31:2	Reserved.	
1	CacheInclusive: cache inclusive. Read-only. Reset: Fixed,1. See	
	Core::X86::Cpuid::CachePropEdx0[CacheInclusive].	
0	<b>WBINVD</b> : <b>Write-Back Invalidate/Invalidate</b> . Read-only. Reset: Fixed,0. 0=WBINVD/INVD invalidates all	
	lower level caches of non-originating cores sharing this cache. 1=WBINVD/INVD may not invalidate all lower	
	level caches of non-originating cores sharing this cache.	

#### CPUID\_Fn8000001D\_EDX\_x03 [Cache Properties (L3)] (Core::X86::Cpuid::CachePropEdx3)

Read-only. Reset: Fixed,0000 0001h. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].

Core::X86::Cpuid::CachePropEdx3 reports reports topology information for the L3. See

Core::X86::Cpuid::CachePropEax0.		
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001D_EDX_x03		
Bits	Bits Description	
31:2	Reserved.	
1	CacheInclusive: cache inclusive. Read-only. Reset: Fixed,0. See	
	Core::X86::Cpuid::CachePropEdx0[CacheInclusive].	
0	0 <b>WBINVD</b> : <b>Write-Back Invalidate/Invalidate</b> . Read-only. Reset: Fixed,1. 0=WBINVD/INVD invalidates all	
	lower level caches of non-originating cores sharing this cache. 1=WBINVD/INVD may not invalidate all lower	
	level caches of non-originating cores sharing this cache.	

#### CPUID\_Fn8000001D\_EDX\_x04 [Cache Properties Null] (Core::X86::Cpuid::CachePropEdx4)

Read-only. Reset: Fixed,0000\_0000h. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].

Core::X86::Cpuid::CachePropEax3 reports done/null. See Core::X86::Cpuid::CachePropEax0.

lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn8000001D\_EDX\_x04

# Bits Description

31:0 Reserved.

#### CPUID\_Fn8000001E\_EAX [Extended APIC ID] (Core::X86::Cpuid::ExtApicId)

Read-only. Enable: (Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions] &&

Core::X86::Msr::APIC\_BAR[ApicEn]).

If Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions] == 0 then CPUID Fn8000001E\_E[D,C,B,A]X are Reserved. If (Core::X86::Msr::APIC\_BAR[ApicEn] == 0) then Core::X86::Cpuid::ExtApicId[ExtendedApicId] is Reserved.

lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn8000001E\_EAX

Bits   Description	ntion
--------------------	-------

31:0 **ExtendedApicId: extended APIC ID.** Read-only. See 2.1.12.2.1.3 [ApicId Enumeration Requirements].

Reset: (Core::X86::Msr::APIC\_BAR[ApicEn] && Core::X86::Msr::APIC\_BAR[x2ApicEn])?

Core::X86::Msr::APIC\_ID[ApicId[31:0]] : Core::X86::Msr::APIC\_BAR[ApicEn] ? {00\_0000h,

Core::X86::Apic::ApicId[ApicId]} : 0000\_0000h.

#### CPUID\_Fn8000001E\_EBX [Core Identifiers] (Core::X86::Cpuid::CoreId)

Read-only. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].

See Core::X86::Cpuid::ExtApicId.

lthree[1:0]\_core[3:0]\_thread[1:0]; CPUID\_Fn8000001E\_EBX

Bits	Description
31.16	Decerved

**ThreadsPerCore**: **threads per core**. Read-only. Reset: XXh. The number of threads per core is ThreadsPerCore 15:8

**CoreId**: **core ID**. Read-only. Reset: Fixed,XXh. Identifies the logical core ID. 7:0

#### CPUID\_Fn8000001E\_ECX [Node Identifiers] (Core::X86::Cpuid::NodeId)

Read-only. Enable: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].

_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001E_ECX		
Bits	Description		
31:11	Reserved.		
10:8	0:8 NodesPerProcessor: Node per processor. Read-only. Reset: XXXb.		
	ValidValues:		
	Value	Description	
	0h	1 node per processor.	
	7h-1h	Reserved.	
7:0	NodeId: Node ID. Read-only. Reset: Fixed,XXh.		

#### CPUID\_Fn8000001F\_EAX [AMD Secure Encryption EAX] (Core::X86::Cpuid::SecureEncryptionEax)

er erzer neutre en er puer en er prometer en er pro			
Read-	Read-only. Reset: Fixed,0001_000Fh.		
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001F_EAX			
Bits	Description		
31:17	Reserved.		
16	<b>VTE:</b> Virtual Transparent Encryption for SEV. Read-only. Reset: Fixed,1. The Virtual Transparent Encryption		
	feature can be enabled to force all memory accesses within an SEV guest to be encrypted with the guest's key.		
	When enabled the hardware pretends that the C-bits for all guest mode accesses are 1 regardless of the actual		
	guest page tables.		
15:4	Reserved.		
3	SevEs. Read-only. Reset: Fixed,1. Secure Encrypted ES.		
2	VmPgFlush: VM Page Flush MSR is supported. Read-only. Reset: Fixed,1. See		
	Core::X86::Msr::VMPAGE_FLUSH.		
1	SEV. Read-only. Reset: Fixed,1. Secure Encrypted Virtualization supported.		
0	<b>SME</b> . Read-only. Reset: Fixed,1. Secure Memory Encryption supported.		

# CPUID\_Fn8000001F\_EBX [AMD Secure Encryption EBX] (Core::X86::Cpuid::SecureEncryptionEbx)

Read-only.			
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001F_EBX		
Bits	Bits Description		
31:12	Reserved.		
11:6 <b>MemEncryptPhysAddWidth</b> . Read-only. Reset: 000XXXb. Reduction of physical address space in bits w			
	memory e	encryption is enabled (0 indicates no reduction).	
ValidValues:		ies:	
	Value	Description	
	00h	Physical Address width is not reduced.	
01h Physical Address width is reduced by one. 02h Physical Address width is reduced by two. 03h Physical Address width is reduced by three. 04h Physical Address width is reduced by four.		Physical Address width is reduced by one.	
		Physical Address width is reduced by two.	
		Physical Address width is reduced by three.	
		Physical Address width is reduced by four.	
	05h	Physical Address width is reduced by five.	
	3Fh-06h	Reserved.	
5:0	5:0 <b>CBit</b> . Read-only. Reset: 2Fh. Page table bit number used to enable memory encryption.		

# CPUID\_Fn8000001F\_ECX [AMD Secure Encryption ECX] (Core::X86::Cpuid::SecureEncryptionEcx)

Read-only.		
	_lthree[1	L:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001F_ECX
	Bits	Description
	31:0	<b>NumEncryptedGuests</b> . Read-only. Reset: XXXX_XXXh. Indicates the maximum ASID value that may be
		used for an SEV-enabled guest.

CPUID_Fn8000001F_EDX [Minimum ASID]	(Core::X86::Cpuid::SecureEncryptionEdx)

		1.
	Read-	only.
	_lthree[1	1:0]_core[3:0]_thread[1:0]; CPUID_Fn8000001F_EDX
	Bits	Description
	31:0	MinimumSEVASID: Minimum SEV enabled, SEV-ES disabled ASID. Read-only. Reset: 0000_000Xh.
		Indicates the minimum ASID value that must be used for an SEV-enabled, SEV-ES-disabled guest.

#### CPUID\_Fn80000020\_EAX\_x00 [Platform QoS Enforcement for Memory Bandwidth]

#### (Core::X86::Cpuid::PgeBandwidthEax0)

Corc	mion epaiding qebana madinaxo)
Read-only. Reset: 0000_0000h.	
_lthree[1	:0]_core[3:0]_thread[1:0]; CPUID_Fn80000020_EAX_x00
Bits	Description
31:0	Reserved.

# CPUID\_Fn80000020\_EBX\_x00 [Platform QoS Enforcement for Memory Bandwidth]

(Core::X86::Cpuid::PqeBandwidthEbx0)

Read-	Read-only. Reset: 0000_0002h.	
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000020_EBX_x00		
Bits	Description	
31:2	Reserved.	
1	MBE: memory bandwidth enforcement. Read-only. Reset: 1. Memory bandwidth enforcement.	
0	Reserved.	

# CPUID\_Fn80000020\_ECX\_x00 [Platform QoS Enforcement for Memory Bandwidth]

(Core::X86::Cpuid::PqeBandwidthEcx0)

Read-only. Reset: 0000_0000h.		
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000020_ECX_x00		
Bits	Description	
31:0	Reserved.	

# CPUID\_Fn80000020\_EDX\_x00 [Platform QoS Enforcement for Memory Bandwidth]

(Core::X86::Cpuid::PgeBandwidthEdx0)

Read-only. Reset: 0000_0000h.	
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000020_EDX_x00	
Bits	Description

# CPUID\_Fn80000020\_EAX\_x01 [Platform QoS Enforcement for Memory Bandwidth]

(Core::X86::Cpuid::PqeBandwidthEax1)

_	•	* *
Read-only. Reset: 0000_000Bh.		only. Reset: 0000_000Bh.
Γ.	_lthree[1	l:0]_core[3:0]_thread[1:0]; CPUID_Fn80000020_EAX_x01
	Bits	Description
	31:0	BW_LEN: QOS Memory Bandwidth Enforcement Limit Size. Read-only. Reset: 0000_000Bh. Size of the
		QOS Memory Bandwidth Enforcement Limit.

# $CPUID\_Fn80000020\_EBX\_x01~[Platform~QoS~Enforcement~for~Memory~Bandwidth]$

(Core::X86::Cpuid::PqeBandwidthEbx1)	
Read-	-only. Reset: 0000_0000h.
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000020_EBX_x01	
Bits	Description
31:0	Reserved.

#### CPUID\_Fn80000020\_ECX\_x01 [Platform QoS Enforcement for Memory Bandwidth]

(Core::X86::Cpuid::PqeBandwidthEcx1)		
Read-only. Reset: 0000_0000h.		
_lthree[1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000020_ECX_x01		
Bits Description		
31:0 Reserved.		
CPUID Fn80000020 EDX x01 [Platform OoS Enforcement for Memory Bandwidth]		

# CPUID\_Fn80000020\_EDX\_x01 [Platform QoS Enforcement for Memory Bandwidth] (Core::X86::Cpuid::PqeBandwidthEdx1)

D 1	1. P
Read-	only. Reset: 0000_000Fh.
_lthree[1	1:0]_core[3:0]_thread[1:0]; CPUID_Fn80000020_EDX_x01
Bits	Description
31:0	NumClassService. Read-only. Reset: 0000_000Fh. Number of classes of service.

## 2.1.14 MSR Registers

#### 2.1.14.1 MSRs - MSR0000\_xxxx

See 1.4.3 [Register Mnemonics] for a description of the register naming convention. MSRs are accessed through x86 WRMSR and RDMSR instructions.

********	With lost and Testisist instructions.		
MSR	MSR0000_0010 [Time Stamp Counter] (Core::X86::Msr::TSC)		
Read-v	Read-write, Volatile. Reset: 0000_0000_00000_0000h.		
The TSC uses a common reference for all sockets, cores and threads.			
_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_0010			
Bits	Description		
63:0	<b>TSC</b> : <b>time stamp counter</b> . Read-write, Volatile. Reset: 0000_0000_0000h. The TSC increments at the P0		
	frequency. The TSC counts at the same rate in all P-states, all C states, S0, or S1. A read of this MSR in guest		
	mode is affected by Core::X86::Msr::TscRateMsr. The value (TSC/TSCRatio) is the TSC P0 frequency based		
	value (as if TSCRatio == 1.0) when (TSCRatio != 1.0).		

# MSR0000\_001B [APIC Base Address] (Core::X86::Msr::APIC\_BAR)

_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_001B	
Bits	Description
63:48	Reserved.
47:12	<b>ApicBar[47:12]: APIC base address register</b> . Read-write. Reset: 0_000F_EE00h. Specifies the base address,
	physical address [47:12], for the APICXX register set in xAPIC mode. See 2.1.12.2.1.2 [APIC Register Space].
11	<b>ApicEn</b> : <b>APIC enable</b> . Read-write. Reset: 0. 0=Disable Local Apic. 1=Local APIC is enabled in xAPIC mode.
	See 2.1.12.2.1.2 [APIC Register Space].
10	<b>x2ApicEn:</b> Extended APIC enable. Read-write. Reset: 0. 0=Disable Extended Local Apic. 1=Extended Local
	APIC is enabled in x2APIC mode.
9	Reserved.
8	<b>BSC</b> : <b>boot strap core</b> . Read-write, Volatile. Reset: X. 0=The core is not the boot core of the BSP. 1=The core is
	the boot core of the BSP.
7:0	Reserved.

# MSR0000\_002A [Cluster ID] (Core::X86::Msr::EBL\_CR\_POWERON)

Moreove_ver[claster ib] (corexcom/mir.ibbb_cit_1 o whiten)		
Writes to this register result in a GP fault with error code 0.		to this register result in a GP fault with error code 0.
_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_002A		:0]_core[3:0]_thread[1:0]; MSR0000_002A
	Bits	Description
	63:18	Reserved.

17:16	ClusterID. Read, Error-on-write. Reset: 0h. The field does not affect hardware.
15:0	Reserved.

#### MSR0000\_0048 [Speculative Control] (Core::X86::Msr::SPEC\_CTRL)

_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_0048	
Bits	Description
63:3	Reserved.
2	<b>SSBD</b> : <b>Speculative Store Bypass Disable</b> . Read-write. Reset: 0. 1=SSBD is enabled by setting.
1	STIBP: single thread indirect branch predictor. Read-write. Reset: 0.
0	IBRS: indirect branch restriction speculation. Read-write. Reset: 0.

# MSR0000\_0049 [Prediction Command] (Core::X86::Msr::PRED\_CMD)

_lthree[1:0]_core[3:0]; MSR0000_0049	
Bits	Description
63:1	Reserved.
0	<b>IBPB</b> : <b>indirect branch prediction barrier</b> . Write-only,Error-on-read. Reset: 0. Supported if
	Core::X86::Cpuid::FeatureExtIdEbx[IBPB] == 1.

# MSR0000\_008B [Patch Level] (Core::X86::Msr::PATCH\_LEVEL)

Read,I	Read,Error-on-write,Volatile. Reset: 0000_0000_0000_0000h.	
_lthree[1:0]_core[3:0]; MSR0000_008B		
Bits	Description	
63:32	Reserved.	
31:0	<b>PatchLevel</b> . Read, Error-on-write, Volatile. Reset: 0000_0000h. This returns an identification number for the	
	microcode patch that has been loaded. If no patch has been loaded, this returns 0.	

# MSR0000\_00E7 [Max Performance Frequency Clock Count] (Core::X86::Msr::MPERF)

Read-write, Volatile. Reset: 0000_0000_00000_0000h.			
	_lthree[1	:0]_core[3:0]_thread[1:0]; MSR0000_00E7	
	Bits	Description	
	63:0	<b>MPERF</b> : <b>maximum core clocks counter</b> . Read-write, Volatile. Reset: 0000_0000_0000_0000h. Incremented by	]
		hardware at the P0 frequency while the core is in C0. This register does not increment when the core is in the	
		stop-grant state. In combination with Core::X86::Msr::APERF, this is used to determine the effective frequency	
		of the core. A Read of this MSR in guest mode is affected by Core::X86::Msr::TscRateMsr. This field uses	
		software P-state numbering. See Core::X86::Msr::HWCR[EffFreqCntMwait], 2.1.5 [Effective Frequency].	

# MSR0000\_00E8 [Actual Performance Frequency Clock Count] (Core::X86::Msr::APERF)

Read-	write, Volatile. Reset: 0000_0000_0000_0000h.
_lthree[1	L:0]_core[3:0]_thread[1:0]; MSR0000_00E8
Bits	Description
63:0	<b>APERF</b> : actual core clocks counter. Read-write, Volatile. Reset: 0000_0000_0000_0000h. This register
	increments in proportion to the actual number of core clocks cycles while the core is in C0. The register does not
	increment when the core is in the stop-grant state. See Core::X86::Msr::MPERF.

#### MSR0000\_00FE [MTRR Capabilities] (Core::X86::Msr::MTRRcap)

Read,I	Error-on-write. Reset: 0000_0000_0000_0508h.
_lthree[1	:0]_core[3:0]; MSR0000_00FE
Bits	Description
63:11	Reserved.
10	MtrrCapWc: write-combining memory type. Read,Error-on-write. Reset: 1. 1=The write combining memory
	type is supported.
9	Reserved.
8	MtrrCapFix: fixed range register. Read,Error-on-write. Reset: 1. 1=Fixed MTRRs are supported.

7:0 **MtrrCapVCnt**: **variable range registers count**. Read,Error-on-write. Reset: 08h. Specifies the number of variable MTRRs supported.

# MSR0000\_0174 [SYSENTER CS] (Core::X86::Msr::SYSENTER\_CS)

1120210	(
Read-write. Reset: 0000_0000_0000_0000h.	
_lthree[1	L:0]_core[3:0]_thread[1:0]; MSR0000_0174
Bits	Description
63:16	Reserved.
15:0	SysEnterCS: SYSENTER target CS. Read-write, Reset: 0000h, Holds the called procedure code segment.

#### MSR0000\_0175 [SYSENTER ESP] (Core::X86::Msr::SYSENTER\_ESP)

	· · · · · · · · · · · · · · · · · · ·	
Read-	Read-write. Reset: 0000_0000_0000_0000h.	
_lthree[1	1:0]_core[3:0]_thread[1:0]; MSR0000_0175	
Bits	Description	
63:32	Reserved.	
31:0	SysEnterESP: SYSENTER target SP. Read-write. Reset: 0000_0000h. Holds the called procedure stack	
	pointer.	

## MSR0000\_0176 [SYSENTER EIP] (Core::X86::Msr::SYSENTER\_EIP)

Read-write. Reset: 0000_0000_0000_0000h.		
_lthree[1	L:0]_core[3:0]_thread[1:0]; MSR0000_0176	
Bits	Description	
63:32	Reserved.	
31:0	SysEnterEIP: SYSENTER target IP. Read-write. Reset: 0000_0000h. Holds the called procedure instruction	
	pointer.	

#### MSR0000\_0179 [Global Machine Check Capabilities] (Core::X86::Msr::MCG\_CAP)

_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_0179	
Bits	Description	
63:9	Reserved.	
8	8 McgCtlP: MCG_CTL register present. Read-only, Error-on-write. Reset: Fixed, 1. 1=The machine check control	
	registers (MCi_CTL) are present. See 3.1 [Machine Check Architecture].	
7:0	<b>Count</b> . Read-only, Error-on-write, Volatile. Reset: XXh. Indicates the number of error reporting banks visible to	
	the core. This value may differ from core to core.	

#### MSR0000 017A [Global Machine Check Status] (Core::X86::Msr::MCG\_STAT)

WISK	MSR0000_01/A [Global Machine Check Status] (Core::A60::MSF::MCG_S1A1)		
Read-write, Volatile. Reset: 0000_0000_0000_0000h.			
See 3.	1 [Machine Check Architecture].		
_lthree[1	L:0]_core[3:0]_thread[1:0]; MSR0000_017A		
Bits	Bits Description		
63:3	Reserved.		
2	<b>MCIP</b> : machine check in progress. Read-write, Volatile. Reset: 0. 1=A machine check is in progress. Machine		
	check progress.		
1	<b>EIPV</b> : <b>error instruction pointer valid</b> . Read-write, Volatile. Reset: 0. 1=The instruction pointer that was pushed		
	onto the stack by the machine check mechanism references the instruction that caused the machine check error.		
0	<b>RIPV</b> : <b>restart instruction pointer valid</b> . Read-write, Volatile. Reset: 0. 0=The interrupt was not precise and/or		
	the process (task) context may be corrupt; continued operation of this process may not be possible without		
	intervention, however system processing or other processes may be able to continue with appropriate software		
	clean up. 1=Program execution can be reliably restarted at the EIP address on the stack.		

#### MSR0000\_017B [Global Machine Check Exception Reporting Control] (Core::X86::Msr::MCG\_CTL)

Reset: 0000\_0000\_0000\_0000h.

This register controls enablement of the individual error reporting banks; see 3.1 [Machine Check Architecture]. When a

machine check register bank is not enabled in MCG\_CTL, errors for that bank are not logged or reported, and actions enabled through the MCA are not taken; each MCi\_CTL register identifies which errors are still corrected when MCG\_CTL[i] is disabled.

lthree[1:0]\_core[3:0]\_thread[1:0]; MSR0000\_017B

_lthree[1	ee[1:0]_core[3:0]_thread[1:0]; MSR0000_017B		
Bits	Description		
63:7	<b>MCnEn</b> . Configurable. Reset: 000_0000_0000h.		
	Descripti	<b>on</b> : 1=The MC0 machine check register bank is enabled. Width of this field is SOC implementation and	
	configura	tion specific.	
See 3.1.2.1 [Global Registers].		.1 [Global Registers].	
6:0	MCnEnCore. Read-write. Reset: 00h. 1=The MC0 machine check register bank is enabled.		
	ValidValues:		
	Bit	Description	
	[0]	Enable MCA for LSDC.	
	[1]	Enable MCA for ICBP.	
	[2]	Enable MCA for L2.	
	[3]	Enable MCA for DE.	
	[4]	Reserved.	
	[5]	Enable MCA for SCEX.	
	[6]	Enable MCA for FP.	

# MSR0000\_01D9 [Debug Control] (Core::X86::Msr::DBG\_CTL\_MSR)

_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_01D9	
Bits	Description
63:6	Reserved.
5:2	<b>PB</b> : <b>performance monitor pin control</b> . Read-write. Reset: 0h. This field does not control any hardware.
1	<b>BTF</b> . Read-write. Reset: 0. 1=Enable branch single step.
0	<b>LBR</b> . Read-write. Reset: 0. 1=Enable last branch record.

#### MSR0000\_01DB [Last Branch From IP] (Core::X86::Msr::BR\_FROM)

Read,Error-on-write,Volatile. Reset: 0000_0000_0000h.		
_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_01DB		
Bits	Bits Description	
63:0	<b>LastBranchFromIP</b> . Read,Error-on-write,Volatile. Reset: 0000_0000_0000_0000h. Loaded with the segment	
	offset of the branch instruction.	

#### MSR0000 01DC [Last Branch To IP] (Core::X86::Msr::BR TO)

_		<u>-</u>
Γ	Read,Error-on-write,Volatile. Reset: 0000_0000_0000h.	
	lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_01DC	
	Bits Description	
	63:0	<b>LastBranchToIP</b> . Read,Error-on-write,Volatile. Reset: 0000_0000_0000h. Holds the target RIP of the last
		branch that occurred before an exception or interrupt.

#### MSR0000\_01DD [Last Exception From IP] (Core::X86::Msr::LastExcpFromIp)

	Read,Error-on-write,Volatile. Reset: 0000_0000_0000_0000h.	
_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_01DD  Bits Description		:0]_core[3:0]_thread[1:0]; MSR0000_01DD
		Description
	63:0	<b>LastIntFromIP</b> . Read,Error-on-write,Volatile. Reset: 0000_0000_0000h. Holds the source RIP of the last
		branch that occurred before the exception or interrupt.

#### MSR0000\_01DE [Last Exception To IP] (Core::X86::Msr::LastExcpToIp)

Read, Error-on-write, Volatile. Reset: 0000_0000_0000.
_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_01DE

Bits	Description
63:0	<b>LastIntToIP</b> . Read,Error-on-write,Volatile. Reset: 0000_0000_0000h. Holds the target RIP of the last
	branch that occurred before the exception or interrupt.

#### MSR0000\_020[0...E] [Variable-Size MTRRs Base] (Core::X86::Msr::MtrrVarBase)

Each MTRR (Core::X86::Msr::MtrrVarBase, Core::X86::Msr::MtrrFix\_64K through Core::X86::Msr::MtrrFix\_4K\_7, or Core::X86::Msr::MTRRdefType) specifies a physical address range and a corresponding memory type (MemType) associated with that range. Setting the memory type to an unsupported value results in a #GP.

The variable-size MTRRs come in pairs of base and mask registers (MSR0000\_0200 and MSR0000\_0201 are the first pair, etc.). Variables MTRRs are enabled through Core::X86::Msr::MTRRdefType[MtrrDefTypeEn]. A core access--with address CPUAddr--is determined to be within the address range of a variable-size MTRR if the following equation is

CPUAddr[47:12] & PhyMask[47:12] == PhyBase[47:12] & PhyMask[47:12].

For example, if the variable MTRR spans 256 KB and starts at the 1-MB address the PhyBase would be set to 0\_0010\_0000h and the PhyMask to F\_FFFC\_0000h (with zeros filling in for bits[11:0]). This results in a range from 0\_0010\_0000h to 0\_0013\_FFFFh.

0_0010_0000II to 0_0015_FFFFII.	
_lthree[1:0]_core[3:0]_n0; MSR0000_0200	
_lthree[1:0]_core[3:0]_n1; MSR0000_0202	
_lthree[1:0]_core[3:0]_n2; MSR0000_0204	
_lthree[1:0]_core[3:0]_n3; MSR0000_0206	
_lthree[1:0]_core[3:0]_n4; MSR0000_0208	
_lthree[1:0]_core[3:0]_n5; MSR0000_020A	
_lthree[1:0]_core[3:0]_n6; MSR0000_020C	
_lthree[1:0]_core[3:0]_n7; MSR0000_020E	
Pita Description	

DILS	Description
63.48	Reserved

#### 05.40 Reserveu.

47:12 **PhyBase: base address**. Read-write. Reset: X XXXX XXXXh.

#### 11:3 Reserved.

2:0 **MemType**: **memory type**. Read-write. Reset: XXXb. Address range from 00000h to 0FFFFh.

#### ValidValues:

Value	Description
0h	UC or uncacheable.
1h	WC or write combining.
3h-2h	Reserved.
4h	WT or write through.
5h	WP or write protect.
6h	WB or write back.
7h	Reserved.

#### MSR0000 020[1...Fl [Variable-Size MTRRs Mask] (Core::X86::Msr::MtrrVarMask)

Moreovo_o=o[imi][variable objectifities mash](coreovisosmissimiter variation)				
_lthree[1:0]_core[3:0]_n0; MSR0000_0201				
_lthree[1:0]_core[3:0]_n1; MSR0000_0203				
_lthree[1:0]_core[3:0]_n2; MSR0000_0205				
_lthree[1:0]_core[3:0]_n3; MSR0000_0207				
_lthree[1:0]_core[3:0]_n4; MSR0000_0209				
_lthree[1:0]_core[3:0]_n5; MSR0000_020B				
_lthree[1:0]_core[3:0]_n6; MSR0000_020D				
_lthree[1:0]_core[3:0]_n7; MSR0000_020F				
S Description				
63:48 Reserved.				
47:12 PhyMask: address mask. Read-write. Reset: X_XXXX_XXXXh.				
11 <b>Valid</b> : <b>valid</b> . Read-write. Reset: X. 1=The variable-size MTRR pair is enabled.				

10:0 Reserved.

# MSR0000\_0250 [Fixed-Size MTRRs] (Core::X86::Msr::MtrrFix\_64K)

See Core::X86::Msr::MtrrVarBase for general MTRR information. Fixed MTRRs are enabled through

Core::X86::Msr::MTRRdefType[MtrrDefTypeFixEn,MtrrDefTypeEn]. For addresses below 1-MB, the appropriate Fixed MTRRs override the default access destination. Each fixed MTRR includes two bits, RdDram and WrDram, that determine the destination based on the access type. Writing Reserved MemType values causes an Error-on-write.

lthree[1:0]\_core[3:0]\_nSIZE64K; MSR0000\_0250

	Bits	Description		
	63:61	Reserved.		
	60 <b>RdDram_64K_70000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read access			
		the range are marked as destined for DRAM.		
		AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn]? Read-write: Read,Error-on-write-1. Reset:		
		Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
	59	<b>WrDram_64K_70000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses		
		d		

the range are marked as destined for DRAM. AccessType: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:

Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn]? X : Fixed,0.

58:56 **MemType\_64K\_70000**: **memory type**. Read-write. Reset: XXXb.

#### ValidValues:

Value Description	
0h	UC or uncacheable.
1h	WC or write combining.
3h-2h	Reserved.
4h	WT or write through.
5h	WP or write protect.
6h	WB or write back.
7h	Reserved.

#### 55:53 Reserved.

52 RdDram\_64K\_60000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as destined for DRAM.

AccessType: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? X : Fixed,0.

51 **WrDram 64K 60000: Write DRAM.** 0=Write accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as destined for DRAM.

AccessType: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? X : Fixed,0.

50:48 **MemType\_64K\_60000**: **memory type**. Read-write. Reset: XXXb.

#### ValidValues:

varia values.		
e Description		
UC or uncacheable.		
WC or write combining.		
Reserved.		
WT or write through.		
WP or write protect.		
WB or write back.		
Reserved.		

#### 47:45 Reserved.

RdDram\_64K\_50000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as destined for DRAM.

	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
43	<b>WrDram_64K_50000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to		
	the range	are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
42:40	MemTyp	e_64K_50000: memory type. Read-write. Reset: XXXb.	
	ValidValues:		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
39:37	Reserved.		
36		<b>_64K_40000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
35 <b>WrDram_64K_40000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as MMIO.			
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
34:32 MemType_64K_40000: memory type. Read-write. Reset: XXXb.			
	ValidValu		
	Value	UC or uncacheable.	
	0h		
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
24.20	7h	Reserved.	
	Reserved.		
28		<b>_64K_30000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
27	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
WrDram_64K_30000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write access the range are marked as destined for DRAM.			
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
26:24			
	ValidValues:		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	

	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
23:21	Reserved		
20	RdDram	<b>_64K_20000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
19	WrDram	<b>_64K_20000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
		are marked as destined for DRAM.	
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
18:16	MemTyp	e_64K_20000: memory type. Read-write. Reset: XXXb.	
	ValidVal	ues:	
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
15.13	Reserved		
12	<b>RdDram_64K_10000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
11	<b>WrDram_64K_10000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to		
	the range are marked as destined for DRAM.		
	_	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
10:8	MemType_64K_10000: memory type. Read-write. Reset: XXXb.		
	ValidVal	ues:	
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
7:5	Reserved		
4		_64K_00000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM. Address range from 00000h to 0FFFFh.	
	_	6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Access Tv	pe: Core::Aoo::Msr::5 r 5_CrG[MurrixDrailiMouEll] ? Read-write : Read,Effor-off-write-1. Reset:	

3	<b>WrDram_64K_00000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to			
the range are marked as destined for DRAM. Address range from 00000h to 0FFFFh.				
Core::X86::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.				
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:			
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
2:0	MemType_64K_00000: memory type. Read-write. Reset: XXXb. Address range from 00000h to 0FFFFh.			
	ValidValues:			
Value Description		Description		
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		
	7h	Reserved.		

#### MSR0000\_0258 [Fixed-Size MTRRs] (Core::X86::Msr::MtrrFix\_16K\_0)

_itili ee[ i	_itinee[1.0]_C01e[5.0]_151EE10K0, W15K0000_0250			
Bits	Description			
63:61	Reserved.			
60 <b>RdDram_16K_9C000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as MMIO.				
	the range are marked as destined for DRAM.			
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:			
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
59	<b>WrDram_16K_9C000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to			
	the range are marked as destined for DRAM.			
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:			
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
58:56	MemType_16K_9C000: memory type. Read-write. Reset: XXXb.			
	ValidValues:			

***************************************	, mile ,			
Value	Description			
0h	UC or uncacheable.			
1h	WC or write combining.			
3h-2h	Reserved.			
4h	WT or write through.			
5h	WP or write protect.			
6h	WB or write back.			
7h	Reserved.			

#### 55:53 Reserved.

**RdDram\_16K\_98000: Read DRAM.** 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as destined for DRAM.

AccessType: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? X : Fixed,0.

WrDram\_16K\_98000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as destined for DRAM.

AccessType: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:

	CorouVO	C. Mayu. CVC CECIMtyr Eiy Dyam MadEn 12 V. Eiyad 0			
FO. 40	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.				
50:40	MemType_16K_98000: memory type. Read-write. Reset: XXXb.  ValidValues:				
		UC or uncacheable.			
	0h				
	1h	WC or write combining.			
	3h-2h	Reserved.			
	4h	WT or write through.			
	5h	WP or write protect.			
	6h	WB or write back.			
	7h	Reserved.			
	Reserved.				
44		<b>_16K_94000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to			
		are marked as destined for DRAM.			
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:			
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
43		<b>_16K_94000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to			
		are marked as destined for DRAM.			
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:			
10.10		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
42:40		e_16K_94000: memory type. Read-write. Reset: XXXb.			
	ValidValu				
	Value	Description			
	0h	UC or uncacheable.			
	1h	WC or write combining.			
	3h-2h	Reserved.			
	4h	WT or write through.			
	5h	WP or write protect.			
	6h	WB or write back.			
	7h	Reserved.			
39:37	Reserved.				
36		<b>_16K_90000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to			
	the range are marked as destined for DRAM.				
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:				
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.				
35		<b>_16K_90000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to			
	the range are marked as destined for DRAM.				
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:				
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.				
34:32	MemType_16K_90000: memory type. Read-write. Reset: XXXb.				
	ValidValues:				
	Value	Description			
	0h	UC or uncacheable.			
	1h	WC or write combining.			
	3h-2h	Reserved.			
	4h	WT or write through.			
	5h	WP or write protect.			
	6h	WB or write back.			
	7h	Reserved.			

	_			
	Reserved			
28	<b>RdDram_16K_8C000: Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as destined for DRAM.			
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
27	WrDram	<b>16K_8C000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to are marked as destined for DRAM.		
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
26.24	MemType_16K_8C000: memory type. Read-write. Reset: XXXb.			
20.24	ValidValues:			
		Description		
	Oh	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		
	7h	Reserved.		
	Reserved			
20		<b>_16K_88000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		
		are marked as destined for DRAM.		
	Core::X8	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
19		<b>_16K_88000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to are marked as destined for DRAM.		
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
18:16	MemType_16K_88000: memory type. Read-write. Reset: XXXb.			
	ValidValues:			
	Value	Description		
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		
	7h	Reserved.		
15:13	Reserved			
12		_16K_84000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		
12	the range	are marked as destined for DRAM.		
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
11		<b>1_16K_84000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to are marked as destined for DRAM.		
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
10:8	MemType_16K_84000: memory type. Read-write. Reset: XXXb.			
	ValidValues:			

	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
7:5	Reserved	•	
4		<b>_16K_80000: Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM. Address range from 80000h to 83FFFh.	
		6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
3	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
3	<b>WrDram_16K_80000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as destined for DRAM. Address range from 80000h to 83FFFh.		
	Core::X86::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
		e_16K_80000: memory type. Read-write. Reset: XXXb. Address range from 80000h to 83FFFh.	
	ValidVal	ues:	
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	

#### MSR0000\_0259 [Fixed-Size MTRRs] (Core::X86::Msr::MtrrFix\_16K\_1)

See Core::X86::Msr::MtrrVarBase for general MTRR information. Fixed MTRRs are enabled through Core::X86::Msr::MTRRdefType[MtrrDefTypeFixEn,MtrrDefTypeEn]. For addresses below 1-MB, the appropriate Fixed MTRRs override the default access destination. Each fixed MTRR includes two bits, RdDram and WrDram, that determine the destination based on the access type. Writing Reserved MemType values causes an Error-on-write.

_lthree[1	hthree[1:0]_core[3:0]_nSIZE16K1; MSR0000_0259		
Bits	Descripti	on	
63:61	Reserved.		
60	<b>RdDram_16K_BC000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		
	the range are marked as destined for DRAM.		
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
	Core::X80	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
59	WrDram_16K_BC000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write accesses to		
	the range	the range are marked as destined for DRAM.	
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
58:56	MemType_16K_BC000: memory type. Read-write. Reset: XXXb.		
	ValidValues:		
	Value	Description	
	0h	UC or uncacheable.	

	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
55:53	Reserved		
	<b>RdDram_16K_B8000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
51		<b>_16K_B8000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
	the range are marked as destined for DRAM.		
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
50:48	MemTyp	e_16K_B8000: memory type. Read-write. Reset: XXXb.	
	ValidValı	ies:	
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
17:15	Reserved		
		<b>_16K_B4000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
77		are marked as destined for DRAM.	
,		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
43		<b>_16K_B4000: Write DRAM.</b> 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
	the range are marked as destined for DRAM.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
42:40		e_16K_B4000: memory type. Read-write. Reset: XXXb.	
	ValidValı		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
39:37	Reserved		
30	<b>RdDram_16K_B0000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as destined for DRAM.		
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn]? Read-write : Read,Error-on-write-1. Reset:		
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
	COIEAO	omnomo 10_01 Opinini indiminioudiij : A . Fineu,o.	

25	X47D	1CIV DOOOD TATA DDAM O-TATA		
35	WrDram_16K_B0000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as destined for DRAM.			
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:			
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
34:32				
	ValidValu	ValidValues:		
	Value	Description		
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		
	7h	Reserved.		
31:29	Reserved.			
28		<b>_16K_AC000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		
		are marked as destined for DRAM.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
		5::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
27		_16K_AC000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write accesses		
		ge are marked as destined for DRAM.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
26.24		e_16K_AC000: memory type. Read-write. Reset: XXXb.		
20.24	ValidValı	U UI		
	Value	Description		
	Oh	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		
	7h	Reserved.		
23:21	Reserved.			
20		<b>_16K_A8000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		
		are marked as destined for DRAM.		
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
19		<b>_16K_A8000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to		
		are marked as destined for DRAM.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
10.10		5::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
18:16	MemType_16K_A8000: memory type. Read-write. Reset: XXXb.			
	ValidValu			
	Value	<b>Description</b> UC or uncacheable.		
	0h			
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		

	Eb	W/D or verito protect
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
	Reserved.	
12	<b>RdDram_16K_A4000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
11		5::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
11	<b>WrDram_16K_A4000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
10:8	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  MemType_16K_A4000: memory type. Read-write. Reset: XXXb.	
10.0	ValidValı	
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	
	5h	WT or write through. WP or write protect.
	6h	WB or write back.
	7h	Reserved.
7.5		
7:5 4	Reserved.	
4		<b>_16K_A0000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to are marked as destined for DRAM. Address range from A0000h to A3FFFh.
		6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.
,		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		5::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
3		<b>_16K_A0000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
		are marked as destined for DRAM. Address range from A0000h to A3FFFh.
		6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn]? Read-write: Read,Error-on-write-1. Reset:
		5::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
2:0	MemTyp	e_16K_A0000: memory type. Read-write. Reset: XXXb. Address range from A0000h to A3FFFh.
	ValidValues:	
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.

#### MSR0000\_0268 [Fixed-Size MTRRs] (Core::X86::Msr::MtrrFix\_4K\_0)

See Core::X86::Msr::MtrrVarBase for general MTRR information. Fixed MTRRs are enabled through Core::X86::Msr::MTRRdefType[MtrrDefTypeFixEn,MtrrDefTypeEn]. For addresses below 1-MB, the appropriate Fixed MTRRs override the default access destination. Each fixed MTRR includes two bits, RdDram and WrDram, that determine the destination based on the access type. Writing Reserved MemType values causes an Error-on-write.

\_lthree[1:0]\_core[3:0]\_nSIZE4K0; MSR0000\_0268

Bits	Description		
	Reserved.		
60		<b>_4K_C7000: Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
		<b>_4K_C7000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
		the range are marked as destined for DRAM.	
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-or		
	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
58:56		e_4K_C7000: memory type. Read-write. Reset: XXXb.	
	ValidValu		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
55:53	Reserved.		
52	RdDram	<b>_4K_C6000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
51		<b>_4K_C6000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
50.40		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
50:48		e_4K_C6000: memory type. Read-write. Reset: XXXb.	
	ValidValu		
		Description  I.G. and the skills of the skil	
		UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
45, 45	7h	Reserved.	
	Reserved.		
44		<b>_4K_C5000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
43	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  WrDram_4K_C5000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write accesses to		
40		are marked as destined for DRAM.	
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
42:40	MemType_4K_C5000: memory type. Read-write. Reset: XXXb.		
	-J <b>P</b>	<u> </u>	

	ValidValı	ValidValues:	
	Value	Description	
	Oh	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
20.27			
	Reserved.		
36		<b>_4K_C4000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to are marked as destined for DRAM.	
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Core::X86	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
35	WrDram	<b>_4K_C4000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
34:32		e_4K_C4000: memory type. Read-write. Reset: XXXb.	
	ValidValu		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
31:29	Reserved.		
28	<b>RdDram_4K_C3000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as destined for DRAM.		
,		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		5::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
27	WrDram	<b>_4K_C3000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
	the range	are marked as destined for DRAM.	
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
26:24	MemTyp	e_4K_C3000: memory type. Read-write. Reset: XXXb.	
	ValidValı	ies:	
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
23:21	Reserved.		
20			
20	<b>RdDram_4K_C2000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		

	the range are marked as destined for DRAM.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
19		<b>_4K_C2000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to are marked as destined for DRAM.	
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
10.10		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
18:16		e_4K_C2000: memory type. Read-write. Reset: XXXb.	
	ValidValues:		
		Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
15:13	Reserved.		
12	RdDram	<b>_4K_C1000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
	the range	are marked as destined for DRAM.	
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
11	WrDram	<b>_4K_C1000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
	the range	are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
10:8			
	ValidValu		
	Value Description		
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
7:5	Reserved.		
4	RdDram	<b>_4K_C0000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM. Address range from C0000h to C0FFFh.	
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.	
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
3	WrDram_4K_C0000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write accesses to		
	_	are marked as destined for DRAM. Address range from C0000h to C0FFFh.	
		6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
2:0		<b>e_4K_C0000</b> : <b>memory type</b> . Read-write. Reset: XXXb. Address range from C0000h to C0FFFh.	
	ValidValı	ies:	

	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.

## MSR0000\_0269 [Fixed-Size MTRRs] (Core::X86::Msr::MtrrFix\_4K\_1)

See Core::X86::Msr::MtrrVarBase for general MTRR information. Fixed MTRRs are enabled through Core::X86::Msr::MTRRdefType[MtrrDefTypeFixEn,MtrrDefTypeEn]. For addresses below 1-MB, the appropriate Fixed MTRRs override the default access destination. Each fixed MTRR includes two bits, RdDram and WrDram, that determine the destination based on the access type. Writing Reserved MemType values causes an Error-on-write

determ	etermine the destination based on the access type. Writing Reserved MemType values causes an Error-on-write.			
_lthree[1	1:0]_core[3:0]_nSIZE4K1; MSR0000_0269			
Bits	Description			
63:61	Reserved.			
60		<b>_4K_CF000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		
		are marked as destined for DRAM.		
		AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
59		<b>_4K_CF000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to		
		are marked as destined for DRAM.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
58:56		e_4K_CF000: memory type. Read-write. Reset: XXXb.		
	ValidValu			
	Value	Description		
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		
	7h	Reserved.		
55:53	Reserved.			
52	RdDram	<b>_4K_CE000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		
	the range	are marked as destined for DRAM.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
51	WrDram_4K_CE000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write access			
		are marked as destined for DRAM.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
50:48	MemTyp	e_4K_CE000: memory type. Read-write. Reset: XXXb.		

# ValidValues:

	· · · · · · · · · · · · · · · · · · ·	
Value	Description	
0h	UC or uncacheable.	
1h	WC or write combining.	
3h-2h	Reserved.	

	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
47:45	Reserved	
44	RdDram	<b>_4K_CD000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to are marked as destined for DRAM.
	Core::X8	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
43	the range	<b>1_4K_CD000: Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to are marked as destined for DRAM.
	Core::X8	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
42:40	MemTyp	e_4K_CD000: memory type. Read-write. Reset: XXXb.
	ValidVal	ues:
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
39.37	Reserved	
36		_4K_CC000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to
		are marked as destined for DRAM.
		rpe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
35		<b>1_4K_CC000: Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
		are marked as destined for DRAM.
		rpe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
34:32	MemTyp	e_4K_CC000: memory type. Read-write. Reset: XXXb.
	ValidVal	ues:
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
31.29	Reserved	
28		_4K_CB000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to
20		are marked as destined for DRAM.
		rpe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
27		<b>1_4K_CB000: Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
		are marked as destined for DRAM.

	A T	C VOC M CVC CECIM, E' D M IE 12 D 1 ', D IE 4 D
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
26.24		e_4K_CB000: memory type. Read-write. Reset: XXXb.
20.24	ValidVal	
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
22.21	Reserved	
20.21		_4K_CA000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to
20		are marked as destined for DRAM.
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
19		<b>1_4K_CA000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to are marked as destined for DRAM.
-		rpe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
18.16		e_4K_CA000: memory type. Read-write. Reset: XXXb.
10.10	ValidVal	
		Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
15.13	Reserved	
12		<b>_4K_C9000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to
		are marked as destined for DRAM.
		rpe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
11	WrDram	<b>_4K_C9000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
	the range	are marked as destined for DRAM.
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
10:8	MemType_4K_C9000: memory type. Read-write. Reset: XXXb.	
	ValidValues:	
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.

7h

55:53 Reserved.

Reserved.

	7h	Reserved.		
7:5	Reserved			
4		RdDram_4K_C8000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		
		are marked as destined for DRAM. Address range from C8000 to C8FFF.		
		6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
3		<b>_4K_C8000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to		
		are marked as destined for DRAM. Address range from C8000 to C8FFF.		
		6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
2:0	MemType_4K_C8000: memory type. Read-write. Reset: XXXb. Address range from C8000 to C8FFF.			
	ValidValues:			
	Value	Description		
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		
	7h	Reserved.		

# MSR0000\_026A [Fixed-Size MTRRs] (Core::X86::Msr::MtrrFix\_4K\_2)

See Core::X86::Msr::MtrrVarBase for general MTRR information. Fixed MTRRs are enabled through Core::X86::Msr::MTRRdefType[MtrrDefTypeFixEn,MtrrDefTypeEn]. For addresses below 1-MB, the appropriate Fixed MTRRs override the default access destination. Each fixed MTRR includes two bits, RdDram and WrDram, that determine the destination based on the access type. Writing Reserved MemType values causes an Error-on-write.

determine the destination based on the access type. Writing Reserved MemType values causes an Error-on-write.				
_lthree[1	1:0]_core[3:0]_nSIZE4K2; MSR0000_026A			
Bits	Descripti	on		
63:61	Reserved			
60	RdDram	<b>_4K_D7000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		
	the range	are marked as destined for DRAM.		
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
59	WrDram	<b>_4K_D7000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to		
	the range	are marked as destined for DRAM.		
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
58:56	MemTyp	e_4K_D7000: memory type. Read-write. Reset: XXXb.		
	ValidValu	ues:		
	Value	Description		
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h WP or write protect.			
	6h	WB or write back.		

52		<b>_4K_D6000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to are marked as destined for DRAM.	
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
	Core::X80	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
51	WrDram	<b>_4K_D6000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
	the range	are marked as destined for DRAM.	
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Rese		
		5::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
50:48	MemTyp	e_4K_D6000: memory type. Read-write. Reset: XXXb.	
	ValidValu	ies:	
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
47.45	Reserved.		
44		<b>_4K_D5000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
43		<b>_4K_D5000: Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
<b>-</b> 5		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
42:40		e_4K_D5000: memory type. Read-write. Reset: XXXb.	
	ValidValues:		
	Value Description		
	0h	UC or uncacheable.	
	1h	WC or write combining.	
		Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
39:37	Reserved.		
36		<b>_4K_D4000: Read DRAM.</b> 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
35		<b>_4K_D4000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
34:32		e_4K_D4000: memory type. Read-write. Reset: XXXb.	
	ValidValı		
	Value	Description	

	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
31:29	Reserved.	
28	RdDram	<b>_4K_D3000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to
	the range	are marked as destined for DRAM.
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
27	WrDram	<b>_4K_D3000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
	the range	are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
26:24		e_4K_D3000: memory type. Read-write. Reset: XXXb.
	ValidValu	ies:
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
23:21	Reserved.	
20	RdDram	<b>_4K_D2000: Read DRAM.</b> 0=Read accesses to the range are marked as MMIO. 1=Read accesses to
		are marked as destined for DRAM.
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
19	WrDram	<b>_4K_D2000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
	the range	are marked as destined for DRAM.
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
18:16		<b>e_4K_D2000</b> : <b>memory type</b> . Read-write. Reset: XXXb.
	ValidValu	
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
15:13	Reserved.	
12		<b>_4K_D1000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to
		are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
	J	•

	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
11		<b>_4K_D1000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
	the range are marked as destined for DRAM.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
10:8		e_4K_D1000: memory type. Read-write. Reset: XXXb.	
	ValidValu		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
7:5	Reserved.		
4		<b>_4K_D0000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM. Address range from D0000h to D0FFFh.	
		6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
3		5::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
3		<b>_4K_D0000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to are marked as destined for DRAM. Address range from D0000h to D0FFFh.	
		6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn]? X : Fixed,0.	
2:0	MemTyp	<b>e_4K_D0000</b> : <b>memory type</b> . Read-write. Reset: XXXb. Address range from D0000h to D0FFFh.	
	ValidValues:		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	

# MSR0000\_026B [Fixed-Size MTRRs] (Core::X86::Msr::MtrrFix\_4K\_3)

See Core::X86::Msr::MtrrVarBase for general MTRR information. Fixed MTRRs are enabled through Core::X86::Msr::MTRRdefType[MtrrDefTypeFixEn,MtrrDefTypeEn]. For addresses below 1-MB, the appropriate Fixed MTRRs override the default access destination. Each fixed MTRR includes two bits, RdDram and WrDram, that determine the destination based on the access type. Writing Reserved MemType values causes an Error-on-write.

lthree[1:0]\_core[3:0]\_nSIZE4K3; MSR0000\_026B

_lthree[ l	three[1:0]_core[3:0]_nSIZE4K3; MSR0000_026B	
Bits	Description	
63:61	Reserved.	
60	RdDram_4K_DF000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
	the range are marked as destined for DRAM.	
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
59	<b>WrDram_4K_DF000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	

	,		
		are marked as destined for DRAM.	
	Core::X86	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
58:56	MemTyp	e_4K_DF000: memory type. Read-write. Reset: XXXb.	
	ValidValu	ies:	
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
55:53	Reserved.		
52		<b>_4K_DE000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		5::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
51		<b>_4K_DE000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
	the range	are marked as destined for DRAM.	
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Core::X86	5::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
50:48	MemTyp	e_4K_DE000: memory type. Read-write. Reset: XXXb.	
	ValidValues:		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
47:45	Reserved.		
44	RdDram	<b>_4K_DD000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM.	
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Core::X86	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
43		<b>_4K_DD000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		S::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
42:40		e_4K_DD000: memory type. Read-write. Reset: XXXb.	
	ValidValu		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	

	6h	WB or write back.	
	7h	Reserved.	
39:37	Reserved		
36		<b>_4K_DC000: Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
35	WrDram	<b>_4K_DC000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to are marked as destined for DRAM.	
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
34.32			
J-1.J2		MemType_4K_DC000: memory type. Read-write. Reset: XXXb. ValidValues:	
	Value	Description Description	
	0h	UC or uncacheable.	
	1h		
		WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
31:29	Reserved		
28		<b>_4K_DB000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
27	the range	<b>_4K_DB000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
26:24	<b>.</b>	e_4K_DB000: memory type. Read-write. Reset: XXXb.	
	ValidValu	ues:	
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
23:21			
20	the range	<b>_4K_DA000: Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
19	WrDram	<b>_4K_DA000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
	2010210		

10,16	MomTrm	a AV DA000, mamous time Dood visite Deept VVVb		
10:10	ValidValı	e_4K_DA000: memory type. Read-write. Reset: XXXb.		
	Value	Description Description		
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		
	7h	Reserved.		
15:13	Reserved.			
		<b>_4K_D9000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		
12		are marked as destined for DRAM.		
-		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
11		<b>_4K_D9000: Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to		
11		are marked as destined for DRAM.		
-		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
		5::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
10:8		e 4K D9000: memory type. Read-write. Reset: XXXb.		
-	ValidValı			
	Value	Description		
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		
	7h	Reserved.		
7:5	Reserved.			
4		<b>_4K_D8000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		
-		are marked as destined for DRAM. Address range from D8000h to D8FFFh.		
	Core::X86::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.			
	AccessType: Core::X86::Msr::SYS CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:			
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
3	WrDram	<b>_4K_D8000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to		
	the range are marked as destined for DRAM. Address range from D8000h to D8FFFh.			
		6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
2:0	MemType_4K_D8000: memory type. Read-write. Reset: XXXb. Address range from D8000h to D8FFFh.			
	ValidValu			
	Value	Description		
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		

	7h	Reserved.	٦
--	----	-----------	---

#### MSR0000\_026C [Fixed-Size MTRRs] (Core::X86::Msr::MtrrFix\_4K\_4)

See Core::X86::Msr::MtrrVarBase for general MTRR information. Fixed MTRRs are enabled through

Core::X86::Msr::MTRRdefType[MtrrDefTypeFixEn,MtrrDefTypeEn]. For addresses below 1-MB, the appropriate Fixed MTRRs override the default access destination. Each fixed MTRR includes two bits, RdDram and WrDram, that determine the destination based on the access type. Writing Reserved MemType values causes an Error-on-write.

lthree[1:0]\_core[3:0]\_nSIZE4K4; MSR0000\_026C

Bits	Description
63:61	Reserved.
60	<b>RdDram_4K_E7000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the
	range are marked as destined for DRAM.
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
59	WrDram_4K_E7000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
	the range are marked as destined for DRAM.
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:

58:56 **MemType\_4K\_E7000**: **memory type**. Read-write. Reset: XXXb.

Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? X : Fixed,0.

#### ValidValues:

Value	Description
0h	UC or uncacheable.
1h	WC or write combining.
3h-2h	Reserved.
4h	WT or write through.
5h	WP or write protect.
6h	WB or write back.
7h	Reserved.

#### 55:53 Reserved.

**RdDram\_4K\_E6000: Read DRAM**. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as destined for DRAM.

AccessType: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? X : Fixed,0.

**WrDram\_4K\_E6000: Write DRAM.** 0=Write accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as destined for DRAM.

AccessType: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? X : Fixed,0.

50:48 **MemType\_4K\_E6000**: **memory type**. Read-write. Reset: XXXb.

## ValidValues:

Value	Description
0h	UC or uncacheable.
1h	WC or write combining.
3h-2h	Reserved.
4h	WT or write through.
5h	WP or write protect.
6h	WB or write back.
7h	Reserved.

# 47:45 Reserved.

**RdDram\_4K\_E5000**: **Read DRAM**. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as destined for DRAM.

		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
43	WrDram	<b>_4K_E5000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
	the range	are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
42:40		
	ValidValu	ues:
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
39:37	Reserved.	
36	RdDram	<b>_4K_E4000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the
		marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
35		<b>_4K_E4000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
		are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
0.4.00		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
34:32		e_4K_E4000: memory type. Read-write. Reset: XXXb.
	ValidValu	
	Value	UC or uncacheable.
	0h	
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
24.20	7h	Reserved.
	Reserved.	
28		<b>_4K_E3000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the
		marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
27		<b>_4K_E3000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
21		are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
26:24		e_4K_E3000: memory type. Read-write. Reset: XXXb.
	ValidValı	
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
		- 0

	a) -1	I	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
23:21	Reserved	•	
20	RdDram	<b>_4K_E2000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the	
		marked as destined for DRAM.	
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
19	WrDram	<b>1_4K_E2000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
	the range	are marked as destined for DRAM.	
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
18:16	MemTyp	e_4K_E2000: memory type. Read-write. Reset: XXXb.	
	ValidVal	ues:	
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
15.13	Reserved		
12		<b>_4K_E1000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the	
		marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
11		<b>1_4K_E1000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
	the range are marked as destined for DRAM.		
		rpe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
10:8		e_4K_E1000: memory type. Read-write. Reset: XXXb.	
	ValidVal		
	Value	Description	
	0h	UC or uncacheable.	
	l 1h	WC or write combining.	
	1h 3h-2h	WC or write combining.  Reserved	
	3h-2h	Reserved.	
	3h-2h 4h	Reserved. WT or write through.	
	3h-2h 4h 5h	Reserved. WT or write through. WP or write protect.	
	3h-2h 4h 5h 6h	Reserved. WT or write through. WP or write protect. WB or write back.	
7.5	3h-2h 4h 5h 6h 7h	Reserved. WT or write through. WP or write protect. WB or write back. Reserved.	
7:5	3h-2h 4h 5h 6h 7h Reserved	Reserved. WT or write through. WP or write protect. WB or write back. Reserved.	
7:5 4	3h-2h 4h 5h 6h 7h Reserved	Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.  -4K_E0000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the	
	3h-2h 4h 5h 6h 7h Reserved RdDram range are	Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.   _4K_E0000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the marked as destined for DRAM. Address range from E0000h to E0FFFh.	
	3h-2h 4h 5h 6h 7h Reserved RdDram range are Core::X8	Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.  -4K_E0000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the marked as destined for DRAM. Address range from E0000h to E0FFFh.  6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.	
	3h-2h 4h 5h 6h 7h Reserved RdDram range are Core::X8 AccessTy	Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.	

3	WrDram	<b>_4K_E0000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to		
the range are marked as destined for DRAM. Address range from E0000h to E0FFFh.				
	Core::X86::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.			
	AccessTy	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
	Core::X8	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
2:0	MemTyp	<b>e_4K_E0000</b> : <b>memory type</b> . Read-write. Reset: XXXb. Address range from E0000h to E0FFFh.		
	ValidValu	ValidValues:		
	Value Description			
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		
	7h	Reserved.		

# MSR0000\_026D [Fixed-Size MTRRs] (Core::X86::Msr::MtrrFix\_4K\_5)

See Core::X86::Msr::MtrrVarBase for general MTRR information. Fixed MTRRs are enabled through Core::X86::Msr::MTRRdefType[MtrrDefTypeFixEn,MtrrDefTypeEn]. For addresses below 1-MB, the appropriate Fixed MTRRs override the default access destination. Each fixed MTRR includes two bits, RdDram and WrDram, that determine the destination based on the access type. Writing Reserved MemType values causes an Error-on-write.

https://doi.org/10.1016/j.core/10.10

_itiliee[1	u]_cute[3.u]_n312E4K3, M3K0000_020D
Bits	Description
63:61	Reserved.
60	<b>RdDram_4K_EF000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to
	the range are marked as destined for DRAM.
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
59	<b>WrDram_4K_EF000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
	the range are marked as destined for DRAM.
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
58:56	MemType_4K_EF000: memory type. Read-write. Reset: XXXb.
	ValidValues

# ValidValues:

Value	alue Description	
0h	UC or uncacheable.	
1h	WC or write combining.	
3h-2h	Reserved.	
4h	WT or write through.	
5h	WP or write protect.	
6h	WB or write back.	
7h	Reserved.	

#### 55:53 Reserved.

**RdDram\_4K\_EE000: Read DRAM.** 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as destined for DRAM.

AccessType: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? X : Fixed,0.

WrDram\_4K\_EE000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as destined for DRAM.

AccessType: Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:

So:48   MemType_4K_EE000: memory type. Read-write. Reset: XXXb.   ValidValues:			
Valid Value   Description	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
Value   Description			
0h UC or uncacheable. 1h WC or write combining. 3h-2h Reserved. 4h WT or write through. 5h WP or write protect. 6h WB or write back. 7h Reserved.  47:45 Reserved.  47:45 Reserved.  48 RdDram_4K_ED000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read acc the range are marked as destined for DRAM. AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  43 WrDram_4K_ED000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write act the range are marked as destined for DRAM. AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  42:40 MemType_4K_ED000: memory type. Read-write. Reset: XXXb. ValidValues:  Value Description 0h UC or uncacheable. 1h WC or write combining. 3h-2h Reserved. 4h WT or write through. 5h WP or write protect. 6h WB or write back.			
1h WC or write combining. 3h-2h Reserved. 4h WT or write through. 5h WP or write protect. 6h WB or write back. 7h Reserved.  47:45 Reserved.  44 RdDram_4K_ED000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read acc the range are marked as destined for DRAM. AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  43 WrDram_4K_ED000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write act the range are marked as destined for DRAM. AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  42:40 MemType_4K_ED000: memory type. Read-write. Reset: XXXb. ValidValues:  Value Description 0h UC or uncacheable. 1h WC or write combining. 3h-2h Reserved. 4h WT or write through. 5h WP or write protect. 6h WB or write back.			
3h-2h Reserved. 4h WT or write through. 5h WP or write protect. 6h WB or write back. 7h Reserved.  47:45 Reserved.  48dDram_4K_ED000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read acc the range are marked as destined for DRAM. AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  43 WrDram_4K_ED000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write act the range are marked as destined for DRAM. AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  42:40 MemType_4K_ED000: memory type. Read-write. Reset: XXXb. ValidValues:  Value Description 0h UC or uncacheable. 1h WC or write combining. 3h-2h Reserved. 4h WT or write through. 5h WP or write protect. 6h WB or write back.			
4h WT or write through. 5h WP or write protect. 6h WB or write back. 7h Reserved.  47:45 Reserved.  48 RdDram_4K_ED000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses the range are marked as destined for DRAM. AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  43 WrDram_4K_ED000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as destined for DRAM. AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  42:40 MemType_4K_ED000: memory type. Read-write. Reset: XXXb. ValidValues:  Value Description 0h UC or uncacheable. 1h WC or write combining. 3h-2h Reserved. 4h WT or write through. 5h WP or write protect. 6h WB or write back.			
Sh    WP or write protect.			
6h WB or write back. 7h Reserved.  47:45 Reserved.  44 RdDram_4K_ED000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as destined for DRAM.  AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  43 WrDram_4K_ED000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write accessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  42:40 MemType_4K_ED000: memory type. Read-write. Reset: XXXb.  ValidValues:  Value Description  0h UC or uncacheable. 1h WC or write combining. 3h-2h Reserved. 4h WT or write through. 5h WP or write protect. 6h WB or write back.			
7h Reserved.  47:45 Reserved.  44 RdDram_4K_ED000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as destined for DRAM.  AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  43 WrDram_4K_ED000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write accessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  42:40 MemType_4K_ED000: memory type. Read-write. Reset: XXXb.  ValidValues:  Value Description  0h UC or uncacheable.  1h WC or write combining.  3h-2h Reserved.  4h WT or write through.  5h WP or write protect.  6h WB or write back.			
47:45 Reserved.  44 RdDram_4K_ED000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as MMIO. 1=Write accesses to the range are marked as MMIO. 1=Write accessive to the range are marked as MMIO. 1=Write accessive to the range are marked as MMIO. 1=Write accessive to the range are marked as MMIO. 1=Write accessive to the range are marked as MMIO. 1=Write accesses to the range are marked as descined for DRAM.  42:40 MemType_4K_ED000: memory type. Pead-write accesses to the range are marked as descined for DRAM.  42:40 MemType_4K_ED000: memory type. Pead-write accesses to the range are marked a			
44 RdDram_4K_ED000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as MMIO. 1=Read accesses to the range are marked as MMIO. 1=Read accesses type: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  43 WrDram_4K_ED000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write accesses type: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. In Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  42:40 MemType_4K_ED000: memory type. Read-write. Reset: XXXb.  ValidValues:  Value Description  0h UC or uncacheable.  1h WC or write combining.  3h-2h Reserved.  4h WT or write through.  5h WP or write protect.  6h WB or write back.			
the range are marked as destined for DRAM.  AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1.   Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  WrDram_4K_ED000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write actes the range are marked as destined for DRAM.  AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1.   Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  42:40  MemType_4K_ED000: memory type. Read-write. Reset: XXXb.  ValidValues:  Value Description  0h UC or uncacheable.  1h WC or write combining.  3h-2h Reserved.  4h WT or write through.  5h WP or write protect.  6h WB or write back.			
AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  43 WrDram_4K_ED000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write act the range are marked as destined for DRAM.  AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  42:40 MemType_4K_ED000: memory type. Read-write. Reset: XXXb.  ValidValues:  Value Description  0h UC or uncacheable.  1h WC or write combining.  3h-2h Reserved.  4h WT or write through.  5h WP or write protect.  6h WB or write back.	esses to		
Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  43			
WrDram_4K_ED000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write act the range are marked as destined for DRAM.  AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. In Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  42:40 MemType_4K_ED000: memory type. Read-write. Reset: XXXb.  ValidValues:  Value Description  0h UC or uncacheable.  1h WC or write combining.  3h-2h Reserved.  4h WT or write through.  5h WP or write protect.  6h WB or write back.	leset:		
the range are marked as destined for DRAM.  AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1.   Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  42:40  MemType_4K_ED000: memory type. Read-write. Reset: XXXb.  ValidValues:  Value Description  0h UC or uncacheable.  1h WC or write combining.  3h-2h Reserved.  4h WT or write through.  5h WP or write protect.  6h WB or write back.			
AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1.   Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  42:40	cesses to		
Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  42:40			
42:40 MemType_4K_ED000: memory type. Read-write. Reset: XXXb.  ValidValues:  Value Description  Oh UC or uncacheable.  1h WC or write combining.  3h-2h Reserved.  4h WT or write through.  5h WP or write protect.  6h WB or write back.	leset:		
ValidValues:  Value Description  Oh UC or uncacheable.  1h WC or write combining.  3h-2h Reserved.  4h WT or write through.  5h WP or write protect.  6h WB or write back.			
Value Description  Oh UC or uncacheable.  1h WC or write combining.  3h-2h Reserved.  4h WT or write through.  5h WP or write protect.  6h WB or write back.			
0h UC or uncacheable.  1h WC or write combining.  3h-2h Reserved.  4h WT or write through.  5h WP or write protect.  6h WB or write back.			
1h WC or write combining. 3h-2h Reserved. 4h WT or write through. 5h WP or write protect. 6h WB or write back.			
3h-2h Reserved. 4h WT or write through. 5h WP or write protect. 6h WB or write back.			
4h WT or write through. 5h WP or write protect. 6h WB or write back.			
5h WP or write protect. 6h WB or write back.			
6h WB or write back.			
7h Reserved.			
39:37 Reserved.			
36 <b>RdDram_4K_EC000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read acc	esses to		
the range are marked as destined for DRAM.			
AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1.	Reset:		
Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
35 <b>WrDram_4K_EC000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses	cesses to		
the range are marked as destined for DRAM.			
AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1.	leset:		
Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
4:32 MemType_4K_EC000: memory type. Read-write. Reset: XXXb.			
ValidValues:			
Value Description			
0h UC or uncacheable.			
1h WC or write combining.			
3h-2h Reserved.			
4h WT or write through.			
5h WP or write protect.			
6h WB or write back.			
7h Reserved.			

	_	
	Reserved.	
the range are marked as destined for DRAM.		<b>_4K_EB000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to are marked as destined for DRAM.
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
27		<b>_4K_EB000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
	the range	are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
26:24		e_4K_EB000: memory type. Read-write. Reset: XXXb.
	ValidValu	
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
23:21	Reserved.	
20	RdDram	<b>_4K_EA000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to
		are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
		<b>_4K_EA000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
		are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
18:16	MemType_4K_EA000: memory type. Read-write. Reset: XXXb.	
	ValidValu	
		Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
	Reserved.	
12		<b>_4K_E9000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the
		marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
4.4		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
11		<b>_4K_E9000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
		are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
10.0		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
10:8		e_4K_E9000: memory type. Read-write. Reset: XXXb.
	ValidValı	les:

	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
7:5	Reserved		
4		<b>_4K_E8000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the marked as destined for DRAM. Address range from E8000h to E8FFFh.	
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
		<b>_4K_E8000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
		are marked as destined for DRAM. Address range from E8000h to E8FFFh.	
		6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
2:0	<b>MemType_4K_E8000</b> : <b>memory type</b> . Read-write. Reset: XXXb. Address range from E8000h to E8FFFh.		
	ValidVal		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	

## MSR0000\_026E [Fixed-Size MTRRs] (Core::X86::Msr::MtrrFix\_4K\_6)

See Core::X86::Msr::MtrrVarBase for general MTRR information. Fixed MTRRs are enabled through Core::X86::Msr::MTRRdefType[MtrrDefTypeFixEn,MtrrDefTypeEn]. For addresses below 1-MB, the appropriate Fixed MTRRs override the default access destination. Each fixed MTRR includes two bits, RdDram and WrDram, that determine the destination based on the access type. Writing Reserved MemType values causes an Error-on-write.

_lthree[1	three[1:0]_core[3:0]_nSIZE4K6; MSR0000_026E			
Bits	Descripti	on		
63:61	Reserved.			
60	RdDram	<b>RdDram_4K_F7000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the		
	range are	marked as destined for DRAM.		
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
59	<b>WrDram_4K_F7000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to			
	the range	are marked as destined for DRAM.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:		
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.			
58:56	MemType_4K_F7000: memory type. Read-write. Reset: XXXb.			
	ValidValu	ues:		
	Value	Description		
	0h	UC or uncacheable.		

	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
55:53	Reserved		
52		<b>_4K_F6000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the marked as destined for DRAM.	
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
51		<b>1_4K_F6000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
		are marked as destined for DRAM.	
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
50:48		e_4K_F6000: memory type. Read-write. Reset: XXXb.	
	ValidVal		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
45.45			
	Reserved		
	range are	<b>_4K_F5000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the marked as destined for DRAM.	
	Core::X8	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
43	the range	<b>1_4K_F5000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to are marked as destined for DRAM.	
	AccessTy Core::X8	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
42:40	MemTyp	e_4K_F5000: memory type. Read-write. Reset: XXXb.	
	ValidValues:		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
39:37	Reserved		
		<b>_4K_F4000: Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the	
50	range are marked as destined for DRAM.		
		rpe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	

Core::X86::Msr::SYS\_CFG[MtrrFixDramModEn] ? X : Fixed,0.

35		<b>_4K_F4000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
	the range are marked as destined for DRAM.		
	AccessType: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
34:32 <b>MemType_4K_F4000</b> : <b>memory type</b> . Read-write. Reset: XXXb.			
34:32	ValidValı		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
21.20			
	Reserved.		
28		<b>_4K_F3000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Core	6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
27		<b>1_4K_F3000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
27		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
26:24		e_4K_F3000: memory type. Read-write. Reset: XXXb.	
	ValidValues:		
	Value	Description	
	0h	UC or uncacheable.	
	0h 1h	•	
		UC or uncacheable.	
	1h	UC or uncacheable. WC or write combining.	
	1h 3h-2h	UC or uncacheable. WC or write combining. Reserved.	
	1h 3h-2h 4h	UC or uncacheable. WC or write combining. Reserved. WT or write through.	
	1h 3h-2h 4h 5h	UC or uncacheable. WC or write combining. Reserved. WT or write through. WP or write protect.	
23:21	1h 3h-2h 4h 5h 6h	UC or uncacheable. WC or write combining. Reserved. WT or write through. WP or write protect. WB or write back. Reserved.	
23:21	1h 3h-2h 4h 5h 6h 7h Reserved.	UC or uncacheable. WC or write combining. Reserved. WT or write through. WP or write protect. WB or write back. Reserved.	
	1h 3h-2h 4h 5h 6h 7h Reserved.	UC or uncacheable. WC or write combining. Reserved. WT or write through. WP or write protect. WB or write back. Reserved.	
	1h 3h-2h 4h 5h 6h 7h Reserved. RdDram range are AccessTy	UC or uncacheable. WC or write combining. Reserved. WT or write through. WP or write protect. WB or write back. Reserved.  -4K_F2000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the marked as destined for DRAM. pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
20	1h 3h-2h 4h 5h 6h 7h Reserved. RdDram range are AccessTy Core::X86	UC or uncacheable.  WC or write combining.  Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.  -4K_F2000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the marked as destined for DRAM.  pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
	1h 3h-2h 4h 5h 6h 7h Reserved. RdDram range are AccessTy Core::X80	UC or uncacheable.  WC or write combining.  Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.	
20	1h 3h-2h 4h 5h 6h 7h Reserved. RdDram range are AccessTy Core::X80 WrDram the range	UC or uncacheable.  WC or write combining.  Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.	
20	1h 3h-2h 4h 5h 6h 7h Reserved. RdDram range are AccessTy Core::X80 WrDram the range AccessTy	UC or uncacheable.  WC or write combining.  Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.  -4K_F2000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the marked as destined for DRAM.  pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.  -4K_F2000: Write DRAM. 0=Write accesses to the range are marked as MMIO. 1=Write accesses to are marked as destined for DRAM.  pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
19	1h 3h-2h 4h 5h 6h 7h Reserved. RdDram range are AccessTy Core::X80 WrDram the range AccessTy Core::X80	UC or uncacheable.  WC or write combining.  Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.	
19	1h 3h-2h 4h 5h 6h 7h Reserved. RdDram range are AccessTy Core::X80 WrDram the range AccessTy Core::X80 MemTyp	UC or uncacheable.  WC or write combining.  Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.	
19	1h 3h-2h 4h 5h 6h 7h Reserved. RdDram range are AccessTy Core::X80 WrDram the range AccessTy Core::X80 MemTyp ValidValue	UC or uncacheable.  WC or write combining.  Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.	
19	1h 3h-2h 4h 5h 6h 7h Reserved. RdDram range are AccessTy Core::X80 WrDram the range AccessTy Core::X80 MemTyp ValidValue	UC or uncacheable.  WC or write combining.  Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.	
19	1h 3h-2h 4h 5h 6h 7h Reserved. RdDram range are AccessTy Core::X80 WrDram the range AccessTy Core::X80 MemTyp ValidValue 0h	UC or uncacheable.  WC or write combining.  Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.	
19	1h 3h-2h 4h 5h 6h 7h Reserved. RdDram range are AccessTy Core::X80 WrDram the range AccessTy Core::X80 MemTyp ValidValue 0h 1h	UC or uncacheable.  WC or write combining.  Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.	
19	1h 3h-2h 4h 5h 6h 7h Reserved. RdDram range are AccessTy Core::X80 WrDram the range AccessTy Core::X80 MemTyp ValidValue 0h	UC or uncacheable.  WC or write combining.  Reserved.  WT or write through.  WP or write protect.  WB or write back.  Reserved.	

	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
15:13	3 Reserved.		
12	2 RdDram_4K_F1000: Read DRAM. 0=Read accesses to the range are marked as MMIO. 1=Read accesses to		
	range are	marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
11		<b>_4K_F1000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
10:8		e_4K_F1000: memory type. Read-write. Reset: XXXb.	
	ValidValu		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
7:5	Reserved		
4	RdDram	<b>_4K_F0000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the	
	range are	marked as destined for DRAM. Address range from F0000h to F0FFF.	
	Core::X8	6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
3		<b>_4K_F0000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
		are marked as destined for DRAM. Address range from F0000h to F0FFF.	
		6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
	Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.		
2:0	<b>MemType_4K_F0000</b> : <b>memory type</b> . Read-write. Reset: XXXb. Address range from F0000h to F0FFFh.		
	ValidValues:		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	

## MSR0000\_026F [Fixed-Size MTRRs] (Core::X86::Msr::MtrrFix\_4K\_7)

See Core::X86::Msr::MtrrVarBase for general MTRR information. Fixed MTRRs are enabled through Core::X86::Msr::MTRRdefType[MtrrDefTypeFixEn,MtrrDefTypeEn]. For addresses below 1-MB, the appropriate Fixed MTRRs override the default access destination. Each fixed MTRR includes two bits, RdDram and WrDram, that determine the destination based on the access type. Writing Reserved MemType values causes an Error-on-write.

\_lthree[1:0]\_core[3:0]\_nSIZE4K7; MSR0000\_026F

Bits	Descripti	on	
	Reserved.		
60		<b>_4K_FF000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
59	WrDram	<b>_4K_FF000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
58:56		e_4K_FF000: memory type. Read-write. Reset: XXXb.	
	ValidValu		
	Value	Description	
	0h	UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
	7h	Reserved.	
55:53	Reserved.		
52	RdDram	<b>_4K_FE000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
51		<b>_4K_FE000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
	the range are marked as destined for DRAM.		
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
50.40		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
50:48		e_4K_FE000: memory type. Read-write. Reset: XXXb.	
	ValidValu		
		Description  I.G. and the skills of the skil	
		UC or uncacheable.	
	1h	WC or write combining.	
	3h-2h	Reserved.	
	4h	WT or write through.	
	5h	WP or write protect.	
	6h	WB or write back.	
45.45	7h	Reserved.	
44		<b>_4K_FD000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
		are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
42			
43		<b>_4K_FD000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to are marked as destined for DRAM.	
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:	
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.	
42:40		e_4K_FD000: memory type. Read-write. Reset: XXXb.	
72,70	cm ryp	C_11_1 Dood, memory type, redu write, reset, 27/20.	

	ValidValues:	
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
39:37	Reserved.	
		<b>_4K_FC000: Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to
30	the range	are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
35		<b>_4K_FC000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to are marked as destined for DRAM.
	AccessTy	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
34:32	MemTyp	e_4K_FC000: memory type. Read-write. Reset: XXXb.
	ValidValı	ies:
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
31:29	Reserved.	
28		<b>_4K_FB000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
27	WrDram	<b>_4K_FB000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
		are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
26:24		
	ValidValu	
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
23:21	Reserved.	
20	<b>RdDram_4K_FA000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to	
20	ייים ויים ויידי	11_111000. Inclu Div 1111, 0-11cud accesses to the failge are marked as wilvito. 1-11cad accesses to

	the many and an all of the DDAM	
	the range are marked as destined for DRAM.	
	Core::X80	pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset: 6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
		<b>_4K_FA000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
	the range	are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
18:16		<b>e_4K_FA000</b> : <b>memory type</b> . Read-write. Reset: XXXb.
	ValidValu	
	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
15:13	Reserved.	
12	RdDram	<b>_4K_F9000</b> : <b>Read DRAM</b> . 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the
	range are	marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
11	<b>WrDram_4K_F9000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to	
		are marked as destined for DRAM.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
10:8		e_4K_F9000: memory type. Read-write. Reset: XXXb.
	ValidValu	
	Value	Description L.
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
	Reserved.	
		<b>_4K_F8000: Read DRAM.</b> 0=Read accesses to the range are marked as MMIO. 1=Read accesses to the
	_	marked as destined for DRAM. Address range from F8000h to F8FFFh.  6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		6::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
3		<b>_4K_F8000</b> : <b>Write DRAM</b> . 0=Write accesses to the range are marked as MMIO. 1=Write accesses to
5		are marked as destined for DRAM. Address range from F8000h to F8FFFh.
		6::Msr::SYS_CFG[MtrrFixDramEn,MtrrFixDramModEn] masks Reads of the stored value.
		pe: Core::X86::Msr::SYS_CFG[MtrrFixDramModEn] ? Read-write : Read,Error-on-write-1. Reset:
		5::Msr::SYS_CFG[MtrrFixDramModEn] ? X : Fixed,0.
2:0		<b>e_4K_F8000</b> : <b>memory type</b> . Read-write. Reset: XXXb. Address range from F8000h to F8FFFh.
	ValidValı	

ValidValues:

	Value	Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.

#### MSR0000\_0277 [Page Attribute Table] (Core::X86::Msr::PAT) This register specifies the memory type based on the PAT, PCD, and PWT bits in the virtual address page tables. lthree[1:0]\_core[3:0]\_thread[1:0]; MSR0000\_0277 Bits Description 63:59 Reserved. 58:56 **PA7MemType**. Read-write. Reset: 0h. Default UC. MemType for {PAT, PCD, PWT} = 7h. ValidValues: Description Value 0h UC or uncacheable. WC or write combining. 1h 3h-2h Reserved. 4h WT or write through. WP or write protect. 5h 6h WB or write back. 7h Reserved. 55:51 Reserved. 50:48 **PA6MemType**. Read-write. Reset: 7h. Default UC. MemType for {PAT, PCD, PWT} = 6h. ValidValues: Value Description 0h UC or uncacheable. 1h WC or write combining. 3h-2h Reserved. 4h WT or write through. 5h WP or write protect. 6h WB or write back. 7h Reserved. 47:43 Reserved. 42:40 **PA5MemType**. Read-write. Reset: 4h. Default WT. MemType for {PAT, PCD, PWT} = 5h. ValidValues: Description Value 0h UC or uncacheable. WC or write combining. 1h 3h-2h Reserved. 4h WT or write through. 5h WP or write protect. 6h WB or write back. 7h Reserved. 39:35 Reserved.

34:32 **PA4MemType**. Read-write. Reset: 6h. Default WB. MemType for {PAT, PCD, PWT} = 4h.

	¥ 7- 1	D		
	Value	Description LIG		
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		
	7h	Reserved.		
31:27	Reserved			
26:24	PA3Mem	Type. Read-write. Reset: 0h. Default UC. MemType for {PAT, PCD, PWT} = 3h.		
	ValidValu	ues:		
	Value	Description		
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		
	7h	Reserved.		
23:19	Reserved			
18:16	<b>PA2MemType</b> . Read-write. Reset: 7h. Default UC. MemType for {PAT, PCD, PWT} = 2h.			
	ValidValı	ues:		
	Value	Description		
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		
	7h	Reserved.		
15:11	Reserved			
10:8	PA1Mem	Type. Read-write. Reset: 4h. Default WT. MemType for {PAT, PCD, PWT} = 1h.		
	ValidValı	ues:		
	Value	Description		
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		
	4h	WT or write through.		
	5h	WP or write protect.		
	6h	WB or write back.		
	7h	Reserved.		
7:3	Reserved			
2:0	PA0Mem	Type. Read-write. Reset: 6h. MemType for {PAT, PCD, PWT} = 0h.		
	ValidValı			
	Value	Description		
	0h	UC or uncacheable.		
	1h	WC or write combining.		
	3h-2h	Reserved.		

4h	WT or write through.	1
5h	WP or write protect.	
6h	WB or write back.	
7h	Reserved.	

See C	ore::X86::Msr::MtrrVarBase for general MTRR information.				
_lthree[1	_lthree[1:0]_core[3:0]; MSR0000_02FF				
Bits	Description				
63:12	Reserved.				
11	MtrrDefTypeEn: variable and fixed MTRR enable. Read-write. Reset: 0. 0=Fixed and variable MTRRs are not				
	enabled. 1=Core::X86::Msr::MtrrVarBase, and Core::X86::Msr::MtrrFix_64K through				
	Core::X86::Msr::MtrrFix_4K_7 are enabled.				
10	MtrrDefTypeFixEn: fixed MTRR enable. Read-write. Reset: 0. 0=Core::X86::Msr::MtrrFix_64K through				
	Core::X86::Msr::MtrrFix_4K_7 are not enabled. 1=Core::X86::Msr::MtrrFix_64K through				
	Core::X86::Msr::MtrrFix_4K_7 are enabled. This field is ignored (and the fixed MTRRs are not enabled) if				
	Core::X86::Msr::MTRRdefType[MtrrDefTypeEn] == 0.				
9:8	Reserved.				
7:0	MemType: memory type. Read-write. Reset: 00h.				
	<b>Description</b> : If MtrrDefTypeEn == 1 then MemType specifies the memory type for memory space that is not				
	specified by either the fixed or variable range MTRRs. If MtrrDefTypeEn == 0 then the default memory type for				
	all of memory is UC.				
	Valid encodings are {00000b, Core::X86::Msr::MtrrFix_64K through Core::X86::Msr::MtrrFix_4K_7[2:0]}.				
	Other write values cause a GP(0).				

# MSR0000\_0802 [APIC ID] (Core::X86::Msr::APIC\_ID)

_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_0802		
Bits	Description		
63:32	Reserved.		
31:0	ApicId[31:0]: APIC ID[31:0]. Reset: XXXX_XXXXh. Local x2APIC ID register.		
	AccessType: X2APICEN? Read-only, Error-on-write: Error-on-read, Error-on-write.		

# MSR0000\_0803 [APIC Version] (Core::X86::Msr::ApicVersion)

_lthree[1	lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_0803			
Bits	Description			
63:32	Reserved.			
31	<b>ExtApicSpace</b> : <b>extended APIC register space present</b> . Reset: 1. 1=Indicates the presence of extended APIC			
	register space starting at Core::X86::Msr::ExtendedApicFeature.			
	AccessType: X2APICEN? Read-only, Error-on-write: Error-on-read, Error-on-write.			
30:25	Reserved.			
24	<b>DirectedEoiSupport</b> : <b>directed EOI support</b> . Reset: 0. 0=Directed EOI capability not supported. 1=Directed			
	EOI capability supported.			
	AccessType: X2APICEN? Read-only, Error-on-write: Error-on-read, Error-on-write.			
23:16	6 <b>MaxLvtEntry</b> . Reset: XXh. Specifies the number of entries in the local vector table minus one.			
	AccessType: X2APICEN? Read-only, Error-on-write: Error-on-read, Error-on-write.			
15:8	Reserved.			
7:0	<b>Version</b> . Reset: 10h. Indicates the version number of this APIC implementation.			
	AccessType: X2APICEN? Read-only,Error-on-write: Error-on-read,Error-on-write.			

# MSR0000\_0808 [Task Priority] (Core::X86::Msr::TPR)

_itiliee[1	_ttillee[1.0]_cole[3.0]_tillead[1.0], M3K0000_0008				
ъ.	_		. •		

## **Bits** Description

63:8	Reserved.
7:0	<b>Priority</b> . Reset: 00h. This field is assigned by software to set a threshold priority at which the core is interrupted.
	AccessType: X2APICEN? Read-write, Volatile: Error-on-read, Error-on-write.

# MSR0000\_0809 [Arbitration Priority] (Core::X86::Msr::ArbitrationPriority)

Reset:	Reset: 0000_0000_0000_0000h.			
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_0809			
Bits	S Description			
63:8	Reserved.			
7:0	<b>Priority</b> . Reset: 00h. Indicates the current priority for a pending interrupt, or a task or interrupt being serviced by			
	the core. The priority is used to arbitrate between cores to determine which accepts a lowest-priority interrupt			
	request.			
	AccessType: X2APICEN ? Read-only,Error-on-write,Volatile : Error-on-read,Error-on-write.			

# MSR0000\_080A [Processor Priority] (Core::X86::Msr::ProcessorPriority)

Reset:	Reset: 0000_0000_0000_0000h.			
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_080A			
Bits	s Description			
63:8	Reserved.			
7:0	<b>Priority</b> . Reset: 00h. Indicates the core's current priority servicing a task or interrupt, and is used to determine if			
	any pending interrupts should be serviced. It is the higher value of the task priority value and the current highest			
	in-service interrupt.			
	AccessType: X2APICEN? Read-only, Error-on-write, Volatile: Error-on-read, Error-on-write.			

# MSR0000\_080B [End Of Interrupt] (Core::X86::Msr::EOI)

	0000_0000_0000_0000h.		
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_080B		
Bits	Description		
63:0	<b>EOI</b> . Reset: 0000_0000_0000_0000h. A write zero to this field indicates the end of interrupt processing the		
	currently in service interrupt.		
	AccessType: X2APICEN? Write-0-only,Error-on-read,Error-on-write-1: Error-on-read,Error-on-write.		

# MSR0000\_080D [Logical Destination Register] (Core::X86::Msr::LDR)

Reset:	Reset: 0000_0000_0000_0000h.				
_lthree[1	1:0]_core[3:0]_thread[1:0]; MSR0000_080D				
Bits	Descripti	Description			
63:32	Reserved.	Reserved.			
31:16	ClusterD	estination. Reset: 0000h. Specifies cluster's destination identification.			
	AccessTy	pe: X2APICEN ? Read-only : Error-on-read,Error-on-write.			
15:0	LogicalD	<b>estination</b> . Reset: 0000h. Specifies one of up to sixteen x2APICs within the cluster specified by			
	ClusterDe	estination.			
	AccessTy	AccessType: X2APICEN? Read-only: Error-on-read, Error-on-write.			
	ValidValu	/alidValues:			
	Bit	Bit Description			
	[0]	[0] x2APIC 0			
	[1]	[1] x2APIC 1			
	[2]	[2] x2APIC 2			
	[3]	[3] x2APIC 3			
	[4]	x2APIC 4			
	[5]	[5] x2APIC 5			
	[6]	[6] x2APIC 6			

[7]	x2APIC 7
[8]	x2APIC 8
[9]	x2APIC 9
[10]	x2APIC 10
[11]	x2APIC 11
[12]	x2APIC 12
[13]	x2APIC 13
[14]	x2APIC 14
[15]	x2APIC 15

MSR0000_080E	[Spurious	Interrupt	Vector] (	(Core::X86::Msr::SVR)
--------------	-----------	-----------	-----------	-----------------------

_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_080F		
Bits	Description		
63:10	Reserved.		
9	<b>FocusDisable</b> . Reset: 0. 1=Disable focus core checking during lowest-priority arbitrated interrupts.		
	AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.		
8	APICSWEn: APIC software enable. Reset: 0. All LVT entry mask bits are set and cannot be cleared.		
	AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.		
7:0	<b>Vector</b> . Reset: FFh. The vector that is sent to the core in the event of a spurious interrupt.		
	AccessType: X2APICEN ? Read-write : Error-on-read,Error-on-write.		

# MSR0000\_081[0...7] [In Service Register] (Core::X86::Msr::ISR)

Reset: 0000_0000_0000_0000h.		
Interrupt In Service status bits [255:0] accessible through 8 ISR registers.		
_lthree[1:0]_core[3:0]_thread[1:0]_nISR0_aliasMSR; MSR0000_0810		
_lthree[1:0]_core[3:0]_thread[1:0]_nISR1_aliasMSR; MSR0000_0811		
_lthree[1:0]_core[3:0]_thread[1:0]_nISR2_aliasMSR; MSR0000_0812		
_lthree[1:0]_core[3:0]_thread[1:0]_nISR3_aliasMSR; MSR0000_0813		
_lthree[1:0]_core[3:0]_thread[1:0]_nISR4_aliasMSR; MSR0000_0814		
_lthree[1:0]_core[3:0]_thread[1:0]_nISR5_aliasMSR; MSR0000_0815		
_lthree[1:0]_core[3:0]_thread[1:0]_nISR6_aliasMSR; MSR0000_0816		
_lthree[1:0]_core[3:0]_thread[1:0]_nISR7_aliasMSR; MSR0000_0817		
Bits Description		
63:32 Reserved.		
31:0 <b>InServiceBits</b> . Reset: 0000_0000h. These bits are set when the corresponding interrupt is being serviced by the		
core.		
AccessType: X2APICEN? Read-only, Error-on-write, Volatile: Error-on-read, Error-on-write.		

## MSR0000 081[8...F] [Trigger Mode Register] (Core::X86::Msr::TMR)

MOKOOOO_OOT[0r] [111gget Mode Register] (CoreAooMsr1MK)		
Reset: 0000_0000_0000_0000h.		
Trigger Mode status bits [255:0] accessible through 8 TMR registers.		
_lthree[1:0]_core[3:0]_thread[1:0]_nTMR0_aliasMSR; MSR0000_0818		
_lthree[1:0]_core[3:0]_thread[1:0]_nTMR1_aliasMSR; MSR0000_0819		
_lthree[1:0]_core[3:0]_thread[1:0]_nTMR2_aliasMSR; MSR0000_081A		
_lthree[1:0]_core[3:0]_thread[1:0]_nTMR3_aliasMSR; MSR0000_081B		
_lthree[1:0]_core[3:0]_thread[1:0]_nTMR4_aliasMSR; MSR0000_081C		
_lthree[1:0]_core[3:0]_thread[1:0]_nTMR5_aliasMSR; MSR0000_081D		
_lthree[1:0]_core[3:0]_thread[1:0]_nTMR6_aliasMSR; MSR0000_081E		
_lthree[1:0]_core[3:0]_thread[1:0]_nTMR7_aliasMSR; MSR0000_081F		
Bits Description		
63:32 Reserved.		
31:0 <b>TriggerModeBits</b> . Reset: 0000_0000h. The corresponding trigger mode bit is updated when an interrupt is		
accepted.		
AccessType: X2APICEN? Read-only,Error-on-write,Volatile: Error-on-read,Error-on-write.		

ValidValues:	
Value	Description
0	Edge-triggered interrupt
1	Level-triggered interrupt

# MSR0000\_082[0...7] [Interrupt Request Register] (Core::X86::Msr::IRR)

MSK0000_002[0/] [Interrupt Kequest Kegister] (CoreXouWistIKK)		
Reset: 0000_0000_0000_0000h.		
Interrupt Request status bits [255:0] accessible through 8 IRR registers.		
_lthree[1:0]_core[3:0]_thread[1:0]_nIRR0_aliasMSR; MSR0000_0820		
_lthree[1:0]_core[3:0]_thread[1:0]_nIRR1_aliasMSR; MSR0000_0821		
_lthree[1:0]_core[3:0]_thread[1:0]_nIRR2_aliasMSR; MSR0000_0822		
_lthree[1:0]_core[3:0]_thread[1:0]_nIRR3_aliasMSR; MSR0000_0823		
_tthree[1:0]_core[3:0]_thread[1:0]_nIRR4_aliasMSR; MSR0000_0824		
_tthree[1:0]_core[3:0]_thread[1:0]_nIRR5_aliasMSR; MSR0000_0825		
_lthree[1:0]_core[3:0]_thread[1:0]_nIRR6_aliasMSR; MSR0000_0826		
_lthree[1:0]_core[3:0]_thread[1:0]_nIRR7_aliasMSR; MSR0000_0827		
Bits Description		
63:32 Reserved.		
31:0 <b>RequestBits</b> . Reset: 0000_0000h. The corresponding request bit is set when the an interrupt is accepted by the		
x2APIC.		
AccessType: X2APICEN? Read-only, Error-on-write, Volatile: Error-on-read, Error-on-write.		

# MSR0000\_0828 [Error Status Register] (Core::X86::Msr::ESR)

	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,
Reset:	0000_0000_0000_0000h.
_lthree[1	:0]_core[3:0]_thread[1:0]; MSR0000_0828
Bits	Description
63:8	Reserved.
7	<b>IllegalRegAddr</b> : <b>illegal register address</b> . Reset: 0. This bit indicates that an access to a nonexistent register
	location within this APIC was attempted. Can only be set in xAPIC mode.
	AccessType: X2APICEN? Read, Write-0-only, Error-on-write-1, Volatile: Error-on-read, Error-on-write.
6	<b>RcvdIllegalVector</b> : <b>received illegal vector</b> . Reset: 0. This bit indicates that this APIC has received a message
	with an illegal vector (00h to 0Fh for fixed and lowest priority interrupts).
	AccessType: X2APICEN? Read, Write-0-only, Error-on-write-1, Volatile: Error-on-read, Error-on-write.
5	<b>SentIllegalVector</b> . Reset: 0. This bit indicates that this x2APIC attempted to send a message with an illegal
	vector (00h to 0Fh for fixed and lowest priority interrupts).
	AccessType: X2APICEN? Read, Write-0-only, Error-on-write-1, Volatile: Error-on-read, Error-on-write.
4	Reserved.
3	<b>RcvAcceptError</b> : <b>receive accept error</b> . Reset: 0. This bit indicates that a message received by this APIC was not
	accepted by this or any other x2APIC.
	AccessType: X2APICEN? Read, Write-0-only, Error-on-write-1, Volatile: Error-on-read, Error-on-write.
2	<b>SendAcceptError</b> . Reset: 0. This bit indicates that a message sent by this APIC was not accepted by any
	x2APIC.
	AccessType: X2APICEN? Read, Write-0-only, Error-on-write-1, Volatile: Error-on-read, Error-on-write.
1:0	Reserved.

# MSR0000\_0830 [Interrupt Command] (Core::X86::Msr::InterruptCommand)

Reset:	Reset: 0000_0000_0000_0000h.		
_lthree[1	:0]_core[3:0]_thread[1:0]; MSR0000_0830		
Bits	lits Description		
63:32	<b>DestinationField</b> . Reset: 0000_0000h. The destination encoding used when		
	Core::X86::Msr::InterruptCommand[DestShrthnd] == 00b.		
	AccessType: X2APICEN ? Read-write : Error-on-read,Error-on-write.		
31:20	Reserved.		

19:18	<b>DestShrthnd: destination shorthand</b> . Reset: 0h. Provides a quick way to specify a destination for a message.			
	all including self or all excluding self is used, then destination mode is ignored and physical is automatically used. AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.			
	ValidValues:			
	Value Description			
	0h	No shorthand (Destination field).		
	1h	Self.		
	2h	All including self.		
	3h	All excluding self. (This sends a message with a destination encoding of all 1s, so if lowest priority is		
		used the message could end up being reflected back to this APIC.)		
17:16	Reserved.			
15	TM: trigg	ger mode. Reset: 0. 0=Edge triggered. 1=Level triggered. Indicates how this interrupt is triggered.		
	AccessTy	pe: X2APICEN ? Read-write : Error-on-read,Error-on-write.		
14	Level. Re	set: 0. 0=Deasserted. 1=Asserted.		
	AccessTy	pe: X2APICEN ? Read-write : Error-on-read,Error-on-write.		
13:12	Reserved.			
11		I: destination mode. Reset: 0. 0=Physical. 1=Logical.		
		pe: X2APICEN ? Read-write : Error-on-read,Error-on-write.		
10:8		Type. Reset: 0h. The message types are encoded as follows:		
		ssType: X2APICEN ? Read-write : Error-on-read,Error-on-write.		
		lidValues:		
	Value	Description		
	0h	Fixed		
	1h	Lowest Priority.		
	2h	SMI		
	3h	Reserved.		
	4h	NMI		
	5h	INIT		
	6h	Startup		
	7h	External interrupt.		
7:0		eset: 00h. The vector that is sent for this interrupt source.		
	AccessTy	pe: X2APICEN ? Read-write : Error-on-read,Error-on-write.		

# MSR0000\_0832 [LVT Timer] (Core::X86::Msr::TimerLvtEntry)

	•
Reset:	0000_0000_0001_0000h.
_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_0832	
Bits	Description
63:18	Reserved.
17	<b>Mode</b> . Reset: 0. 0=One-shot. 1=Periodic.
	AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.
16	Mask. Reset: 1. 0=Not masked. 1=Masked.
	AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.
15:13	Reserved.
12	<b>DS</b> : <b>interrupt delivery status</b> . Reset: 0. 0=Idle. 1=Send pending. (Indicates that the interrupt has not yet been
	accepted by the core.)
	AccessType: X2APICEN? Read-only, Volatile: Error-on-read, Error-on-write.
11:8	Reserved.
7:0	<b>Vector</b> . Reset: 00h. Interrupt vector number.
	AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.

MSR	0000_0833 [LVT Thermal Sensor] (Core::X86::Msr::ThermalLvtEntry)		
Reset:	Reset: 0000_0000_0001_0000h.		
_lthree[1	:0]_core[3:0]_thread[1:0]; MSR0000_0833		
Bits	Description		
63:17	Reserved.		
16	Mask. Reset: 1. 0=Not masked. 1=Masked.		
	AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.		
15:13	Reserved.		
12	<b>DS</b> : <b>interrupt delivery status</b> . Reset: 0. 0=Idle. 1=Send pending. (Indicates that the interrupt has not yet been		
	accepted by the core.)		
	AccessType: X2APICEN? Read-only, Volatile: Error-on-read, Error-on-write.		
11	Reserved.		
10:8	MsgType: message type. Reset: 0h. See2.1.12.2.1.14 [Generalized Local Vector Table].		
	AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.		
7:0	<b>Vector</b> . Reset: 00h. Interrupt vector number.		
	AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.		

MSR	0000_0834 [LVT Performance Monitor] (Core::X86::Msr::PerformanceCounterLvtEntry)		
Reset:	Reset: 0000_0000_0001_0000h.		
Interru	upts for this local vector table are caused by overflows of:		
•	Core::X86::Msr::PERF_LEGACY_CTL(Performance Event Select [3:0]).		
•	Core::X86::Msr::PERF_CTL(Performance Event Select [5:0]).		
_lthree[1	:0]_core[3:0]_thread[1:0]; MSR0000_0834		
Bits	Description		
63:17	Reserved.		
16	Mask. Reset: 1. 0=Not masked. 1=Masked.		
	AccessType: X2APICEN ? Read-write : Error-on-read, Error-on-write.		
15:13	Reserved.		
12	<b>DS</b> : <b>interrupt delivery status</b> . Reset: 0. 0=Idle. 1=Send pending. (Indicates that the interrupt has not yet been		
	accepted by the core.)		
	AccessType: X2APICEN? Read-only, Volatile: Error-on-read, Error-on-write.		
11	Reserved.		
10:8	<b>MsgType</b> : <b>message type</b> . Reset: 0h. See2.1.12.2.1.14 [Generalized Local Vector Table].		

# MSR0000\_083[5...6] [LVT LINT[1:0]] (Core::X86::Msr::LVTLINT)

**Vector**. Reset: 00h. Interrupt vector number.

7:0

AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.

AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.

Reset: 0000_0000_0001_0000h.	
_lthree[1	:0]_core[3:0]_thread[1:0]_nLVTLINT0_aliasMSR; MSR0000_0835
_lthree[1	:0]_core[3:0]_thread[1:0]_nLVTLINT1_aliasMSR; MSR0000_0836
Bits Description	
63:17	Reserved.
16	Mask. Reset: 1. 0=Not masked. 1=Masked.
	AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.
15	<b>TM</b> : <b>trigger mode</b> . Reset: 0. 0=Edge. 1=Level.
	AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.
14	<b>RmtIRR</b> . Reset: 0. If trigger mode is level, remote Core::X86::Msr::IRR is set when the interrupt has begun
	service. Remote Core::X86::Msr::IRR is cleared when the end of interrupt has occurred.

	AccessType: X2APICEN ? Read-only, Volatile : Error-on-read, Error-on-write.
13	Reserved.
12	<b>DS</b> : <b>interrupt delivery status</b> . Reset: 0. 0=Idle. 1=Send pending. (Indicates that the interrupt has not yet been accepted by the core.)
	AccessType: X2APICEN ? Read-only, Volatile : Error-on-read, Error-on-write.
11	Reserved.
10:8	<b>MsgType</b> : <b>message type</b> . Reset: 0h. See2.1.12.2.1.14 [Generalized Local Vector Table].
	AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.
7:0	<b>Vector</b> . Reset: 00h. Interrupt vector number.
	AccessType: X2APICEN ? Read-write : Error-on-read,Error-on-write.

# MSR0000\_0837 [LVT Error] (Core::X86::Msr::ErrorLvtEntry)

Reset: 0000_0000_0001_0000h.		
_lthree[1	:0]_core[3:0]_thread[1:0]; MSR0000_0837	
Bits Description		
63:17	Reserved.	
16	Mask. Reset: 1. 0=Not masked. 1=Masked.	
	AccessType: X2APICEN ? Read-write : Error-on-read,Error-on-write.	
15:13	Reserved.	
12	<b>DS</b> : <b>interrupt delivery status</b> . Reset: 0. 0=Idle. 1=Send pending. (Indicates that the interrupt has not yet been	
	accepted by the core.)	
	AccessType: X2APICEN? Read-only, Volatile: Error-on-read, Error-on-write.	
11	Reserved.	
10:8	<b>MsgType</b> : <b>message type</b> . Reset: 0h. See 2.1.12.2.1.14 [Generalized Local Vector Table].	
	AccessType: X2APICEN? Read-write: Error-on-read, Error-on-write.	
7:0	<b>Vector</b> . Reset: 00h. Interrupt vector number.	
	AccessType: X2APICEN ? Read-write : Error-on-read,Error-on-write.	

# MSR0000\_0838 [Timer Initial Count] (Core::X86::Msr::TimerInitialCount)

Reset:	0000_0000_0000_0000h.	
_lthree[1	L:0]_core[3:0]_thread[1:0]; MSR0000_0838	
Bits	Description	
63:32	Reserved.	
31:0 <b>Count</b> . Reset: 0000_0000h. The value copied into the current count register when the timer is load		
	AccessType: X2APICEN ? Read-write : Error-on-read,Error-on-write.	

# MSR0000\_0839 [Timer Current Count] (Core::X86::Msr::TimerCurrentCount)

Reset:	0000_0000_0000_0000h.	
_lthree[1	L:0]_core[3:0]_thread[1:0]; MSR0000_0839	
Bits	its Description	
63:32	Reserved.	
31:0	Count. Reset: 0000_0000h. The current value of the counter.	
	AccessType: X2APICEN ? Read-only, Volatile : Error-on-read, Error-on-write.	

## MSR0000\_083E [Timer Divide Configuration] (Core::X86::Msr::TimerDivideConfiguration)

	= 1 8 1
Reset:	0000_0000_0000_0000h.
_lthree[1	:0]_core[3:0]_thread[1:0]; MSR0000_083E
Bits	Description
63:4	Reserved.
3:0	Div[3:0]. Reset: 0h. Div[2] is unused.
	AccessType: X2APICEN ? Read-write : Error-on-read, Error-on-write.

ValidValu	lidValues:	
Value	Description	
0h	Divide by 2.	
1h	Divide by 4.	
2h	Divide by 8.	
3h	Divide by 16.	
7h-4h	Reserved.	
8h	Divide by 32.	
9h	Divide by 64.	
Ah	Divide by 128.	
Bh	Divide by 1.	
Fh-Ch	Reserved.	

## MSR0000\_083F [Self IPI] (Core::X86::Msr::SelfIPI)

Reset: 0000\_0000\_0000\_0000h.

The self IPI register provides a perforamnce optimized path for sending self IPI's. A self IPI is semantically identical to an inter-processor interrupt sent via the ICR, with a Destination Shorthand of Self, Trigger Mode equal to Edge, and a Delivery Mode equal to Fixed.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; MSR0000\_083F

Bits	Description
63:8	Reserved.
7:0	<b>Vector</b> . Reset: 00h. Interrupt vector number.
	AccessType: X2APICEN? Write-only, Error-on-read: Error-on-read, Error-on-write.

# MSR0000\_0840 [Extended APIC Feature] (Core::X86::Msr::ExtendedApicFeature)

	· · · · · · · · · · · · · · · · · · ·	
Reset: 0000_0000_0004_0007h.		
_lthree[1	:0]_core[3:0]_thread[1:0]; MSR0000_0840	
Bits	Description	
63:24	Reserved.	
23:16	<b>ExtLvtCount</b> : <b>extended local vector table count</b> . Reset: 04h. This specifies the number of extended LVT	
	registers (Core::X86::Msr::ExtendedInterruptLvtEntries) in the local APIC.	
	AccessType: X2APICEN? Read-only, Error-on-write: Error-on-read, Error-on-write.	
15:3	Reserved.	
2	<b>ExtApicIdCap: extended APIC ID capable</b> . Reset: 1. 1=The processor is capable of supporting an 8-bit APIC	
	ID, as controlled by Core::X86::Msr::ExtendedApicControl[ExtApicIdEn].	
	AccessType: X2APICEN? Read-only, Error-on-write: Error-on-read, Error-on-write.	
1	<b>SeoiCap: specific end of interrupt capable</b> . Reset: 1. 1=The Core::X86::Msr::SpecificEndOfInterrupt is present.	
	AccessType: X2APICEN? Read-only, Error-on-write: Error-on-read, Error-on-write.	
0	<b>IerCap: interrupt enable register capable</b> . Reset: 1. This bit indicates that the	
	Core::X86::Msr::InterruptEnable0 - 7 are present. See 2.1.12.2.1.8 [Interrupt Masking].	
	AccessType: X2APICEN? Read-only,Error-on-write: Error-on-read,Error-on-write.	

## MSR0000\_0841 [Extended APIC Control] (Core::X86::Msr::ExtendedApicControl)

F	Reset: 0000_0000_0000_0000h.			
	_lthree[1:0]_core[3:0]_thread[1:0]; MSR0000_0841			
	Bits Description			
(	63:3	Reserved.		
	2	ExtApicIdEn: extended APIC ID enable. Reset: 0. 1=Enable 8-bit APIC ID;		
		Core::X86::Msr::APIC_ID[ApicId[31:0]] supports an 8-bit value; an interrupt broadcast in physical destination		
		mode requires that the IntDest[7:0] = 1111_1111b (instead of XXXX_11111b); a match in physical destination		
		mode occurs when (IntDest[7:0] == ApicId[7:0]) instead of (IntDest[3:0] == ApicId[3:0]).		

		AccessType: X2APICEN ? Read-write : Error-on-read,Error-on-write.
1 <b>SeoiEn</b> . Reset: 0. 1=Enable SEOI generation when a write to Core::X86::Msr::SpecificE		SeoiEn. Reset: 0. 1=Enable SEOI generation when a write to Core::X86::Msr::SpecificEndOfInterrupt is
		received.
		AccessType: X2APICEN ? Read-write : Error-on-read,Error-on-write.
	0	IerEn. Reset: 0. 1=Enable writes to the interrupt enable registers.
		AccessType: X2APICEN ? Read-write : Error-on-read,Error-on-write.

# MSR0000\_0842 [Specific End Of Interrupt] (Core::X86::Msr::SpecificEndOfInterrupt)

Reset: 0000_0000_0000_0000h.			
_lthree[1	1:0]_core[3:0]_thread[1:0]; MSR0000_0842		
Bits Description			
63:8	Reserved.		
7:0	<b>EoiVec</b> : <b>end of interrupt vector</b> . Reset: 00h. A write to this field causes an end of interrupt cycle to be performed		
	for the vector specified in this field. The behavior is undefined if no interrupt is pending for the specified interrupt		
	vector.		
	AccessType: X2APICEN ? Read-write : Error-on-read, Error-on-write.		

# MSR0000\_0848 [Interrupt Enable 0] (Core::X86::Msr::InterruptEnable0)

Reset: 0000_0000_FFFF_0000h.				
_lthree[1:0]_core[3:0]_thread[1:0]_n0_aliasMSR; MSR0000_0848				
Bits	Description			
63:32	Reserved.			
31:16	<b>InterruptEnableBits</b> . Reset: FFFFh. The interrupt enable bits can be used to enable each of the 256 interrupts.			
	AccessType: X2APICEN ? Read-write : Error-on-read,Error-on-write.			
15:0	Reserved.			

# MSR0000\_084[9...F] [Interrupt Enable 7..1] (Core::X86::Msr::InterruptEnable71)

Reset: 0000_0000_FFFF_FFFFh.		
_lthree[1:0]_core[3:0]_thread[1:0]_n1_aliasMSR; MSR0000_0849		
_lthree[1:0]_core[3:0]_thread[1:0]_n2_aliasMSR; MSR0000_084A		
_lthree[1:0]_core[3:0]_thread[1:0]_n3_aliasMSR; MSR0000_084B		
_lthree[1:0]_core[3:0]_thread[1:0]_n4_aliasMSR; MSR0000_084C		
_lthree[1:0]_core[3:0]_thread[1:0]_n5_aliasMSR; MSR0000_084D		
_lthree[1:0]_core[3:0]_thread[1:0]_n6_aliasMSR; MSR0000_084E		
_lthree[1:0]_core[3:0]_thread[1:0]_n7_aliasMSR; MSR0000_084F		
Bits Description		
63:32 Reserved.		
10 <b>InterruptEnableBits</b> . Reset: FFFF_FFFFh. The interrupt enable bits can be used to enable each of the 256		
interrupts.		
AccessType: X2APICEN ? Read-write : Error-on-read,Error-on-write.		

# MSR0000\_085[0...3] [Extended Interrupt Local Vector Table] (Core::X86::Msr::ExtendedInterruptLvtEntries)

Reset: 0000_0000_0001_0000h.		
_lthree[1:0]_core[3:0]_thread[1:0]_n0_aliasMSR; MSR0000_0850		
_lthree[1:0]_core[3:0]_thread[1:0]_n1_aliasMSR; MSR0000_0851		
_lthree[1:0]_core[3:0]_thread[1:0]_n2_aliasMSR; MSR0000_0852		
_lthree[1:0]_core[3:0]_thread[1:0]_n3_aliasMSR; MSR0000_0853		
Bits	Description	
	<b>Description</b> Reserved.	
63:17	1	

15:13	Reserved.	
12	<b>DS</b> : <b>interrupt delivery status</b> . Reset: 0. 0=Idle. 1=Send pending. (Indicates that the interrupt has not yet been	
	accepted by the core.)	
	AccessType: X2APICEN? Read-write, Volatile: Error-on-read, Error-on-write.	
11	Reserved.	
10:8	MsgType: message type. Reset: 0h. See2.1.12.2.1.14 [Generalized Local Vector Table].	
	AccessType: X2APICEN ? Read-write : Error-on-read,Error-on-write.	
7:0	Vector. Reset: 00h. Interrupt vector number.	
	AccessType: X2APICEN ? Read-write : Error-on-read,Error-on-write.	

# MSR0000\_0C81 [L3 QoS Configuration] (Core::X86::Msr::L3QosCfg1)

_lthree[1:0]; MSR0000_0C81	
Bits	Description
63:1	Reserved.
0	CDP: CDP enable. Read-write. Reset: 0.

# MSR0000\_0C8D [Monitoring Event Select] (Core::X86::Msr::QM\_EVTSEL)

_lthree[1:0]; MSR0000_0C8D		
Bits	Description	
63:40	Reserved.	
39:32	RMID: Resource Monitoring Identifier. Read-write. Reset: 00h.	
31:8	Reserved.	
7:0	EventId: Monitored Event ID. Read-write. Reset: 00h.	

# MSR0000\_0C8E [QOS L3 Counter] (Core::X86::Msr::QM\_CTR)

Read,Error-on-write. Reset: 0000_0000_00000_0000h.		
_lthree[1:0]; MSR0000_0C8E		
Bits	Description	
63	<b>Error</b> . Read,Error-on-write. Reset: 0. Unsupported RMID or event type was written to	
	Core::X86::Msr::QM_EVTSEL.	
62	<b>Unavailable</b> . Read,Error-on-write. Reset: 0. Data for this RMID is not available or not monitored for this	
	resource or RMID.	
61:0	RmData: Resource Monitored Data. Read.Error-on-write. Reset: 0000 0000 0000 0000h.	

# MSR0000\_0C9[0...F] [L3 QOS Allocation Mask] (Core::X86::Msr::L3QosAllocMask)

	- ,
_lthree[1:0]_n0; MSR0000_0C90	
_lthree[1:0]_n1; MSR0000_0C91	
_lthree[1:0]_n2; MSR0000_0C92	
_lthree[1:0]_n3; MSR0000_0C93	
_lthree[1:0]_n4; MSR0000_0C94	
_lthree[1:0]_n5; MSR0000_0C95	
_lthree[1:0]_n6; MSR0000_0C96	
_lthree[1:0]_n7; MSR0000_0C97	
_lthree[1:0]_n8; MSR0000_0C98	
_lthree[1:0]_n9; MSR0000_0C99	
_lthree[1:0]_n10; MSR0000_0C9A	
_lthree[1:0]_n11; MSR0000_0C9B	
_lthree[1:0]_n12; MSR0000_0C9C	
_lthree[1:0]_n13; MSR0000_0C9D	
_lthree[1:0]_n14; MSR0000_0C9E	
_lthree[1:0]_n15; MSR0000_0C9F	
Bits Description	
63:16 Reserved.	
15:0 WayMask: L3 way mask used for allocation control	l. Read-write. Reset: FFFFh.

# 2.1.14.2 MSRs - MSRC000\_0xxx

See 1.4.3 [Register Mnemonics] for a description of the register naming convention. MSRs are accessed through x86 WRMSR and RDMSR instructions.

MSRO	C000_0080 [Extended Feature Enable] (Core::X86::Msr::EFER)
SKINI	T Execution: 0000_0000_0000_0000h.
_lthree[1	:0]_core[3:0]_thread[1:0]; MSRC000_0080
Bits	Description
63:19	Reserved.
18	IntWbinvdEn. Read-write. Reset: 0. Interruptible WBINVD, WBNOINVD, enable.
17:16	Reserved.
15	<b>TCE</b> : <b>translation cache extension enable</b> . Read-write. Reset: 0. 1=Translation cache extension is enabled. PDC entries related to the linear address of the INVLPG instruction are invalidated. If <value> == 0 all PDC entries are invalidated by the INVLPG instruction.</value>
14	<b>FFXSE</b> : <b>fast FXSAVE/FRSTOR enable</b> . Read-write. Reset: 0. 1=Enables the fast FXSAVE/FRSTOR mechanism. A 64-bit operating system may enable the fast FXSAVE/FRSTOR mechanism if (Core::X86::Cpuid::FeatureExtIdEdx[FFXSR] == 1). This bit is set once by the operating system and its value is not changed afterwards.
13	<b>LMSLE</b> : <b>long mode segment limit enable</b> . Read-write. Reset: 0. 1=Enables the long mode segment limit check mechanism.
12	<b>SVME</b> : <b>secure virtual machine (SVM) enable</b> . Reset: Fixed,0. 1=SVM features are enabled.
	AccessType: Core::X86::Msr::VM_CR[SvmeDisable] ? Read-only,Error-on-write-1 : Read-write.
11	<b>NXE</b> : <b>no-execute page enable</b> . Read-write. Reset: 0. 1=The no-execute page protection feature is enabled.
10	<b>LMA</b> : <b>long mode active</b> . Read-only. Reset: 0. 1=Indicates that long mode is active. When writing the EFER register the value of this bit must be preserved. Software must read the EFER register to determine the value of LMA, change any other bits as required and then write the EFER register. An attempt to write a value that differs from the state determined by hardware results in a #GP fault.
9	Reserved.
8	<b>LME</b> : <b>long mode enable</b> . Read-write. Reset: 0. 1=Long mode is enabled.
7:1	Reserved.
0	<b>SYSCALL</b> : <b>system call extension enable</b> . Read-write. Reset: 0. 1=SYSCALL and SYSRET instructions are enabled. This adds the SYSCALL and SYSRET instructions which can be used in flat addressed operating systems as low latency system calls and returns.

# MSRC000\_0081 [SYSCALL Target Address] (Core::X86::Msr::STAR)

Read-write. Reset: 0000_0000_0000_0000h.	
This register holds the target address used by the SYSCALL instruction and the code and stack segment selector bases	
used by the SYSCALL and SYSRET instructions.	
_lthree[1:0]_core[3:0]_thread[1:0]; MSRC000_0081	
Bits Description	
63:48 SysRetSel: SYSRET CS and SS. Read-write. Reset: 0000h.	
47:32 SysCallSel: SYSCALL CS and SS. Read-write. Reset: 0000h.	
31:0 <b>Target: SYSCALL target address.</b> Read-write. Reset: 0000_0000h.	

# MSRC000\_0082 [Long Mode SYSCALL Target Address] (Core::X86::Msr::STAR64)

Read-write. Reset: 0000_0000_0000_0000h.	
_lthree[1	1:0]_core[3:0]_thread[1:0]; MSRC000_0082
Bits	Description
63:0	<b>LSTAR</b> : <b>long mode target address</b> . Read-write. Reset: 0000_0000_0000h. Target address for 64-bit mode
	calling programs. The address stored in this register must be in canonical form (if not canonical, a #GP fault
	occurs).

# MSRC000\_0083 [Compatibility Mode SYSCALL Target Address] (Core::X86::Msr::STARCOMPAT)

Read-write. Reset: 0000_0000_0000_0000h.	
_lthree[1	1:0]_core[3:0]_thread[1:0]; MSRC000_0083
Bits	Description
63:0	<b>CSTAR</b> : <b>compatibility mode target address</b> . Read-write. Reset: 0000_0000_0000_0000h. Target address for
	compatibility mode. The address stored in this register must be in canonical form (if not canonical, a #GP fault
	occurs)

### MSRC000\_0084 [SYSCALL Flag Mask] (Core::X86::Msr::SYSCALL\_FLAG\_MASK)

	, , , , , , , , , , , , , , , , , , ,
_lthree[1	1:0]_core[3:0]_thread[1:0]; MSRC000_0084
Bits	Description
63:32	Reserved.
31:0	Mask: SYSCALL flag mask. Read-write. Reset: 0000_0000h. This register holds the EFLAGS mask used by the
	SYSCALL instruction. 1=Clear the corresponding EFLAGS bit when executing the SYSCALL instruction.

# MSRC000\_00E7 [Read-Only Max Performance Frequency Clock Count] (Core::X86::Msr::MPerfReadOnly)

Reset:	0000_0000_0000_0000h.
_lthree[1	1:0]_core[3:0]_thread[1:0]; MSRC000_00E7
Bits	Description
63:0	MPerfReadOnly: Read-only maximum core clocks counter. Reset: 0000_0000_0000_0000h. Incremented by
	hardware at the P0 frequency while the core is in C0. In combination with Core::X86::Msr::APerfReadOnly, this
	is used to determine the effective frequency of the core. A Read of this MSR in guest mode is affected by
	Core::X86::Msr::TscRateMsr. This field uses software P-state numbering. See
	Core::X86::Msr::HWCR[EffFreqCntMwait], 2.1.5 [Effective Frequency]. This register is not affected by writes to
	Core::X86::Msr::MPERF.
	AccessType: Core::X86::Msr::HWCR[EffFreqReadOnlyLock]? Read-only, Volatile: Read-write, Volatile.

### MSRC000\_00E8 [Read-Only Actual Performance Frequency Clock Count] (Core::X86::Msr::APerfReadOnly)

Reset:	0000_0000_0000_0000h.
_lthree[1	:0]_core[3:0]_thread[1:0]; MSRC000_00E8
Bits	Description
63:0	APerfReadOnly: Read-only actual core clocks counter. Reset: 0000_0000_0000_0000h. This register
	increments in proportion to the actual number of core clocks cycles while the core is in C0. See
	Core::X86::Msr::MPerfReadOnly. This register is not affected by Writes to Core::X86::Msr::APERF.
	AccessType: Core::X86::Msr::HWCR[EffFreqReadOnlyLock]? Read-only,Volatile: Read-write,Volatile.

# MSRC000\_00E9 [Instructions Retired Performance Count] (Core::X86::Msr::IRPerfCount)

Reset:	0000_0000_0000_0000h.
_lthree[1	L:0]_core[3:0]_thread[1:0]; MSRC000_00E9
Bits	Description
63:0	<b>IRPerfCount</b> : <b>instructions retired counter</b> . Reset: 0000_0000_0000h. Dedicated Instructions Retired
	register increments on once for every instruction retired. See Core::X86::Msr::HWCR[IRPerfEn].
	AccessType: Core::X86::Msr::HWCR[EffFreqReadOnlyLock]? Read-only,Volatile: Read-write,Volatile.

### MSRC000 0100 [FS Base] (Core::X86::Msr::FS BASE)

1,1011	2000_0100 [1 0 2000] (00101111001111101111 0_21102)
Read-	write. Reset: 0000_0000_0000_0000h.
_lthree[1	:0]_core[3:0]_thread[1:0]; MSRC000_0100
Bits	Description
63:0	<b>FSBase</b> : <b>expanded FS segment base</b> . Read-write. Reset: 0000_0000_0000h. This register provides access
	to the expanded 64-bit FS segment base. The address stored in this register must be in canonical form (if not
	canonical, a #GP fault fill occurs).

# MSRC000\_0101 [GS Base] (Core::X86::Msr::GS\_BASE)

Read-	write. Reset: 0000_0000_0000_0000h.
_lthree[1	L:0]_core[3:0]_thread[1:0]; MSRC000_0101
Bits	Description
63:0	<b>GSBase</b> : <b>expanded GS segment base</b> . Read-write. Reset: 0000_0000_0000h. This register provides access
	to the expanded 64-bit GS segment base. The address stored in this register must be in canonical form (if not
	canonical, a #GP fault fill occurs).

### MSRC000 0102 [Kernel GS Base] (Core::X86::Msr::KernelGSbase)

Read-	write. Reset: 0000_0000_0000_0000h.
_lthree[1	1:0]_core[3:0]_thread[1:0]; MSRC000_0102
Bits	Description
63:0	<b>KernelGSBase: kernel data structure pointer</b> . Read-write. Reset: 0000_0000_0000_0000h. This register holds
	the kernel data structure pointer which can be swapped with the GS_BASE register using the SwapGS instruction.
	The address stored in this register must be in canonical form (if not canonical, a #GP fault occurs).

### MSRC000\_0103 [Auxiliary Time Stamp Counter] (Core::X86::Msr::TSC\_AUX)

Read-	write, Volatile. Reset: 0000_0000_0000_0000h.
_lthree[1	1:0]_core[3:0]_thread[1:0]; MSRC000_0103
Bits	Description
63:32	Reserved.
31:0	<b>TscAux</b> : <b>auxiliary time stamp counter data</b> . Read-write, Volatile. Reset: 0000_0000h. It is expected that this is
	initialized by privileged software to a meaningful value, such as a processor ID. This value is returned in the
	RDTSCP instruction.

### MSRC000\_0104 [Time Stamp Counter Ratio] (Core::X86::Msr::TscRateMsr)

Core::X86::Msr::TscRateMsr allows the hypervisor to control the guest's view of the Time Stamp Counter. It provides a multiplier that scales the value returned when Core::X86::Msr::TSC[TSC], Core::X86::Msr::MPERF[MPERF], and Core::X86::Msr::MPerfReadOnly[MPerfReadOnly] are Read by a guest running under virtualization. This allows the hypervisor to provide a consistent TSC, MPERF, and MPerfReadOnly rate for a guest process when moving that process between cores that have a differing P0 rate. The TSC Ratio MSR does not affect the value Read from the TSC, MPERF, and MPerfReadOnly MSRs when Read while in host mode or when virtualization is not being used or when accessed by code executed in system management mode (SMM) unless the SMM code is executed within a guest container. The TSC Ratio value does not affect the rate of the underlying TSC, MPERF, and MPerfReadOnly counters, or the value that gets written to the TSC, MPERF, and MPerfReadOnly MSRs counters on a Write by either the host or the guest. The TSC Ratio MSR contains a fixed-point number in 8.32 format, which is 8 bits of integer and 32 bits of fraction. This number is the ratio of the desired P0 frequency to the P0 frequency of the core. The reset value of the TSC Ratio MSR is 1.0, which results in a guest frequency matches the core P0 frequency.

lthree[1:0]\_core[3:0]\_thread[1:0]; MSRC000\_0104

_iuiree[i	_tunee[1:0]_core[5:0]_unead[1:0]; M5RC000_0104			
Bits	Description			
63:40	Reserved.			
39:32	<b>TscRateMsrInt</b> : <b>time stamp counter rate integer</b> . Read-write. Reset: 01h. Specifies the integer part of the MSR			
	TSC ratio value.			
31:0	<b>TscRateMsrFrac</b> : <b>time stamp counter rate fraction</b> . Read-write. Reset: 0000_0000h. Specifies the fractional			
	part of the MSR TSC ratio value.			

# MSRC000\_020[0...F] [L3 QOS Bandwidth Control] (Core::X86::Msr::L3QosBwControl)

_lthree[1:0]_n0; MSRC000_0200
_lthree[1:0]_n1; MSRC000_0201
_lthree[1:0]_n2; MSRC000_0202
_lthree[1:0]_n3; MSRC000_0203
_lthree[1:0]_n4; MSRC000_0204
_lthree[1:0]_n5; MSRC000_0205
_lthree[1:0]_n6; MSRC000_0206
_lthree[1:0]_n7; MSRC000_0207

_lthree[1:0]_n8; MSRC000_0208		
_lthree[1:0]_n9; MSRC000_0209		
_lthree[1:0]_n10; MSRC000_020A		
_lthree[1:0]_n11; MSRC000_020B		
_lthree[1:0]_n12; MSRC000_020C		
_lthree[1:0]_n13; MSRC000_020D		
_lthree[1:0]_n14; MSRC000_020E		
_lthree[1:0]_n15; MSRC000_020F		
Bits Description		
63:12 Reserved.		
11:0 Ceiling: QOS BW Control BW ceiling value. Read-write. Reset: 800h.		

MSRC000_0410 [MCA Interrupt Configuration] (Core::X86::Msr::McaIntrCfg)				
Read-	Read-write. Reset: 0000_0000_0000_0000h.			
MSRC00	0_0410			
Bits	Description			
63:16	Reserved.			
15:12	<b>ThresholdLvtOffset</b> . Read-write. Reset: 0h. For error thresholding interrupts, specifies the address of the LVT entry in the APIC registers as follows: LVT address = (LvtOffset shifted left 4 bits) + 500h (see Core::X86::Apic::ExtendedInterruptLvtEntries).			
11:8	Reserved.			
7:4	<b>DeferredLvtOffset</b> . Read-write. Reset: 0h. <b>Description</b> : For deferred error interrupts, specifies the address of the LVT entry in the APIC registers as follows: LVT address = (LvtOffset shifted left 4 bits) + 500h (see APIC[530:500]).			
3.0	Reserved			

# 2.1.14.2.1 MSRs - MSRC000\_2xxx

The MCA registers including the legacy aliases (MSR0000\_000[1:0], MSR0000\_04xx) are mapped to MSRC000\_2xxx. See 3.2.5 [MCA Banks].

# 2.1.14.3 MSRs - MSRC001\_0xxx

See 1.4.3 [Register Mnemonics] for a description of the register naming convention. MSRs are accessed through x86 WRMSR and RDMSR instructions.

MSRC001_000[03] [Performance Event Select [3:0]] (Core::X86::Msr::PERF_LEGACY_CTL)			
Read-write. Reset: 0000_0000_0000_0000h.			
The legacy alias of Core::X86::Msr::PERF_CTL. See Core::X86::Msr::PERF_CTL.			
_lthree[1:0]_core[3:0]_thread[1:0]_n0; MSRC001_0000			
_lthree[1:0]_core[3:0]_thread[1:0]_n1; MSRC001_0001			
_lthree[1:0]_core[3:0]_thread[1:0]_n2; MSRC001_0002			
_lthree[1:0]_core[3:0]_thread[1:0]_n3; MSRC001_0003			
Bits Description			
63:42 Reserved.			
41:40 HostGuestOnly: count only host/guest events. Read-write. Reset: 0h.			
39:36 Reserved.			
35:32 EventSelect[11:8]: performance event select. Read-write. Reset: 0h.			
<b>CntMask</b> : <b>counter mask</b> . Read-write. Reset: 00h. Controls the number of events counted per clock cycle.			
ValidValues:			
Value Description			

	00h	The corresponding PERF_CTR[5:0] register increments by the number of events occurring in a clock						
	cycle. See 2.1.15.2 [Large Increment per Cycle Events] for events that can increment greater than 15							
	per cycle.							
	7Fh-01h When Inv == 0, the corresponding PERF_CTR[5:0] register increments by 1, if the number of events							
	occurring in a clock cycle is greater than or equal to the CntMask value. When Inv == 1, the							
		corresponding PERF_CTR[5:0] register increments by 1, if the number of events occurring in a clock						
		cycle is less than CntMask value.						
	FFh-	Reserved.						
	80h							
23	Inv: invert counter mask. Read-write. Reset: 0.							
22	En: enable performance counter. Read-write. Reset: 0.							
21	Reserved.							
20	Int: enable APIC interrupt. Read-write. Reset: 0.							
19	Reserved.							
18	Edge: edge detect. Read-write. Reset: 0.							
17:16	OsUserMode: OS and user mode. Read-write. Reset: 0h.							
15:8	<b>UnitMask</b> : <b>event qualification</b> . Read-write. Reset: 00h. When selecting an event for which not all UnitMask bits							
	are defined, the undefined UnitMask bits should be set to zero.							
7:0	EventSelect[7:0]: event select. Read-write. Reset: 00h.							

# MSRC001\_000[4...7] [Performance Event Counter [3:0]] (Core::X86::Msr::PERF\_LEGACY\_CTR)

Read-write, Volatile. Reset: 0000 0000 0000 0000h.

Note: When counting events that capable of counting greater than 15 events per cycle (MergeEvent) the even and the corresponding odd PERF\_LEGACY\_CTR must be paired to appear as a single 64-bit counter. See 2.1.15.2 [Large Increment per Cycle Events].

The legacy alias of Core::X86::Msr::PERF CTR. See Core::X86::Msr::PERF CTR.

lthree[1:0]\_core[3:0]\_thread[1:0]\_n0; MSRC001\_0004

lthree[1:0]\_core[3:0]\_thread[1:0]\_n1; MSRC001\_0005

\_lthree[1:0]\_core[3:0]\_thread[1:0]\_n2; MSRC001\_0006

lthree[1:0]\_core[3:0]\_thread[1:0]\_n3; MSRC001\_0007

# Bits Description

63:48 Reserved.

47:0 **CTR**: **performance counter value**. Read-write, Volatile. Reset: 0000\_0000\_0000h. In special cases (see 2.1.15.2 [Large Increment per Cycle Events]) CTR can appear as a 64-bit counter.

### MSRC001\_0010 [System Configuration] (Core::X86::Msr::SYS\_CFG)

Reset:	0000_0000_0000_0000h.				
_lthree[1	:0]_core[3:0]; MSRC001_0010				
Bits	Description				
63:24	Reserved.				
23	<b>SMEE</b> : <b>secure memory encryption enable</b> . Read, Write-1-only. Reset: 0. 0=Memory encryption features are				
	disabled. 1=Memory encryption features are enabled. For enabling secure memory encryption see 2.1.4 [Memory				
	Encryption].				
22	Tom2ForceMemTypeWB: top of memory 2 memory type write back. Read-write. Reset: 0. 1=The default				
	memory type of memory between 4-GB and Core::X86::Msr::TOM2 is Write-back instead of the memory type				
	defined by Core::X86::Msr::MTRRdefType[MemType]. For this bit to have any effect,				
	Core::X86::Msr::MTRRdefType[MtrrDefTypeEn] must be 1. MTRRs and PAT can be used to override this				
	memory type.				
21	MtrrTom2En: MTRR top of memory 2 enable. Read-write. Reset: 0. 0=Core::X86::Msr::TOM2 is disabled. 1=				
	Core::X86::Msr::TOM2 is enabled.				
20	MtrrVarDramEn: MTRR variable DRAM enable. Read-write. Reset: 0. Init: BIOS,1.				
	0=Core::X86::Msr::TOP_MEM and IORRs are disabled. 1=These registers are enabled.				

19	MtrrFixDramModEn: MTRR fixed RdDram and WrDram modification enable. Read-write. Reset: 0.				
	0=Core::X86::Msr::MtrrFix_64K through Core::X86::Msr::MtrrFix_4K_7 [RdDram,WrDram] read values is				
	masked 00b; writing does not change the hidden value. 1=Core::X86::Msr::MtrrFix_64K through				
	Core::X86::Msr::MtrrFix_4K_7 [RdDram,WrDram] access type is Read-write. Not shared between threads.				
	Controls access to Core::X86::Msr::MtrrFix_64K through Core::X86::Msr::MtrrFix_4K_7 [RdDram ,WrDram].				
	This bit should be set to 1 during BIOS initialization of the fixed MTRRs, then cleared to 0 for operation.				
18	MtrrFixDramEn: MTRR fixed RdDram and WrDram attributes enable. Read-write. Reset: 0. Init: BIOS,1.				
	1=Enables the RdDram and WrDram attributes in Core::X86::Msr::MtrrFix_64K through				
	Core::X86::Msr::MtrrFix_4K_7.				
17:0	Reserved.				

17:0	17:0 Reserved.					
MSR	C001_0015 [Hardware Configuration] (Core::X86::Msr::HWCR)					
Reset:	Reset: 0000_0000_0100_0010h.					
	three[1:0]_core[3:0]_thread[1:0]; MSRC001_0015					
Bits	Description Description					
63:31	Reserved.					
30	<b>IRPerfEn</b> : <b>enable instructions retired counter</b> . Read-write. Reset: 0. 1=Enable Core::X86::Msr::IRPerfCount.					
29:28	Reserved.					
27	<b>EffFreqReadOnlyLock</b> : <b>read-only effective frequency counter lock</b> . Write-1-only. Reset: 0. Init: BIOS,1. 1=Core::X86::Msr::MPerfReadOnly, Core::X86::Msr::APerfReadOnly and Core::X86::Msr::IRPerfCount are Read-only.					
26	<b>EffFreqCntMwait</b> : <b>effective frequency counting during mwait</b> . Read-write. Reset: 0. 0=The registers do not increment. 1=The registers increment. Specifies whether Core::X86::Msr::MPERF and Core::X86::Msr::APERF increment while the core is in the monitor event pending state. See 2.1.5 [Effective Frequency].					
25	· · · · · · · · · · · · · · · · · · ·					
24	<b>TscFreqSel</b> : <b>TSC frequency select</b> . Read-only. Reset: 1. 1=The TSC increments at the P0 frequency.					
23:22						
21	<b>LockTscToCurrentP0: lock the TSC to the current P0 frequency</b> . Read-write. Reset: 0. 0=The TSC will count at the P0 frequency. 1=The TSC frequency is locked to the current P0 frequency at the time this bit is set and remains fixed regardless of future changes to the P0 frequency.					
20	<b>IoCfgGpFault</b> : <b>IO-space configuration causes a GP fault</b> . Read-write. Reset: 0. 1=IO-space accesses to configuration space cause a GP fault. The fault is triggered if any part of the IO Read/Write address range is between CF8h and CFFh, inclusive. These faults only result from single IO instructions, not to string and REP IO instructions. This fault takes priority over the IO trap mechanism described by Core::X86::Msr::SMI_ON_IO_TRAP_CTL_STS.					
19	Reserved.					
18	<b>McStatusWrEn:</b> machine check status write enable. Read-write. Reset: 0. 0=MCi_STATUS registers are Readable; Writing a non-zero pattern to these registers causes a general protection fault. 1=MCi_STATUS registers are Read-write, including Reserved fields; do not cause general protection faults; such Writes update all implemented bits in these registers; All fields of all threshold registers are Read-write when accessed from MSR space, including Locked, except BlkPtr which is always Read-only; McStatusWrEn does not change the access type for the thresholding registers accessed via configuration space.					
	<b>Description</b> : McStatusWrEn can be used to debug machine check exception and interrupt handlers. See 3.1 [Machine Check Architecture].					
17	<b>Wrap32Dis</b> : <b>32-bit address wrap disable</b> . Read-write. Reset: 0. 1=Disable 32-bit address wrapping. Software can use Wrap32Dis to access physical memory above 4 Gbytes without switching into 64-bit mode. To do so, software should Write a greater-than 4-Gbyte address to Core::X86::Msr::FS_BASE and Core::X86::Msr::GS_BASE. Then it would address ±2 Gbytes from one of those bases using normal memory reference instructions with a FS or GS override prefix. However, the INVLPG, FST, and SSE store instructions					

	generate 32-bit addresses in legacy mode, regardless of the state of Wrap32Dis.					
16:15	Reserved.					
14	RsmSpCycDis: RSM special bus cycle disable. Reset: 0. 0=A link special bus cycle, SMIACK, is generated on					
	a resume from SMI.					
	AccessType: Core::X86::Msr::HWCR[SmmLock] ? Read-only : Read-write.					
13	SmiSpCycDis: SMI special bus cycle disable. Reset: 0. 0=A link special bus cycle, SMIACK, is generated when					
	an SMI interrupt is taken.					
	AccessType: Core::X86::Msr::HWCR[SmmLock]? Read-only: Read-write.					
	Reserved.					
10	MonMwaitUserEn: MONITOR/MWAIT user mode enable. Read-write. Reset: 0. 0=The MONITOR and					
	MWAIT instructions are supported only in privilege level 0; these instructions in privilege levels 1 to 3 cause a					
	#UD exception. 1=The MONITOR and MWAIT instructions are supported in all privilege levels. The state of this					
	bit is ignored if MonMwaitDis is set.					
9	MonMwaitDis: MONITOR and MWAIT disable. Read-write. Reset: 0. 1=The MONITOR and MWAIT					
	opcodes become invalid. This affects what is reported back through Core::X86::Cpuid::FeatureIdEcx[Monitor].					
8	<b>IgnneEm</b> : <b>IGNNE port emulation enable</b> . Read-write. Reset: 0. 1=Enable emulation of IGNNE port.					
7	AllowFerrOnNe: allow FERR on NE. Read-write. Reset: 0. 0=Disable legacy FERR signaling and generate					
C.F	FERR exception directly. 1=Legacy FERR signaling.					
6:5	Reserved.					
4	INVDWBINVD: INVD to WBINVD conversion. Read-write. Reset: 1. 1=Convert INVD to WBINVD.					
	<b>Description</b> : This bit is required to be set for normal operation when any of the following are true:					
	<ul> <li>An L2 is shared by multiple threads.</li> <li>An L3 is shared by multiple cores.</li> </ul>					
	<ul> <li>CC6 is enabled.</li> </ul>					
	<ul> <li>Probe filter is enabled.</li> </ul>					
3	<b>TlbCacheDis: cacheable memory disable</b> . Read-write. Reset: 0. 1=Disable performance improvement that					
	assumes that the PML4, PDP, PDE and PTE entries are in cacheable WB DRAM.					
	<b>Description:</b> Operating systems that maintain page tables in any other memory type must set the TlbCacheDis					
	to insure proper operation.					
	<ul> <li>TlbCacheDis does not override the memory type specified by the SMM ASeg and TSeg memory regions</li> </ul>					
	controlled by Core::X86::Msr::SMMAddr Core::X86::Msr::SMMMask.					
2:1	Reserved.					
0	<b>SmmLock</b> : <b>SMM code lock</b> . Read, Write-1-only. Reset: 0. Init: BIOS, 1. 1=SMM code in the ASeg and TSeg					
	range and the SMM registers are Read-only and SMI interrupts are not intercepted in SVM. See 2.1.12.1.10					
	[Locking SMM].					

# MSRC001\_001[6...8] [IO Range Base] (Core::X86::Msr::IORR\_BASE)

### Read-write.

Core::X86::Msr::IORR\_BASE and Core::X86::Msr::IORR\_MASK combine to specify the two sets of base and mask pairs for two IORR ranges. A core access, with address CPUAddr, is determined to be within IORR address range if the following equation is true:

CPUAddr[47:12] & PhyMask[47:12] == PhyBase[47:12] & PhyMask[47:12].

BIOS can use the IORRs to create an IO hole within a range of addresses that would normally be mapped to DRAM. It can also use the IORRs to re-assert a DRAM destination for a range of addresses that fall within a bigger IO hole that overlays DRAM.

|--|

_ithree[ i	:U]_core[	3:0]_n1;	MSRC00.	1_0018

	2
Bits	Description
63:48	Reserved.
47:12	PhyBase: physical base address. Read-write. Reset: X_XXXX_XXXh.
11:5	Reserved.

4	<b>RdMem: read from memory</b> . Read-write. Reset: X. 0=Read accesses to the range are directed to IO. 1=Read
	accesses to the range are directed to system memory.
3	<b>WrMem</b> : <b>write to memory</b> . Read-write. Reset: X. 0=Write accesses to the range are directed to IO. 1=Write
	accesses to the range are directed to system memory.
2.0	Reserved

# MSRC001\_001[7...9] [IO Range Mask] (Core::X86::Msr::IORR\_MASK)

Read-	Read-write. Reset: 0000_0000_0000_0000h.	
See Co	See Core::X86::Msr::IORR_BASE.	
_lthree[1	_lthree[1:0]_core[3:0]_n0; MSRC001_0017	
_lthree[1	_lthree[1:0]_core[3:0]_n1; MSRC001_0019	
Bits	Description	
63:48	Reserved.	
47:12	PhyMask: physical address mask. Read-write. Reset: 0_0000_0000h.	
11	<b>Valid</b> . Read-write. Reset: 0. 1=The pair of registers that specifies an IORR range is valid.	
10:0	Reserved.	

# MSRC001\_001A [Top Of Memory] (Core::X86::Msr::TOP\_MEM)

Read-	Read-write.	
_lthree[1	_lthree[1:0]_core[3:0]; MSRC001_001A	
Bits	Bits Description	
63:48	Reserved.	
47:23	<b>TOM[47:23]: top of memory</b> . Read-write. Reset: XXX_XXXXh. Specifies the address that divides between	
	MMIO and DRAM. This value is normally placed below 4-GB. From TOM to 4-GB is MMIO; below TOM is	
	DRAM. See 2.1.6.3 [System Address Map].	
22:0	Reserved.	

# MSRC001\_001D [Top Of Memory 2] (Core::X86::Msr::TOM2)

Read-	Read-write.	
_lthree[1:0]_core[3:0]; MSRC001_001D		
Bits	Description	
63:48	Reserved.	
47:23	<b>TOM2[47:23]</b> : <b>second top of memory</b> . Read-write. Reset: XXX_XXXXh. Specifies the address divides between	
	MMIO and DRAM. This value is normally placed above 4 GBs. From 4-GB to (TOM2 - 1) is DRAM; TOM2 and	
	above is MMIO. See 2.1.6.3 [System Address Map]. This register is enabled by	
	Core::X86::Msr::SYS_CFG[MtrrTom2En].	
22:0	Reserved.	

# MSRC001\_0022 [Machine Check Exception Redirection] (Core::X86::Msr::McExcepRedir)

Read-write. Reset: 0000_0000_00000_0000h.		
This r	This register can be used to redirect machine check exceptions (MCEs) to SMIs or vectored interrupts. If both	
RedirSmiEn and RedirVecEn are set, then undefined behavior results.		
_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_0022		
Bits	Bits Description	
63:10	Reserved.	
0	Dedicement Dead with Deads 0.1-Dedicat MCE (that are directed to this gare) to generate an CMI to	

9	<b>RedirSmiEn</b> . Read-write. Reset: 0. 1=Redirect MCEs (that are directed to this core) to generate an SMI-trigger
	IO cycle via Core::X86::Msr::SmiTrigIoCycle. The status is stored in
	Core::X86::Smm::LocalSmiStatus[MceRedirSts].
8	<b>RedirVecEn</b> . Read-write. Reset: 0. 1=Redirect MCEs (that are directed to this core) to generate a vectored
	interrupt, using the interrupt vector specified in RedirVector.
7:0	RedirVector. Read-write. Reset: 00h. See RedirVecEn.

# MSRC001\_003[0...5] [Processor Name String] (Core::X86::Msr::ProcNameString)

### Read-write.

These 6 registers hold the CPUID name string in ASCII. The state of these registers are returned by CPUID instructions, Core::X86::Cpuid::ProcNameStr0Eax through Core::X86::Cpuid::ProcNameStr2Edx. BIOS should set these registers to the product name for the processor as provided by AMD. Each register contains a block of 8 ASCII characters; the least byte corresponds to the first ASCII character of the block; the most-significant byte corresponds to the last character of the block. MSRC001\_0030 contains the first block of the name string; MSRC001\_0035 contains the last block of the name string.

name string.	
_lthree[1:0]_core[3:0]_thread[1:0]_n0; MSRC001_0030	
_lthree[1:0]_core[3:0]_thread[1:0]_n1; MSRC001_0031	
_tthree[1:0]_core[3:0]_thread[1:0]_n2; MSRC001_0032	
_lthree[1:0]_core[3:0]_thread[1:0]_n3; MSRC001_0033	
_lthree[1:0]_core[3:0]_thread[1:0]_n4; MSRC001_0034	
_tthree[1:0]_core[3:0]_thread[1:0]_n5; MSRC001_0035	
Bits Description	
63:56 <b>CpuNameString7</b> . Read-write. Reset: XXh.	
55:48 <b>CpuNameString6</b> . Read-write. Reset: XXh.	
47:40 <b>CpuNameString5</b> . Read-write. Reset: XXh.	
39:32 <b>CpuNameString4</b> . Read-write. Reset: XXh.	
31:24 <b>CpuNameString3</b> . Read-write. Reset: XXh.	
23:16 <b>CpuNameString2</b> . Read-write. Reset: XXh.	
15:8 <b>CpuNameString1</b> . Read-write. Reset: XXh.	
7:0 <b>CpuNameString0</b> . Read-write. Reset: XXh.	

### MSRC001\_005[0...3] [IO Trap] (Core::X86::Msr::SMI\_ON\_IO\_TRAP)

Read-write. Reset: 0000 0000 0000 0000h.

Core::X86::Msr::SMI\_ON\_IO\_TRAP and Core::X86::Msr::SMI\_ON\_IO\_TRAP\_CTL\_STS provide a mechanism for executing the SMI handler if a an access to one of the specified addresses is detected. Access address and access type checking is performed before IO instruction execution. If the access address and access type match one of the specified IO address and access types, then: (1) the IO instruction is not executed; (2) any breakpoint, other than the single-step breakpoint, set on the IO instruction is not taken (the single-step breakpoint is taken after resuming from SMM); and (3) issue the SMI-trigger IO cycle specified by Core::X86::Msr::SmiTrigIoCycle if enabled. The status is stored in Core::X86::Smm::LocalSmiStatus[IoTrapSts].

IO-space configuration accesses are special IO accesses. An IO access is defined as an IO-space configuration access when IO instruction address bits[31:0] are CFCh, CFDh, CFEh, or CFFh when IO-space configuration is enabled (IO::IoCfgAddr[ConfigEn]). The access address for a configuration space access is the current value of IO::IoCfgAddr[BusNo,Device,Function,RegNo]. The access address for an IO access that is not a configuration access is equivalent to the IO instruction address, bits[31:0].

The access address is compared with SmiAddr, and the instruction access type is compared with the enabled access types defined by ConfigSMI, SmiOnRdEn, and SmiOnWrEn. Access address bits[23:0] can be masked with SmiMask. IO and configuration space trapping to SMI applies only to single IO instructions; it does not apply to string and REP IO instructions. The conditional GP fault described by Core::X86::Msr::HWCR[IoCfgGpFault] takes priority over this trap.

_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]_n0; MSRC001_0050	
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]_n1; MSRC001_0051	
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]_n2; MSRC001_0052	
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]_n3; MSRC001_0053	
Bits	Description	
63	SmiOnRdEn: enable SMI on IO read. Read-write. Reset: 0. 1=Enables SMI generation on a Read access.	
62	SmiOnWrEn: enable SMI on IO write. Read-write. Reset: 0. 1=Enables SMI generation on a Write access.	
61	<b>ConfigSmi</b> : <b>configuration space SMI</b> . Read-write. Reset: 0. 0=IO access (that is not an IO-space configuration	
	access). 1=Configuration access.	
60:56	Reserved.	
55:32	SmiMask[23:0]. Read-write. Reset: 00_0000h. 1=Do not mask address bit. 0=Mask address bit. SMI IO trap	

	mask.
31:0	SmiAddr[31:0]. Read-write. Reset: 0000_0000h. SMI IO trap address.

# MSRC001\_0054 [IO Trap Control] (Core::X86::Msr::SMI\_ON\_IO\_TRAP\_CTL\_STS)

_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_0054	
Bits	Description	
63:16	Reserved.	
15	<b>IoTrapEn</b> : <b>IO trap enable</b> . Read-write. Reset: 0. 1=Enable IO and configuration space trapping specified by Core::X86::Msr::SMI_ON_IO_TRAP and Core::X86::Msr::SMI_ON_IO_TRAP_CTL_STS.	
14:8	Reserved.	
7	<b>SmiEn3</b> . Read-write. Reset: 0. 1=The trap Core::X86::Msr::SMI_ON_IO_TRAP_n[3] is enabled.	
6	Reserved.	
5	SmiEn2. Read-write. Reset: 0. 1=The trap Core::X86::Msr::SMI_ON_IO_TRAP_n[2] is enabled.	
4	Reserved.	
3	<b>SmiEn1</b> . Read-write. Reset: 0. 1=The trap Core::X86::Msr::SMI_ON_IO_TRAP_n[1] is enabled.	
2	Reserved.	
1	<b>SmiEn0</b> . Read-write. Reset: 0. 1=The trap Core::X86::Msr::SMI_ON_IO_TRAP_n[0] is enabled.	
0	Reserved.	

### MSRC001\_0055 [Reserved.] (Core::X86::Msr::IntPend)

Read-only. Reset: Fixed,0000_0000_0000_0000h.	
_lthree[1:0]_core[3:0]; MSRC001_0055	
Bits	Description
63:0	Reserved.

# MSRC001\_0056 [SMI Trigger IO Cycle] (Core::X86::Msr::SmiTrigIoCycle)

Read-write. Reset: 0000 0000 0000 0000h.

See 2.1.12.1.3 [SMI Sources And Delivery]. This register specifies an IO cycle that may be generated when a local SMI trigger event occurs. If IoCycleEn is set and there is a local SMI trigger event, then the IO cycle generated is a byte Read or Write, based on IoRd, to address IoPortAddress. If the cycle is a Write, then IoData contains the data written. If the cycle is a Read, the value read is discarded. If IoCycleEn is clear and a local SMI trigger event occurs, then undefined behavior results.

lthree[1:0]\_core[3:0]\_thread[1:0]; MSRC001\_0056

_iunee[1	.0]_core[5.0]_tiread[1.0], M5RC001_0050		
Bits	Description		
63:27	Reserved.		
26	IoRd: IO Read. Read-write. Reset: 0. 0=IO Write. 1=IO Read.		
25	<b>IoCycleEn</b> : <b>IO cycle enable</b> . Read-write. Reset: 0. 1=The SMI trigger IO cycle is enabled to be generated.		
24	Reserved.		
23:16	IoData. Read-write. Reset: 00h.		
15:0	InPortAddress Read-write Reset: 0000h		

### MSRC001\_0058 [MMIO Configuration Base Address] (Core::X86::Msr::MmioCfgBaseAddr)

	See 2.1.7 [Configuration Space] for a description of MMIO configuration space.	
_lthree[1	_lthree[1:0]_core[3:0]; MSRC001_0058	
Bits	Description	
63:48	Reserved.	
47:20	MmioCfgBaseAddr[47:20]: MMIO configuration base address bits[47:20]. Read-write. Reset:	
	XXX_XXXXh. Specifies the base address of the MMIO configuration range.	
19:6	Reserved.	
5:2	<b>BusRange</b> : <b>bus range identifier</b> . Read-write. Reset: 0h. Specifies the number of buses in the MMIO	
	configuration space range. The size of the MMIO configuration space is 1-MB times the number of buses.	

	ValidValı	ValidValues:		
	Value	Description		
	0h	1		
	1h	2		
	2h	4		
	3h	8		
	4h	16		
	5h	32		
	6h	64		
	7h	128		
	8h	256		
	Fh-9h	Reserved		
1	Reserved.			
0	<b>Enable</b> . Read-write. Reset: 0. 1=MMIO configuration space is enabled.			

# MSRC001\_0061 [P-state Current Limit] (Core::X86::Msr::PStateCurLim)

_lthree[1	_lthree[1:0]_core[3:0]; MSRC001_0061		
Bits	Description		
63:7	Reserved.		
6:4	<b>PstateMaxVal</b> : <b>P-state maximum value</b> . Read,Error-on-write,Volatile. Reset: XXXb. Specifies the lowest-performance non-boosted P-state (highest non-boosted value) allowed. Attempts to change		
	Core::X86::Msr::PStateCtl[PstateCmd] to a lower-performance P-state (higher value) are clipped to the value of this field.		
3	Reserved.		
2:0	CurPstateLimit: current P-state limit. Read, Error-on-write, Volatile. Reset: XXXb. Specifies the highest-		
	performance P-state (lowest value) allowed. CurPstateLimit is always bounded by		
	Core::X86::Msr::PStateCurLim[PstateMaxVal]. Attempts to change the CurPstateLimit to a value greater (lower performance) than Core::X86::Msr::PStateCurLim[PstateMaxVal] leaves CurPstateLimit unchanged.		

# MSRC001\_0062 [P-state Control] (Core::X86::Msr::PStateCtl)

_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_0062		
Bits	its Description		
63:3	Reserved.		
2:0	<b>PstateCmd: P-state change command</b> . Read-write. Reset: XXXb. Cold reset value varies by product; after a		
	warm reset, value initializes to the P-state the core was in prior to the reset. Writes to this field cause the core to		
	change to the indicated non-boosted P-state number, specified by Core::X86::Msr::PStateDef. 0=P0, 1=P1, etc. P-		
	state limits are applied to any P-state requests made through this register. Reads from this field return the last		
	written value, regardless of whether any limits are applied.		

# MSRC001\_0063 [P-state Status] (Core::X86::Msr::PStateStat)

Read,Error-on-write,Volatile.		
_lthree[1:0]_core[3:0]; MSRC001_0063		
Bits	its Description	
63:3	Reserved.	
2:0	<b>CurPstate</b> : <b>current P-state</b> . Read,Error-on-write,Volatile. Reset: XXXb. This field provides the frequency	
	component of the current non-boosted P-state of the core (regardless of the source of the P-state change, including	
	Core::X86::Msr::PStateCtl[PstateCmd]. 0=P0, 1=P1, etc. The value of this field is updated when the COF	
	transitions to a new value associated with a P-state.	

# MSRC001\_006[4...B] [P-state [7:0]] (Core::X86::Msr::PStateDef)

Read-write.

Each of these registers specify the frequency and voltage associated with each of the core P-states.

The CpuVid field in these registers is required to be programmed to the same value in all cores of a processor, but are allowed to be different between processors in a multi-processor system. All other fields in these registers are required to he programmed to the same value in each core of the coherent fabric

be programmed to the same value in each core of the conferent rabile.		
_n0; MSRC001_0064		
_n1; MSRC001_0065		
_n2; MSRC001_0066		
_n3; MSRC001_0067		
_n4; MSRC001_0068		
_n5; MSRC001_0069		
_n6; MSRC001_006A		
n7: MSRC001 006B		

### **Description** Bits

- **PstateEn.** Read-write. Reset: X. 0=The P-state specified by this MSR is not valid. 1=The P-state specified by this 63 MSR is valid. The purpose of this register is to indicate if the rest of the P-state information in the register is valid after a reset; it controls no hardware.
- 62:32 Reserved.
- 31:30 **IddDiv**: **current divisor**. Read-write. Reset: XXb. See IddValue.
- 29:22 IddValue: current value. Read-write. Reset: XXXXXXXXb. After a reset, IddDiv and IddValue combine to specify the expected maximum current dissipation of a single core that is in the P-state corresponding to the MSR number. These values are intended to be used to create ACPI-defined \_PSS objects. The values are expressed in amps; they are not intended to convey final product power levels; they may not match the power levels specified in the Power and Thermal Datasheets.
- 21:14 **CpuVid[7:0]**: **core VID**. Read-write. Reset: XXXXXXXXb.
- **CpuDfsId**: **core divisor ID**. Read-write. Reset: XXXXXXb. Specifies the core frequency divisor; see CpuFid. 13:8 For values [1Ah:08h], 1/8th integer divide steps supported down to VCO/3.25 (Note, L3/L2 FIFO logic related to 4-cycle data heads-up requires core to be 1/3 of L3 frequency or higher). For values [30h:1Ch], 1/4th integer divide steps supported down to VCO/6 (DID[0] should zero if DID[5:0] > 1Ah). (Note, core and L3 frequencies below 400MHz are not supported by the architecture). Core supports DID up to 30h, but L3 must be 2Ch (VCO/5.5) or less.

ValidValı	ValidValues:		
Value	Description		
00h	Off		
07h-01h	Reserved.		
08h	VCO/1		
09h	VCO/1.125		
1Ah-	VCO/ <value 8=""></value>		
0Ah			
1Bh	Reserved.		
1Ch	VCO/ <value 8=""></value>		
1Dh	Reserved.		
1Eh	VCO/ <value 8=""></value>		
1Fh	Reserved.		
20h	VCO/ <value 8=""></value>		
21h	Reserved.		
22h	VCO/ <value 8=""></value>		
23h	Reserved.		
24h	VCO/ <value 8=""></value>		
25h	Reserved.		
26h	VCO/ <value 8=""></value>		
27h	Reserved.		
28h	VCO/ <value 8=""></value>		

29h	Reserved.	
2Ah	VCO/ <value 8=""></value>	
2Bh	Reserved.	
2Ch	VCO/ <value 8=""></value>	
3Fh-	Reserved.	
2Dh		
7:0 <b>CpuFid[7:0]</b> : <b>core frequency ID</b> . Read-write. Reset: XXh. Specifies the core frequency multiplier. The core		
COF is a function of CpuFid and CpuDid, and defined by CoreCOF.		
ValidValues:		
Value	Description	
0Fh-00h	Reserved.	
FFh-	<value>*25</value>	
10h		

# MSRC001\_0073 [C-state Base Address] (Core::X86::Msr::CStateBaseAddr)

Read-	Read-write. Reset: 0000_0000_0000_0000h.		
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_0073		
Bits	its Description		
63:16	Reserved.		
15:0	<b>CstateAddr: C-state address</b> . Read-write. Reset: 0000h. Specifies the IO addresses trapped by the core for C-		
	state entry requests. A value of 0 in this field specifies that the core does not trap any IO addresses for C-state		
	entry. Writing values greater than FFF8h into this field result in undefined behavior. All other values cause the		
	core to trap IO addresses CstateAddr through CstateAddr + 7.		

# MSRC001\_0074 [CPU Watchdog Timer] (Core::X86::Msr::CpuWdtCfg)

Read-	Read-write. Reset: 0000_0000_0000_0280h.		
_lthree[1	_lthree[1:0]_core[3:0]; MSRC001_0074		
Bits	Description		
63:10	Reserved.		
9:7	<b>CpuWdTmrCfgSeverity</b> . Read-write. Reset: 5h. Specifies the CPU Watch Dog Timer severity.		
	ValidValues:		
	Value Description		
	4h-0h	Reserved.	
	5h MCA_EXSC_ERROR_SEVERITY_FATAL		
	7h-6h Reserved.		
6.3	6:3 CpuWdtCountSel: CPII watchdog timer count select. Read-write. Reset: 0h. CpuWdtCountSel and		

**CpuWdtCountSel**: **CPU** watchdog timer count select. Read-write. Reset: 0h. CpuWdtCountSel and CpuWdtTimeBase together specify the time period required for the WDT to expire. The time period is ((the multiplier specified by CpuWdtCountSel) \* (the time base specified by CpuWdtTimeBase)). The actual timeout period may be anywhere from zero to one increment less than the values specified, due to non-deterministic behavior.

# ValidValues:

Value	Description
0h	4095
1h	2047
2h	1023
3h	511
4h	255
5h	127
6h	63
7h	31

	8h	8191
	9h	16383
	Fh-Ah	Reserved
2:1	CpuWdt	<b>TimeBase</b> : <b>CPU</b> watchdog timer time base. Read-write. Reset: 0h. Specifies the time base for the
	timeout p	eriod specified in CpuWdtCountSel.
	ValidValu	les:
	Value	Description
	0h	1.31ms
	1h	1.28us
	3h-2h	Reserved
0	CpuWdt	En: CPU watchdog timer enable. Read-write. Reset: 0. Init: BIOS,1. 1=The WDT is enabled.

# MSRC001\_0111 [SMM Base Address] (Core::X86::Msr::SMM\_BASE)

Reset: 0000\_0000\_0003\_0000h.

This holds the base of the SMM memory region. The value of this register is stored in the save state on entry into SMM (see 2.1.12.1.5 [SMM Save State]) and it is restored on returning from SMM. The 16-bit CS (code segment) selector is loaded with SmmBase[19:4] on entering SMM. SmmBase[3:0] is required to be 0. The SMM base address can be changed in two ways:

- The SMM base address, at offset FF00h in the SMM state save area, may be changed by the SMI handler. The RSM instruction updates SmmBase with the new value.
- Normal WRMSR access to this register.

_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_0111	
Bits	Description
63:32	Reserved.
31:0	<b>SmmBase</b> . Reset: 0003_0000h.
	AccessType: Core::X86::Msr::HWCR[SmmLock]? Read-only: Read-write.

### MSRC001\_0112 [SMM TSeg Base Address] (Core::X86::Msr::SMMAddr)

Configurable. Reset: 0000 0000 0000 0000h.

See 2.1.12.1 [System Management Mode (SMM)] and 2.1.6.3.1 [Memory Access to the Physical Address Space]. See Core::X86::Msr::SMMMask for more information about the ASeg and TSeg address ranges.

Each CPU access, directed at CPUAddr, is determined to be in the TSeg range if the following is true:

CPUAddr[47:17] & TSegMask[47:17] == TSegBase[47:17] & TSegMask[47:17].

For example, if TSeg spans 256 KBs and starts at the 1-MB address. The Core::X86::Msr::SMMAddr[TSegBase[47:17]] would be set to 0010\_0000h and the Core::X86::Msr::SMMMask[TSegMask[47:17]] to FFFC\_0000h (with zeros filling in for bits[16:0]). This results in a TSeg range from 0010\_0000 to 0013\_FFFFh.

\_lthree[1:0]\_core[3:0]; MSRC001\_0112

Bits	Description	
63:48	Reserved.	
47:17	TSegBase[47:17]: TSeg address range base. Configurable. Reset: 0000_0000h. AccessType:	
	(Core::X86::Msr::HWCR[SmmLock])? Read-only : Read-write.	
16:0	Reserved.	

### MSRC001\_0113 [SMM TSeg Mask] (Core::X86::Msr::SMMMask)

Configurable. Reset: 0000 0000 0000 0000h.

See 2.1.12.1 [System Management Mode (SMM)].

The ASeg address range is located at a fixed address from A0000h–BFFFFh. The TSeg range is located at a variable base (specified by Core::X86::Msr::SMMAddr[TSegBase[47:17]]) with a variable size (specified by

Core::X86::Msr::SMMMask[TSegMask[47:17]]). These ranges provide a safe location for SMM code and data that is not readily accessible by non-SMM applications. The SMI handler can be located in one of these two ranges, or it can be located outside these ranges. These ranges must never overlap each other.

This register specifies how accesses to the ASeg and TSeg address ranges are controlled as follows:

- If [A,T]Valid == 1, then:
  - If in SMM, then:
    - If [A, T]Close == 0, then the accesses are directed to DRAM with memory type as specified in [A, T]MTypeDram.
    - If [A, T]Close == 1, then instruction accesses are directed to DRAM with memory type as specified in [A, T]MTypeDram and data accesses are directed at MMIO space and with attributes based on [A, T]MTypeIoWc.
  - If not in SMM, then the accesses are directed at MMIO space with attributes based on [A,T]MTvpeIoWc.
- See 2.1.6.3.1.1 [Determining Memory Type].

_lthree[1	:0]_core[3:0]	; MSRC001_0113
	Descript	
63:48	Reserved	
47:17	TSegMa	sk[47:17]: TSeg address range mask. Configurable. Reset: 0000_0000h. See
		6::Msr::SMMAddr. AccessType: (Core::X86::Msr::HWCR[SmmLock]) ? Read-only : Read-write.
16:15	Reserved	
14:12	<b>TMTypeDram: TSeg address range memory type.</b> Configurable. Reset: 0h. Specifies the memory type for	
	SMM accesses to the TSeg range that are directed to DRAM. AccessType:	
		86::Msr::HWCR[SmmLock]) ? Read-only : Read-write.
	ValidVal	
		Description
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
	7h	Reserved.
11	Reserved	
10:8	<b>AMTypeDram</b> : <b>ASeg Range Memory Type</b> . Configurable. Reset: 0h. Specifies the memory type for SMM	
		to the ASeg range that are directed to DRAM. AccessType: (Core::X86::Msr::HWCR[SmmLock])?
		y : Read-write.
	ValidVal	
		<b>Description</b>
	0h	UC or uncacheable.
	1h	WC or write combining.
	3h-2h	Reserved.
	4h	WT or write through.
	5h	WP or write protect.
	6h	WB or write back.
<b>7</b> .0	7h	Reserved.
7:6	Reserved	
5		<b>IoWc: non-SMM TSeg address range memory type.</b> Configurable. Reset: 0. 0=UC (uncacheable).
	1=MC(N)	write combining). Specifies the attribute of TSeg accesses that are directed to MMIO space. AccessType:

(Core::X86::Msr::HWCR[SmmLock])? Read-only: Read-write.

4	<b>AMTypeIoWc: non-SMM ASeg address range memory type.</b> Configurable. Reset: 0. 0=UC (uncacheable).
	1=WC (write combining). Specifies the attribute of ASeg accesses that are directed to MMIO space. AccessType:
	(Core::X86::Msr::HWCR[SmmLock]) ? Read-only : Read-write.
3	TClose: send TSeg address range data accesses to MMIO. Configurable. Reset: 0. 1=When in SMM, direct
	data accesses in the TSeg address range to MMIO space. See AClose. AccessType:
	(Core::X86::Msr::HWCR[SmmLock]) ? Read-only : Read-write.
2	AClose: send ASeg address range data accesses to MMIO. Configurable. Reset: 0. 1=When in SMM, direct
	data accesses in the ASeg address range to MMIO space. [A,T]Close allows the SMI handler to access the MMIO
	space located in the same address region as the [A,T]Seg. When the SMI handler is finished accessing the MMIO
	space, it must clear the bit. Failure to do so before resuming from SMM causes the CPU to erroneously read the
	save state from MMIO space. AccessType: (Core::X86::Msr::HWCR[SmmLock])? Read-only : Read-write.
1	<b>TValid</b> : <b>enable TSeg SMM address range</b> . Configurable. Reset: 0. 1=The TSeg address range SMM enabled.
	AccessType: (Core::X86::Msr::HWCR[SmmLock]) ? Read-only : Read-write.
0	<b>AValid</b> : <b>enable ASeg SMM address range</b> . Configurable. Reset: 0. 1=The ASeg address range SMM enabled.
	AccessType: (Core::X86::Msr::HWCR[SmmLock]) ? Read-only : Read-write.

# MSRC001\_0114 [Virtual Machine Control] (Core::X86::Msr::VM\_CR)

Reset: 0000_0000_0000_0000h.		
_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_0114		
Bits	Description	
63:5	Reserved.	
4	<b>SymeDisable: SVME disable.</b> Configurable. Reset: 0. 0=Core::X86::Msr::EFER[SVME] is Read-write.	
	1=Core::X86::Msr::EFER[SVME] is Read-only,Error-on-write-1. See Lock for the access type of this field.	
	Attempting to set this field when (Core::X86::Msr::EFER[SVME] == 1) causes a #GP fault, regardless of the	
	state of Lock. See the docAPM2 section titled "Enabling SVM" for software use of this field.	
3	<b>Lock</b> : <b>SVM lock</b> . Read-only, Volatile. Reset: 0. 0=SvmeDisable is Read-write. 1=SvmeDisable is Read-only. See	
	Core::X86::Msr::SvmLockKey[SvmLockKey] for the condition that causes hardware to clear this field.	
2	Reserved.	
1	<b>InterceptInit</b> : <b>intercept INIT</b> . Read-write, Volatile. Reset: 0. 0=INIT delivered normally. 1=INIT translated into	
	a SX interrupt. This bit controls how INIT is delivered in host mode. This bit is set by hardware when the SKINIT	
	instruction is executed.	
0	Reserved.	

# MSRC001\_0115 [IGNNE] (Core::X86::Msr::IGNNE)

Reset: 0000_0000_0000_0000h.		
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_0115	
Bits	Description	
63:1	Reserved.	
0	<b>IGNNE</b> : <b>current IGNNE state</b> . Read-write. Reset: 0. This bit controls the current state of the processor internal	
	IGNNE signal.	

# MSRC001\_0116 [SMM Control] (Core::X86::Msr::SMM\_CTL)

Reset: 0000 0000 0000 0000h.

The bits in this register are processed in the order of: SmmEnter, SmiCycle, SmmDismiss, RsmCycle and SmmExit. However, only the following combination of bits may be set in a single Write (all other combinations result in undefined behavior):

- SmmEnter and SmiCycle.
- SmmEnter and SmmDismiss.
- SmmEnter, SmiCycle and SmmDismiss.
- SmmExit and RsmCycle.

Software is responsible for ensuring that SmmEnter and SmmExit operations are properly matched and are not nested. \_lthree[1:0]\_core[3:0]\_thread[1:0]; MSRC001\_0116

Bits	Description
63:5	Reserved.
4	RsmCycle: send RSM special cycle. Reset: 0. 1=Send a RSM special cycle.
	AccessType: Core::X86::Msr::HWCR[SmmLock]? Error-on-read,Error-on-write: Write-only,Error-on-read.
3	SmmExit: exit SMM. Reset: 0. 1=Exit SMM.
	AccessType: Core::X86::Msr::HWCR[SmmLock]? Error-on-read,Error-on-write: Write-only,Error-on-read.
2	SmiCycle: send SMI special cycle. Reset: 0. 1=Send a SMI special cycle.
	AccessType: Core::X86::Msr::HWCR[SmmLock]? Error-on-read,Error-on-write: Write-only,Error-on-read.
1	SmmEnter: enter SMM. Reset: 0. 1=Enter SMM.
	AccessType: Core::X86::Msr::HWCR[SmmLock]? Error-on-read, Error-on-write: Write-only, Error-on-read.
0	SmmDismiss: clear SMI. Reset: 0. 1=Clear the SMI pending flag.
	AccessType: Core::X86::Msr::HWCR[SmmLock]? Error-on-read,Error-on-write: Write-only,Error-on-read.

# MSRC001\_0117 [Virtual Machine Host Save Physical Address] (Core::X86::Msr::VM\_HSAVE\_PA)

Reset: 0000_0000_0000_0000h.	
_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_0117	
Bits	Description
63:48	Reserved.
47:12	VM_HSAVE_PA: physical address of host save area. Read-write. Reset: 0_0000_0000h. This register contains
	the physical address of a 4-KB region where VMRUN saves host state and where vm-exit restores host state from.
	Writing this register causes a #GP if (FFFF_FFFF_Fh >= VM_HSAVE_PA >= FFFD_0000_0h) or if either the
	TSEG or ASEG regions overlap with the range defined by this register.
11:0	Reserved.

# MSRC001\_0118 [SVM Lock Key] (Core::X86::Msr::SvmLockKey)

Read-write. Reset: Fixed,0000_0000_0000_0000h.		
_lthree[	_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_0118	
Bits	Description	
63:0	SvmLockKey: SVM lock key. Read-write. Reset: Fixed,0000_0000_0000h. Writes to this register when	
	(Core::X86::Msr::VM_CR[Lock] == 0) modify SvmLockKey. If ((Core::X86::Msr::VM_CR[Lock] == 1) &&	
	(SvmLockKey != 0) && (The Write value == The value stored in SvmLockKey)) for a Write to this register then	
	hardware updates Core::X86::Msr::VM_CR[Lock] = 0.	

# MSRC001\_011A [Local SMI Status] (Core::X86::Msr::LocalSmiStatus)

Read-write. Reset: 0000\_0000\_0000\_0000h.

This register returns the same information that is returned in Core::X86::Smm::LocalSmiStatus portion of the SMM save state. The information in this register is only updated when Core::X86::Msr::SMM\_CTL[SmmDismiss] is set by software.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; MSRC001\_011A

Bits	Description
63:32	Reserved.
31:0	LocalSmiStatus. Read-write. Reset: 0000_0000h. See Core::X86::Smm::LocalSmiStatus.

# MSRC001\_011B [AVIC Doorbell] (Core::X86::Msr::AvicDoorbell)

MISIK	ISKC001_011D [Av IC D001Dell] (C01eA00visiAvicD001Dell)		
Reset:	Reset: 0000_0000_0000_0000h.		
The A	he ApicId is a physical APIC Id; not valid for logical APIC ID.		
See Co	See Core::X86::Cpuid::SvmRevFeatIdEdx[AVIC].		
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_011B		
Bits	Description		
63:8	Reserved.		
7:0	ApicId: APIC ID [7:0]. Write-only, Error-on-read. Reset: 00h.		

MSRC001_011E [VM Page Flush] (Core::X86::Msr::VMPAGE_FLUSH)			
Writes to this MSR cause 4 KBs of encrypted, guest-tagged data to be flushed from caches if present.			
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_011E		
Bits	Bits Description		
63:12	VirtualAddr. Reset: X_XXXX_XXXX_XXXXh. Guest physical address of page to flush.		
	AccessType: Core::X86::Msr::SYS_CFG[SMEE] ? Write-only,Error-on-read : Error-on-read,Error-on-write.		
11:0	<b>ASID</b> . Reset: XXXh. ASID to use for flush. Writing reserved values generates #GP.		
	AccessType: Core::X86::Msr::SYS_CFG[SMEE] ? Write-only,Error-on-read : Error-on-read,Error-on-write.		

# MSRC001\_0130 [Guest Host Communication Block] (Core::X86::Msr::GHCB)

	Misrcovi_visv [duest first communication block] (corexvovisrdifeb)		
	Read-v	write. Reset: 0000_0000_0000_0000h.	
If Core::X86::Msr::GHCB is accessed in hypervisor mode, #GP is generated.			
_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_0130		:0]_core[3:0]_thread[1:0]; MSRC001_0130	
Bits Description			
63:0 <b>GHCBPA</b> . Read-write. Reset: 0000_0000_0000h. Guest physical addr		<b>GHCBPA</b> . Read-write. Reset: 0000_0000_0000_0000h. Guest physical address of GHCB.	

# MSRC001\_0131 [SEV Status] (Core::X86::Msr::SEV\_Status)

Read,Error-on-write. Reset: 0000_0000_0000_0000h.		
_lthree[1	1:0]_core[3:0]_thread[1:0]; MSRC001_0131	
Bits	Bits Description	
63:2	Reserved.	
1 <b>SevEsEnabled</b> . Read,Error-on-write. Reset: 0. 1=The guest was launched with the Sev-ES feature enabled		
VMCB offset 90h.		
0	0 <b>SevEnabled</b> . Read,Error-on-write. Reset: 0. 1=The guest was launched with SEV feature enabled in VMCB	
	offset 90h.	

# MSRC001\_0140 [OS Visible Work-around Length] (Core::X86::Msr::OSVW\_ID\_Length)

	Read-v	write. Reset: 0000_0000_0000_0000h.	
	_lthree[1	:0]_core[3:0]_thread[1:0]; MSRC001_0140	
	Bits	ts Description	
63:16 Reserved.		Reserved.	
	15:0 <b>OSVWIdLength: OS visible work-around ID length.</b> Read-write. Reset: 0000h. See the Revision Guide for the		
definition of this field: see 1.2 [Reference Documents].			

# MSRC001\_0141 [OS Visible Work-around Status] (Core::X86::Msr::OSVW\_Status)

Read-write. Reset: 0000_0000_0000_0000h.			
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_0141		
Bits	Bits Description		
63:0	OsvwStatusBits: OS visible work-around status bits. Read-write. Reset: 0000_0000_0000_0000h. See the		
	Revision Guide for the definition of this field; see 1.2 [Reference Documents].		

### MSRC001\_020[0...A] [Performance Event Select [5:0]] (Core::X86::Msr::PERF\_CTL)

MSKG001_020[013] [1 criormanice Event Select [5:0]] (Core200MSL.:1 ERT_C1E)		
Read-write. Reset: 0000_0000_0000_0000h.		
See 2.1.15 [Performance Monitor Counters]. Core::X86::Msr::PERF_LEGACY_CTL is an alias of		
MSRC001_020[6,4,2,0].		
_lthree[1:0]_core[3:0]_thread[1:0]_n0; MSRC001_0200		
_lthree[1:0]_core[3:0]_thread[1:0]_n1; MSRC001_0202		
_lthree[1:0]_core[3:0]_thread[1:0]_n2; MSRC001_0204		
_lthree[1:0]_core[3:0]_thread[1:0]_n3; MSRC001_0206		
_lthree[1:0]_core[3:0]_thread[1:0]_n4; MSRC001_0208		
_lthree[1:0]_core[3:0]_thread[1:0]_n5; MSRC001_020A		
Bits Description		
63:42 Reserved.		

41:40	HostGues	stOnly: count only host/guest events. Read-write. Reset: 0h.		
11, 10	ValidValı	, , ,		
		Description		
	0h	Count all events, irrespective of guest/host.		
	1h	Count guest events if [SVME] == 1.		
	2h	Count host events if [SVME] == 1.		
	3h	Count all guest and host events if [SVME] == 1.		
20.26	Reserved.	Count an guest and nost events if [5 v WiL] == 1.		
		ect[11:8]: performance event select. Read-write. Reset: 0h.		
31:24		:: <b>counter mask</b> . Read-write. Reset: 00h. Controls the number of events counted per clock cycle.		
	ValidValu			
	Value	Description The PERF CERTS of the state of t		
	00h	The corresponding PERF_CTR[5:0] register increments by the number of events occurring in a clock cycle. See 2.1.15.2 [Large Increment per Cycle Events] for events that can increment greater than 15 per cycle.		
	7Fh-01h	When Inv == 0, the corresponding PERF_CTR[5:0] register increments by 1, if the number of events occurring in a clock cycle is greater than or equal to the CntMask value. When Inv == 1, the corresponding PERF_CTR[5:0] register increments by 1, if the number of events occurring in a clock cycle is less than CntMask value.		
	FFh- 80h	Reserved.		
23	Inv: inve	rt counter mask. Read-write. Reset: 0. See CntMask.		
22	En: enab	le performance counter. Read-write. Reset: 0. 1=Performance event counter is enabled.		
21	Reserved.	•		
20	Int: enable APIC interrupt. Read-write. Reset: 0. 1=APIC performance counter LVT interrupt generate an interrupt via Core::X86::Apic::PerformanceCounterLvtEntry when the performance overflows.			
19	Reserved.			
18	mode incr without d event is a	ge detect. Read-write. Reset: 0. 0=Level detect. 1=Zero-to-one Edge detect. Read-write. The edge count rements the counter when a transition happens on the monitored event. If the event selected is changed isabling the counter, an extra edge is falsely detected when the first event is a static 0 and the second static one. To avoid this false edge detection, disable the counter when changing the event and then e counter with a second MSR write.		
17:16	Iode: OS and user mode. Read-write. Reset: 0h.			
	ValidValu			
	Value	Description		
	0h	Count no events.		
	1h	Count user events (CPL > 0).		
	2h	Count OS events (CPL = 0).		
	3h	Count all events, irrespective of the CPL.		
15:8		k: <b>event qualification</b> . Read-write. Reset: 00h. Each UnitMask bit further specifies or qualifies the		
15.0	event spec	cified by EventSelect. All events selected by UnitMask are simultaneously monitored. Unless otherwise UnitMask values shown may be combined (logically ORed) to select any desired combination of the		
		s for a given event. In some cases, certain combinations can result in misleading counts, or the		
		value is an ordinal rather than a bit mask. These situations are described where applicable, or should be		
		com the event descriptions. For events where no U <mark>nitMask table</mark> is shown, the UnitMask is Unused.		
		ecting an event for which not all UnitMask bits are defined, the undefined UnitMask bits should be set		
	to zero.			
7:0	EventSel	ect[7:0]: event select. Read-write. Reset: 00h. EventSelect[11:0] = {EventSelect[11:8], ect[7:0]}. EventSelect specifies the event or event duration in a processor unit to be counted by the		

corresponding PERF\_CTR[5:0] register. The events are specified in 2.1.15.3 [Core Performance Monitor Counters]. Some events are Reserved; when a Reserved event is selected, the results are undefined.

### MSRC001\_020[1...B] [Performance Event Counter [5:0]] (Core::X86::Msr::PERF\_CTR)

Note: When counting events that capable of counting greater than 15 events per cycle (MergeEvent) the even and the corresponding odd PERF\_CTR must be paired to appear as a single 64 bit counter. See 2.1.15.2 [Large Increment per Cycle Events].

Core::X86::Msr::PERF\_CTL. Core::X86::Msr::PERF\_LEGACY\_CTR is an alias of MSRC001\_020[7,5,3,1]. Also can be Read via x86 instructions RDPMC ECX = [05:00].

lthree[1:0]\_core[3:0]\_thread[1:0]\_n0; MSRC001\_0201

\_lthree[1:0]\_core[3:0]\_thread[1:0]\_n1; MSRC001\_0203

lthree[1:0]\_core[3:0]\_thread[1:0]\_n2; MSRC001\_0205

\_lthree[1:0]\_core[3:0]\_thread[1:0]\_n3; MSRC001\_0207

\_lthree[1:0]\_core[3:0]\_thread[1:0]\_n4; MSRC001\_0209

lthree[1:0]\_core[3:0]\_thread[1:0]\_n5; MSRC001\_020B

# Bits | Description

63:48 Reserved.

47:0 **CTR**: **performance counter value**. Read-write, Volatile. Reset: 0000\_0000\_0000h.

# MSRC001\_023[0...A] [L3 Performance Event Select [5:0]] (Core::X86::Msr::ChL3PmcCfg)

Read-write. Reset: 0000\_0000\_0000\_0000h.

See 2.1.15.4 [L3 Cache Performance Monitor Counters].

lthree[1:0]\_n0; MSRC001\_0230

lthree[1:0]\_n1; MSRC001\_0232

lthree[1:0] n2; MSRC001 0234

lthree[1:0]\_n3; MSRC001\_0236

\_lthree[1:0]\_n4; MSRC001\_0238

\_lthree[1:0]\_n5; MSRC001\_023A

### Bits Description

63:56 **ThreadMask**. Read-write. Reset: 00h. Controls which of the up to 8 threads in the complex are being counted (Dependent upon number of cores). In non-SMT mode, thread 0 must be selected. One or more threads must be selected unless otherwise specified by the specific L3PMC event.

### ValidValues:

Bit	Description
[0]	Core 0 Thread 0 mask.
[1]	Core 0 Thread 1 mask.
[2]	Core 1 Thread 0 mask.
[3]	Core 1 Thread 1 mask.
[4]	Core 2 Thread 0 mask.
[5]	Core 2 Thread 1 mask.
[6]	Core 3 Thread 0 mask.
[7]	Core 3 Thread 1 mask.

55:52 Reserved.

51:48 **SliceMask**. Read-write. Reset: 0h. Controls which L3 slices are counting this event. One or more Slices must be selected unless otherwise specified by the specific L3PMC event.

### ValidValues:

Description
L3 Slice 0 mask.
L3 Slice 1 mask.
L3 Slice 2 mask.
L3 Slice 3 mask.

### 47:23 Reserved.

22 **Enable: Enable L3 performance counter.** Read-write. Reset: 0. 1=Enable.

21:16	Reserved.	
15:8	<b>UnitMask</b> : <b>event qualification</b> . Read-write. Reset: 00h. Each UnitMask bit further specifies or qualifies the	
	event specified by EventSelect. All events selected by UnitMask are simultaneously monitored. Unless otherwise	
	stated, the UnitMask values shown may be combined (logically ORed) to select any desired combination of the	
	sub-events for a given event. In some cases, certain combinations can result in misleading counts, or the	
	UnitMask value is an ordinal rather than a bit mask. These situations are described where applicable, or should be	
	obvious from the event descriptions. For events where no UnitMask table is shown, the UnitMask is Unused.	
	When selecting an event for which not all UnitMask bits are defined, the undefined UnitMask bits should be set	
to zero.		
7:0	EventSel: event select. Read-write. Reset: 00h.	

# MSRC001\_023[1...B] [L3 Performance Event Counter [5:0]] (Core::X86::Msr::ChL3Pmc)

Morrows_cas(1m2) [25 1 errormance 2 vene counter [500]] (coremisormance)		
Reset: 0000_0000_0000_0000h.		
Also can be read via x86 instructions RDPMC ECX = [0F:0A].		
_lthree[1:0]_n0; MSRC001_0231		
_lthree[1:0]_n1; MSRC001_0233		
_lthree[1:0]_n2; MSRC001_0235		
_lthree[1:0]_n3; MSRC001_0237		
_lthree[1:0]_n4; MSRC001_0239		
_lthree[1:0]_n5; MSRC001_023B		
Bits Description		
63:49 Reserved.		
48 <b>Overflow</b> . Read-write. Reset: 0.		
47:32 <b>CountHi</b> . Read-write, Volatile. Reset: 0000h.		
31:0 <b>CountLo</b> . Read-write, Volatile. Reset: 0000_0000h.		

# MSRC001 024[0...6] [Data Fabric Performance Event Select [3:0]] (Core::X86::Msr::DF PERF CTL)

MSRC	C001_024[06] [Data Fabric Performance Event Select [3:0]] (Core::X86::Msr::DF_PERF_CTL)		
Read-	Read-write. Reset: 0000_0000_0000_0000h.		
See 2.	1.15 [Performance Monitor Counters].		
The D	F Performance Monitors are shared by all cores/threads in the node. See 2.1.10 [Register Sharing].		
_n0; MS	RC001_0240		
_n1; MSRC001_0242			
_n2; MSRC001_0244			
	RC001_0246		
Bits	Description		
63:61	Reserved.		
60:59	EventSelect[13:12]: performance event select. Read-write. Reset: 0h.		
58:36	Reserved.		
35:32	EventSelect[11:8]: performance event select. Read-write. Reset: 0h. See EventSelect[7:0].		
31:23	31:23 Reserved.		
22	<b>En</b> : <b>enable performance counter</b> . Read-write. Reset: 0. 1=Performance event counter is enabled.		
21:16	Reserved.		
15:8	<b>UnitMask</b> : <b>event qualification</b> . Read-write. Reset: 00h. Each UnitMask bit further specifies or qualifies the		
	event specified by EventSelect. All events selected by UnitMask are simultaneously monitored.		
7:0	EventSelect[7:0]: event select. Read-write. Reset: 00h. This field, along with EventSelect[13:12] and		
	EventSelect[11:8] above, combine to form the 14-bit event select field, EventSelect[13:0]. EventSelect specifies		
	the event or event duration in a processor unit to be counted by the corresponding DF_PERF_CTR[3:0] register.		
	Some events are reserved; when a reserved event is selected, the results are undefined.		

# MSRC001\_024[1...7] [Data Fabric Performance Event Counter [3:0]] (Core::X86::Msr::DF\_PERF\_CTR)

See Core::X86::Msr::DF\_PERF\_CTL. Also can be Read via x86 instructions RDPMC ECX = [09:06]. The DF Performance Monitors are shared by all cores/threads in the node. See 2.1.10 [Register Sharing].

\_n0; MSRC001\_0241

\_n1; MSRC001\_0243

_n2; MS	_n2; MSRC001_0245	
_n3; MSRC001_0247		
Bits	Description	
63:48	Reserved.	
47:0	CTR[47:0]: performance counter value[47:0]. Read-write, Volatile. Reset: 0000_0000_0000h. The current value	
	of the event counter.	

# MSRC001 0299 [RAPL Power Unit] (Core::X86::Msr::RAPL PWR UNIT)

WISIC	MISKCOOI_U299 [KAPL POWER CHIL] (COTE::X60::MISF::KAPL_PWK_CNIT)		
	Read-only, Volatile. Reset: 0000_0000_000A_1003h.		
_lthree[1	hree[1:0]; MSRC001_0299		
Bits	Descripti	on	
63:20	Reserved		
19:16	TU: Time	<b>Units in seconds</b> . Read-only, Volatile. Reset: Ah. Time information (in Seconds) is based on the	
	multiplier	; 1/ 2^TU; where TU is an unsigned integer. Default value is 1010b, indicating time unit is in 976	
	microseco	onds increment.	
	ValidValu	ues:	
	Value	Description	
	Fh-0h	1/2^ <value> Seconds</value>	
15:13	Reserved		
12:8	ESU: En	ergy Status Units. Read-only, Volatile. Reset: 10h. Energy information (in Joules) is based on the	
		; 1/2^ESU; where ESU is an unsigned integer. Default value is 10000b, indicating energy status unit is	
	in 15.3 m	icro-Joules increment.	
	ValidValu	ies:	
	Value	Description	
	1Fh-00h	1/2^ <value> Joules</value>	
7:4	Reserved		
3:0	PU: Pow	er Units. Read-only, Volatile. Reset: 3h. Power information (in Watts) is based on the multiplier, 1/	
	2^PU; wh	ere PU is an unsigned integer. Default value is 0011b, indicating power unit is in 1/8 Watts increment.	
	ValidValu	les:	
	Value	Description	
	Fh-0h	1/2^ <value> Watts</value>	

### MSRC001\_029A [Core Energy Status] (Core::X86::Msr::CORE\_ENERGY\_STAT)

	indicated and proceedings of the second of t	
Read-only, Volatile. Reset: 0000_0000_0000_0000h.		
_lthree[1	_lthree[1:0]_core[3:0]; MSRC001_029A	
Bits	Description	
63:32	Reserved.	
31:0	TotalEnergyConsumed. Read-only, Volatile. Reset: 0000_0000h.	

# MSRC001\_029B [Package Energy Status] (Core::X86::Msr::PKG\_ENERGY\_STAT)

Read-	Read-only, Volatile. Reset: 0000_0000_0000_0000h.	
MSRC00	MSRC001_029B	
Bits	Description	
63:32	Reserved.	
31:0	<b>TotalEnergyConsumed</b> . Read-only, Volatile. Reset: 0000_0000h.	

# MSRC001\_02F0 [Protected Processor Inventory Number Control] (Core::X86::Msr::PPIN\_CTL)

MSRC001\_02F0

Bits	Description
63:2	Reserved.
1	<b>PPIN_EN</b> . Unpredictable. Reset: X. 0=Reading Core::X86::Msr::PPIN will cause a #GP.
	1=Core::X86::Msr::PPIN is accessible using RDMSR. Once set, attempting to Write 1 to
	Core::X86::Msr::PPIN_CTL[Lockout] will cause a #GP.
0	<b>Lockout</b> . Unpredictable. Reset: X. 0=Writes to Core::X86::Msr::PPIN_CTL are permitted if PPIN_EN=0.
	1=Further writes to Core::X86::Msr::PPIN_CTL are ignored.
	<b>Description</b> : Writing 1 to Core::X86::Msr::PPIN_CTL[Lockout] is permitted only if
	Core::X86::Msr::PPIN_CTL[PPIN_EN] == 0.
	BIOS should provide an opt-in menu to enable the user to turn on Core::X86::Msr::PPIN_CTL[PPIN_EN] for
	privileged inventory initialization agent to access Core::X86::Msr::PPIN. After reading Core::X86::Msr::PPIN,
	the privileged inventory initialization agent should write 00b followed by 01b to Core::X86::Msr::PPIN_CTL to
	disable further access to MSR_PPIN and prevent unauthorized modification to MSR_PPIN_CTL.
	Once this bit is written with 1, subsequent writes to this register are ignored, and a reset (warm or cold) is
	required in order to clear it, which gives BIOS the opportunity to set it again at the next boot.

# MSRC001\_02F1 [Protected Processor Inventory Number] (Core::X86::Msr::PPIN)

A unique value within a given CPUID family/model/stepping signature that a privileged inventory initialization agent can access to identify each physical processor, when access to MSR\_PPIN is enabled. Access to MSR\_PPIN is permitted only if MSR\_PPIN\_CTL[1:0] == 10b.

MSRC00	01_02F1	
Bits	Description	
63:0	PPIN: Protected Processor Inventory Number. Reset: Fixed,XXXX_XXXX_XXXX_XXXXh.	
	AccessType: ({Core::X86::Msr::PPIN_CTL[PPIN_EN], Core::X86::Msr::PPIN_CTL[Lockout]} == 2h)?	

# 2.1.14.4 MSRs - MSRC001\_1xxx

Read, Error-on-write: Error-on-read, Error-on-write.

See 1.4.3 [Register Mnemonics] for a description of the register naming convention. MSRs are accessed through x86 WRMSR and RDMSR instructions.

W KIVISK AIIU KIDIVISK IIISUUCUOIIS.		
MSRC001_1002 [CPUID Features for CPUID Fn00000007_E[A,B]X] (Core::X86::Msr::CPUID_7_Features)		
Read-write.		
Core::X86::Msr::CPUID_7_Features[63:32] provides control over values Read from		
Core::X86::Cpuid::StructExtFeatIdEax0; Core::X86::Msr::CPUID_7_Features[31:0] provides control over values Read		
from Core::X86::Cpuid::StructExtFeatIdEbx0.		
_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_1002		
Bits Description		
63:30 Reserved.		
29 SHA. Read-write. Reset: Core::X86::Cpuid::StructExtFeatIdEbx0[SHA].		
28:25 Reserved.		
CLWB: cache line write back. Read-write. Reset: Core::X86::Cpuid::StructExtFeatIdEbx0[CLWB].		
23 <b>CLFSHOPT</b> . Read-write. Reset: Core::X86::Cpuid::StructExtFeatIdEbx0[CLFSHOPT].		
22:21 Reserved.		
20 <b>SMAP</b> . Read-write. Reset: Core::X86::Cpuid::StructExtFeatIdEbx0[SMAP].		
19 <b>ADX</b> . Read-write. Reset: Core::X86::Cpuid::StructExtFeatIdEbx0[ADX].		
18 <b>RDSEED</b> . Read-write. Reset: Core::X86::Cpuid::StructExtFeatIdEbx0[RDSEED].		
17:16 Reserved.		
15 <b>PQE</b> . Read-write. Reset: Core::X86::Cpuid::StructExtFeatIdEbx0[PQE].		
14:13 Reserved.		
12 <b>PQM</b> . Read-write. Reset: Core::X86::Cpuid::StructExtFeatIdEbx0[PQM].		

11:9	Reserved.
8	<b>BMI2</b> . Read-write. Reset: Core::X86::Cpuid::StructExtFeatIdEbx0[BMI2].
7	<b>SMEP</b> . Read-write. Reset: Core::X86::Cpuid::StructExtFeatIdEbx0[SMEP].
6	Reserved.
5	AVX2. Read-write. Reset: Core::X86::Cpuid::StructExtFeatIdEbx0[AVX2].
4	Reserved.
3	<b>BMI1</b> . Read-write. Reset: Core::X86::Cpuid::StructExtFeatIdEbx0[BMI1].
2:1	Reserved.
0	<b>FSGSBASE</b> . Read-write. Reset: Core::X86::Cpuid::StructExtFeatIdEbx0[FSGSBASE].

# MSRC001\_1003 [Thermal and Power Management CPUID Features] (Core::X86::Msr::CPUID\_PWR\_THERM)

Read-write.		
Core::	Core::X86::Msr::CPUID_PWR_THERM provides control over values Read from	
Core::	Core::X86::Cpuid::ThermalPwrMgmtEcx.	
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_1003	
Bits	Bits Description	
63:1	63:1 Reserved.	
0	<b>EffFreq</b> . Read-write. Reset: Core::X86::Cpuid::ThermalPwrMgmtEcx[EffFreq].	

MSR	MSRC001_1004 [CPUID Features for CPUID Fn00000001_E[C,D]X] (Core::X86::Msr::CPUID_Features)		
Read-	Read-write.		
Core::	Core::X86::Msr::CPUID_Features[63:32] provides control over values Read from Core::X86::Cpuid::FeatureIdEcx;		
	Core::X86::Msr::CPUID_Features[31:0] provides control over values Read from Core::X86::Cpuid::FeatureIdEdx.		
	:0]_core[3:0]_thread[1:0]; MSRC001_1004		
Bits	Description		
63	Reserved.		
62	RDRAND. Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[RDRAND].		
61	<b>F16C</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[F16C].		
60	<b>AVX</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[AVX].		
59	OSXSAVE. Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[OSXSAVE]. Modifies		
	Core::X86::Cpuid::FeatureIdEcx[OSXSAVE] only if CR4[OSXSAVE].		
58	<b>XSAVE</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[XSAVE].		
57	<b>AES</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[AES]. Modifies		
	Core::X86::Cpuid::FeatureIdEcx[AES] only if the reset value is 1.		
56	Reserved.		
55	<b>POPCNT</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[POPCNT].		
54	MOVBE. Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[MOVBE].		
53	<b>X2APIC</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[X2APIC].		
52	SSE42. Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[SSE42].		
51	SSE41. Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[SSE41].		
50:46	Reserved.		
45	CMPXCHG16B. Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[CMPXCHG16B].		
44	<b>FMA</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[FMA].		
43:42	Reserved.		
41	SSSE3. Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[SSSE3].		
40:36	Reserved.		
35	Monitor. Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[Monitor]. Modifies		
	Core::X86::Cpuid::FeatureIdEcx[Monitor] only if ~Core::X86::Msr::HWCR[MonMwaitDis].		
34	Reserved.		
33	PCLMULQDQ. Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[PCLMULQDQ]. Modifies		

	Core::X86::Cpuid::FeatureIdEcx[PCLMULQDQ] only if the reset value is 1.
32	SSE3. Read-write. Reset: Core::X86::Cpuid::FeatureIdEcx[SSE3].
31:29	Reserved.
28	HTT. Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[HTT].
27	Reserved.
26	SSE2. Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[SSE2].
25	SSE. Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[SSE].
24	<b>FXSR</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[FXSR].
23	MMX: MMX instructions. Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[MMX].
22:20	Reserved.
19	<b>CLFSH</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[CLFSH].
18	Reserved.
17	<b>PSE36</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[PSE36].
16	PAT. Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[PAT].
15	<b>CMOV</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[CMOV].
14	MCA. Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[MCA].
13	<b>PGE</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[PGE].
12	MTRR. Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[MTRR].
11	SysEnterSysExit. Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[SysEnterSysExit].
10	Reserved.
9	<b>APIC</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[APIC]. Modifies
	Core::X86::Cpuid::FeatureIdEdx[APIC] only if Core::X86::Msr::APIC_BAR[ApicEn].
8	CMPXCHG8B. Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[CMPXCHG8B].
7	MCE. Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[MCE].
6	PAE. Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[PAE].
5	MSR. Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[MSR].
4	TSC. Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[TSC].
3	<b>PSE</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[PSE].
2	<b>DE</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[DE].
1	VME. Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[VME].
0	<b>FPU</b> . Read-write. Reset: Core::X86::Cpuid::FeatureIdEdx[FPU].

# MSRC001\_1005 [CPUID Features for CPUID Fn80000001\_E[C,D]X] (Core::X86::Msr::CPUID\_ExtFeatures)

MISIK	C001_1005 [CPOID Features for CPOID Fil800000001_E[C,D]X] (C07e::A80::MSF::CPOID_EXTFeatures)	
Read-write.		
Core::X86::Msr::CPUID_ExtFeatures[63:32] provides control over values Read from		
Core::	X86::Cpuid::FeatureExtIdEcx; Core::X86::Msr::CPUID_ExtFeatures[31:0] provides control over values Read	
from (	Core::X86::Cpuid::FeatureExtIdEdx.	
_lthree[1	:0]_core[3:0]_thread[1:0]; MSRC001_1005	
Bits	Description	
63	Reserved.	
62	AdMskExtn. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[AdMskExtn].	
61	<b>MwaitExtended</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[MwaitExtended].	
60	<b>PerfCtrExtLLC</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[PerfCtrExtLLC].	
59	<b>PerfTsc</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[PerfTsc].	
58	<b>DataBreakpointExtension</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[DataBreakpointExtension].	
57	Reserved.	
56	<b>PerfCtrExtDF</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[PerfCtrExtDF].	
55	<b>PerfCtrExtCore</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[PerfCtrExtCore].	
54	<b>TopologyExtensions</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[TopologyExtensions].	

53.50	Reserved.	
49	TCE. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[TCE].	
48	FMA4. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[FMA4].	
	<b>LWP</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[LWP].	
46	Reserved.	
45	<b>WDT</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[WDT].	
44	<b>SKINIT</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[SKINIT].	
43	<b>XOP</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[XOP].	
42	<b>IBS</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[IBS].	
41	OSVW. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[OSVW].	
40	<b>ChreeDNowPrefetch</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[ThreeDNowPrefetch].	
39	MisAlignSse. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[MisAlignSse].	
38	SSE4A. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[SSE4A].	
37	<b>ABM</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[ABM].	
36	AltMovCr8. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[AltMovCr8].	
35	ExtApicSpace. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[ExtApicSpace].	
34	SVM. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[SVM].	
33	CmpLegacy. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[CmpLegacy].	
32	<b>LahfSahf</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEcx[LahfSahf].	
31	<b>ThreeDNow: 3DNow! instructions</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[ThreeDNow].	
30	ThreeDNowExt. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[ThreeDNowExt].	
29	LM. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[LM].	
28	Reserved.	
27	RDTSCP. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[RDTSCP].	
26	Page1GB. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[Page1GB].	
25	<b>FFXSR</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[FFXSR].	
24	<b>FXSR</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[FXSR].	
23	MMX: MMX instructions. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[MMX].	
22	MmxExt. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[MmxExt].	
21	Reserved.	
20	NX. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[NX].	
19:18	Reserved.	
17	<b>PSE36</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[PSE36].	
16	PAT. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[PAT].	
15	<b>CMOV</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[CMOV].	
14	MCA. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[MCA].	
13	<b>PGE</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[PGE].	
12	MTRR. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[MTRR].	
11	SysCallSysRet. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[SysCallSysRet].	
10	Reserved.	
9	APIC. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[APIC].	
8	CMPXCHG8B. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[CMPXCHG8B].	
7	MCE. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[MCE].	
6	PAE. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[PAE].	
5	MSR. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[MSR].	
4	TSC. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[TSC].	
3	PSE. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[PSE].	
2	<b>DE</b> . Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[DE].	

1	VME. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[VME].
0	FPU. Read-write. Reset: Core::X86::Cpuid::FeatureExtIdEdx[FPU].

# MSRC001\_1019 [Address Mask For DR1 Breakpoint] (Core::X86::Msr::DR1\_ADDR\_MASK)

112021	institution in the property (Continue in the property)		
Read-	lead-write. Reset: 0000_0000_0000_0000h.		
Suppo	Support indicated by Core::X86::Cpuid::FeatureExtIdEcx[DataBreakpointExtension].		
_lthree[1	:0]_core[3:0]_thread[1:0]; MSRC001_1019		
Bits	Description		
63:32	Reserved.		
31:0	AddrMask: mask for DR linear address data breakpoint DR1. Read-write. Reset: 0000_0000h. 1=Exclude bit		
	into address compare. 0=Include bit into address compare. See Core::X86::Msr::DR1_ADDR_MASK.		
	AddrMask[11:0] qualifies the DR1 linear address instruction breakpoint, allowing the DR1 instruction breakpoint		
	on a range of addresses in memory.		

# MSRC001\_101A [Address Mask For DR2 Breakpoint] (Core::X86::Msr::DR2\_ADDR\_MASK)

	,	
Read-	ead-write. Reset: 0000_0000_0000_0000h.	
Suppo	Support indicated by Core::X86::Cpuid::FeatureExtIdEcx[DataBreakpointExtension].	
_lthree[1	hree[1:0]_core[3:0]_thread[1:0]; MSRC001_101A	
Bits	Description	
63:32	Reserved.	
31:0	AddrMask: mask for DR linear address data breakpoint DR2. Read-write. Reset: 0000_0000h. 1=Exclude bit	
	into address compare. 0=Include bit into address compare. See Core::X86::Msr::DR0_ADDR_MASK.	
	AddrMask[11:0] qualifies the DR2 linear address instruction breakpoint, allowing the DR2 instruction breakpoint	
	on a range of addresses in memory.	

# MSRC001\_101B [Address Mask For DR3 Breakpoint] (Core::X86::Msr::DR3\_ADDR\_MASK)

111011	Albiteour_rub [ruaress Mush rub Bits Breakpoint] (core		
Read-	-write. Reset: 0000_0000_0000_0000h.		
Suppo	oort indicated by Core::X86::Cpuid::FeatureExtIdEcx[DataBreakpointExtension].		
_lthree[	ee[1:0]_core[3:0]_thread[1:0]; MSRC001_101B		
Bits	Description		
63:32	Reserved.		
31:0	AddrMask: mask for DR linear address data breakpoint DR3. Read-write. Reset: 0000_0000h. 1=Exclude bit		
	into address compare. 0=Include bit into address compare. See Core::X86::Msr::DR0_ADDR_MASK.		
	AddrMask[11:0] qualifies the DR3 linear address instruction breakpoint, allowing the DR3 instruction breakpoint		
	on a range of addresses in memory.		

# MSRC001\_1023 [Table Walker Configuration] (Core::X86::Msr::TW\_CFG)

Read-v	vrite. Reset: 0000_0000_0000_0000h.	
_lthree[1	:0]_core[3:0]; MSRC001_1023	
Bits	Description	
63:50	Reserved.	
49	TwCfgCombineCr0Cd: combine CR0_CD for both threads of a core. Read-write. Reset: 0. Init: BIOS,1.	
	1=The host Cr0_Cd values from the two threads are OR'd together and used by both threads.	
48:0	Reserved.	

# MSRC001 1027 [Address Mask For DR0 Breakpoints] (Core::X86::Msr::DR0 ADDR MASK)

MSKC	MSRC001_1027 [Address Mask For DR0 Breakpoints] (Core::x86::Msr::DR0_ADDR_MASK)		
Read-v	Read-write. Reset: 0000_0000_0000_0000h.		
Suppo	Support for DR0[31:12] is indicated by Core::X86::Cpuid::FeatureExtIdEcx[DataBreakpointExtension]. See		
Core::	Core::X86::Msr::DR1_ADDR_MASK.		
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_1027		
Bits	Description		
63:32	Reserved.		

DR0: mask for DR0 linear address data breakpoint. Read-write. Reset: 0000\_0000h. 1=Exclude bit into address compare. 0=Include bit into address compare. See Core::X86::Msr::DR1\_ADDR\_MASK. This field qualifies the DR0 linear address data breakpoint, allowing the DR0 data breakpoint on a range of addresses in memory. AddrMask[11:0] qualifies the DR0 linear address instruction breakpoint, allowing the DR0 instruction breakpoint on a range of addresses in memory. DR0[31:12] is only valid for data breakpoints. The legacy DR0 breakpoint function is provided by DR0[31:0] == 0000\_0000h. The mask bits are active high. DR0 is always used, and it can be used in conjunction with any debug function that uses DR0.

### MSRC001\_1030 [IBS Fetch Control] (Core::X86::Msr::IBS\_FETCH\_CTL)

Reset: 0000 0000 0000 0000h.

See 2.1.16 [Instruction Based Sampling (IBS)].

The IBS fetch sampling engine is described as follows:

- The periodic fetch counter is an internal 20-bit counter:
  - The periodic fetch counter [19:4] is set to IbsFetchCnt[19:4] and the periodic fetch counter [3:0] is set according to IbsRandEn when IbsFetchEn is changed from 0 to 1.
  - It increments for every fetch cycle that completes when IbsFetchEn == 1 and IbsFetchVal == 0.
    - The periodic fetch counter is undefined when IbsFetchEn == 0 or IbsFetchVal == 1.
  - When IbsFetchCnt[19:4] is Read it returns the current value of the periodic fetch counter [19:4].
- When the periodic fetch counter reaches {IbsFetchMaxCnt[19:4],0h} and the selected instruction fetch completes or is aborted:
  - IbsFetchVal is set to 1.
    - Drivers can't assume that IbsFetchCnt[19:4] is 0 when IbsFetchVal == 1.
- The status of the operation is written to the IBS fetch registers (this register, Core::X86::Msr::IBS\_FETCH\_LINADDR and Core::X86::Msr::IBS\_FETCH\_PHYSADDR).
- An interrupt is generated as specified by Core::X86::Msr::IBS\_CTL. The interrupt service routine associated with this interrupt is responsible for saving the performance information stored in IBS execution registers.

_lthree[1	1:0]_core[3:0]_thread[1:0]; MSRC001_1030		
Bits	Descripti	on	
63:59	Reserved.		
58	IbsFetch	<b>L2Miss</b> : <b>L2 cache miss for the sampled fetch</b> . Read-only, Volatile. Reset: 0. 1=The instruction fetch	
	missed in	the L2 Cache. Qualified by (IbsFetchComp == 1).	
57		En: random instruction fetch tagging enable. Read-write. Reset: 0. 0=Bits[3:0] of the fetch counter	
		re set to 0h when IbsFetchEn is set to start the fetch counter. 1=Bits[3:0] of the fetch counter are randomized	
		FetchEn is set to start the fetch counter.	
56		<b>IbsL2TlbMiss</b> : <b>instruction cache L2TLB miss</b> . Read-only, Volatile. Reset: 0. 1=The instruction fetch missed in	
	the L2 TL		
55		Miss: instruction cache L1TLB miss. Read-only, Volatile. Reset: 0. 1=The instruction fetch missed in	
	the L1 TL	·	
54:53		<b>PgSz</b> : <b>instruction cache L1TLB page size</b> . Read-only, Volatile. Reset: 0h. Indicates the page size of the	
		n in the L1 TLB. This field is only valid if IbsPhyAddrValid == 1.	
	ValidValu		
	Value	Description	
	0h	4 KB	
	1h	2 MB	
	2h	1 GB	
	3h	16K	
52	IbsPhyA	ddrValid: instruction fetch physical address valid. Read-only, Volatile. Reset: 0. 1=The physical	
	address in	Core::X86::Msr::IBS_FETCH_PHYSADDR and the IbsL1TlbPgSz field are valid for the instruction	
	fetch.		
51	IbsIcMiss	s: instruction cache miss. Read-only, Volatile. Reset: 0. 1=The instruction fetch missed in the	
	instruction	n cache.	
50	IbsFetch	Comp: instruction fetch complete. Read-only, Volatile. Reset: 0. 1=The instruction fetch completed and	

	the data is available for use by the instruction decoder.
49	<b>IbsFetchVal</b> : <b>instruction fetch valid</b> . Read-only, Volatile. Reset: 0. 1=New instruction fetch data available. When
	this bit is set, the fetch counter stops counting and an interrupt is generated as specified by
	Core::X86::Msr::IBS_CTL. This bit must be cleared for the fetch counter to start counting. When clearing this bit,
	software can write 0000h to IbsFetchCnt[19:4] to start the fetch counter at IbsFetchMaxCnt[19:4].
48	<b>IbsFetchEn</b> : <b>instruction fetch enable</b> . Read-write. Reset: 0. 1=Instruction fetch sampling is enabled.
47:32	<b>IbsFetchLat</b> : <b>instruction fetch latency</b> . Read-only, Volatile. Reset: 0000h. Indicates the number of clock cycles
	from when the instruction fetch was initiated to when the data was delivered to the core. If the instruction fetch is
	abandoned before the fetch completes, this field returns the number of clock cycles from when the instruction
	fetch was initiated to when the fetch was abandoned.
31:16	<b>IbsFetchCnt[19:4]</b> . Read-write, Volatile. Reset: 0000h. Provides Read/Write access to bits[19:4] of the periodic
	fetch counter. Programming this field to a value greater than or equal to IbsFetchMaxCnt[19:4] results in
	undefined behavior.
15:0	<b>IbsFetchMaxCnt[19:4]</b> . Read-write. Reset: 0000h. Specifies bits[19:4] of the maximum count value of the
	periodic fetch counter. Programming this field to 0000h and setting IbsFetchEn results in undefined behavior.
	Bits[3:0] of the maximum count are always 0000b.

### MSRC001\_1031 [IBS Fetch Linear Address] (Core::X86::Msr::IBS\_FETCH\_LINADDR)

Read-	ead-write, Volatile. Reset: 0000_0000_0000_0000h.	
Reset	eset: 0000_0000_0000_0000h.	
_lthree[	1:0]_core[3:0]_thread[1:0]; MSRC001_1031	
Bits	Description	
63:0	<b>IbsFetchLinAd</b> : instruction fetch linear address. Read-write, Volatile. Reset: 0000_0000_0000_0000h.	
	Provides the linear address in canonical form for the tagged instruction fetch.	

# MSRC001\_1032 [IBS Fetch Physical Address] (Core::X86::Msr::IBS\_FETCH\_PHYSADDR)

_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_1032	
Bits	Description	
63:48	Reserved.	
47:0	<b>IbsFetchPhysAd</b> : <b>instruction fetch physical address</b> . Read-write, Volatile. Reset: 0000_0000_0000h. Provides	
	the physical address for the tagged instruction fetch. The lower 12 bits are not modified by address translation, so	
	they are always the same as the linear address. This field contains valid data only if	
	Core::X86::Msr::IBS_FETCH_CTL[IbsPhyAddrValid] is asserted.	

### MSRC001\_1033 [IBS Execution Control] (Core::X86::Msr::IBS\_OP\_CTL)

Reset: 0000\_0000\_0000\_0000h.

See 2.1.16 [Instruction Based Sampling (IBS)].

The IBS execution sampling engine is described as follows for IbsOpCntCtl == 1. If IbsOpCntCtl == 1n then references to "periodic op counter" mean "periodic cycle counter".

- The periodic op counter is an internal 27-bit counter:
  - It is set to IbsOpCurCnt[26:0] when IbsOpEn is changed from 0 to 1.
  - It increments every dispatched op when IbsOpEn == 1 and IbsOpVal == 0.
    - The periodic op counter is undefined when IbsOpEn == 0 or IbsOpVal == 1.
  - When IbsOpCurCnt[26:0] is Read then it returns the current value of the periodic micro-op counter [26:0].
- When the periodic micro-op counter reaches IbsOpMaxCnt:
  - The next dispatched micro-op is tagged if IbsOpCntCtl == 1. A valid op in the next dispatched line is tagged if IbsOpCntCtl == 0. See IbsOpCntCtl.
  - The periodic micro-op counter [26:7] = 0; [6:0] is randomized by hardware.
- The periodic micro-op counter is not modified when a tagged micro-op is flushed.
- When a tagged micro-op is retired:
  - IbsOpVal is set to 1.
    - Drivers can't assume that IbsOpCurCnt == 0 when IbsOpVal == 1.

FFFFh-

0009h

- The status of the operation is written to the IBS execution registers (this register, Core::X86::Msr::IBS\_OP\_RIP, Core::X86::Msr::IBS\_OP\_DATA, Core::X86::Msr::IBS\_OP\_DATA2, Core::X86::Msr::IBS\_OP\_DATA3, Core::X86::Msr::IBS\_DC\_LINADDR and Core::X86::Msr::IBS\_DC\_PHYSADDR).
- An interrupt is generated as specified by Core::X86::Msr::IBS\_CTL. The interrupt service routine associated with this interrupt is responsible for saving the performance information stored in IBS execution registers.

	with this interrupt is responsible for saving the performance information stored in IBS execution registers.		
_lthree[1	1:0]_core[3:0]_thread[1:0]; MSRC001_1033		
Bits	Description		
63:59	Reserved.		
58:32	<b>IbsOpCurCnt[26:0]: periodic op counter current count</b> . Read-write, Volatile. Reset: 000_0000h. Returns the current value of the periodic op counter.		
31:27	Reserved.		
26:20	bsOpMaxCnt[26:20]: periodic op counter maximum count. Read-write. Reset: 00h. See IbsOpMaxCnt[19:4].		
19	<b>IbsOpCntCtl</b> : <b>periodic op counter count control</b> . Read-write. Reset: 0. 0=Count clock cycles; a 1-of-4 round-robin counter selects an op in the next dispatch line; if the op pointed to by the round-robin counter is invalid, then the next younger valid op is selected. 1=Count dispatched Micro-Ops; when a roll-over occurs, the counter is preloaded with a pseudorandom 7-bit value between 1 and 127.		
18	<b>IbsOpVal</b> : <b>micro-op sample valid</b> . Read-write, Volatile. Reset: 0. 1=New instruction execution data available; the periodic op counter is disabled from counting. An interrupt may be generated when this bit is set as specified by Core::X86::Msr::IBS_CTL[LvtOffset].		
17	<b>IbsOpEn</b> : micro-op sampling enable. Read-write. Reset: 0. 1=Instruction execution sampling enabled.		
16	Reserved.		
15:0	<b>IbsOpMaxCnt[19:4]: periodic op counter maximum count</b> . Read-write. Reset: 0000h. IbsOpMaxCnt[26:0] = {IbsOpMaxCnt[26:20], IbsOpMaxCnt[19:4], 0000b}. Specifies maximum count value of the periodic op counter.		
	Bits[3:0] of the maximum count are always 0000b.		
	Bits[3:0] of the maximum count are always 0000b.  ValidValues:		
	ValidValues:		

# MSRC001\_1034 [IBS Op Logical Address] (Core::X86::Msr::IBS\_OP\_RIP)

	/	
Read-	Read-write, Volatile. Reset: 0000_0000_0000_0000h.	
_lthree[1	ree[1:0]_core[3:0]_thread[1:0]; MSRC001_1034	
Bits	Description	
63:0	<b>IbsOpRip</b> : micro-op linear address. Read-write, Volatile. Reset: 0000_0000_0000_0000h. Linear address in	
	canonical form for the instruction that contains the tagged micro-op.	

# MSRC001\_1035 [IBS Op Data] (Core::X86::Msr::IBS\_OP\_DATA)

<Value> \*16 Ops.

Read-	Read-write, Volatile. Reset: 0000_0000_0000_0000h.	
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_1035	
Bits	Description	
63:41	Reserved.	
40	<b>IbsOpMicrocode</b> . Read-write, Volatile. Reset: 0. 1=Tagged operation from microcode.	
39	<b>IbsOpBrnFuse</b> : <b>fused branch micro-op</b> . Read-write, Volatile. Reset: 0. 1=Tagged operation was a fused branch	
	micro-op. Support indicated by Core::X86::Cpuid::IbsIdEax[OpBrnFuse].	
38	<b>IbsRipInvalid</b> : <b>RIP is invalid</b> . Read-write, Volatile. Reset: 0. 1=Tagged operation RIP is invalid. Support	
	indicated by Core::X86::Cpuid::IbsIdEax[RipInvalidChk].	
37	<b>IbsOpBrnRet</b> : <b>branch micro-op retired</b> . Read-write, Volatile. Reset: 0. 1=Tagged operation was a branch micro-	
	op that retired.	
36	<b>IbsOpBrnMisp:</b> mispredicted branch micro-op. Read-write, Volatile. Reset: 0. 1=Tagged operation was a	

	oranch micro-op that was mispredicted. Qualified by IbsOpBrnRet == 1.	
35	<b>IbsOpBrnTaken</b> : <b>taken branch micro-op</b> . Read-write, Volatile. Reset: 0. 1=Tagged operation was a branch	
	micro-op that was taken. Qualified by IbsOpBrnRet == 1.	
34	<b>IbsOpReturn</b> : <b>return micro-op</b> . Read-write, Volatile. Reset: 0. 1=Tagged operation was return micro-op.	
	Qualified by (IbsOpBrnRet == 1).	
33:32	Reserved.	
31:16	6 <b>IbsTagToRetCtr</b> : micro-op tag to retire count. Read-write, Volatile. Reset: 0000h. This field returns the number	
	of cycles from when the micro-op was tagged to when the micro-op was retired. This field is equal to	
	IbsCompToRetCtr when the tagged micro-op is a NOP.	
15:0	<b>IbsCompToRetCtr</b> : micro-op completion to retire count. Read-write, Volatile. Reset: 0000h. This field returns	
	the number of cycles from when the micro-op was completed to when the micro-op was retired.	

# MSRC001\_1036 [IBS Op Data 2] (Core::X86::Msr::IBS\_OP\_DATA2)

Reset: 0000\_0000\_0000\_0000h.

Data is only valid for load operations that miss both the L1 data cache and the L2 cache. If a load operation crosses a cache line boundary, the data returned in this register is the data for the access to the lower cache line.

\_lthree[1:0]\_core[3:0]\_thread[1:0]; MSRC001\_1036

Bits	Description	
63:6	Reserved.	
5	CacheHitSt: IBS cache hit state. Read-write, Volatile. Reset: 0. 0=M State. 1=O State. Valid when the data	
	source type is Cache(2h).	
4	RmtNode: IBS request destination node. Read-write, Volatile. Reset: 0. 0=The request is serviced by the NB in	
	the same node as the core. 1=The request is serviced by the NB in a different node than the core. Valid when	
	NbIbsReqSrc is non-zero.	
3	Reserved.	
	T	

2:0 **DataSrc: northbridge IBS request data source**. Read-write. Reset: 0h.

### ValidValues:

7 622762 7 6227	varia variasi.	
Value	Description	
0h	No valid status.	
1h	Reserved.	
2h	Cache: data returned from another cores cache.	
3h	DRAM: data returned from DRAM.	
4h	Reserved for remote cache.	
6h-5h	Reserved.	
7h	Other: data returned from MMIO/Config/PCI/APIC.	

### MSRC001\_1037 [IBS Op Data 3] (Core::X86::Msr::IBS\_OP\_DATA3)

Read-write, Volatile. Reset: 0000\_0000\_0000\_0000h.

If a load or store operation crosses a 256-bit boundary, the data returned in this register is the data for the access to the data below the 256-bit boundary.

uata D	d below the 250-bit boundary.	
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]; MSRC001_1037	
Bits	Description	
63:48	<b>IbsTlbRefillLat</b> : <b>L1 DTLB refill latency</b> . Read-write, Volatile. Reset: 0000h. The number of cycles from when a	
	L1 DTLB refill is triggered by a tagged op to when the L1 DTLB fill has been completed.	
47:32 <b>IbsDcMissLat</b> : data cache miss latency. Read-write, Volatile. Reset: 0000h. Indicates the number of clock of		
	from when a miss is detected in the data cache to when the data was delivered to the core. The value returned by	
	this counter is not valid for data cache writes or prefetch instructions.	
31:26 <b>IbsOpDcMissOpenMemReqs: outstanding memory requests on DC fill</b> . Read-write, Volatile. Reset: 00		
	number of allocated, valid DC MABs when the MAB corresponding to a tagged DC miss op is deallocated.	
	Includes the MAB allocated by the sampled op. 00000b=No information provided.	
25:22	<b>IbsOpMemWidth</b> : <b>load/store size in bytes</b> . Read-write, Volatile. Reset: 0h. Report the number of bytes the load	

	or store is attempting to access.		
	ValidValues:		
	Value	Description	
	0h	No information provided.	
	1h	Byte.	
	2h	Word.	
	3h	DW.	
	4h	QW.	
	5h	OW.	
	Fh-6h	Reserved.	
21	IbsSwPf:	<b>software prefetch</b> . Read-write, Volatile. Reset: 0. 1=The op is a software prefetch.	
20	IbsL2Mis	ss: <b>L2 cache miss for the sampled operation</b> . Read-write, Volatile. Reset: 0. 1=The operation missed in	
the L2, regardless of whether the op initiated the request to the L2.		gardless of whether the op initiated the request to the L2.	
19		<b>FlbHit1G</b> : <b>data cache L2TLB hit in 1G page</b> . Read-write, Volatile. Reset: 0. 1=The physical address gged load or store operation was present in a 1G page table entry in the data cache L2TLB.	
18		<b>yAddrValid</b> : <b>data cache physical address valid</b> . Read-write, Volatile. Reset: 0. 1=The physical address K86::Msr::IBS_DC_PHYSADDR is valid for the load or store operation.	
17		AddrValid: data cache linear address valid. Read-write, Volatile. Reset: 0. 1=The linear address in	
	Core::X80	6::Msr::IBS_DC_LINADDR is valid for the load or store operation.	
16	DcMissN	oMabAlloc: DC miss with no MAB allocated. Read-write, Volatile. Reset: 0. 1=The tagged load or	
		ration hit on an already allocated MAB.	
15	<b>IbsDcLockedOp</b> : <b>locked operation</b> . Read-write, Volatile. Reset: 0. 1=Tagged load or store operation is a locked		
	operation.		
14	<b>IbsDcUcMemAcc</b> : <b>UC memory access</b> . Read-write, Volatile. Reset: 0. 1=Tagged load or store operation accessed		
uncacheable memory.		·	
13 <b>IbsDcWcMemAcc: WC memory access</b> . Read-write, Volatile. Reset: 0. 1=Tagged load or store of			
12.0	accessed write combining memory.		
12:9	Reserved.		
8	256-bit ac	sAcc: misaligned access. Read-write, Volatile. Reset: 0. 1=The tagged load or store operation crosses a ldress boundary.	
7	l	ss: data cache miss. Read-write, Volatile. Reset: 0. 1=The cache line used by the tagged load or store	
		resent in the data cache.	
6	l	dbHit2M: data cache L2TLB hit in 2M page. Read-write, Volatile. Reset: 0. 1=The physical address	
_		gged load or store operation was present in a 2M page table entry in the data cache L2TLB.	
5		<b>FibHit1G</b> : <b>data cache L1TLB hit in 1G page</b> . Read-write, Volatile. Reset: 0. 1=The physical address	
1	for the tagged load or store operation was present in a 1G page table entry in the data cache L1TLB.		
4	<b>IbsDcL1TlbHit2M</b> : <b>data cache L1TLB hit in 2M page</b> . Read-write, Volatile. Reset: 0. 1=The physical address for the tagged load or store operation was present in a 2M page table entry in the data cache L1TLB.		
3		<b>FlbMiss:</b> data cache L2TLB miss. Read-write, Volatile. Reset: 0. 1=The physical address for the tagged	
3		ore operation was not present in the data cache L2TLB.	
2		<b>lbMiss:</b> data cache L1TLB miss. Read-write, Volatile. Reset: 0. 1=The physical address for the tagged	
		ore operation was not present in the data cache L1TLB.	
1		<b>store op</b> . Read-write, Volatile. Reset: 0. 1=Tagged operation is a store operation.	
0		: <b>load op</b> . Read-write, Volatile. Reset: 0. 1=Tagged operation is a load operation.	
	P	The state of the s	

# MSRC001\_1038 [IBS DC Linear Address] (Core::X86::Msr::IBS\_DC\_LINADDR)

Read-v	ead-write,Volatile. Reset: 0000_0000_0000_0000h.	
_lthree[1	ree[1:0]_core[3:0]_thread[1:0]; MSRC001_1038	
Bits	Description	
62.0	The Delin Ad Dood write Velatile Deset: 0000, 0000, 0000, 0000h Dravides the linear address in canonical form	

for the tagged load or store operation. This field contains valid data only if Core::X86::Msr::IBS OP DATA3[IbsDcLinAddrValid] is asserted.

# MSRC001\_1039 [IBS DC Physical Address] (Core::X86::Msr::IBS\_DC\_PHYSADDR) Read-write, Volatile. Reset: 0000\_0000\_00000\_0000h. \_lthree[1:0]\_core[3:0]\_thread[1:0]; MSRC001\_1039 Bits Description 63:48 Reserved. 47:0 IbsDcPhysAd: load or store physical address. Read-write, Volatile. Reset: 0000\_0000\_0000h. Provides the physical address for the tagged load or store operation. The lower 12 bits are not modified by address translation, so they are always the same as the linear address. This field contains valid data only if Core::X86::Msr::IBS\_OP\_DATA3[IbsDcPhyAddrValid] is asserted.

# MSRC001\_103A [IBS Control] (Core::X86::Msr::IBS\_CTL)

	, , , , , , , , , , , , , , , , , , , ,	
Read,1	Read,Error-on-write.	
_lthree[1	:0]_core[3:0]_thread[1:0]; MSRC001_103A	
Bits	Description	
63:9 Reserved.	Reserved.	
8	LvtOffsetVal: local vector table offset valid. Read, Error-on-write. Reset: X.	
7:4	Reserved.	
3:0	LvtOffset: local vector table offset. Read,Error-on-write. Reset: Xh.	

# MSRC001\_103B [IBS Branch Target Address] (Core::X86::Msr::BP\_IBSTGT\_RIP)

WIGHT	(Corexiovxisrbr_ibb1G1_ixi)	
Read-	lead-write, Volatile. Reset: 0000_0000_0000_0000h.	
Suppo	port for this register indicated by Core::X86::Cpuid::IbsIdEax[BrnTrgt].	
_lthree[1	e[1:0]_core[3:0]_thread[1:0]; MSRC001_103B	
Bits	Description	
63:0	<b>IbsBrTarget</b> . Read-write, Volatile. Reset: 0000_0000_0000_0000h. The logical address in canonical form for the	
	branch target. Contains a valid target if != 0. Qualified by Core::X86::Msr::IBS_OP_DATA[IbsOpBrnRet] == 1.	

# MSRC001\_103C [IBS Fetch Control Extended] (Core::X86::Msr::IC\_IBS\_EXTD\_CTL)

Read-	Read-only, Volatile. Reset: 0000_0000_0000_0000h.	
	Support for this register indicated by Core::X86::Cpuid::IbsIdEax[IbsFetchCtlExtd].	
_lthree[1	:0]_core[3:0]_thread[1:0]; MSRC001_103C	
Bits	Description	
63:16	Reserved.	
15:0	5:0 <b>IbsItlbRefillLat: ITLB Refill Latency for the sampled fetch, if there is a reload</b> . Read-only, Volatile. Reset:	
	0000h. The number of cycles when the fetch engine is stalled for an ITLB reload for the sampled fetch. If there is	
	no reload, the latency $== 0$ .	

### 2.1.15 Performance Monitor Counters

### 2.1.15.1 RDPMC Assignments

There are six core performance event counters per thread, six performance events counters per L3 complex and four Data Fabric performance events counters mapped to the RDPMC instruction as follows:

- The RDPMC[5:0] instruction accesses core events. See 2.1.15.3 [Core Performance Monitor Counters].
- The RDPMC[9:6] instruction accesses data fabric events.
- The RDPMC[F:A] instruction accesses L3 cache events. See 2.1.15.4 [L3 Cache Performance Monitor Counters].

### 2.1.15.2 Large Increment per Cycle Events

Table 18: PMC Definitions

Term	Description
MergeEvent	A PMC event that is capable of counter increments greater than 15, thus requiring merging a pair
	of even/odd performance monitors.

The maximum increment for a regular performance event is 15 (i.e., a 4-bit event). However some event types can have a larger increments every cycle (example: Core::X86::Pmc::Core::FpRetSseAvxOps).

An option is provided for merging a pair of even/odd performance monitors to acquire an accurate count. First the odd numbered Core::X86::Msr::PERF\_CTL is programmed with the event Core::X86::Pmc::Core::Merge (PMCxFFF) with the enable bit (En) turned on and with the remaining bits off. Then the corresponding even numbered Core::X86::Msr::PERF\_CTL is programmed with the desired PMC event. The performance monitor combines the count value to an 8-bit increment event and extends the counter to a 64-bit counter.

Software wanting to preload a value to a merged counter pair writes the high-order 16-bit value to the low-order 16 bits of the odd counter and then writes the low-order 48-bit value to the even counter. Reading the even counter of the merged counter pair returns the full 64-bit value.

If an even performance monitor is programmed with the event Core::X86::Pmc::Core::Merge the read results are undetermined. If an even performance monitor is programmed with a non-merge-able event (i.e., a 4-bit event) while the corresponding odd performance monitor is programmed as Merge, the Read results are undetermined. When discontinuing use of a merged counter pair, clear the Merge event from the odd performance monitor.

PMCxFFF [Merge] (Core::X86::Pmc::Core::Merge)	
See 2.1.15.2 [Large Increment per Cycle Events].	
PMCxFFF	
Bits	Description
7:0	Reserved.

### 2.1.15.3 Core Performance Monitor Counters

This section provides the core performance counter events that may be selected through

Core::X86::Msr::PERF\_CTL[EventSelect[11:8],EventSelect[7:0],UnitMask]. See Core::X86::Msr::PERF\_CTR. See

Core::X86::Msr::PERF\_LEGACY\_CTL and Core::X86::Msr::PERF\_LEGACY\_CTR.

### 2.1.15.3.1 Floating Point (FP) Events

# PMCx003 [Retired SSE/AVX FLOPs] (Core::X86::Pmc::Core::FpRetSseAvxOps)

Read-write. Reset: 00h.
This is a retire-based event. The number of retired SSE/AVX FLOPs. The number of events logged per cycle can vary
from 0 to 64. This event is a MergeEvent since it can count above 15 events per cycle. See 2.1.15.2 [Large Increment per
Cycle Events].
PMCx003

1 111 01101	11101000	
Bits	Description	
7:4	Reserved.	
3	<b>MacFLOPs</b> . Read-write. Reset: 0. MacFLOPs count as 2 FLOPs. Does not provide a useful count without use of	
	the MergeEvent feature. See 2.1.15.2 [Large Increment per Cycle Events].	
2	<b>DivFLOPs</b> : <b>Divide/square root FLOPs</b> . Read-write. Reset: 0. Does not provide a useful count without use of the	
	MergeEvent feature. See 2.1.15.2 [Large Increment per Cycle Events].	

1	<b>MultFLOPs</b> : <b>Multiply FLOPs</b> . Read-write. Reset: 0. Does not provide a useful count without use of the	
	MergeEvent feature. See 2.1.15.2 [Large Increment per Cycle Events].	
0	<b>AddSubFLOPs</b> : <b>Add/subtract FLOPs</b> . Read-write. Reset: 0. Does not provide a useful count without use of the	

MergeEvent feature. See 2.1.15.2 [Large Increment per Cycle Events].

PMCx005 [Retired Serializing Ops] (Core::X86::Pmc::Core::FpRetiredSerOps)	
Read-write. Reset: 00h.	
The number of serializing Ops retired.	
PMCx005	
Bits	Description
7:4	Reserved.
3	SseBotRet: SSE bottom-executing uOps retired. Read-write. Reset: 0.
2	SseCtrlRet: SSE control word mispredict traps due to mispredictions in RC, FTZ or DAZ, or changes in
	mask bits. Read-write. Reset: 0.
1	X87BotRet: x87 bottom-executing uOps retired. Read-write. Reset: 0.
0	X87CtrlRet: x87 control word mispredict traps due to mispredictions in RC or PC, or changes in mask bits.
	Read-write. Reset: 0.

# PMCx00E [FP Dispatch Faults] (Core::X86::Pmc::Core::FpDispFaults)

Read-write. Reset: 00h.		
Floating Point Dispatch Faults.		
PMCx00E		
Bits	Description	
7:4	Reserved.	
3	YmmSpillFault: YMM Spill fault. Read-write. Reset: 0.	
2	YmmFillFault: YMM Fill fault. Read-write. Reset: 0.	
1	XmmFillFault: XMM Fill fault. Read-write. Reset: 0.	
0	<b>x87FillFault</b> : <b>x87 Fill fault</b> . Read-write. Reset: 0.	

### 2.1.15.3.2 LS Events

# PMCx024 [Bad Status 2] (Core::X86::Pmc::Core::LsBadStatus2)

Read-write. Reset: 00h.		
PMCx02	PMCx024	
Bits	Description	
7:2	Reserved.	
1	<b>StliOther</b> . Read-write. Reset: 0. Store-to-load conflicts: A load was unable to complete due to a non-forwardable conflict with an older store. Most commonly, a load's address range partially but not completely overlaps with an uncompleted older store. Software can avoid this problem by using same-size and same-alignment loads and stores when accessing the same data. Vector/SIMD code is particularly susceptible to this problem; software should construct wide vector stores by manipulating vector elements in registers using shuffle/blend/swap instructions prior to storing to memory, instead of using narrow element-by-element stores.	
0	Reserved.	

# PMCx025 [Retired Lock Instructions] (Core::X86::Pmc::Core::LsLocks)

Read-write. Reset: 00h.		
Unit Mask 0x0E represents cacheable locks.		
PMCx025		
Bits	Description	
7:1	Reserved.	

**BusLock**. Read-write. Reset: 0. Comparable to legacy bus lock.

# PMCx026 [Retired CLFLUSH Instructions] (Core::X86::Pmc::Core::LsRetClClush)

The number of retired CLFLUSH instructions. This is a non-speculative event.

PMCx026

Bits Description

7:0 Reserved.

### PMCx027 [Retired CPUID Instructions] (Core::X86::Pmc::Core::LsRetCpuid)

The number of CPUID instructions retired.

PMCx027

Bits Description

7:0 Reserved.

### PMCx029 [LS Dispatch] (Core::X86::Pmc::Core::LsDispatch)

Read-write. Reset: 00h.

Counts the number of operations dispatched to the LS unit. Unit Masks ADDed.

PMCx029

Bits   I	escription
----------	------------

- 7:3 Reserved.
- 2 **LdStDispatch**: **Load-op-Store Dispatch**. Read-write. Reset: 0. Dispatch of a single op that performs a load from and store to the same memory address.
- **StoreDispatch**. Read-write. Reset: 0. Dispatch of a single op that performs a memory store.
- 0 **LdDispatch**. Read-write. Reset: 0. Dispatch of a single op that performs a memory load.

### PMCx02B [SMIs Received] (Core::X86::Pmc::Core::LsSmiRx)

Counts the number of SMIs received.

PMCx02B

Bits Description

7:0 Reserved.

### PMCx02C [Interrupts Taken] (Core::X86::Pmc::Core::LsIntTaken)

Counts the number of interrupts taken.

PMCx02C

Bits Description

Reserved.

### PMCx035 [Store to Load Forward] (Core::X86::Pmc::Core::LsSTLF)

Number of STLF hits.

PMCx035

Bits Description

7:0 Reserved.

### PMCx037 [Store Commit Cancels 2] (Core::X86::Pmc::Core::LsStCommitCancel2)

Read-write. Reset: 00h.

PMCx037

D:4-	D 4'
Bits	Description

7:1 Reserved.

**StCommitCancelWcbFull**. Read-write. Reset: 0. A non-cacheable store and the non-cacheable commit buffer is

### PMCx041 [LS MAB Allocates by Type] (Core::X86::Pmc::Core::LsMabAlloc)

Read-write. Reset: 00h.

PMCx04	PMCx041	
Bits	Description	
7:4	Reserved.	
3	<b>DcPrefetcher</b> . Read-write. Reset: 0.	
2	Reserved.	
1	Stores. Read-write. Reset: 0.	
0	Loads. Read-write. Reset: 0.	

#### PMCx043 [Data Cache Refills from System] (Core::X86::Pmc::Core::LsRefillsFromSys)

Read-write. Reset: 00h.		
Demand Data Cache Fills by Data Source.		
PMCx04	3	
Bits	Bits Description	
7	Reserved.	
6	LS_MABRESP_RMT_DRAM. Read-write. Reset: 0. From DRAM (home node remote).	
5	Reserved.	
4	LS_MABRESP_RMT_CACHE. Read-write. Reset: 0. From another cache (home node remote).	
3	LS_MABRESP_LCL_DRAM. Read-write. Reset: 0. From DRAM (home node local).	
2	Reserved.	
1	LS_MABRESP_LCL_CACHE. Read-write. Reset: 0. From another cache (home node local).	
0	MABRESP_LCL_L2. Read-write. Reset: 0. From local L2 hit.	

#### PMCx045 [L1 DTLB Misses] (Core::X86::Pmc::Core::LsL1DTlbMiss)

Read-write. Reset: 00h.			
PMCx04	5		
Bits	its Description		
7	<b>TlbReload1GL2Miss</b> . Read-write. Reset: 0. DTLB reload to a 1G page that also miss in the L2 TLB.		
6	<b>TlbReload2ML2Miss</b> . Read-write. Reset: 0. DTLB reload to a 2M page that also miss in the L2 TLB.		
5	TlbReloadCoalescedPageMiss. Read-write. Reset: 0.		
4	<b>TlbReload4KL2Miss</b> . Read-write. Reset: 0. DTLB reload to a 4K page that miss the L2 TLB.		
3	<b>TlbReload1GL2Hit</b> . Read-write. Reset: 0. DTLB reload to a 1G page that hit in the L2 TLB.		
2	<b>TlbReload2ML2Hit</b> . Read-write. Reset: 0. DTLB reload to a 2M page that hit in the L2 TLB.		
1	TlbReloadCoalescedPageHit. Read-write. Reset: 0.		
0	TlbReload4KL2Hit. Read-write. Reset: 0. DTLB reload to a 4K page that hit in the L2 TLB.		

#### PMCx047 [Misaligned loads] (Core::X86::Pmc::Core::LsMisalLoads)

PMCx047	
Bits	Description
7:0	Reserved.

#### PMCx04B [Prefetch Instructions Dispatched] (Core::X86::Pmc::Core::LsPrefInstrDisp)

Read-	write. Reset: 00h.	
Softw	are Prefetch Instructions Dispatched (Speculative).	
PMCx04	4B	
Bits	Bits Description	
7:3	7:3 Reserved.	
2	2 <b>PrefetchNTA</b> . Read-write. Reset: 0. PrefetchNTA instruction. See docAPM3 PREFETCHlevel.	
1	<b>PrefetchW</b> . Read-write. Reset: 0. PrefetchW instruction. See docAPM3 PREFETCHW.	
0	0 <b>Prefetch: Prefetch_T0_T1_T2</b> . Read-write. Reset: 0. PrefetchT0, T1 and T2 instructions. See docAPM3	
	PREFETCHlevel.	

PMCx052 [Ineffective Software Prefetches] (Core::X86::Pmc::Core::LsInefSwPref)			
Read-v	Read-write. Reset: 00h.		
The nu	The number of software prefetches that did not fetch data outside of the processor core.		
PMCx05	x052		
Bits	ts Description		
7:2	Reserved.		
1	<b>MabMchCnt.</b> Read-write. Reset: 0. Software PREFETCH instruction saw a match on an already-allocated miss		
	request buffer.		
0	<b>DataPipeSwPfDcHit</b> . Read-write. Reset: 0. Software PREFETCH instruction saw a DC hit.		

#### PMCx059 [Software Prefetch Data Cache Fills] (Core::X86::Pmc::Core::LsSwPfDcFills)

1 1/1 02	i i i cavos [Software 1 referen Butu Guene 1 ms] (Gore23501 meGoreEs5w1 iBet ms)	
Read-	Read-write. Reset: 00h.	
Softwa	Software Prefetch Data Cache Fills by Data Source.	
PMCx05	PMCx059	
Bits	ts Description	
7	Reserved.	
6	LS_MABRESP_RMT_DRAM. Read-write. Reset: 0. From DRAM (home node remote).	
5	Reserved.	
4	LS_MABRESP_RMT_CACHE. Read-write. Reset: 0. From another cache (home node remote).	
3	LS_MABRESP_LCL_DRAM. Read-write. Reset: 0. From DRAM (home node local).	
2	Reserved.	
1	LS_MABRESP_LCL_CACHE. Read-write. Reset: 0. From another cache (home node local).	
0	MABRESP_LCL_L2. Read-write. Reset: 0. From local L2 hit.	

#### PMCx05A [Hardware Prefetch Data Cache Fills] (Core::X86::Pmc::Core::LsHwPfDcFills)

Read-write. Reset: 00h.		
Hardware Prefetch Data Cache Fills by Data Source.		
PMCx05	5A	
Bits Description		
7	Reserved.	
6	6 LS_MABRESP_RMT_DRAM. Read-write. Reset: 0. From DRAM (home node remote).	
5	5 Reserved.	
4	4 LS_MABRESP_RMT_CACHE. Read-write. Reset: 0. From another cache (home node remote).	
3	LS_MABRESP_LCL_DRAM. Read-write. Reset: 0. From DRAM (home node local).	
2	2 Reserved.	
1 LS_MABRESP_LCL_CACHE. Read-write. Reset: 0. From another cache (home node local).		
0	MABRESP LCL L2. Read-write. Reset: 0. From local L2 hit.	

#### PMCx05F [Count of Allocated Mabs] (Core::X86::Pmc::Core::LsAllocMabCount)

This event counts the in-flight L1 data cache misses each cycle. This event is a MergeEvent since it can count above 15 events per cycle. See 2.1.15.2 [Large Increment per Cycle Events].

PMCx05F	
Bits	Description
7:0	Reserved.

#### PMCx076 [Cvcles not in Halt] (Core::X86::Pmc::Core::LsNotHaltedCyc)

	PMCx07	76
	Bits	Description
ſ	7:0	Reserved.

#### **2.1.15.3.3 IC and BP Events**

Note: All instruction cache events are speculative events unless specified otherwise.

#### PMCx082 [Instruction Cache Refills from L2] (Core::X86::Pmc::Core::IcCacheFillL2)

The number of 64-byte instruction cache line was fulfilled from the L2 cache.

PMCx082

**Bits Description** 7:0 Reserved.

#### PMCx083 [Instruction Cache Refills from System] (Core::X86::Pmc::Core::IcCacheFillSys)

The number of 64-byte instruction cache line fulfilled from system memory or another cache.

PMCx083

Bits Description

7:0 Reserved.

#### PMCx084 [L1 ITLB Miss, L2 ITLB Hit] (Core::X86::Pmc::Core::BpL1TlbMissL2TlbHit)

The number of instruction fetches that miss in the L1 ITLB but hit in the L2 ITLB.

PMCx084

Bits Description

7:0 Reserved.

#### PMCx085 [L1 ITLB Miss, L2 ITLB Miss] (Core::X86::Pmc::Core::BpL1TlbMissL2TlbMiss)

Read-write. Reset: 00h.

The number of instruction fetches that miss in both the L1 and L2 TLBs.

PMCx085

Bits Description

7:3 Reserved.

2 **IF1G**: **Instruction fetches to a 1 GB page**. Read-write. Reset: 0.

1 **IF2M**: **Instruction fetches to a 2 MB page**. Read-write. Reset: 0.

0 **IF4K**: **Instruction fetches to a 4 KB page**. Read-write. Reset: 0.

#### PMCx08A [L1 Branch Prediction Overrides Existing Prediction (speculative)]

(Core::X86::Pmc::Core::BpL1BTBCorrect)

PMCx08A

Bits Description

7:0 Reserved.

#### PMCx08B [L2 Branch Prediction Overrides Existing Prediction (speculative)]

(Core::X86::Pmc::Core::BpL2BTBCorrect)

PMCx08B

| Bits | Description

7:0 Reserved.

#### PMCx08E [Dynamic Indirect Predictions] (Core::X86::Pmc::Core::BpDynIndPred)

Indirect Branch Prediction for potential multi-target branch (speculative).

PMCx08E

Bits Description

7:0 Reserved.

#### PMCx091 [Decoder Overrides Existing Branch Prediction (speculative)] (Core::X86::Pmc::Core::BpDeReDirect)

PMCx091

D.	T
Bits	Description
	- co ca a p ca o a

7:0 Reserved.

PMCx094 [ITLB Instruction Fetch Hits] (Core::X86::Pmc::Core::BpL1TlbFetchHit)		
Read-write. Reset: 00h.		
The number of instruction fetches that hit in the L1 ITLB.		
PMCx09	PMCx094	
Bits	Bits Description	
7:3	Reserved.	
2	2 <b>IF1G.</b> Read-write. Reset: 0. L1 Instruction TLB hit (1G page size).	
1	1 <b>IF2M.</b> Read-write. Reset: 0. L1 Instruction TLB hit (2M page size).	
0	<b>IF4K</b> . Read-write. Reset: 0. L1 Instruction TLB hit (4K page size).	

#### 2.1.15.3.4 **DE Events**

PMCx0A9 [Micro-Op Queue Empty] (Core::X86::Pmc::Core::DeDisUopQueueEmpty)		
Cycles	Cycles where the Micro-Op Queue is empty.	
PMCx0A9		
Bits	Description	
7:0	Reserved.	

# PMCx0AA [UOps Dispatched From Decoder] (Core::X86::Pmc::Core::DeDisUopsFromDecoder) Read-write. Reset: 00h. Ops dispatched from either the decoders, OpCache or both. PMCx0AA Rits Description

Bits	Description	
7:2	Reserved.	
1	<b>OpCacheDispatched: Count of dispatched Ops from OpCache</b> . Read-write. Reset: 0.	
0	<b>DecoderDispatched: Count of dispatched Ops from Decoder</b> . Read-write. Reset: 0.	

#### PMCx0AE [Dispatch Resource Stall Cycles 1] (Core::X86::Pmc::Core::DeDisDispatchTokenStalls1)

Read-write. Reset: 00h. Cycles where a dispatch group is valid but does not get dispatched due to a Token Stall. PMCx0AE Bits Description **FPMiscRsrcStall: FP Miscellaneous resource unavailable.** Read-write. Reset: 0. Applies to the recovery of mispredicts with FP ops. **FPSchRsrcStall: FP scheduler resource stall.** Read-write. Reset: 0. Applies to ops that use the FP scheduler. 6 5 **FpRegFileRsrcStall: floating point register file resource stall.** Read-write. Reset: 0. Applies to all FP ops that have a destination register. 4 TakenBrnchBufferRsrc: taken branch buffer resource stall. Read-write. Reset: 0. 3 IntSchedulerMiscRsrcStall: Integer Scheduler miscellaneous resource stall. Read-write. Reset: 0. 2 **StoreQueueRsrcStall: Store Queue resource stall.** Read-write. Reset: 0. Applies to all ops with store semantics. **LoadQueueRsrcStall:** Load Queue resource stall. Read-write. Reset: 0. Applies to all ops with load semantics. 1 0 IntPhyRegFileRsrcStall: Integer Physical Register File resource stall. Read-write. Reset: 0. Integer Physical Register File, applies to all ops that have an integer destination register.

# PMCx0AF [Dispatch Resource Stall Cycles 0] (Core::X86::Pmc::Core::DeDisDispatchTokenStalls0) Read-write. Reset: 00h. Cycles where a dispatch group is valid but does not get dispatched due to a token stall. PMCx0AF Bits Description 7:4 Reserved.

3	ALUTokenStall: ALU tokens total unavailable. Read-write. Reset: 0.
2:0	Reserved.

#### 2.1.15.3.5 EX (SC) Events

# PMCx0C0 [Retired Instructions] (Core::X86::Pmc::Core::ExRetInstr) **Bits** Description

Dits	Description
7:0	Reserved.

#### PMCx0C1 [Retired Uops] (Core::X86::Pmc::Core::ExRetCops)

The number of micro-ops retired. This count includes all processor activity (instructions, exceptions, interrupts, microcode assists, etc.). The number of events logged per cycle can vary from 0 to 8.

PMCx0C1

Bits	Description
7.0	Reserved

#### PMCx0C2 [Retired Branch Instructions] (Core::X86::Pmc::Core::ExRetBrn)

The number of branch instructions retired. This includes all types of architectural control flow changes, including exceptions and interrupts.

PMCx0C2

Bits	Description
7:0	Reserved.

#### PMCx0C3 [Retired Branch Instructions Mispredicted] (Core::X86::Pmc::Core::ExRetBrnMisp)

The number of branch instructions retired, of any type, that were not correctly predicted. This includes those for which prediction is not attempted (far control transfers, exceptions and interrupts).

PMCx0C3

Bits	Description
7:0	Reserved.

#### PMCx0C4 [Retired Taken Branch Instructions] (Core::X86::Pmc::Core::ExRetBrnTkn)

The number of taken branches that were retired. This includes all types of architectural control flow changes, including exceptions and interrupts.

PMCX0C4	
Bits	Description
7:0	Reserved.

#### PMCx0C5 [Retired Taken Branch Instructions Mispredicted] (Core::X86::Pmc::Core::ExRetBrnTknMisp)

The number of retired taken branch instructions that were mispredicted.

PMCx0C5

Bits	Description
7:0	Reserved.

#### PMCx0C6 [Retired Far Control Transfers] (Core::X86::Pmc::Core::ExRetBrnFar)

The number of far control transfers retired including far call/jump/return, IRET, SYSCALL and SYSRET, plus exceptions and interrupts. Far control transfers are not subject to branch prediction.

PMCx00	Ľ6
Bits	Description
7:0	Reserved.

#### PMCx0C8 [Retired Near Returns] (Core::X86::Pmc::Core::ExRetNearRet)

The number of near return instructions (RET or RET Iw) retired.  PMCx0C8	
PMCx0C8	
Bits	Description
7:0	Reserved.

#### PMCx0C9 [Retired Near Returns Mispredicted] (Core::X86::Pmc::Core::ExRetNearRetMispred)

The number of near returns retired that were not correctly predicted by the return address predictor. Each such mispredict incurs the same penalty as a mispredicted conditional branch instruction.

PMCx0C

PIVICXUC	)C3	
Bits	Description	
7:0	Reserved.	

#### PMCx0CA [Retired Indirect Branch Instructions Mispredicted] (Core::X86::Pmc::Core::ExRetBrnIndMisp)

The number of indirect branches retired that were not correctly predicted. Each such mispredict incurs the same penalty as a mispredicted conditional branch instruction. Note that only EX mispredicts are counted.

PMCx0CA

PMCX0C	JXUCA		
Bits	Description		
7:0	Reserved.		

#### PMCx0CB [Retired MMX/FP Instructions] (Core::X86::Pmc::Core::ExRetMmxFpInstr)

Read-write. Reset: 00h.

The number of MMX, SSE or x87 instructions retired. The UnitMask allows the selection of the individual classes of instructions as given in the table. Each increment represents one complete instruction. Since this event includes non-numeric instructions it is not suitable for measuring MFLOPs.

PMCx0CB

Bits	Description
7:3	Reserved.
2	<b>SseInstr</b> . Read-write. Reset: 0. SSE instructions (SSE, SSE2, SSE3, SSE3, SSE4A, SSE41, SSE42, AVX).
1	MmxInstr. Read-write. Reset: 0. MMX instructions.
0	X87Instr: x87 instructions. Read-write. Reset: 0.

#### PMCx0D1 [Retired Conditional Branch Instructions] (Core::X86::Pmc::Core::ExRetCond)

PMCx0D1	
Bits	Description
7:0	Reserved.

#### PMCx0D3 [Div Cycles Busy count] (Core::X86::Pmc::Core::ExDivBusy)

		J	J	٠, ١	, , , , , , , , , , , , , , , , , , ,
PMCx0I	PMCx0D3				
Bits	Description	n			
7:0	Reserved.				

#### PMCx0D4 [Div Op Count] (Core::X86::Pmc::Core::ExDivCount)

PMCx0D4		
Bits	Description	
7:0	Reserved.	

# PMCx1C7 [Retired Mispredicted Branch Instructions due to Direction Mismatch] (Core::X86::Pmc::Core::ExRetMsprdBrnchInstrDirMsmtch)

The number of retired conditional branch instructions that were not correctly predicted because of a branch direction mismatch.

PMCx1C7

Bits	Description			
7:0	Reserved.			

PMC	PMCx1CF [Tagged IBS Ops] (Core::X86::Pmc::Core::ExTaggedIbsOps)		
Read-	Read-write. Reset: 00h.		
PMCx10	CF CF		
Bits	Description		
7:3	Reserved.		
2	<b>IbsCountRollover</b> . Read-write. Reset: 0. Number of times an op could not be tagged by IBS because of a		
	previous tagged op that has not retired.		
1	IbsTaggedOpsRet: Number of Ops tagged by IBS that retired. Read-write. Reset: 0.		
0	IbsTaggedOps: Number of Ops tagged by IBS. Read-write. Reset: 0.		

#### PMCx1D0 [Retired Fused Instructions] (Core::X86::Pmc::Core::ExRetFusBrnchInst)

The number of fuse-branch instructions retired per cycle. The number of events logged per cycle can vary from 0-8. PMCx1D0

Bits	Description
7:0	Reserved.

#### **2.1.15.3.6 L2 Cache Events**

PMCx060 [Requests to L2 Group1] (Core::X86::Pmc::Core::L2RequestG1)			
Read-	Read-write. Reset: 00h.		
All L2	All L2 Cache Requests (Breakdown 1 - Common).		
PMCx06	0		
Bits	Description		
7	RdBlkL. Read-write. Reset: 0. Data Cache Reads (including hardware and software prefetch).		
6	RdBlkX. Read-write. Reset: 0. Data Cache Stores.		
5	LsRdBlkC_S. Read-write. Reset: 0. Data Cache Shared Reads.		
4	CacheableIcRead. Read-write. Reset: 0. Instruction Cache Reads.		
3	ChangeToX: Data Cache State Change Requests. Read-write. Reset: 0. Request change to writable, check L2		
	for current state.		
2	PrefetchL2Cmd. Read-write. Reset: 0.		
1	<b>L2HwPf</b> : <b>L2 Prefetcher</b> . Read-write. Reset: 0. All prefetches accepted by L2 pipeline, hit or miss. Types of PF		
	and L2 hit/miss broken out in a separate perfmon event.		
0	<b>Group2</b> . Read-write. Reset: 0. Miscellaneous events covered in more detail by		
	Core::X86::Pmc::Core::L2RequestG2 (PMCx061).		

PMCx061 [Requests to L2 Group2] (Core::X86::Pmc::Core::L2RequestG2)			
Read-	Read-write. Reset: 00h.		
All L2	Cache Requests (Breakdown 2 - Rare).		
PMCx06	31		
Bits	Description		
7	<b>Group1</b> . Read-write. Reset: 0. Miscellaneous events covered in more detail by		
	Core::X86::Pmc::Core::L2RequestG1 (PMCx060).		
6	LsRdSized. Read-write. Reset: 0. Data cache Read sized.		
5	LsRdSizedNC. Read-write. Reset: 0. Data cache Read sized non-cacheable.		
4	IcRdSized. Read-write. Reset: 0. Instruction cache Read sized.		
3	IcRdSizedNC. Read-write. Reset: 0. Instruction cache Read sized non-cacheable.		
2	SmcInval. Read-write. Reset: 0. Self-modifying code invalidates.		
1	BusLocksOriginator: Bus locks. Read-write. Reset: 0.		
0	BusLocksResponses. Read-write. Reset: 0. Bus Lock Response.		

PMCx064 [Core to L2 Cacheable Request Access Status] (Core::X86::Pmc::Core::L2CacheReqStat)			
Read-	Read-write. Reset: 00h.		
L2 Ca	L2 Cache Request Outcomes (not including L2 Prefetch).		
PMCx06	54		
Bits	Description		
7	LsRdBlkCS: Data Cache Shared Read Hit in L2. Read-write. Reset: 0.		
6	LsRdBlkLHitX: Data Cache Read Hit in L2. Read-write. Reset: 0.		
5	LsRdBlkLHitS: Data Cache Read Hit on Shared Line in L2. Read-write. Reset: 0.		
4	LsRdBlkX: Data Cache Store or State Change Hit in L2. Read-write. Reset: 0.		
3	LsRdBlkC: Data Cache Req Miss in L2 (all types). Read-write. Reset: 0.		
2	IcFillHitX: Instruction Cache Hit Modifiable Line in L2. Read-write. Reset: 0.		
1	IcFillHitS: Instruction Cache Hit Clean Line in L2. Read-write. Reset: 0.		
0	IcFillMiss: Instruction Cache Req Miss in L2. Read-write. Reset: 0.		

#### PMCx070 [L2 Prefetch Hit in L2] (Core::X86::Pmc::Core::L2PfHitL2)

Reset:	Reset: 00h.		
Requires unit mask 0xFF to engage event for counting.			
PMCx070			
Bits	Description		
7:0	Reserved.		

#### PMCx071 [L2 Prefetcher Hits in L3] (Core::X86::Pmc::Core::L2PfMissL2HitL2)

TIVICA	(CoreXoo meCoreE21 missE21mtE2)				
Reset:	00h.				
Requi	Requires unit mask 0xFF to engage event for counting.				
Counts	Counts all L2 prefetches accepted by the L2 pipeline which miss the L2 cache and hit the L3.				
PMCx07	PMCx071				
Bits	Description				
7:0	Reserved.				

#### PMCx072 [L2 Prefetcher Misses in L3] (Core::X86::Pmc::Core::L2PfMissL2L3)

Reset:	Reset: 00h.				
Requi	Requires unit mask 0xFF to engage event for counting.				
Count	Counts all L2 prefetches accepted by the L2 pipeline which miss the L2 and the L3 caches.				
PMCx07	PMCx072				
Bits	Description				
7:0	Reserved.				

#### 2.1.15.4 L3 Cache Performance Monitor Counters

This section provides the core performance counter events that may be selected through Core::X86::Msr::ChL3PmcCfg.

- Unless otherwise noted, L3 Perfmon events require the Core::X86::Msr::ChL3PmcCfg[SliceMask] field to be set or the PMC count will be zero.
- Unless otherwise noted, L3 PMC's require Core::X86::Msr::ChL3PmcCfg[ThreadMask] to be set or the PMC count will be zero.
- When in non-SMT mode, thread 0 must be selected for events that don't ignore ThreadMask.

#### **2.1.15.4.1 L3 Cache PMC Events**

#### L3PMCx04 [All L3 Cache Requests] (Core::X86::Pmc::L3::L3LookupState)

Read-	Read-write. Reset: 00h.				
L3PMC	L3PMCx04				
Bits	Description				
7:0	AllL3ReqTyps: All L3 Request Types. Read-write. Reset: 00h.				

#### L3PMCx90 [L3 Cache Miss Latency] (Core::X86::Pmc::L3::XiSysFillLatency)

LOI IV.	Est Wexpo [Est Guene Wiss Euteney] (Corexso1 meEstxisyst inducency)				
Ignore	Ignores SliceMask and ThreadMask.				
Total o	Total cycles for all transactions divided by 16.				
L3PMC:	L3PMCx90				
Bits	Description				
7:0	Reserved.				

L3PM	L3PMCx9A [L3 Misses by Request Type] (Core::X86::Pmc::L3::XiCcxSdpReq1)				
Reset:	Reset: 00h.				
Ignore	Ignores SliceMask and ThreadMask.				
Requi	Requires unit mask 0xFF to engage event for counting.				
L3PMCx	L3PMCx9A				
Bits	Description				
7:0	Reserved.				

#### 2.1.16 Instruction Based Sampling (IBS)

IBS is a code profiling mechanism that enables the processor to select a random instruction fetch or micro-Op after a programmed time interval has expired and record specific performance information about the operation. An interrupt is generated when the operation is complete as specified by Core::X86::Msr::IBS\_CTL. An interrupt handler can then Read the performance information that was logged for the operation.

The IBS mechanism is split into two parts: instruction fetch performance controlled by Core::X86::Msr::IBS\_FETCH\_CTL; and instruction execution performance controlled by Core::X96::Msr::IBS\_OR\_CTL\_Instruction fotch campling provides information about instru

Core::X86::Msr::IBS\_OP\_CTL. Instruction fetch sampling provides information about instruction TLB and instruction cache behavior for fetched instructions. Instruction execution sampling provides information about micro-Op execution behavior. The data collected for instruction fetch performance is independent from the data collected for instruction execution performance. Support for the IBS feature is indicated by the Core::X86::Cpuid::FeatureExtIdEcx[IBS].

Instruction fetch performance is profiled by recording the following performance information for the tagged instruction fetch:

- If the instruction fetch completed or was aborted. See Core::X86::Msr::IBS\_FETCH\_CTL.
- The number of clock cycles spent on the instruction fetch. See Core::X86::Msr::IBS FETCH CTL.
- If the instruction fetch hit or missed the IC, hit/missed in the L1 and L2 TLBs, and page size. See Core::X86::Msr::IBS\_FETCH\_CTL.
- The linear address, physical address associated with the fetch. See Core::X86::Msr::IBS\_FETCH\_LINADDR, Core::X86::Msr::IBS\_FETCH\_PHYSADDR.

Instruction execution performance is profiled by tagging one micro-Op associated with an instruction. Instructions that decode to more than one micro-Op return different performance data depending upon which micro-Op associated with the instruction is tagged. These micro-Ops are associated with the RIP of the next instruction to retire. The following performance information is returned for the tagged micro-Op:

- Branch and execution status for micro-ops. See Core::X86::Msr::IBS OP DATA.
- Branch target address for branch micro-ops. See Core::X86::Msr::BP\_IBSTGT\_RIP.
- The logical address associated with the micro-Op. See Core::X86::Msr::IBS\_OP\_RIP.
- The linear and physical address associated with a load or store micro-Op. See Core::X86::Msr::IBS\_DC\_LINADDR, Core::X86::Msr::IBS\_DC\_PHYSADDR.

- The data cache access status associated with the micro-Op: DC hit/miss, DC miss latency, TLB hit/miss, TLB page size. See Core::X86::Msr::IBS\_OP\_DATA3.
- The number clocks from when the micro-Op was tagged until the micro-Op retires. See Core::X86::Msr::IBS\_OP\_DATA.
- The number clocks from when the micro-Op completes execution until the micro-Op retires. See Core::X86::Msr::IBS\_OP\_DATA.
- Source information for DRAM and MMIO. See Core::X86::Msr::IBS\_OP\_DATA2.

#### 3 Reliability, Availability, and Serviceability (RAS) Features

A full implementation of RAS involves capabilities and support from the processor design, board hardware design, BIOS, firmware, and software.

#### 3.1 Machine Check Architecture

*Table 19: Machine Check Terms and Acronyms* 

Term	Description
MCA	Machine Check Architecture.
MCAX	Machine Check Architecture eXtensions.
WRIG	Writes Ignored.

#### 3.1.1 Overview

The processor contains logic and registers to detect, log, and correct errors in the data or control paths. The Machine Check Architecture (MCA) defines facilities by which processor and system hardware errors are logged and reported to system software. This allows system software to perform a strategic role in recovery from and diagnosis of hardware errors.

#### 3.1.1.1 Legacy Machine Check Architecture

The legacy x86 Machine Check Architecture (MCA) refers to the standard x86 facilities for error logging and reporting. Refer to the AMD64 Architecture Programmer's Manual for an architectural overview of the Machine Check Architecture.

Support for the MCA is indicated by Core::X86::Cpuid::FeatureIdEdx[MCA] or Core::X86::Cpuid::FeatureExtIdEdx[MCA].

#### 3.1.1.2 Machine Check Architecture Extensions

Machine Check Architecture Extensions (MCAX) is AMD's x86-64 extension to the Machine Check Architecture.

#### Goals of MCAX include:

- Accommodate a variety of implementations, where each implementation may have a different assignment of MCA bank to block.
  - For example, one implementation may have 1 memory channel with an MCA bank, and another otherwise identical implementation may have 2 memory channels, each with their own MCA bank. Therefore, MCA bank allocation will appear different between these two implementations. MCAX is designed to require no assumptions about which MCA banks access which blocks.
  - Provide granular information for error logging, to improve error handling and diagnosibility.
  - Preserve compatibility with system software which is not MCAX-aware.

#### Features of the MCA Extensions include:

- Increased MCA Bank Count: Features to support an expansion of the number of MCA banks supported by AMD processors.
- MCA Extension Registers: Expanded information logged in MCA banks to allow for improved error handling, better diagnosability, and future scalability.
- MCA DOER/SEER Roles: Separation of MCA information to take advantage of emerging software roles, namely

Error Management (Dynamic Operational Error Handling, or DOER) for managing running programs, and Fault Management (Symptom Elaboration of Errors, or SEER) for hardware diagnosability and reconfiguration. This clearer separation is accompanied by the assurances of architectural state (vs. implementation dependent state), so that operating systems can rely on the state and exploit new functionality.

Support for Machine Check Architecture Extensions (MCAX) is indicated by Core::X86::Cpuid::RasCap[ScalableMca].

#### 3.1.1.3 Use of MCA Information

The MCA registers contain information that can be used for multiple purposes. Some of this information is architecturally specified, and remains consistent from generation to generation, enabling portable, stable code. Some of this information is implementation specific; it is vital for diagnosis and other software functions, but may change with new implementations. It is important to understand how this information is categorized, and how it should be used. This section describes a framework for that.

There are two fundamental roles to be carried out after an error occurs; Error Management and Fault Management. All information required for Error Management is architectural and stable; some information required for Fault Management is also architectural.

#### 3.1.1.3.1 Error Management

Error Management describes actions necessary by operational software (e.g., the operating system or the hypervisor) to manage running programs that are affected by the error. The list of possible actions for operational error management is generally fairly short: take no action; terminate a single affected process, program, or virtual machine; terminate system operation. The Error Management role is defined as the DOER role (Dynamic Operational Error Handling). The name is intended to indicate an active role in managing running programs. Information used by the DOER is fairly limited and straightforward. It includes only those status fields needed to make decisions about the scope and severity of the error, and to determine what immediate action is to be taken.

#### 3.1.1.3.2 Fault Management

Fault Management describes optional actions for purposes of diagnosis, repair, and reconfiguration of the underlying hardware. The Fault Management role is described as SEER (Symptom Elaboration of Errors) because it peers further into hardware behavior and may try to influence future behavior via Predictive Fault Analysis, reconfiguration, service actions, etc. Because the SEER depends on understanding specifics of hardware configuration, it necessarily requires implementation specific knowledge and may not be portable across implementations.

Fields that are not explicitly specified as DOER are SEER. By separating error handling software into DOER and SEER roles, programmers can create both simpler and more functional code. The terms DOER and SEER appear in other sections of this document as an aid to reasoning about error handling and understanding actions to be taken.

#### 3.1.2 Machine Check Registers

Host software references MCA registers via MSRs. MSRs are accessed through x86 WRMSR and RDMSR instructions. MSR addresses are private to a logical core; a given MSR referenced by two different cores results in references to two different MCA registers.

#### 3.1.2.1 Global Registers

Core::X86::Cpuid::FeatureIdEdx[MCA] or Core::X86::Cpuid::FeatureExtIdEdx[MCA] indicates the presence of the following machine check registers:

- Core::X86::Msr::MCG\_CAP
  - Reports how many machine check register banks are supported. This value reflects the number of MCA
    banks visible to that logical core. Some banks may be RAZ/WRIG either due to the bank being reserved
    or unused on this processor or because the block's MCA bank is controlled by another logical core.
- Core::X86::Msr::MCG STAT
  - Provides basic information about processor state after the occurrence of a machine check error.
- Core::X86::Msr::MCG CTL
  - Used by software to enable or disable the logging and reporting of machine check errors in the error reporting banks. Some bits may be RAZ/WRIG either due to the bank being reserved or unused on this processor or because the block's MCA bank is controlled by another logical core.
- Core::X86::Msr::McaIntrCfg
  - Used by software to configure certain machine check interrupts

#### 3.1.2.2 Machine Check Banks

A processor contains multiple blocks, and some of them have banks of machine check architecture registers (MCA banks). An MCA bank logs and reports errors to software.

The legacy MCA supports up to 32 MCA banks per logical core. MCAX supports up to 64 MCA banks per logical core.

The processor ensures that non-zero error status in an MCA bank is visible to exactly one logical core in a system, and that error notifications are directed to that logical core. Hardware also makes MCA bank configuration and control registers available to exactly one logical core. Banks associated with a CPU core are controlled by that logical core. Banks associated with other blocks are controlled by an implementation-specific logical core.

#### 3.1.2.2.1 Legacy MCA Registers

Each legacy MCA bank allocates address space for 4 legacy MCA registers.

The legacy MCA registers include:

- MCA CTL
  - Enables error reporting via machine check exception.
- MCA\_STATUS
  - Logs information associated with errors.
- MCA\_ADDR
  - Logs address information associated with errors.
- MCA MISCO
  - Logs miscellaneous information associated with errors.

#### 3.1.2.2.2 Legacy MCA MSRs

The legacy MCA MSRs are MSR0000\_04[7F:00]. The legacy MCA MSR space contains 32 banks of 4 registers per bank. The layout of the legacy MCA MSR space is given in Table 20 [Legacy MCA MSR Layout].

*Table 20: Legacy MCA MSR Layout* 

MCA bank	MCA_CTL	MCA_STATUS	MCA_ADDR	MCA_MISC0
(decimal)	(MSR0000_0xxx)			
0	400	401	402	403
1	404	405	406	407
2	408	409	40A	40B
3	40C	40D	40E	40F

4	410	411	412	413
5	414	415	416	417
6	418	419	41A	41B
31	47C	47D	47E	47F

Features and registers associated with the MCA Extensions are not available in this legacy MSR address range. AMD recommends that operating systems use the MCAX MSR address range, rather than rely on the legacy MCA MSR address range.

All unimplemented or unused registers in the legacy MCA MSR address range are RAZ/WRIG. MC4 registers (MSR0000\_0410:0000\_0413) are RAZ/WRIG.

MSR0000\_0000 is aliased to the MCAX MSR address for MC0\_ADDR, and MSR0000\_0001 is aliased to the MCAX MSR address of MC0\_STATUS.

#### 3.1.2.2.3 MCAX Registers

Each MCAX bank allocates address space for 16 MCA registers. All unimplemented registers in the MCA MSR space are RAZ/WRIG. MCAX bank registers include the legacy MCA registers as well as registers associated with the MCA Extensions.

The MCA Extension registers include:

- MCA\_CONFIG
  - Provide configuration capabilities for this MCA bank.
- MCA IPID
  - Provides information on the block associated with this MCA bank.
- MCA\_SYND
  - Logs physical location information associated with a logged error.
- MCA\_DESTATUS
  - Logs status information associated with a deferred error.
- MCA DEADDR
  - Logs address information associated with a deferred error.
- MCA MISC[1:4]
  - Provides additional threshold counters within an MCA bank.

#### 3.1.2.2.4 MCAX MSRs

MCAX MSRs are present at MSRC000\_2[3FF:000]. This MSR address range contains space for 64 banks of 16 registers each. MSRC000\_2[FFF:400] are Reserved for future use. The MCAX MSR address range allows access to both legacy MCA registers and MCAX registers in each MCA bank.

The x86 MCAX MSR address format is SSSS\_SBBR (hex). S = MCA register space (i.e., MSRC000\_2xxx). B=MCA bank. R=Register offset within MCA bank. The layout of the MCAX MSR space is given in Table 21 [MCAX MSR Layout].

Access to unused MCAX MSRs is RAZ/WRIG. MCA Bank 4 is always Read-as-zero (RAZ/WRIG).

Table 21: MCAX MSR Layout

MCA		MCAX MSR (MSRC000_2xxx)
bank	Legacy MCA Bank registers	MCAX Bank registers

	CTL	STATUS	ADDR	MISC0	CONFIG	IPID	SYND	Reserved	DESTAT	DEADDR	MISC[4:1]
0	000	001	002	003	004	005	006	007	008	009	00D:00A
1	010	011	012	013	014	015	016	017	018	019	01D:01A
2	020	021	022	023	024	025	026	027	028	029	02D:02A
63	3F0	3F1	3F2	3F3	3F4	3F5	3F6	3F7	3F8	3F9	3FD:3FA

All processors maintain the same mapping of MSR to MCA bank number (MSRC000\_2000 for the beginning of MCA Bank 0, MSRC000\_2010 for the beginning of MCA Bank 1, etc.), regardless of what block the bank represents (see 3.1.5.5 [Determining Bank Type]).

MCA\_CTL\_MASK MSRs are present at MSRC001\_04[3F:00]. MSRC001\_04[FF:40] are Reserved for future use. The layout of these registers is given in Table 22 [MCAX Implementation-Specific Register Layout].

*Table 22: MCAX Implementation-Specific Register Layout* 

MCA bank	MCA_CTL_MASK
	(MSRC001_04xx)
0	00
1	01
2	02
63	3F

#### 3.1.2.3 Access Permissions

When McStatusWrEn == 0, a write to an implemented MCA\_STATUS register causes a General Protection Fault (#GP) unless the value being written is zero. When McStatusWrEn == 1, a Write to an implemented MCA\_STATUS register does not cause a #GP regardless of data value.

Access to legacy MCA\_CTL\_MASK (MSRC001\_00xx) causes a General Protection Fault (#GP).

Access to legacy MC4 MISC1-8 (MSRC000 0408:C000 040F) is RAZ/WRIG.

#### 3.1.3 Machine Check Errors

#### 3.1.3.1 Error Severities

The classes of machine check errors are, in priority order from highest to lowest:

- Uncorrected
- Deferred
- Corrected

Uncorrected errors cannot be corrected by hardware. Uncorrected errors update the status and address registers if not masked from logging in MCA\_CTL\_MASK. Information in the status and address registers from a previously logged lower priority error is overwritten. Previously logged errors of the same priority are not overwritten. Uncorrected errors that are enabled for reporting in MCA\_CTL result in reporting to software via machine check exceptions. If an uncorrected error is masked from logging, the error is ignored by hardware (exceptions are noted in the register definitions). If an uncorrected error is disabled from reporting, containment of the error and logging/reporting of subsequent errors may be affected. Therefore, enable reporting of unmasked uncorrected errors for normal operation. Disable reporting of uncorrected errors only for debug purposes.

Deferred errors are errors that cannot be corrected by hardware, but do not cause an immediate interruption in program flow, loss of data integrity, or corruption of processor state. These errors indicate that data has been corrupted but not consumed; no exception is generated because the data has not been referenced by a core or an IO link. Hardware writes information to the status and address registers in the corresponding bank that identifies the source of the error if deferred errors are enabled for logging. If there is information in the status and address registers from a previously logged lower priority error, it is overwritten. Previously logged errors of the same or higher priority are not overwritten. Deferred errors are not reported via machine check exceptions; they can optionally be reported via LVT or SMI.

Corrected errors are those which have been corrected by hardware and cause no loss of data or corruption of processor state. Hardware writes the status and address registers in the corresponding register bank with information that identifies the source of the error if they are enabled for logging. Corrected errors are not reported via machine check exceptions. Some corrected errors may optionally be reported to software via LVT or SMI if the number of errors exceeds a configurable threshold.

An error to be logged when the status register contains valid data can result in an overflow condition. During error overflow conditions, the new error may not be logged or an error which has already been logged in the status register may be overwritten.

Table 23 [Error Overwrite Priorities] indicates which errors are overwritten in the error status registers.

Table 25. Birdi Overwitte Friorities								
			Older Error					
		Uncorrected	Deferred	Corrected				
	Uncorrected	-	Overwrite	Overwrite				
Newer	Deferred	-	-	Overwrite				
Error	Corrected	-	-	-				

Table 23: Error Overwrite Priorities

Table 24 [Error Scope Hierarchy] provides a hierarchy of error scopes that determine the potential ability to recover the system based on fields in MCA\_STATUS when MCA\_STATUS[Val] == 1.

Table	21.	Frror	Scone	Hierarchy	
Tune	Z <b>4</b> .	raioi	JUDIE	THEIGICHY	

PCC	UC	TCC	Deferred	Comments
1	X	X	X	Uncorrected system fatal error. Action required. A hardware-uncorrected error has corrupted system state. The error is fatal to the system and the system processing must be terminated.
0	1	1	X	Uncorrected thread fatal error. Action required. A hardware-uncorrected error has corrupted state for the process thread executing on the interrupted logical core. State for other process threads is unaffected.
0	1	0	X	Uncorrected recoverable error. Action required. A hardware-uncorrected error has not corrupted state of the process thread. Recovery of the process thread is possible if the uncorrected error is corrected by software.
0	0	0	1	Deferred error. Action optional. A hardware-uncorrected error has been discovered but not yet consumed. Error handling software may attempt to correct this error, or prevent access by processes which map the data, or make the physical resource containing the data inaccessible.

0	0	0	0	Corrected error. Action optional. A hardware-corrected error has
				been corrected. No action is required by error handling software.

#### 3.1.3.2 Exceptions and Interrupts

Some or all errors logged in the MCA may require an interrupt or exception to be signaled.

The processor supports the following x86 interrupt/exception types to be communicated to the x86 core in response to an error:

- Machine Check Exception (MCE)
- System Management Interrupt (SMI)
- APIC based interrupt (LVT)

MCEs can be architecturally precise, context-synchronous, or asynchronous. An MCE that sets Core::X86::Msr::MCG\_STAT[RIPV] = 1 and Core::X86::Msr::MCG\_STAT[EIPV] = 1 is precise and the program can be restarted reliably. Other interrupts are architecturally asynchronous.

The ability of hardware to generate a machine check exception upon an error is indicated by Core::X86::Cpuid::FeatureIdEdx[MCE] or Core::X86::Cpuid::FeatureExtIdEdx[MCE].

#### 3.1.3.3 Error Codes

The MCA\_STATUS[ErrorCode] field contains information used to identify the logged error. This section identifies how to decode the ErrorCode field.

*Table 25: Error Code Types* 

Error Code	Error Code Type	Description
0000 0000 0001 TTLL	TLB	TT = Transaction Type
		LL = Cache Level
0000 0001 RRRR TTLL	Memory	RRRR = Memory Transaction Type
		TT = Transaction Type
		LL = Cache Level
0000 1XXT RRRR XXLL	Bus	XX = Reserved
		T = Timeout
		RRRR = Memory Transaction Type
		LL = Cache Level
0000 01UU 0000 0000	Internal Unclassified	UU = Internal Error Type

#### *Table 26: Error code: transaction type (TT)*

TT	Transaction Type
00	Instruction
01	Data
10	Generic
11	Reserved

#### Table 27: Error codes: cache level (LL)

· · ·	
LL	Cache Level
00	L0: Core
01	L1: Level 1

10	L2: Level 2
11	LG: Generic

*Table 28: Error codes: memory transaction type (RRRR)* 

RRRR	Memory Transaction Type
0000	Generic
0001	Generic Read
0010	Generic Write
0011	Data Read
0100	Data Write
0101	Instruction Fetch
0110	Prefetch
0111	Evict
1000	Snoop (Probe)

Errors can also be identified by the MCA\_STATUS[ErrorCodeExt] field. MCA\_STATUS[ErrorCodeExt] indicates which bit position in the corresponding MCA\_CTL register enables error reporting for the logged error. For instance, MCA\_STATUS[ErrorCodeExt] == 0x9 means that the logged error is enabled by MCA\_CTL[9], and the description of MCA\_CTL[9] contains information on decoding the error log. Specific ErrorCodeExt values are implementation dependent, and should not be used by architectural or portable code.

#### 3.1.3.4 Extended Error Codes

The MCA\_STATUS[ErrorCodeExt] field contains additional information used to identify the logged error. Error positions in MCA\_CTL and MCA\_CTL\_MASK and Extended Error Codes are fixed within a given bank type. That is, for an MCA bank with a given MCA\_IPID[HwId, McaType] value, the processor ensures that the same error is reported in a given bit position of of MCA\_CTL regardless of the product in which that bank appears. Similarly, for an MCA bank with a given MCA\_IPID[HwId, McaType] value, hardware ensures that the mapping of errors to Extended Error Codes is consistent across products.

#### 3.1.3.5 DOER and SEER State

The DOER fields are:

- MCG\_STAT
  - Count
  - MCIP
  - RIPV
  - EIPV
- MCA\_STATUS
  - Val
  - PCC
  - TCC
  - UC
  - MiscV
  - AddrV

The MCA\_STATUS[Deferred] bit is used for SEER functionality but is architectural.

#### 3.1.3.6 MCA Overflow Recovery

MCA Overflow Recovery is a feature allowing recovery of the system when the overflow bit is set. MCA Overflow Recovery is supported when Core::X86::Cpuid::RasCap[McaOverflowRecov] == 1.

When MCA Overflow Recovery is supported, software may rely on MCA\_STATUS[PCC] == 1 to indicate all system-fatal conditions. When MCA Overflow Recovery is not supported, an uncorrected error logged with MCA\_STATUS[Overflow] = 1 may indicate the system-fatal condition that an error requiring software intervention was not logged. Therefore, software must terminate system processing whenever an uncorrected error is logged with MCA\_STATUS[Overflow] = 1.

#### 3.1.3.7 MCA Recovery

MCA Recovery is a feature allowing recovery of the system when the hardware cannot correct an error. MCA Recovery is supported when Core::X86::Cpuid::RasCap[SUCCOR] == 1.

When MCA Recovery is supported and an uncorrected error has been detected that the hardware can contain to the task or process to which the machine check has been delivered, it logs a context-synchronous uncorrectable error (MCA\_STATUS[UC] = 1, MCA\_STATUS[PCC] = 0). The rest of the system is unaffected and may continue running if supervisory software can terminate only the affected process or VM.

#### 3.1.4 Machine Check Features

#### 3.1.4.1 Error Thresholding

For some types of errors, the hardware maintains counts of the number of errors. When the counter reaches a programmable threshold, an event may optionally be triggered to signal system software. This is known as error thresholding. The primary purpose of error thresholding is to help software recognize an excessive rate of errors, which may indicate marginal or failing hardware. This information can be used to make decisions about deconfiguring hardware or scheduling service actions. The error count is incremented for corrected, deferred, and uncorrected errors.

The MCA\_MISCx registers contain the architectural interface for error thresholding. The registers contain a 12-bit error counter that can be initialized to any value except FFFh, with the option to interrupt when the counter reaches FFFh.

MCA\_MISCx[ThresholdIntType] determines the type of interrupt to be generated for threshold overflow errors in that counter. This can be set to None, LVT, or SMI. If this is set to LVT, Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset] specifies the LVT offset that is used. Only one LVT offset is used per socket and the interrupt is routed to the APIC of the logical core from which the MCA bank is visible.

#### 3.1.4.2 Error Simulation

Error simulation involves creating the appearance to software that an error occurred, and can be used to debug machine check interrupt handlers. See Core::X86::Msr::HWCR[McStatusWrEn] for making MCA registers writable for non-zero values. When McStatusWrEn is set, privileged software can write non-zero values to the specified registers without generating exceptions, and then simulate a machine check using the INT18 instruction (INTn instruction with an operand of 18). Setting a reserved bit in these registers does not generate an exception when this mode is enabled. However, setting a reserved bit may result in undefined behavior.

#### 3.1.5 Software Guidelines

#### 3.1.5.1 Recognizing MCAX Support

Software which reads the MCA registers must recognize whether an implementation uses the legacy format or the MCAX format. This is accomplished by starting with CPUID Fn8000\_0007\_EBX[ScalableMca]. If ScalableMca == 1, then the implementation supports the MCAX indicator (MCA\_CONFIG[Mcax]). An MCA bank is an MCAX bank if MCA\_CONFIG[Mcax] == 1 in that bank.

#### 3.1.5.2 Communicating MCAX Support

Software which supports MCAX must set MCA\_CONFIG[McaxEn] = 1 in each MCA bank.

Software that supports MCAX should use the MCAX MSRs to access both legacy and MCAX registers.

#### 3.1.5.3 Machine Check Initialization

The following initialization sequence must be followed:

- Platform firmware must initialize the MCA\_CTL\_MASK registers prior to the initialization of the MCA\_CTL registers and Core::X86::Msr::MCG\_CTL. Platform firmware and the operating system must not clear MCA\_CTL\_MASK bits that are set to 1. MCA\_CTL\_MASK registers must be set the same across all cores.
- The operating system must initialize the MCA\_CONFIG registers prior to initialization of the MCA\_CTL registers.
- The MCA\_CTL registers must be initialized prior to enabling the error reporting banks in MCG\_CTL.
- The Core::X86::Msr::MCG\_CTL register must be programmed identically for all cores in a processor, although the Read-write bits may differ per core.
- CR4.MCE must be set to enable machine check exceptions.

The operating system should configure the MCA\_CONFIG registers as follows:

- MCA\_CONFIG[McaxEn] = 1 if the operating system has been updated to use the MCA Extension MSR addresses. Otherwise, the operating system should preserve the platform firmware-programmed value of this field.
- MCA\_CONFIG[LogDeferredInMcaStat] and MCA\_CONFIG[DeferredIntType] to appropriate values based on OS support for deferred errors.

MCA\_STATUS MSRs are cleared by hardware after a cold reset. If initializing after a warm reset, then platform firmware should check for valid MCA errors and if present save the status for later diagnostic use.

Platform firmware may initialize the MCA without setting CR4.MCE; this results in a shutdown on any machine check which would have caused a machine check exception (followed by a reboot if configured). Alternatively, platform firmware that wishes to ensure continued operation in the event that a machine check occurs during boot may write MCG\_CTL with all ones and write zeros into each MCA\_CTL register. With these settings, a machine check error results in MCA\_STATUS being written without generating a machine check exception or a shutdown. Platform firmware may then poll MCA\_STATUS registers during critical sections of boot to ensure system integrity. Note that the system may be operating with corrupt data before polling MCA\_STATUS registers. Before passing control to the operating system, platform firmware should restore the values of those registers to what the operating system is expecting.

After MCA initialization, system software should check the Val bit on each MCA\_STATUS register. It is possible that valid error status information has already been logged in the MCA\_STATUS registers at the time software is attempting to initialize them. The status can reflect errors logged prior to a warm reset or errors recorded during the system power-up and boot process. Before clearing the MCA\_STATUS registers, software should examine their contents and log any errors

found.

#### 3.1.5.4 Determining Bank Count

System software should Read Core::X86::Msr::MCG\_CAP[Count] to determine the number of machine check banks visible to a logical core. The banks are numbered from 0 to one less than the value found in Core::X86::Msr::MCG\_CAP[Count]. For example, if the Count field indicates five banks are supported, they are numbered MC0 through MC4.

#### 3.1.5.5 Determining Bank Type

To determine which type of block is mapped to an MCA bank, software can query the MCA\_IPID register within that bank. This register exists when MCA\_CONFIG[McaX] == 1 in a given bank.

MCA\_IPID[HardwareID] provides the block type for the block that contains this MCA bank. For blocks that contain multiple MCA bank types (e.g., CPU cores), MCA\_IPID[McaType] provides an identifier for the type of MCA bank. MCA\_IPID[McaType] values are specific to a given MCA\_IPID[HardwareID]. Therefore, an MCA bank type can be identified by the value of {MCA\_IPID[Hwid], MCA\_IPID[McaType]}. For instance, the CPU core's LS bank is identified by MCA::LS::MCA\_IPID\_LS[McaType] == 0. An MCA\_IPID[HardwareID] value of 0 indicates an unpopulated MCA bank that is ensured to be RAZ/WRIG.

MCA\_IPID[InstanceId] provides a unique instance number to allow software to differentiate blocks with multiple identical instances within a processor. MCA\_IPID[InstanceId] values are processor-specific and are not ensured to be stable across different processor generations.

#### 3.1.5.6 Recognizing Error Type

Software can use the combination of MCA\_IPID[HwId, McaType] and MCA\_STATUS[ErrorCodeExt] to recognize a specific error type.

#### 3.1.5.7 Machine Check Error Handling

A machine check handler is invoked to handle an exception for a particular thread. The information needed by the machine check handler is not shared with other threads, so no cross-thread coordination or special handling is required. Specifically, all MCA banks are only visible from a single thread, so software on a single thread can access each bank through MSR space without contention from other threads.

At a minimum, the machine check handler must be capable of logging error information for later examination. The handler should log as much information as is needed to diagnose the error. More thorough exception handler implementations can analyze errors to determine if each error is recoverable by software. If a recoverable error is identified, the exception handler can attempt to correct the error and restart the interrupted program. An error may not be recoverable for the process or virtual machine it directly affects, but may be containable, so that other processes or virtual machines in the system are unaffected and system operation is recovered.

Machine check exception handlers that attempt to recover must be thorough in their analysis and the corrective actions they take. The following guidelines should be used when writing such a handler:

- Data collection:
  - Read Core::X86::Msr::MCG\_CAP[Count] to determine the number of status registers visible to the logical core.
  - All status registers in all error reporting banks must be examined to identify the cause of the machine check exception.

- Check the valid bit in each status register (MCA\_STATUS[Val]). The remainder of the status register should be examined only when its valid bit is set.
- When identifying the error condition and determining how to handle the error, portable exception handlers should examine only DOER fields in machine check registers.
- Error handlers should collect all available MCA information, but should only interrogate details to the level which affects their actions. Lower level details may be useful for diagnosis and root cause analysis, but not for error handling.
- Error handlers should save the values in MCA\_ADDR, MCA\_MISC0, and MCA\_SYND even if MCA\_STATUS[AddrV], MCA\_STATUS[MiscV], and MCA\_STATUS[SyndV] are zero. Error handlers should save the values in MCA\_MISC[4:1] if the registers exist.
- DOER Error Management:
  - Check MCA STATUS[PCC].
    - If PCC is set, error recovery is not possible. The handler should log the error information and terminate the system. If PCC is clear, the handler may continue with the following recovery steps.
  - Check MCA STATUS[UC].
    - If UC is set, the processor did not correct the error. Continue with the following recovery steps.
      - If MCA Overflow Recovery is not supported, and MCA\_STATUS[Overflow] == 1, error recovery is not possible; follow the steps for PCC = 1. See 3.1.3.6 [MCA Overflow Recovery].
      - If MCA Recovery is not supported, error recovery is not possible; follow the steps for PCC = 1. See 3.1.3.7 [MCA Recovery].
      - If MCA Recovery is supported:
        - Check MCA\_STATUS[TCC].
          - If TCC is set, the context of the process thread executing on the interrupted logical core may be corrupt and the thread cannot be recovered. The rest of the system is unaffected; it is possible to terminate only the affected process thread.
          - If TCC is clear, the context of the process thread executing on the
            interrupted logical core is not corrupt. Recovery of the process thread
            may be possible, but only if the uncorrected error condition is first
            corrected by software; otherwise, the interrupted process thread must be
            terminated.
          - Legacy exception handlers can check
             Core::X86::Msr::MCG\_STAT[RIPV] and
             Core::X86::Msr::MCG\_STAT[EIPV] in place of MCA\_STATUS[TCC].
             If RIPV == EIPV == 1, the interrupted program can be restarted reliably.
             Otherwise, the program cannot be restarted reliably.
    - If UC is clear, the processor either corrected or deferred the error and no software action is needed. The handler can log the error information and continue process execution.
- Exit:
  - When an exception handler is able to successfully log an error condition, clear the MCA\_STATUS
    registers prior to exiting the machine check handler.
  - Prior to exiting the machine check handler, clear Core::X86::Msr::MCG\_STAT[MCIP]. MCIP indicates that a machine check exception is in progress. If this bit is set when another machine check exception occurs, the processor enters the shutdown state.

#### 3.2 Machine Check Architecture Implementation

#### 3.2.1 Implemented Machine Check Banks

Table 29: Blocks Capable of Supporting MCA Banks

Acronym	Block Function
LS	Load-Store Unit
IF	Instruction Fetch Unit
L2	L2 Cache Unit
DE	Decode Unit
EX	Execution Unit
FP	Floating Point Unit
L3	L3 Cache Unit
PIE	Power Management, Interrupts, Etc.
CS	Coherent Slave
UMC	Unified Memory Controller

*Table 30: Mapping of Blocks to MCA\_IPID[HwId] and MCA\_IPID[McaType]* 

Block	Hardware ID	MCA Type
LS	0xB0	0x0
IF	0xB0	0x1
L2	0xB0	0x2
UMC	0x96	0x0
L3	0xB0	0x7
PIE	0x2E	0x1
CS	0x2E	0x2
EX	0xB0	0x5
FP	0xB0	0x6
DE	0xB0	0x3

#### 3.2.2 Implemented Machine Check Bank Registers

Table 31 [Legacy MCA Registers] provides links to the description of each block's Legacy MCA registers. Table 32 [MCAX Registers] provides links to the description of each block's MCA Extension Registers.

Table 31: Legacy MCA Registers

Block	MCA Register					
	CTL	STATUS	ADDR	MISC	CTL_MASK	
LS	MCA::LS::MCA_CTL_LS	MCA::LS::MCA_STATUS_	MCA::LS::MCA_ADDR_L	MCA::LS::MCA_MISC0_L	MCA::LS::MCA_CTL_MA	
		LS	S	S	SK_LS	
IF	MCA::IF::MCA_CTL_IF	MCA::IF::MCA_STATUS_I	MCA::IF::MCA_ADDR_IF	MCA::IF::MCA_MISC0_IF	MCA::IF::MCA_CTL_MAS	
		F			K_IF	
L2	MCA::L2::MCA_CTL_L2	MCA::L2::MCA_STATUS_	MCA::L2::MCA_ADDR_L	MCA::L2::MCA_MISC0_L	MCA::L2::MCA_CTL_MA	
		L2	2	2	SK_L2	
DE	MCA::DE::MCA_CTL_DE	MCA::DE::MCA_STATUS_	MCA::DE::MCA_ADDR_D	MCA::DE::MCA_MISC0_D	MCA::DE::MCA_CTL_MA	
		DE	E	E	SK_DE	
EX	MCA::EX::MCA_CTL_EX	MCA::EX::MCA_STATUS_	MCA::EX::MCA_ADDR_E	MCA::EX::MCA_MISC0_E	MCA::EX::MCA_CTL_MA	
		EX	X	X	SK_EX	
FP	MCA::FP::MCA_CTL_FP	MCA::FP::MCA_STATUS_F	MCA::FP::MCA_ADDR_F	MCA::FP::MCA_MISC0_F	MCA::FP::MCA_CTL_MA	
		P	P	P	SK_FP	
L3	MCA::L3::MCA_CTL_L3	MCA::L3::MCA_STATUS_	MCA::L3::MCA_ADDR_L	MCA::L3::MCA_MISC0_L	MCA::L3::MCA_CTL_MA	
		L3	3	3	SK_L3	
PIE	MCA::PIE::MCA_CTL_PIE	MCA::PIE::MCA_STATUS_	MCA::PIE::MCA_ADDR_P	MCA::PIE::MCA_MISC0_P	MCA::PIE::MCA_CTL_MA	
		PIE	IE	IE	SK_PIE	
CS	MCA::CS::MCA_CTL_CS	MCA::CS::MCA_STATUS_	MCA::CS::MCA_ADDR_C	MCA::CS::MCA_MISC0_C	MCA::CS::MCA_CTL_MA	
		CS	S	S	SK_CS	
UMC	MCA::UMC::MCA_CTL_U	MCA::UMC::MCA_STATU	MCA::UMC::MCA_ADDR	MCA::UMC::MCA_MISC0	MCA::UMC::MCA_CTL_M	

		MCA::UMC::MCA_MISC1	
		_UMC	

Table 32: MCAX Registers

Block	MCA Register					
	CONFIG	IPID	SYND	DESTAT	DEADDR	
LS	MCA::LS::MCA_CONFIG	MCA::LS::MCA_IPID_LS	MCA::LS::MCA_SYND_L	MCA::LS::MCA_DESTAT_	MCA::LS::MCA_DEADDR	
	LS		S	LS	_LS	
IF	MCA::IF::MCA_CONFIG_ IF	MCA::IF::MCA_IPID_IF	MCA::IF::MCA_SYND_IF			
L2	MCA::L2::MCA_CONFIG	MCA::L2::MCA_IPID_L2	MCA::L2::MCA_SYND_L2	MCA::L2::MCA_DESTAT_	MCA::L2::MCA_DEADDR	
	_L2			L2	_L2	
DE	MCA::DE::MCA_CONFIG	MCA::DE::MCA_IPID_DE	MCA::DE::MCA_SYND_D			
	_DE		E			
EX	_	MCA::EX::MCA_IPID_EX	MCA::EX::MCA_SYND_E		<del> </del>	
	_EX		X			
FP	MCA::FP::MCA_CONFIG_FP	MCA::FP::MCA_IPID_FP	MCA::FP::MCA_SYND_FP			
L3	MCA::L3::MCA_CONFIG	MCA::L3::MCA_IPID_L3	MCA::L3::MCA_SYND_L3	MCA::L3::MCA_DESTAT_	MCA::L3::MCA_DEADDR	
_	_L3			L3	_L3	
PIE	MCA::PIE::MCA_CONFI	MCA::PIE::MCA_IPID_PIE	MCA::PIE::MCA_SYND_P	MCA::PIE::MCA_DESTAT	MCA::PIE::MCA_DEADD	
	G_PIE		IE	_PIE	R_PIE	
CS	_	MCA::CS::MCA_IPID_CS	MCA::CS::MCA_SYND_C	MCA::CS::MCA_DESTAT_	MCA::CS::MCA_DEADDR	
	_CS		S	CS	_CS	
UMC	_			MCA::UMC::MCA_DESTA		
	IG_UMC	MC	UMC	T_UMC	DR_UMC	

#### 3.2.3 Mapping of Banks to Blocks

Table 33 [Core MCA Bank to Block Mapping] shows MCA banks that are present in the address space of every logical core:

Table 33: Core MCA Bank to Block Mapping

Bank	Block
0	LS
1	IF
2	L2
3	DE
4	RAZ
5	EX
6	FP

Table 34 [Non-core MCA Bank to Block Mapping] shows MCA banks that are present in the address space of specific logical cores:

Table 34: Non-core MCA Bank to Block Mapping

Bank	Thread <b>0</b>
7	L3
8	L3
9	L3
10	L3
11	L3

12	L3
13	L3
14	L3
15	RAZ
16	RAZ
17	UMC
18	UMC
19	CS
20	CS
21	RAZ
22	RAZ
23	RAZ
24	RAZ
25	RAZ
26	RAZ
27	PIE

#### 3.2.4 Decoding Error Type

If a valid error is logged in MCA\_STATUS or MCA\_DESTAT of an MCA bank:

- 1. Read the values of this bank's MCA\_IPID and MCA\_STATUS registers.
- 2. Use Table 30 [Mapping of Blocks to MCA\_IPID[HwId] and MCA\_IPID[McaType]] to look up the block associated with the values of MCA\_IPID[HwId] and MCA\_IPID[McaType].
- 3. In 3.2.5 [MCA Banks], find the sub-section associated with the block in error.
- 4. In this sub-section, find the MCA\_STATUS table.
- 5. In the table, look up the row associated with the MCA\_STATUS[ErrorCodeExt] value.
- 6. The error type in this row is the logged error. The MCA\_STATUS, MCA\_ADDR and MCA\_SYND tables contain information associated with this error.
- 7. If there is an error in both MCA\_STATUS and MCA\_DESTAT, the registers contain the same error if MCA\_STATUS[Deferred] is set. If MCA\_STATUS[Deferred] is not set, MCA\_DESTAT contains information for a different error than MCA\_STATUS. MCA\_DESTAT does not contain an ErrorCodeExt field, so in this case it is not possible to determine the type of error logged in MCA\_DESTAT.

#### 3.2.5 MCA Banks

#### 3.2.5.1 LS

MSR0000_0400MSRC000_2000 [LS Machine Check Control] (MCA::LS::MCA_CTL_LS)			
Read-write. Reset: 0000_0000_0000_0000h.			
0=Disables error reporting for the corresponding error. 1=Enables error reporting via machine check exception for the			
corresponding error. The MCA::LS::MCA_CTL_LS register must be enabled by the corresponding enable bit in			
Core::X86::Msr::MCG_CTL. Does not affect error detection, correction, or logging.			
_lthree[1:0]_core[3:0]_inst0_aliasMSRLEGACY; MSR0000_0400			
_lthree[1:0]_core[3:0]_inst0_aliasMSR; MSRC000_2000			
Bits Description			
63:21 Reserved.			
20 <b>L2DataErr</b> . Read-write. Reset: 0. L2 Fill Data error.			

19	<b>DcTagErr7</b> . Read-write. Reset: 0. DC Tag error type 5.
18	<b>DcTagErr3</b> . Read-write. Reset: 0. DC Tag error type 3.
17	PDC. Read-write. Reset: 0. PDC parity error. MCA_ADDR_LS logs a virtual address.
16	<b>L2DTLB</b> . Read-write. Reset: 0. Level 2 TLB parity error. MCA_ADDR_LS logs a virtual address.
15	<b>DcTagErr4</b> . Read-write. Reset: 0. DC Tag error type 4.
14	<b>DcDataErr3</b> . Read-write. Reset: 0. DC Data error type 3.
13	<b>DcDataErr2</b> . Read-write. Reset: 0. DC Data error type 2.
12	<b>DcDataErr1</b> . Read-write. Reset: 0. DC Data error type 1 and poison consumption. MCA_STATUS[Poison] is set on poison consumption from L2/L3.
11	<b>DcTagErr2</b> . Read-write. Reset: 0. DC Tag error type 2.
10	<b>SystemReadDataErrorT1</b> . Read-write. Reset: 0. System Read Data Error Thread 1. An error in a Read of a line
	from the data fabric. Possible reasons include master abort and target abort.
9	<b>SystemReadDataErrorT0</b> . Read-write. Reset: 0. System Read Data Error Thread 0. An error in a Read of a line
	from the data fabric. Possible reasons include master abort and target abort.
8	IntErrTyp2. Read-write. Reset: 0. Internal error type 2.
7	IntErrTyp1. Read-write. Reset: 0. Internal error type 1.
6	<b>DcTagErr1</b> . Read-write. Reset: 0. DC Tag error type 1.
5	<b>DcTagErr6</b> . Read-write. Reset: 0. DC Tag error type 6.
4	<b>DcTagErr5</b> . Read-write. Reset: 0. DC Tag error type 5.
3	<b>L1DTLB</b> . Read-write. Reset: 0. Level 1 TLB parity error.
2	MAB. Read-write. Reset: 0. Miss address buffer payload parity error.
1	STQ. Read-write. Reset: 0. Store queue parity error.
0	<b>LDQ</b> . Read-write. Reset: 0. Load queue parity error.

### MSR0000\_0001...MSRC000\_2001 [LS Machine Check Status Thread 0] (MCA::LS::MCA\_STATUS\_LS)

Reset:	Cold,0000_0000_0000_0000h.		
Logs i	Logs information associated with errors.		
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]_inst0_aliasMSRLSLEGACY; MSR0000_0001		
	1:0]_core[3:0]_thread[1:0]_inst0_aliasMSRLEGACY; MSR0000_0401		
	1:0]_core[3:0]_thread[1:0]_inst0_aliasMSR; MSRC000_2001		
Bits	Description		
63	<b>Val</b> . Reset: Cold,0. 1=A valid error has been detected. This bit should be cleared by software after the register has		
	been Read.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.		
62	<b>Overflow</b> . Reset: Cold,0. 1=An error was detected while the valid bit (Val) was set; at least one error was not		
	logged. Overflow is set independently of whether the existing error is overwritten. See 3.1.3 [Machine Check		
	Errors].		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.		
61	UC. Reset: Cold,0. 1=The error was not corrected by hardware.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.		
60	<b>En</b> . Reset: Cold,0. 1=MCA error reporting is enabled for this error, as indicated by the corresponding bit in		
	MCA::LS::MCA_CTL_LS. This bit is a copy of the bit in MCA::LS::MCA_CTL_LS for this error.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.		
59	<b>MiscV</b> . Reset: Cold,0. 1=Valid thresholding in MCA::LS::MCA_MISCO_LS. In certain modes, MISC registers		
	are owned by platform firmware and will RAZ when Read by non-SMM code. Therefore, it is possible for MiscV		
	== 1 and the MISC register to Read as all zeros.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.		
58	<b>AddrV</b> . Reset: Cold,0. 1=MCA::LS::MCA_ADDR_LS contains address information associated with the error.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.		
57	<b>PCC</b> . Reset: Cold,0. 1=Hardware context held by the processor may have been corrupted. Continued operation of		

	the system may have unpredictable results. The error is not recoverable or survivable, and the system should be reinitialized.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
56	ErrCoreIdVal. Reset: Cold,0. 1=The ErrCoreId field is valid.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
55	TCC. Reset: Cold,0. 1=Hardware context of the process thread to which the error was reported may have been
	corrupted. Continued operation of the thread may have unpredictable results. The thread must be terminated. Only
	meaningful when MCA::LS::MCA_STATUS_LS[PCC] == 0.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
54	RESERV4. Reset: Cold,0. MCA_STATUS Register Reserved bit.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
53	<b>SyndV</b> . Reset: Cold,0. 1=This error logged information in MCA::LS::MCA_SYND_LS. If
	MCA::LS::MCA_SYND_LS[ErrorPriority] is the same as the priority of the error in
	MCA::LS::MCA_STATUS_LS, then the information in MCA::LS::MCA_SYND_LS is associated with the error
	in MCA::LS::MCA_STATUS_LS.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
52	Reserved.
51:47	RESERV3. Reset: Cold,00h. MCA_STATUS Register Reserved bits.
10	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
46	<b>CECC.</b> Reset: Cold,0. 1=The error was a correctable ECC error according to the restrictions of the ECC
	algorithm. UC indicates whether the error was actually corrected by the processor.
45	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
45	<b>UECC</b> . Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC
	algorithm. UC indicates whether the error was actually corrected by the processor.
44	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1. <b>Deferred</b> . Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data
44	error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is
	consumed.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
43	<b>Poison</b> . Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
42:41	<b>RESERV2</b> . Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
40	<b>Scrub</b> . Reset: Cold,0. 1=The error was the result of a scrub operation.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
39:38	RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
37:32	<b>ErrCoreId</b> . Reset: Cold,00h. When (ErrCoreIdVal == 1), this field indicates which core within the processor is
	associated with the error. Otherwise, this field is Reserved.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
31:22	RESERVO. Reset: Cold,000h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
21:16	<b>ErrorCodeExt</b> . Reset: Cold,00h. Extended Error Code. This field is used to identify the error type for root cause
	analysis. This field indicates which bit position in MCA::LS::MCA_CTL_LS enables error reporting for the
	logged error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
15:0	<b>ErrorCode</b> . Reset: Cold,0000h. Error code for this error. See 3.1.3.3 [Error Codes] for details on decoding this
	field.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.

Table 35: MCA\_STATUS\_LS

Error Type	ErrorCode	UC	PCC	TCC	Deferred	Poison	AddrV
	Ext						
LDQ	0x0	1	1	1	0	0	0
STQ	0x1	1	1	1	0	0	0
MAB	0x2	1	1	1	0	0	0
L1DTLB	0x3	1	1	1	0	0	1
DcTagErr5	0x4	1	1	1	0	0	0
DcTagErr6	0x5	1	1	1	0	0	0
DcTagErr1	0x6	1	1	1	0	0	0
IntErrTyp1	0x7	1	1	1	0	0	0
IntErrTyp2	0x8	0/1	0/1	0/1	0	0	0
SystemRead	0x9	1	1	1	0	0	0/1
DataErrorT0							
SystemRead	0xA	1	1	1	0	0	0/1
DataErrorT1							
DcTagErr2	0xB	0	0	0	0	0	0
DcDataErr1	0xC	0/1	0	0/1	0	0/1	1
DcDataErr2	0xD	0	0	0	0/1	0	1
DcDataErr3	0xE	0	0	0	0/1	0	0/1
DcTagErr4	0xF	0	0	0	1	0	0
L2DTLB	0x10	0	0	0	0	0	0/1
PDC	0x11	0	0	0	0	0	0/1
DcTagErr3	0x12	0	0	0	0	0	0
DcTagErr7	0x13	0	0	0	0	0	0
L2DataErr	0x14					0	0

MSR0000_0000MSRC000_2002 [LS Machine Check Address Thread 0] (MCA::LS::MCA_ADDR_LS)			
Reset: Cold,0000_0000_0000_0000h.			
MCA::LS::MCA_ADDR_LS stores an address and other information associated with the error in			
MCA::LS::MCA_STATUS_LS. The register is only meaningful if MCA::LS::MCA_STATUS_LS[Val] == 1 and			
$MCA::LS::MCA\_STATUS\_LS[AddrV] == 1.$			
_lthree[1:0]_core[3:0]_thread[1:0]_inst0_aliasMSRLSLEGACY; MSR0000_0000			
_lthree[1:0]_core[3:0]_thread[1:0]_inst0_aliasMSRLEGACY; MSR0000_0402			
_lthree[1:0]_core[3:0]_thread[1:0]_inst0_aliasMSR; MSRC000_2002			
Bits Description			
63:62 Reserved.			
61:56 <b>LSB</b> . Read-write, Volatile. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in			
MCA::LS::MCA_ADDR_LS[ErrorAddr]. For example, a value of 0 indicates that			
MCA::LS::MCA_ADDR_LS[55:0] contains a valid byte address. A value of 6 indicates that			
MCA::LS::MCA_ADDR_LS[55:6] contains a valid cache line address and that			
MCA::LS::MCA_ADDR_LS[5:0] are not part of the address and should be ignored by error handling software. A			
value of 12 indicates that MCA::LS::MCA_ADDR_LS[55:12] contains a valid 4-KB memory page and that			
MCA::LS::MCA_ADDR_LS[11:0] should be ignored by error handling software.			

Table 36: MCA\_ADDR\_LS

55:0

Error Type	Bits	Description

**ErrorAddr**. Read-write, Volatile. Reset: Cold,00\_0000\_0000\_0000h. Unless otherwise specified by an error,

the most significant bit is given by Core::X86::Cpuid::LongModeInfo[PhysAddrSize].

contains the address associated with the error logged in MCA::LS::MCA\_STATUS\_LS. For physical addresses,

LDQ	[55:0]	Reserved.
STQ	[55:0]	Reserved.
MAB	[55:0]	Reserved.
L1DTLB	[55:48]	Reserved.
	[47:12]	Virtual Address.
	[11:0]	Reserved.
DcTagErr5	[55:0]	Reserved.
DcTagErr6	[55:0]	Reserved.
DcTagErr1	[55:0]	Reserved.
IntErrTyp1	[55:0]	Reserved.
IntErrTyp2	[55:0]	Reserved.
SystemReadDataErrorT0	[55:48]	Reserved.
	[47:6]	Physical Address.
SystemReadDataErrorT1	[55:48]	Reserved.
	[47:6]	Physical Address.
DcTagErr2	[55:0]	Reserved.
DcDataErr1	[55:48]	Reserved.
	[47:6]	Physical Address.
	[5:1]	MCA_STATUS_LS[Poison]=1 ? 5'b0 : Physical Address
DcDataErr2	[55:48]	Reserved.
	[47:1]	Physical Address.
DcDataErr3	[55:48]	Reserved.
	[47:1]	Physical Address.
DcTagErr4	[55:0]	Reserved.
L2DTLB	[55:48]	Reserved.
	[47:12]	Virtual Address.
	[11:0]	Reserved.
PDC	[55:48]	Reserved.
	[47:12]	Virtual Address.
	[11:0]	Reserved.
DcTagErr3	[55:0]	Reserved.
DcTagErr7	[55:0]	Reserved.
L2DataErr	[55:0]	Reserved.

# MSR0000\_0403...MSRC000\_2003 [LS Machine Check Miscellaneous 0 Thread 0] (MCA::LS::MCA\_MISC0\_LS)

Log miscellaneous information associated with errors.			
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]_inst0_aliasMSRLEGACY; MSR0000_0403		
_lthree[1	1:0]_core[3:0]_thread[1:0]_inst0_aliasMSR; MSRC000_2003		
Bits	Description		
63	<b>Valid</b> . Reset: 1. 1=A valid CntP field is present in this register.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.		
62	<b>CntP</b> . Reset: 1. 1=A valid threshold counter is present.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.		
61	<b>Locked</b> . Reset: 0. 1=Writes to this register are ignored. This bit is set by BIOS to indicate that this register is not		
	available for OS use. BIOS should set this bit if ThresholdIntType is set to SMI.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.		
60	IntP. Reset: 1. 1=ThresholdIntType can be used to generate interrupts. 0=ThresholdIntType and interrupt		
	generation are not supported.		
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::LS::MCA_MISC0_LS[Locked]) ? Read-write :		

	Read-only.
59:56	Reserved.
55:52	<b>LvtOffset</b> . Reset: 0h. One per die. For error thresholding interrupts, specifies the address of the LVT entry in the APIC registers as follows: LVT address = (LvtOffset shifted left 4 bits) + 500h (see Core::X86::Apic::ExtendedInterruptLvtEntries).
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::LS::MCA_MISC0_LS[Locked]) ? Read-write : Read-only.
51	CntEn. Reset: 0. 1=Count thresholding errors.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::LS::MCA_MISCO_LS[Locked]) ? Read-write : Read-only.
50:49	<b>ThresholdIntType</b> . Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1.
	00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::LS::MCA_MISC0_LS[Locked]) ? Read-write : Read-only.
48	<b>Ovrflw</b> . Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is generated.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::LS::MCA_MISCO_LS[Locked]) ? Read-write : Read-only.
47:44	Reserved.
43:32	<b>ErrCnt</b> . Reset: Cold,000h. This is Written by software to set the starting value of the error counter. This is
	incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The
	threshold value, Written by software, is (FFFh - the desired error count (the number of errors necessary in order
	for an interrupt to be taken)); the desired error count of 0 (a Write value of FFFh) is not supported.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::LS::MCA_MISC0_LS[Locked]) ? Read-write :
	Read-only.
	<b>BlkPtr</b> . Read-write. Reset: 00h. 00h=Extended MISC MSR block is not valid. 01h=Extended MSR block is valid.
23:0	Reserved.

# MSRC000\_2004 [LS Machine Check Configuration] (MCA::LS::MCA\_CONFIG\_LS)

1110111	2000_2001 [25 Machine Check Comigaration] (McMachine Check Comigaration)		
Reset:	0000_0002_0000_0025h.		
Contro	Controls configuration of the associated machine check bank.		
_lthree[1	:0]_core[3:0]_inst0_aliasMSR; MSRC000_2004		
Bits	Description		
63:39	Reserved.		
38:37	<b>DeferredIntType</b> . Read-write. Reset: 0h. Specifies the type of interrupt signaled when a deferred error is logged. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[DeferredLvtOffset]). 10b=SMI trigger event. 11b=Reserved.		
36:35	Reserved.		
34	LogDeferredInMcaStat. Read-write. Reset: 0. Init: BIOS,1. 1=Log deferred errors in MCA::LS::MCA_STATUS_LS and MCA::LS::MCA_ADDR_LS in addition to MCA::LS::MCA_DESTAT_LS and MCA::LS::MCA_DEADDR_LS. 0=Only log deferred errors in MCA::LS::MCA_DESTAT_LS and MCA::LS::MCA_DEADDR_LS. This bit does not affect logging of deferred errors in MCA::LS::MCA_SYND_LS, MCA::LS::MCA_MISCO_LS.		
33	Reserved.		
32	<b>McaXEnable</b> . Read-write. Reset: 0. Init: BIOS,1. Check: 1. 1=Software has acknowledged support for the MCAX feature set. 0=Software has not acknowledged support for the MCAX feature set. All uncorrected and fatal errors will cause an ErrorEvent packet to be generated. Deferred error interrupts are configured via Core::X86::Msr::McaIntrCfg.		
31:6	Reserved.		

5	<b>DeferredIntTypeSupported</b> . Read-only. Reset: 1. 1=MCA::LS::MCA_CONFIG_LS[DeferredIntType] controls
	the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if
	MCA::LS::MCA_CONFIG_LS[DeferredErrorLoggingSupported] == 1.
4:3	Reserved.
2	<b>DeferredErrorLoggingSupported</b> . Read-only. Reset: 1. 1=Deferred errors are supported in this MCA bank, and
	MCA::LS::MCA_CONFIG_LS[LogDeferredInMcaStat] controls the logging behavior of these errors.
	MCA::LS::MCA_DESTAT_LS and MCA::LS::MCA_DEADDR_LS are supported in this MCA bank.
	0=Deferred errors are not supported in this bank.
1	Reserved.
0	<b>McaX</b> . Read-only. Reset: 1. 1=This bank provides Machine Check Architecture Extensions. Up to 4 additional
	MISC registers (MISC1-MISC4) are supported. MCA::LS::MCA_MISC0_LS[BlkPtr] indicates the presence of
	the additional MISC registers, but is not used to determine their MSR numbers. Deferred error interrupt type is
	specifiable by MCA bank, MCA::LS::MCA STATUS LS[TCC] is present.

#### MSRC000\_2005 [LS IP Identification] (MCA::LS::MCA\_IPID\_LS)

MSKC000_2005 [ES IF Identification] (MCAESMCA_IFID_ES)		
Reset: 0000_00B0_0000_0000h.		
The MCA::LS::MCA_IPID_LS register is used by software to determine what IP type and revision is associated with the		
MCA bank.		
_lthree[1:0]_core[3:0]_inst0_aliasMSR; MSRC000_2005		
Bits Description		
63:48 <b>McaType</b> . Read-only. Reset: 0000h. The McaType of the MCA bank within this IP.		
47:44 Reserved.		
43:32 <b>HardwareID</b> . Read-only. Reset: 0B0h. The Hardware ID of the IP associated with this MCA bank.		
31:0 <b>InstanceId</b> . Read-write. Reset: 0000_0000h. The instance ID of this IP. This is initialized to a unique ID per		
instance of this register.		

# MSRC000\_2006 [LS Machine Check Syndrome Thread 0] (MCA::LS::MCA\_SYND\_LS)

Read-write, Volatile. Reset: Cold, 0000_0000_0000h.		
Logs physical location information associated with the error in MCA::LS::MCA_STATUS_LS Thread 0.		
_lthree[1	:0]_core[3:0]_thread[1:0]_inst0_aliasMSR; MSRC000_2006	
Bits	Description	
63:38	Reserved.	
37:32	<b>Syndrome</b> . Read-write, Volatile. Reset: Cold, 00h. Contains the syndrome, if any, associated with the error logged	
	in MCA::LS::MCA_STATUS_LS. The low-order bit of the syndrome is stored in bit[0], and the syndrome has a	
	length specified by MCA::LS::MCA_SYND_LS[Length]. The Syndrome field is only valid when	
	MCA::LS::MCA_SYND_LS[Length] != 0.	
31:27	Reserved.	
26:24	<b>ErrorPriority</b> . Read-write, Volatile. Reset: Cold, 0h. Encodes the priority of the error logged in	
	MCA::LS::MCA_SYND_LS. 000b=No error. 001b=Reserved. 010b=Corrected Error. 011b=Deferred Error.	
	100b=Uncorrected Error. 101b=Fatal Error. 111b-110b=Reserved.	
23:18	<b>Length.</b> Read-write, Volatile. Reset: Cold, 00h. Specifies the length in bits of the syndrome contained in	
	MCA::LS::MCA_SYND_LS[Syndrome]. A value of 0 indicates that there is no valid syndrome in	
	MCA::LS::MCA_SYND_LS. For example, a syndrome length of 9 means that	
	MCA::LS::MCA_SYND_LS[Syndrome] bits[8:0] contains a valid syndrome.	
17:0	<b>ErrorInformation</b> . Read-write, Volatile. Reset: Cold, 0_0000h. Contains error-specific information about the	
	location of the error. Decoding is available in Table 37 [MCA_SYND_LS].	

#### Table 37: MCA\_SYND\_LS

Error Type	Bits	Description
LDQ	[17:0]	Reserved.
STQ	[17:0]	Reserved.

MAB	[17:0]	Reserved.
L1DTLB	[17:0]	Reserved.
DcTagErr5	[17:16]	2'b11
	[15:8]	Index.
	[7:0]	Way.
DcTagErr6	[17:16]	2'b11
	[15:8]	Index.
	[7:0]	Way.
DcTagErr1	[17:16]	2'b11
	[15:8]	Index.
	[7:0]	Way.
IntErrTyp1	[17:11]	Reserved.
	[10]	Thread ID
	[9:0]	Reserved.
IntErrTyp2	[17:12]	Reserved.
	[11]	Thread ID
	[10:1]	Reserved.
	[0]	Reserved.
SystemReadDataErrorT0	[17:2]	Reserved.
	[1:0]	2'b00 = Master Abort; 2'b01 = Target Abort; 2'b10 = Transaction
		Error; 2'b11 = Protection Violation
SystemReadDataErrorT1	[17:2]	Reserved.
	[1:0]	2'b00 = Master Abort; 2'b01 = Target Abort; 2'b10 = Transaction
		Error; 2'b11 = Protection Violation
DcTagErr2	[17:16]	2'b11
	[15:8]	Index.
	[7:0]	Way.
DcDataErr1	[17:16]	MCA_STATUS_LS[Poison]=1 ? 2'b00 : 2'b11
	[15:8]	Index.
	[7:0]	Way.
DcDataErr2	[17:16]	2'b11
	[15:8]	Index.
	[7:0]	Way.
DcDataErr3	[17:16]	2'b11
	[15:14]	Reserved.
	[13:8]	Index.
	[7:3]	Physical Address[5:1]
	[2:0]	Way.
DcTagErr4	[17:16]	Reserved.
	[15:8]	Index.
	[7:0]	Way.
L2DTLB	[17:16]	2'b11
	[15]	Reserved.
	[14:8]	Reserved.
	[7:4]	Reserved.
	[3:0]	Reserved.
PDC	[17:0]	Reserved.

43:0 Reserved.

Reset: Cold,0000\_0000\_0000\_0000h.

DcTagErr3	[17:16]	2'b11
	[15:8]	Index.
	[7:0]	Way.
DcTagErr7	[17:16]	2'b11
	[15:8]	Index.
	[7:0]	Way.
L2DataErr	[17:0]	Reserved.

MSR	C000_2008 [LS Machine Check Deferred Error Status Thread 0] (MCA::LS::MCA_DESTAT_LS)		
Read-	write, Volatile. Reset: Cold, 0000_0000_0000h.		
Holds	Holds status information for the first deferred error seen in this bank.		
_lthree[1	:0]_core[3:0]_thread[1:0]_inst0_aliasMSR; MSRC000_2008		
Bits	Description		
63	<b>Val</b> . Read-write, Volatile. Reset: Cold, 0. 1=A valid error has been detected (whether it is enabled or not).		
62	<b>Overflow</b> . Read-write, Volatile. Reset: Cold, 0. 1=An error was detected while the valid bit (Val) was set; at least		
	one error was not logged. Overflow is set independently of whether the existing error is overwritten. (See the		
	section on overwrite priorities.)		
61:59	Reserved.		
58	<b>AddrV</b> . Read-write, Volatile. Reset: Cold, 0. 1=MCA::LS::MCA_DEADDR_LS contains address information		
	associated with the error.		
57:54	Reserved.		
53	<b>SyndV</b> . Read-write, Volatile. Reset: Cold, 0. 1=This error logged information in MCA::LS::MCA_SYND_LS. If		
	MCA::LS::MCA_SYND_LS[ErrorPriority] is the same as the priority of the error in		
	MCA::LS::MCA_STATUS_LS, then the information in MCA::LS::MCA_SYND_LS is associated with the error		
	in MCA::LS::MCA_DESTAT_LS.		
52:45	Reserved.		
44	<b>Deferred</b> . Read-write, Volatile. Reset: Cold, 0. 1=A deferred error was created. A deferred error is the result of an		
	uncorrectable data error which did not immediately cause a processor exception; poison is created and an		
	exception is deferred until the poison data is consumed.		

#### MSRC000\_2009 [LS Deferred Error Address Thread 0] (MCA::LS::MCA\_DEADDR\_LS)

The MCA::LS::MCA\_DEADDR\_LS register stores the address associated with the error in

	:LS::MCA_DESTAT_LS. The register is only meaningful if MCA::LS::MCA_DESTAT_LS[Val] == 1 and		
MCA:	MCA::LS::MCA_DESTAT_LS[AddrV] == 1. The lowest valid bit of the address is defined by		
MCA:	:LS::MCA_DEADDR_LS[LSB].		
_lthree[1	:0]_core[3:0]_thread[1:0]_inst0_aliasMSR; MSRC000_2009		
Bits	Description		
63:62	Reserved.		
61:56	<b>LSB</b> . Read-write, Volatile. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in		
	MCA::LS::MCA_DEADDR_LS[ErrorAddr]. For example, a value of 0 indicates that		
	MCA::LS::MCA_DEADDR_LS[55:0] contains a valid byte address. A value of 6 indicates that		
	MCA::LS::MCA_DEADDR_LS[55:6] contains a valid cache line address and that		
	MCA::LS::MCA_DEADDR_LS[5:0] are not part of the address and should be ignored by error handling		
	software. A value of 12 indicates that MCA::LS::MCA_DEADDR_LS[55:12] contain a valid 4-KB memory page		
	and that MCA::LS::MCA_DEADDR_LS[11:0] should be ignored by error handling software.		
55:0	<b>ErrorAddr</b> . Read-write, Volatile. Reset: Cold,00_0000_0000_0000h. Contains the address, if any, associated with		
	the error logged in MCA::LS::MCA_DESTAT_LS. The lowest-order valid bit of the address is specified in		
	MCA::LS::MCA_DEADDR_LS[LSB].		

MSR	C001_0400 [LS Machine Check Control Mask] (MCA::LS::MCA_CTL_MASK_LS)		
Read-	write. Reset: 0000_0000_0000_0000h.		
Inhibit detection of an error source.			
	:0]_core[3:0]_inst0_aliasMSR; MSRC001_0400		
Bits	Description		
63:21	Reserved.		
20	L2DataErr. Read-write. Reset: 0. L2 Fill Data error.		
19	<b>DcTagErr7</b> . Read-write. Reset: 0. DC Tag error type 5.		
18	<b>DcTagErr3</b> . Read-write. Reset: 0. DC Tag error type 3.		
17	<b>PDC</b> . Read-write. Reset: 0. PDC parity error. MCA_ADDR_LS logs a virtual address.		
16	<b>L2DTLB</b> . Read-write. Reset: 0. Level 2 TLB parity error. MCA_ADDR_LS logs a virtual address.		
15	<b>DcTagErr4</b> . Read-write. Reset: 0. DC Tag error type 4.		
14	<b>DcDataErr3</b> . Read-write. Reset: 0. DC Data error type 3.		
13	<b>DcDataErr2</b> . Read-write. Reset: 0. DC Data error type 2.		
12	<b>DcDataErr1</b> . Read-write. Reset: 0. DC Data error type 1 and poison consumption. MCA_STATUS[Poison] is set		
	on poison consumption from L2/L3.		
11	<b>DcTagErr2</b> . Read-write. Reset: 0. DC Tag error type 2.		
10	<b>SystemReadDataErrorT1</b> . Read-write. Reset: 0. Init: BIOS,1. System Read Data Error Thread 1. An error in a		
	Read of a line from the data fabric. Possible reasons include master abort and target abort.		
9	<b>SystemReadDataErrorT0</b> . Read-write. Reset: 0. Init: BIOS,1. System Read Data Error Thread 0. An error in a		
	Read of a line from the data fabric. Possible reasons include master abort and target abort.		
8	IntErrTyp2. Read-write. Reset: 0. Internal error type 2.		
7	IntErrTyp1. Read-write. Reset: 0. Internal error type 1.		
6	<b>DcTagErr1</b> . Read-write. Reset: 0. DC Tag error type 1.		
5	<b>DcTagErr6</b> . Read-write. Reset: 0. DC Tag error type 6.		
4	<b>DcTagErr5</b> . Read-write. Reset: 0. DC Tag error type 5.		
3	L1DTLB. Read-write. Reset: 0. Level 1 TLB parity error.		
2	MAB. Read-write. Reset: 0. Miss address buffer payload parity error.		
1	STQ. Read-write. Reset: 0. Store queue parity error.		
0	LDQ. Read-write. Reset: 0. Load queue parity error.		

#### 3.2.5.2 IF

MSR0000_0404MSRC000_2010 [IF Machine Check Control] (MCA::IF::MCA_CTL_IF)						
Read-v	Read-write. Reset: 0000_0000_0000_0000h.					
0=Disa	0=Disables error reporting for the corresponding error. 1=Enables error reporting via machine check exception for the					
corresp	corresponding error. The MCA::IF::MCA_CTL_IF register must be enabled by the corresponding enable bit in					
Core::X86::Msr::MCG_CTL. Does not affect error detection, correction, or logging.						
_lthree[1:0]_core[3:0]_inst1_aliasMSRLEGACY; MSR0000_0404						
	:0]_core[3:0]_inst1_aliasMSR; MSRC000_2010					
Bits	Description					
63:14	Reserved.					
13	<b>SystemReadDataError</b> . Read-write. Reset: 0. System Read Data Error. An error in a demand fetch of a line.					
	Possible reasons include master abort and target abort.					
12	<b>L2RespPoison</b> . Read-write. Reset: 0. L2 Cache Response Poison Error. Error is the result of consuming poison					
	data.					
11	L2BtbMultiHit. Read-write. Reset: 0. L2 BTB Multi-Match Error.					
10	L1BtbMultiHit. Read-write. Reset: 0. L1 BTB Multi-Match Error.					
9	<b>BpqSnpParT1</b> . Read-write. Reset: 0. BPQ Thread 1 Snoop Parity Error.					

8	<b>BpqSnpParT0</b> . Read-write. Reset: 0. BPQ Thread 0 Snoop Parity Error.
7	L2ItlbParity. Read-write. Reset: 0. L2 ITLB Parity Error.
6	L1ItlbParity. Read-write. Reset: 0. L1 ITLB Parity Error.
5	L0ItlbParity. Read-write. Reset: 0. L0 ITLB Parity Error.
4	<b>DqParity</b> . Read-write. Reset: 0. Decoupling Queue PhysAddr Parity Error.
3	<b>DataParity</b> . Read-write. Reset: 0. IC Data Array Parity Error.
2	TagParity. Read-write. Reset: 0. IC Full Tag Parity Error.
1	TagMultiHit. Read-write. Reset: 0. IC Microtag or Full Tag Multi-hit Error.
0	OcUtagParity. Read-write. Reset: 0. Op Cache Microtag Probe Port Parity Error.

#### MSR0000 0405...MSRC000 2011 [IF Machine Check Status Thread 0] (MCA::IF::MCA STATUS IF)

	0000_0405MSRC000_2011 [IF Machine Check Status Thread 0] (MCA::IF::MCA_STATUS_IF)						
Reset: Cold,0000_0000_0000h.							
Logs information associated with errors.							
_lthree[1:0]_core[3:0]_thread[1:0]_inst1_aliasMSRLEGACY; MSR0000_0405							
	_lthree[1:0]_core[3:0]_thread[1:0]_inst1_aliasMSR; MSRC000_2011						
	Description  Vol. Description  Vol. Description						
63	<b>Val</b> . Reset: Cold,0. 1=A valid error has been detected. This bit should be cleared by software after the register has been Read.						
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.						
62	<b>Overflow</b> . Reset: Cold,0. 1=An error was detected while the valid bit (Val) was set; at least one error was not logged. Overflow is set independently of whether the existing error is overwritten. See 3.1.3 [Machine Check Errors].						
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.						
61	UC. Reset: Cold,0. 1=The error was not corrected by hardware.						
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.						
60	<b>En</b> . Reset: Cold,0. 1=MCA error reporting is enabled for this error, as indicated by the corresponding bit in MCA::IF::MCA_CTL_IF. This bit is a copy of the bit in MCA::IF::MCA_CTL_IF for this error.						
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.						
59	<b>MiscV</b> . Reset: Cold,0. 1=Valid thresholding in MCA::IF::MCA_MISC0_IF. In certain modes, MISC registers are						
	owned by platform firmware and will RAZ when Read by non-SMM code. Therefore, it is possible for MiscV ==						
	1 and the MISC register to Read as all zeros.						
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.						
58	<b>AddrV</b> . Reset: Cold,0. 1=MCA::IF::MCA_ADDR_IF contains address information associated with the error.						
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.						
57	<b>PCC</b> . Reset: Cold,0. 1=Hardware context held by the processor may have been corrupted. Continued operation of the system may have unpredictable results. The error is not recoverable or survivable, and the system should be reinitialized.						
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.						
56	ErrCoreIdVal. Reset: Cold,0. 1=The ErrCoreId field is valid.						
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.						
55	<b>TCC</b> . Reset: Cold,0. 1=Hardware context of the process thread to which the error was reported may have been corrupted. Continued operation of the thread may have unpredictable results. The thread must be terminated. Only meaningful when MCA::IF::MCA_STATUS_IF[PCC] == 0.						
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.						
54	RESERV4. Reset: Cold,0. MCA_STATUS Register Reserved bit.						
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.						
53	SyndV. Reset: Cold,0. 1=This error logged information in MCA::IF::MCA_SYND_IF. If						
	MCA::IF::MCA_SYND_IF[ErrorPriority] is the same as the priority of the error in						
	MCA::IF::MCA_STATUS_IF, then the information in MCA::IF::MCA_SYND_IF is associated with the error in						
	MCA::IF::MCA_STATUS_IF.						

	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
52	Reserved.
51:47	RESERV3. Reset: Cold,00h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
46	<b>CECC</b> . Reset: Cold,0. 1=The error was a correctable ECC error according to the restrictions of the ECC
	algorithm. UC indicates whether the error was actually corrected by the processor.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
45	<b>UECC</b> . Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC
	algorithm. UC indicates whether the error was actually corrected by the processor.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
44	<b>Deferred</b> . Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data
	error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is
	consumed.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
43	<b>Poison</b> . Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
42:41	RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
40	<b>Scrub</b> . Reset: Cold,0. 1=The error was the result of a scrub operation.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
39:38	<b>RESERV1</b> . Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
37:32	
	associated with the error. Otherwise, this field is Reserved.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
31:22	<b>RESERV0</b> . Reset: Cold,000h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
21:16	<b>ErrorCodeExt</b> . Reset: Cold,00h. Extended Error Code. This field is used to identify the error type for root cause
	analysis. This field indicates which bit position in MCA::IF::MCA_CTL_IF enables error reporting for the logged
	error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
15:0	<b>ErrorCode</b> . Reset: Cold,0000h. Error code for this error. See 3.1.3.3 [Error Codes] for details on decoding this
	field.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.

Table 38: MCA\_STATUS\_IF

Error Type	ErrorCode	UC	PCC	TCC	Deferred	Poison	AddrV
31	Ext						
OcUtagParit	0x0	0	0	0	0	0	0
у							
TagMultiHit	0x1	0	0	0	0	0	1
TagParity	0x2	0	0	0	0	0	1
DataParity	0x3	0	0	0	0	0	1
DqParity	0x4	1	1	1	0	0	1
L0ItlbParity	0x5	1	1	1	0	0	1
L1ItlbParity	0x6	0	0	0	0	0	1
L2ItlbParity	0x7	0	0	0	0	0	1
BpqSnpParT	0x8	1	1	1	0	0	1
0							

BpqSnpParT 1	0x9	1	1	1	0	0	1
L1BtbMulti Hit	0xA	0	0	0	0	0	0
L2BtbMulti Hit	0xB	0	0	0	0	0	0
L2RespPoiso n	0xC	1	0	1	0	0	1
SystemRead DataError	0xD	1	0	1	0	0	1

MSR0	0000_0406MSRC000_2012 [IF Machine Check Address Thread 0] (MCA::IF::MCA_ADDR_IF)				
Reset:	Reset: Cold,0000_0000_0000_0000h.				
MCA:	:IF::MCA_ADDR_IF stores an address and other information associated with the error in				
MCA:	:IF::MCA_STATUS_IF. The register is only meaningful if MCA::IF::MCA_STATUS_IF[Val] == 1 and				
MCA:	:IF::MCA_STATUS_IF[AddrV] == 1.				
	:0]_core[3:0]_thread[1:0]_inst1_aliasMSRLEGACY; MSR0000_0406				
	:0]_core[3:0]_thread[1:0]_inst1_aliasMSR; MSRC000_2012				
Bits	Description				
63:62	Reserved.				
61:56	:56 <b>LSB</b> . Read-write, Volatile. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in				
	MCA::IF::MCA_ADDR_IF[ErrorAddr]. For example, a value of 0 indicates that				
	MCA::IF::MCA_ADDR_IF[55:0] contains a valid byte address. A value of 6 indicates that				
	MCA::IF::MCA_ADDR_IF[55:6] contains a valid cache line address and that MCA::IF::MCA_ADDR_IF[5:0]				
	are not part of the address and should be ignored by error handling software. A value of 12 indicates that				
	MCA::IF::MCA_ADDR_IF[55:12] contains a valid 4-KB memory page and that				
	MCA::IF::MCA_ADDR_IF[11:0] should be ignored by error handling software.				
55:0	:0 <b>ErrorAddr</b> . Read-write, Volatile. Reset: Cold,00_0000_0000h. Unless otherwise specified by an error,				
	contains the address associated with the error logged in MCA::IF::MCA_STATUS_IF. For physical addresses, the				
	most significant bit is given by Core::X86::Cpuid::LongModeInfo[PhysAddrSize].				

# Table 39: MCA\_ADDR\_IF

Error Type	Bits	Description
OcUtagParity	[55:0]	Reserved.
TagMultiHit	[55:48]	Reserved.
	[47:0]	Physical Address.
TagParity	[55:48]	Reserved.
	[47:0]	Physical Address.
DataParity	[55:48]	Reserved.
	[47:0]	Physical Address.
DqParity	[55:48]	Reserved.
	[47:0]	Physical Address.
L0ItlbParity	[55:48]	Reserved.
	[47:12]	Linear Address.
	[11:0]	Reserved.
L1ItlbParity	[55:48]	Reserved.
	[47:12]	Linear Address.
	[11:0]	Reserved.
L2ItlbParity	[55:48]	Reserved.
	[47:12]	Linear Address.

	[11:0]	Reserved.
BpqSnpParT0	[55:0]	Reserved.
BpqSnpParT1	[55:0]	Reserved.
L1BtbMultiHit	[55:0]	Reserved.
L2BtbMultiHit	[55:0]	Reserved.
L2RespPoison	[55:48]	Reserved.
	[47:5]	Physical Address.
	[4:0]	Reserved.
SystemReadDataError	[55:48]	Reserved.
	[47:5]	Physical Address.
	[4:0]	Reserved.

#### MSR0000 0407...MSRC000 2013 [IF Machine Check Miscellaneous 0 Thread 0] (MCA::IF::MCA MISC0 IF)

MSKU	000_0407MSRC000_2013 [IF Machine Check Miscellaneous 0 Thread 0] (MCA::IF::MCA_MISC0_IF)
	iscellaneous information associated with errors.
	:0]_core[3:0]_thread[1:0]_inst1_aliasMSRLEGACY; MSR0000_0407
	:0]_core[3:0]_thread[1:0]_inst1_aliasMSR; MSRC000_2013
-	Description
63	<b>Valid</b> . Reset: 1. 1=A valid CntP field is present in this register.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.
62	<b>CntP</b> . Reset: 1. 1=A valid threshold counter is present.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.
61	<b>Locked</b> . Reset: 0. 1=Writes to this register are ignored. This bit is set by BIOS to indicate that this register is not
	available for OS use. BIOS should set this bit if ThresholdIntType is set to SMI.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.
60	<b>IntP</b> . Reset: 1. 1=ThresholdIntType can be used to generate interrupts. 0=ThresholdIntType and interrupt generation are not supported.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::IF::MCA_MISC0_IF[Locked]) ? Read-write : Read-only.
59:56	Reserved.
55:52	<b>LvtOffset</b> . Reset: 0h. One per die. For error thresholding interrupts, specifies the address of the LVT entry in the APIC registers as follows: LVT address = (LvtOffset shifted left 4 bits) + 500h (see Core::X86::Apic::ExtendedInterruptLvtEntries).
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::IF::MCA_MISC0_IF[Locked]) ? Read-write : Read-only.
51	CntEn. Reset: 0. 1=Count thresholding errors.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::IF::MCA_MISC0_IF[Locked]) ? Read-write : Read-only.
50:49	<b>ThresholdIntType</b> . Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::IF::MCA_MISC0_IF[Locked]) ? Read-write : Read-only.
48	<b>Ovrflw</b> . Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is generated.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::IF::MCA_MISC0_IF[Locked]) ? Read-write : Read-only.
47:44	Reserved.
	<b>ErrCnt</b> . Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The

	threshold value, written by software, is (FFFh - the desired error count (the number of errors necessary in order
	for an interrupt to be taken)); the desired error count of 0 (a write value of FFFh) is not supported.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::IF::MCA_MISC0_IF[Locked]) ? Read-write :
	Read-only.
31:24	<b>BlkPtr</b> . Read-write. Reset: 00h. 00h=Extended MISC MSR block is not valid. 01h=Extended MSR block is valid.
23:0	Reserved.

### MSRC000\_2014 [IF Machine Check Configuration] (MCA::IF::MCA\_CONFIG\_IF) Reset: 0000\_0002\_0000\_0021h. Controls configuration of the associated machine check bank. lthree[1:0]\_core[3:0]\_inst1\_aliasMSR; MSRC000\_2014 Bits Description 63:39 Reserved. 38:37 **DeferredIntType**. Read-write. Reset: 0h. Specifies the type of interrupt signaled when a deferred error is logged. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[DeferredLvtOffset]). 10b=SMI trigger event. 11b=Reserved. 36:33 Reserved. McaXEnable. Read-write. Reset: 0. Init: BIOS,1. Check: 1. 1=Software has acknowledged support for the 32 MCAX feature set. 0=Software has not acknowledged support for the MCAX feature set. All uncorrected and fatal errors will cause an ErrorEvent packet to be generated. Deferred error interrupts are configured via Core::X86::Msr::McaIntrCfg. 31:6 Reserved. **DeferredIntTypeSupported.** Read-only. Reset: 1. 1=MCA::IF::MCA\_CONFIG\_IF[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if MCA::IF::MCA\_CONFIG\_IF[DeferredErrorLoggingSupported] == 1. 4:3 Reserved. **DeferredErrorLoggingSupported**. Read-only. Reset: 0. 1=Deferred errors are supported in this MCA bank, and the LogDeferredInMcaStat field in this register controls the logging behavior of these errors. MCA\_DESTAT and MCA DEADDR are supported in this MCA bank. 0=Deferred errors are not supported in this bank. 1 Reserved. McaX. Read-only. Reset: 1. 1=This bank provides Machine Check Architecture Extensions. Up to 4 additional MISC registers (MISC1-MISC4) are supported. MCA::IF::MCA\_MISC0\_IF[BlkPtr] indicates the presence of the additional MISC registers, but is not used to determine their MSR numbers. Deferred error interrupt type is

#### MSRC000 2015 [IF IP Identification] (MCA··IF··MCA IPID IF)

specifiable by MCA bank. MCA::IF::MCA\_STATUS\_IF[TCC] is present.

MSKC000_2015 [IF IT Identification] (MCAIFMCA_ITID_IF)			
set: 0001_00B0_0000_0000h.			
The MCA::IF::MCA_IPID_IF register is used by software to determine what IP type and revision is associated with the			
MCA bank.			
lthree[1:0]_core[3:0]_inst1_aliasMSR; MSRC000_2015			
Bits Description			
33:48 <b>McaType</b> . Read-only. Reset: 0001h. The McaType of the MCA bank within this IP.			
7:44 Reserved.			
3:32 <b>HardwareID</b> . Read-only. Reset: 0B0h. The Hardware ID of the IP associated with this MCA bank.			
InstanceId. Read-write. Reset: 0000_0000h. The instance ID of this IP. This is initialized to a unique ID per			
instance of this register.			

#### MSRC000 2016 [IF Machine Check Syndrome Thread 0] (MCA::IF::MCA SYND IF)

Read-write, Volatile. Reset: Cold, 0000_0000_0000_0000h.
Logs physical location information associated with the error in MCA::IF::MCA_STATUS_IF Thread 0.
_lthree[1:0]_core[3:0]_thread[1:0]_inst1_aliasMSR; MSRC000_2016

#### Bits Description

63:33	Reserved.
32	<b>Syndrome</b> . Read-write, Volatile. Reset: Cold,0. Contains the syndrome, if any, associated with the error logged in MCA::IF::MCA_STATUS_IF. The low-order bit of the syndrome is stored in bit[0], and the syndrome has a length specified by MCA::IF::MCA_SYND_IF[Length]. The Syndrome field is only valid when MCA::IF::MCA_SYND_IF[Length]!= 0.
31:27	Reserved.
26:24	<b>ErrorPriority</b> . Read-write, Volatile. Reset: Cold,0h. Encodes the priority of the error logged in MCA::IF::MCA_SYND_IF. 000b=No error. 001b=Reserved. 010b=Corrected Error. 011b=Deferred Error. 100b=Uncorrected Error. 101b=Fatal Error. 111b-110b=Reserved.
23:18	<b>Length</b> . Read-write, Volatile. Reset: Cold,00h. Specifies the length in bits of the syndrome contained in MCA::IF::MCA_SYND_IF[Syndrome]. A value of 0 indicates that there is no valid syndrome in MCA::IF::MCA_SYND_IF. For example, a syndrome length of 9 means that MCA::IF::MCA_SYND_IF[Syndrome] bits[8:0] contains a valid syndrome.
17:0	<b>ErrorInformation</b> . Read-write, Volatile. Reset: Cold, 0_0000h. Contains error-specific information about the location of the error. Decoding is available in Table 40 [MCA_SYND_IF].

# Table 40: MCA\_SYND\_IF

Error Type	Bits	Description
OcUtagParity	[17:6]	Reserved.
	[5:0]	Index.
TagMultiHit	[17:16]	Reserved.
	[15:8]	Subcache.
	[8:0]	Reserved.
TagParity	[17:8]	Reserved.
	[7:0]	Way.
DataParity	[17:16]	Reserved.
	[15:8]	Subcache.
	[8:0]	Way.
DqParity	[17:0]	Reserved.
L0ItlbParity	[17:4]	Reserved.
	[3:0]	Reserved.
L1ItlbParity	[17:6]	Reserved.
	[5:0]	Reserved.
L2ItlbParity	[17:8]	Reserved.
	[7:0]	Reserved.
BpqSnpParT0	[17:0]	Reserved.
BpqSnpParT1	[17:0]	Reserved.
L1BtbMultiHit	[17:0]	Reserved.
L2BtbMultiHit	[17:0]	Reserved.
L2RespPoison	[17:0]	Reserved.
SystemReadDataError	[17:2]	Reserved.
	[1:0]	2'b00 = Master Abort; 2'b01 = Target Abort; 2'b10 = Transaction
		Error; 2'b11 = Protection Violation

# MSRC001\_0401 [IF Machine Check Control Mask] (MCA::IF::MCA\_CTL\_MASK\_IF)

Read-write. Reset: 0000_0000_0000_0000h.		
Inhibit detection of an error source.		
_tthree[1:0]_core[3:0]_inst1_aliasMSR; MSRC001_0401		
Bits Description		

63:14	Reserved.			
13	<b>SystemReadDataError</b> . Read-write. Reset: 0. Init: BIOS,1. System Read Data Error. An error in a demand fetch			
	of a line. Possible reasons include master abort and target abort.			
12	<b>L2RespPoison</b> . Read-write. Reset: 0. L2 Cache Response Poison Error. Error is the result of consuming poison			
	data.			
11	L2BtbMultiHit. Read-write. Reset: 0. Init: BIOS,1. L2 BTB Multi-Match Error.			
10	L1BtbMultiHit. Read-write. Reset: 0. Init: BIOS,1. L1 BTB Multi-Match Error.			
9	<b>BpqSnpParT1</b> . Read-write. Reset: 0. BPQ Thread 1 Snoop Parity Error.			
8	<b>BpqSnpParT0</b> . Read-write. Reset: 0. BPQ Thread 0 Snoop Parity Error.			
7	L2ItlbParity. Read-write. Reset: 0. L2 ITLB Parity Error.			
6	L1ItlbParity. Read-write. Reset: 0. L1 ITLB Parity Error.			
5	L0ItlbParity. Read-write. Reset: 0. L0 ITLB Parity Error.			
4	<b>DqParity</b> . Read-write. Reset: 0. Decoupling Queue PhysAddr Parity Error.			
3	DataParity. Read-write. Reset: 0. IC Data Array Parity Error.			
2	TagParity. Read-write. Reset: 0. IC Full Tag Parity Error.			
1	TagMultiHit. Read-write. Reset: 0. IC Microtag or Full Tag Multi-hit Error.			
0	OcUtagParity. Read-write. Reset: 0. Op Cache Microtag Probe Port Parity Error.			

#### 3.2.5.3 L2

Read-write. Reset: 0000_0000_0000_0000h.
0=Disables error reporting for the corresponding error. 1=Enables error reporting via machine check exception for the
corresponding error. The MCA::L2::MCA_CTL_L2 register must be enabled by the corresponding enable bit in
Core::X86::Msr::MCG_CTL. Does not affect error detection, correction, or logging.

MSR0000\_0408...MSRC000\_2020 [L2 Machine Check Control] (MCA::L2::MCA\_CTL\_L2)

\_lthree[1:0]\_core[3:0]\_inst2\_aliasMSRLEGACY; MSR0000\_0408

lthree[1:0] core[3:0] inst2 aliasMSR: MSRC000 2020

_lthree[1	_lthree[1:0]_core[3:0]_inst2_aliasMSR; MSRC000_2020		
Bits	Description		
63:4 Reserved.			
3	3 <b>Hwa</b> . Read-write. Reset: 0. Hardware Assert Error.		
2	Data. Read-write. Reset: 0. L2M Data Array ECC Error.		
1	1 <b>Tag.</b> Read-write. Reset: 0. L2M Tag or State Array ECC Error.		
0	MultiHit. Read-write. Reset: 0. L2M Tag Multiple-Way-Hit error.		

# MSR0000\_0409...MSRC000\_2021 [L2 Machine Check Status Thread 0] (MCA::L2::MCA\_STATUS\_L2)

Reset:	Reset: Cold,0000_0000_0000_0000h.			
Logs information associated with errors.				
	_lthree[1:0]_core[3:0]_thread[1:0]_inst2_aliasMSRLEGACY; MSR0000_0409			
	:0]_core[3:0]_thread[1:0]_inst2_aliasMSR; MSRC000_2021			
Bits	Bits Description			
63	<b>Val</b> . Reset: Cold,0. 1=A valid error has been detected. This bit should be cleared by software after the register has			
	been Read.			
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.			
62	<b>Overflow</b> . Reset: Cold,0. 1=An error was detected while the valid bit (Val) was set; at least one error was not			
	logged. Overflow is set independently of whether the existing error is overwritten. See 3.1.3 [Machine Check			
	Errors].			
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.			
61	UC. Reset: Cold,0. 1=The error was not corrected by hardware.			
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.			
60	<b>En</b> . Reset: Cold,0. 1=MCA error reporting is enabled for this error, as indicated by the corresponding bit in			

	MCA::L2::MCA_CTL_L2. This bit is a copy of the bit in MCA::L2::MCA_CTL_L2 for this error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
59	<b>MiscV</b> . Reset: Cold,0. 1=Valid thresholding in MCA::L2::MCA_MISCO_L2. In certain modes, MISC registers
	are owned by platform firmware and will RAZ when Read by non-SMM code. Therefore, it is possible for MiscV
	== 1 and the MISC register to Read as all zeros.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
58	<b>AddrV</b> . Reset: Cold,0. 1=MCA::L2::MCA_ADDR_L2 contains address information associated with the error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
57	<b>PCC</b> . Reset: Cold,0. 1=Hardware context held by the processor may have been corrupted. Continued operation of
	the system may have unpredictable results. The error is not recoverable or survivable, and the system should be
	reinitialized.
<b>5</b> 0	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
56	ErrCoreIdVal. Reset: Cold,0. 1=The ErrCoreId field is valid.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
55	<b>TCC</b> . Reset: Cold,0. 1=Hardware context of the process thread to which the error was reported may have been
	corrupted. Continued operation of the thread may have unpredictable results. The thread must be terminated. Only
	meaningful when MCA::L2::MCA_STATUS_L2[PCC] == 0.
F 4	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
54	RESERV4. Reset: Cold, 0. MCA_STATUS Register Reserved bit.
53	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
53	<b>SyndV</b> . Reset: Cold,0. 1=This error logged information in MCA::L2::MCA_SYND_L2. If MCA::L2::MCA_SYND_L2[ErrorPriority] is the same as the priority of the error in
	MCA::L2::MCA_STATUS_L2, then the information in MCA::L2::MCA_SYND_L2 is associated with the error
	in MCA::L2::MCA_STATUS_L2.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
52	Reserved.
51:47	
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
	• • • • • • • • • • • • • • • • • • • •
46	CECC. Resel: Cold, 0. 1=1 lie error was a correctable ECC error according to the restrictions of the ECC
46	<b>CECC</b> . Reset: Cold,0. 1=The error was a correctable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.
46	algorithm. UC indicates whether the error was actually corrected by the processor.
45	
	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC
	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.
45	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
45	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Deferred. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is consumed.
45	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Deferred. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is consumed.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
45	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Deferred. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is consumed.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Poison. Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.
45 44 43	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Deferred. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is consumed.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Poison. Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
45 44 43	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Deferred. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is consumed.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Poison. Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.
45 44 43 42:41	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Deferred. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is consumed.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Poison. Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
45 44 43	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Deferred. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is consumed.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Poison. Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Scrub. Reset: Cold,0. 1=The error was the result of a scrub operation.
45 44 43 42:41 40	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Deferred. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is consumed.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Poison. Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Scrub. Reset: Cold,0. 1=The error was the result of a scrub operation.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
45 44 43 42:41 40	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Deferred. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is consumed.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Poison. Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Scrub. Reset: Cold,0. 1=The error was the result of a scrub operation.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.
45 44 43 42:41 40 39:38	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Deferred. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is consumed.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Poison. Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Scrub. Reset: Cold,0. 1=The error was the result of a scrub operation.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.
45 44 43 42:41 40 39:38	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Deferred. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is consumed.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Poison. Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Scrub. Reset: Cold,0. 1=The error was the result of a scrub operation.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  ErrCoreId. Reset: Cold,00h. When (ErrCoreIdVal == 1), this field indicates which core within the processor is
45 44 43 42:41 40 39:38	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Deferred. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is consumed.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Poison. Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Scrub. Reset: Cold,0. 1=The error was the result of a scrub operation.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV1. Reset: Cold,0h. When (ErrCoreIdVal == 1), this field indicates which core within the processor is associated with the error. Otherwise, this field is Reserved.
45 44 43 42:41 40 39:38 37:32	algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  UECC. Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Deferred. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is consumed.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Poison. Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  Scrub. Reset: Cold,0. 1=The error was the result of a scrub operation.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.  AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  ErrCoreId. Reset: Cold,00h. When (ErrCoreIdVal == 1), this field indicates which core within the processor is

	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
21:16	<b>ErrorCodeExt.</b> Reset: Cold,00h. Extended Error Code. This field is used to identify the error type for root cause
	analysis. This field indicates which bit position in MCA::L2::MCA_CTL_L2 enables error reporting for the
	logged error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
15:0	<b>ErrorCode</b> . Reset: Cold,0000h. Error code for this error. See 3.1.3.3 [Error Codes] for details on decoding this
	field.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.

# *Table 41: MCA\_STATUS\_L2*

Error Type	ErrorCode Ext	UC	PCC	TCC	Deferred	Poison	AddrV
MultiHit	0x0					-	-
Tag	0x1					-	-
Data	0x2					-	-
Hwa	0x3					-	-

MSR0000_040AMSRC000_2022 [L2 Machine Check Address Thread 0] (MCA::L2::MCA_ADDR_L2)				
Reset: Cold,0000_0000_0000_0000h.				
MCA::L2::MCA_ADDR_L2 stores an address and other information associated with the error in				
MCA::L2::MCA_STATUS_L2. The register is only meaningful if MCA::L2::MCA_STATUS_L2[Val] == 1 and				
$MCA::L2::MCA\_STATUS\_L2[AddrV] == 1.$				
hthree[1:0]_core[3:0]_thread[1:0]_inst2_aliasMSRLEGACY; MSR0000_040A				
hthree[1:0]_core[3:0]_thread[1:0]_inst2_aliasMSR; MSRC000_2022				
Bits Description				
Reserved.				
LSB. Read-write, Volatile. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in				
MCA::L2::MCA_ADDR_L2[ErrorAddr]. For example, a value of 0 indicates that				
MCA::L2::MCA_ADDR_L2[55:0] contains a valid byte address. A value of 6 indicates that				
MCA::L2::MCA_ADDR_L2[55:6] contains a valid cache line address and that MCA::L2::MCA_ADDR_L2[5:0]				
are not part of the address and should be ignored by error handling software. A value of 12 indicates that				
MCA::L2::MCA_ADDR_L2[55:12] contains a valid 4-KB memory page and that				
MCA::L2::MCA_ADDR_L2[11:0] should be ignored by error handling software.				
55:0 <b>ErrorAddr</b> . Read-write, Volatile. Reset: Cold,00_0000_0000h. Unless otherwise specified by an error,				
contains the address associated with the error logged in MCA::L2::MCA_STATUS_L2. For physical addresses,				
the most significant bit is given by Core::X86::Cpuid::LongModeInfo[PhysAddrSize].				

# Table 42: MCA\_ADDR\_L2

Error Type	Bits	Description
MultiHit	[55:48]	Reserved.
	[47:6]	Physical Address.
	[5:0]	Reserved.
Tag	[55:48]	Reserved.
	[47:6]	Physical Address.
	[5:0]	Reserved.
Data	[55:48]	Reserved.
	[47:6]	Physical Address.
	[5:0]	Reserved.
Hwa	[31:0]	Reserved.

# MSR0000\_040B...MSRC000\_2023 [L2 Machine Check Miscellaneous 0 Thread 0] (MCA::L2::MCA\_MISC0\_L2)

	iscellaneous information associated with errors.					
	:0]_core[3:0]_thread[1:0]_inst2_aliasMSRLEGACY; MSR0000_040B :0]_core[3:0]_thread[1:0]_inst2_aliasMSR; MSRC000_2023					
	Bits Description					
	•					
63	<b>Valid.</b> Reset: 1. 1=A valid CntP field is present in this register.					
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.					
62	<b>CntP</b> . Reset: 1. 1=A valid threshold counter is present.					
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.					
61	<b>Locked</b> . Reset: 0. 1=Writes to this register are ignored. This bit is set by BIOS to indicate that this register is not					
	available for OS use. BIOS should set this bit if ThresholdIntType is set to SMI.					
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.					
60	<b>IntP</b> . Reset: 1. 1=ThresholdIntType can be used to generate interrupts. 0=ThresholdIntType and interrupt					
	generation are not supported.					
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L2::MCA_MISC0_L2[Locked]) ? Read-write :					
	Read-only.					
59:56	Reserved.					
55:52	<b>LvtOffset</b> . Reset: 0h. One per die. For error thresholding interrupts, specifies the address of the LVT entry in the					
	APIC registers as follows: LVT address = (LvtOffset shifted left 4 bits) + 500h (see					
	Core::X86::Apic::ExtendedInterruptLvtEntries).					
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L2::MCA_MISC0_L2[Locked]) ? Read-write :					
	Read-only.					
51	CntEn. Reset: 0. 1=Count thresholding errors.					
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L2::MCA_MISC0_L2[Locked]) ? Read-write :					
	Read-only.					
50:49	<b>ThresholdIntType</b> . Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1.					
	00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI					
	trigger event. 11b=Reserved.					
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L2::MCA_MISC0_L2[Locked]) ? Read-write :					
	Read-only.					
48	<b>Ovrflw</b> . Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set,					
	ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is					
	generated.					
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L2::MCA_MISC0_L2[Locked]) ? Read-write :					
	Read-only.					
47:44	Reserved.					
	<b>ErrCnt</b> . Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is					
.5,52	incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The					
	threshold value, written by software, is (FFFh - the desired error count (the number of errors necessary in order					
	for an interrupt to be taken)); the desired error count of 0 (a write value of FFFh) is not supported.					
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L2::MCA_MISC0_L2[Locked]) ? Read-write :					
	Read-only.					
31:24	<b>BlkPtr</b> . Read-write. Reset: 00h. 00h=Extended MISC MSR block is not valid. 01h=Extended MSR block is valid.					
23:0	Reserved.					
25.0	reserved.					

# MSRC000\_2024 [L2 Machine Check Configuration] (MCA::L2::MCA\_CONFIG\_L2)

Reset: 0000_0000_0000_0025h.		
Controls configuration of the associated machine check bank.		
_lthree[1:0]_core[3:0]_inst2_aliasMSR; MSRC000_2024		
Bits Description		
63:39 Reserved.		

38:37	<b>DeferredIntType</b> . Read-write. Reset: 0h. Specifies the type of interrupt signaled when a deferred error is logged.				
00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[DeferredLvtOffset]).					
trigger event. 11b=Reserved.  36:35 Reserved.					
36:35					
34 <b>LogDeferredInMcaStat</b> . Read-write. Reset: 0. Init: BIOS,1. 1=Log deferred errors in					
	MCA::L2::MCA_STATUS_L2 and MCA::L2::MCA_ADDR_L2 in addition to MCA::L2::MCA_DESTAT_L2				
	and MCA::L2::MCA_DEADDR_L2. 0=Only log deferred errors in MCA::L2::MCA_DESTAT_L2 and				
MCA::L2::MCA_DEADDR_L2. This bit does not affect logging of deferred errors in					
	MCA::L2::MCA_SYND_L2, MCA::L2::MCA_MISC0_L2.				
33	Reserved.				
32	<b>McaXEnable</b> . Read-write. Reset: 0. Init: BIOS,1. Check: 1. 1=Software has acknowledged support for the				
	MCAX feature set. 0=Software has not acknowledged support for the MCAX feature set. All uncorrected and				
	fatal errors will cause an ErrorEvent packet to be generated. Deferred error interrupts are configured via				
	Core::X86::Msr::McaIntrCfg.				
0.4.0	Reserved.				
31:6	Reserved.				
31:6 5	<b>DeferredIntTypeSupported</b> . Read-only. Reset: 1. 1=MCA::L2::MCA_CONFIG_L2[DeferredIntType] controls				
	<b>DeferredIntTypeSupported</b> . Read-only. Reset: 1. 1=MCA::L2::MCA_CONFIG_L2[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if				
	<b>DeferredIntTypeSupported</b> . Read-only. Reset: 1. 1=MCA::L2::MCA_CONFIG_L2[DeferredIntType] controls				
	<b>DeferredIntTypeSupported</b> . Read-only. Reset: 1. 1=MCA::L2::MCA_CONFIG_L2[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if				
5	<b>DeferredIntTypeSupported</b> . Read-only. Reset: 1. 1=MCA::L2::MCA_CONFIG_L2[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if MCA::L2::MCA_CONFIG_L2[DeferredErrorLoggingSupported] == 1.				
4:3	DeferredIntTypeSupported. Read-only. Reset: 1. 1=MCA::L2::MCA_CONFIG_L2[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if MCA::L2::MCA_CONFIG_L2[DeferredErrorLoggingSupported] == 1.  Reserved.  DeferredErrorLoggingSupported. Read-only. Reset: 1. 1=Deferred errors are supported in this MCA bank, and MCA::L2::MCA_CONFIG_L2[LogDeferredInMcaStat] controls the logging behavior of these errors.				
5 4:3	<b>DeferredIntTypeSupported</b> . Read-only. Reset: 1. 1=MCA::L2::MCA_CONFIG_L2[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if MCA::L2::MCA_CONFIG_L2[DeferredErrorLoggingSupported] == 1.  Reserved. <b>DeferredErrorLoggingSupported</b> . Read-only. Reset: 1. 1=Deferred errors are supported in this MCA bank, and				
4:3	DeferredIntTypeSupported. Read-only. Reset: 1. 1=MCA::L2::MCA_CONFIG_L2[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if MCA::L2::MCA_CONFIG_L2[DeferredErrorLoggingSupported] == 1.  Reserved.  DeferredErrorLoggingSupported. Read-only. Reset: 1. 1=Deferred errors are supported in this MCA bank, and MCA::L2::MCA_CONFIG_L2[LogDeferredInMcaStat] controls the logging behavior of these errors.				
4:3	DeferredIntTypeSupported. Read-only. Reset: 1. 1=MCA::L2::MCA_CONFIG_L2[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if MCA::L2::MCA_CONFIG_L2[DeferredErrorLoggingSupported] == 1.  Reserved.  DeferredErrorLoggingSupported. Read-only. Reset: 1. 1=Deferred errors are supported in this MCA bank, and MCA::L2::MCA_CONFIG_L2[LogDeferredInMcaStat] controls the logging behavior of these errors.  MCA::L2::MCA_DESTAT_L2 and MCA::L2::MCA_DEADDR_L2 are supported in this MCA bank.				
4:3 2	DeferredIntTypeSupported. Read-only. Reset: 1. 1=MCA::L2::MCA_CONFIG_L2[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if MCA::L2::MCA_CONFIG_L2[DeferredErrorLoggingSupported] == 1.  Reserved.  DeferredErrorLoggingSupported. Read-only. Reset: 1. 1=Deferred errors are supported in this MCA bank, and MCA::L2::MCA_CONFIG_L2[LogDeferredInMcaStat] controls the logging behavior of these errors.  MCA::L2::MCA_DESTAT_L2 and MCA::L2::MCA_DEADDR_L2 are supported in this MCA bank. 0=Deferred errors are not supported in this bank.  Reserved.  McaX. Read-only. Reset: 1. 1=This bank provides Machine Check Architecture Extensions. Up to 4 additional				
5 4:3 2	DeferredIntTypeSupported. Read-only. Reset: 1. 1=MCA::L2::MCA_CONFIG_L2[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if MCA::L2::MCA_CONFIG_L2[DeferredErrorLoggingSupported] == 1.  Reserved.  DeferredErrorLoggingSupported. Read-only. Reset: 1. 1=Deferred errors are supported in this MCA bank, and MCA::L2::MCA_CONFIG_L2[LogDeferredInMcaStat] controls the logging behavior of these errors.  MCA::L2::MCA_DESTAT_L2 and MCA::L2::MCA_DEADDR_L2 are supported in this MCA bank. 0=Deferred errors are not supported in this bank.  Reserved.  McaX. Read-only. Reset: 1. 1=This bank provides Machine Check Architecture Extensions. Up to 4 additional MISC registers (MISC1-MISC4) are supported. MCA::L2::MCA_MISC0_L2[BlkPtr] indicates the presence of				
5 4:3 2	DeferredIntTypeSupported. Read-only. Reset: 1. 1=MCA::L2::MCA_CONFIG_L2[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if MCA::L2::MCA_CONFIG_L2[DeferredErrorLoggingSupported] == 1.  Reserved.  DeferredErrorLoggingSupported. Read-only. Reset: 1. 1=Deferred errors are supported in this MCA bank, and MCA::L2::MCA_CONFIG_L2[LogDeferredInMcaStat] controls the logging behavior of these errors.  MCA::L2::MCA_DESTAT_L2 and MCA::L2::MCA_DEADDR_L2 are supported in this MCA bank. 0=Deferred errors are not supported in this bank.  Reserved.  McaX. Read-only. Reset: 1. 1=This bank provides Machine Check Architecture Extensions. Up to 4 additional				

### MSRC000 2025 [L2 IP Identification] (MCA::L2::MCA IPID L2)

Mondovo_2025 [E2 II Identification] (Mondous EMon_II ID_E2)				
Reset: 0002_00B0_0000_0000h.				
The MCA::L2::MCA_IPID_L2 register is used by software to determine what IP type and revision is associated with the				
MCA bank.				
_lthree[1:0]_core[3:0]_inst2_aliasMSR; MSRC000_2025				
Bits Description				
63:48 <b>McaType</b> . Read-only. Reset: 0002h. The McaType of the MCA bank within this IP.				
47:44 Reserved.				
43:32 <b>HardwareID</b> . Read-only. Reset: 0B0h. The Hardware ID of the IP associated with this MCA bank.				
31:0 <b>InstanceId</b> . Read-write. Reset: 0000_0000h. The instance ID of this IP. This is initialized to a unique ID per				
instance of this register.				

# MSRC000\_2026 [L2 Machine Check Syndrome Thread 0] (MCA::L2::MCA\_SYND\_L2)

Read-	write, Volatile. Reset: Cold, 0000_0000_0000.			
Logs p	Logs physical location information associated with the error in MCA::L2::MCA_STATUS_L2 Thread 0.			
_lthree[1	1:0]_core[3:0]_thread[1:0]_inst2_aliasMSR; MSRC000_2026			
Bits	Description			
63:49	Reserved.			
48:32	<b>Syndrome</b> . Read-write, Volatile. Reset: Cold,0_0000h. Contains the syndrome, if any, associated with the error logged in MCA::L2::MCA_STATUS_L2. The low-order bit of the syndrome is stored in bit[0], and the syndrome has a length specified by MCA::L2::MCA_SYND_L2[Length]. The Syndrome field is only valid when MCA::L2::MCA_SYND_L2[Length]!= 0.			
31:27	Reserved.			

26:24	<b>ErrorPriority</b> . Read-write, Volatile. Reset: Cold, 0h. Encodes the priority of the error logged in					
	MCA::L2::MCA_SYND_L2. 000b=No error. 001b=Reserved. 010b=Corrected Error. 011b=Deferred Error.					
	100b=Uncorrected Error. 101b=Fatal Error. 111b-110b=Reserved.					
23:18	<b>Length</b> . Read-write, Volatile. Reset: Cold, 00h. Specifies the length in bits of the syndrome contained in					
	MCA::L2::MCA_SYND_L2[Syndrome]. A value of 0 indicates that there is no valid syndrome in					
	MCA::L2::MCA_SYND_L2. For example, a syndrome length of 9 means that					
	MCA::L2::MCA_SYND_L2[Syndrome] bits[8:0] contains a valid syndrome.					
17:0	<b>ErrorInformation</b> . Read-write, Volatile. Reset: Cold, 0_0000h. Contains error-specific information about the					
	location of the error. Decoding is available in Table 43 [MCA_SYND_L2].					

#### *Table 43: MCA\_SYND\_L2*

Error Type	Bits	Description
MultiHit	Hit [17:8] Index.	
	[7:0]	One-hot way vector.
Tag	[17:13]	Reserved.
	[12:3]	Index.
	[2:0]	Way.
Data	[17:15]	Reserved.
	[14:5]	Index.
	[4:3]	Quarter-line.
	[2:0]	Way.
Hwa	[17:0]	Reserved.

#### MSRC000 2028 [L2 Machine Check Deferred Error Status Thread 0] (MCA::L2::MCA DESTAT L2)

MSK	2000_2020 [L2 Machine Check Deferred Effor Status Tiffead 0] (MCA::L2::MCA_DESTAT_L2)				
Read-	Read-write, Volatile. Reset: Cold, 0000_0000_0000h.				
Holds	status information for the first deferred error seen in this bank.				
_lthree[1	:0]_core[3:0]_thread[1:0]_inst2_aliasMSR; MSRC000_2028				
Bits	Description				
63	<b>Val</b> . Read-write, Volatile. Reset: Cold, 0. 1=A valid error has been detected (whether it is enabled or not).				
62	<b>Overflow</b> . Read-write, Volatile. Reset: Cold,0. 1=An error was detected while the valid bit (Val) was set; at least one error was not logged. Overflow is set independently of whether the existing error is overwritten. (See the section on overwrite priorities.)				
61:59	Reserved.				
58	<b>AddrV</b> . Read-write, Volatile. Reset: Cold, 0. 1=MCA::L2::MCA_DEADDR_L2 contains address information associated with the error.				
57:54	Reserved.				
53	<b>SyndV</b> . Read-write, Volatile. Reset: Cold,0. 1=This error logged information in MCA::L2::MCA_SYND_L2. If MCA::L2::MCA_SYND_L2[ErrorPriority] is the same as the priority of the error in MCA::L2::MCA_STATUS_L2, then the information in MCA::L2::MCA_SYND_L2 is associated with the error in MCA::L2::MCA_DESTAT_L2.				
52:45	Reserved.				
44	<b>Deferred</b> . Read-write, Volatile. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; poison is created and an exception is deferred until the poison data is consumed.				
43:0	Reserved.				

### MSRC000\_2029 [L2 Deferred Error Address Thread 0] (MCA::L2::MCA\_DEADDR\_L2)

Dogota	Cold.0000	$\Omega$	$\Omega$	0000b
Reset.	Corarono	UUUUU	www	OOOOH.

The MCA::L2::MCA\_DEADDR\_L2 register stores the address associated with the error in MCA::L2::MCA\_DESTAT\_L2. The register is only meaningful if MCA::L2::MCA\_DESTAT\_L2[Val] == 1 and

MCA:	MCA::L2::MCA_DESTAT_L2[AddrV] == 1. The lowest valid bit of the address is defined by				
MCA:	MCA::L2::MCA_DEADDR_L2[LSB].				
_lthree[1	:0]_core[3:0]_thread[1:0]_inst2_aliasMSR; MSRC000_2029				
Bits	Description				
63:62	Reserved.				
61:56	<b>LSB</b> . Read-write, Volatile. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in				
	MCA::L2::MCA_DEADDR_L2[ErrorAddr]. For example, a value of 0 indicates that				
	MCA::L2::MCA_DEADDR_L2[55:0] contains a valid byte address. A value of 6 indicates that				
	MCA::L2::MCA_DEADDR_L2[55:6] contains a valid cache line address and that				
	MCA::L2::MCA_DEADDR_L2[5:0] are not part of the address and should be ignored by error handling				
	software. A value of 12 indicates that MCA::L2::MCA_DEADDR_L2[55:12] contains a valid 4-KB memory				
	page and that MCA::L2::MCA_DEADDR_L2[11:0] should be ignored by error handling software.				
55:0	<b>ErrorAddr</b> . Read-write, Volatile. Reset: Cold,00_0000_0000_0000h. Contains the address, if any, associated with				
	the error logged in MCA::L2::MCA_DESTAT_L2. The lowest-order valid bit of the address is specified in				
	MCA::L2::MCA_DEADDR_L2[LSB].				

#### MSRC001\_0402 [L2 Machine Check Control Mask] (MCA::L2::MCA\_CTL\_MASK\_L2)

Read-	ead-write. Reset: 0000_0000_0000_0000h.			
Inhibi	t detection of an error source.			
_lthree[1	1:0]_core[3:0]_inst2_aliasMSR; MSRC001_0402			
Bits	Description			
63:4	Reserved.			
3	<b>Hwa</b> . Read-write. Reset: 0. Init: BIOS,1. Hardware Assert Error.			
2	<b>Data</b> . Read-write. Reset: 0. L2M Data Array ECC Error.			
1	Tag. Read-write. Reset: 0. L2M Tag or State Array ECC Error.			
0	MultiHit. Read-write. Reset: 0. L2M Tag Multiple-Way-Hit error.			

#### 3.2.5.4 DE

#### MSR0000\_040C...MSRC000\_2030 [DE Machine Check Control] (MCA::DE::MCA\_CTL\_DE)

Read-write. Reset: 0000\_0000\_0000\_0000h.

0=Disables error reporting for the corresponding error. 1=Enables error reporting via machine check exception for the corresponding error. The MCA::DE::MCA\_CTL\_DE register must be enabled by the corresponding enable bit in Core::X86::Msr::MCG\_CTL. Does not affect error detection, correction, or logging.

lthree[1:0] core[3:0] inst3 aliasMSRLEGACY; MSR0000 040C

	_mmce[1.0]_core[0.0]_moto_unusmortaberre 1, mortoooo_core		
_lthree[1	_lthree[1:0]_core[3:0]_inst3_aliasMSR; MSRC000_2030		
Bits	Description		
63:9	Reserved.		
8	<b>OCBQ</b> . Read-write. Reset: 0. Micro-op buffer parity error.		
7	<b>UcSeq.</b> Read-write. Reset: 0. Patch RAM sequencer parity error.		
6	UcDat. Read-write. Reset: 0. Patch RAM data parity error.		
5	<b>Faq.</b> Read-write. Reset: 0. Fetch address FIFO parity error.		
4	Idq. Read-write. Reset: 0. Instruction dispatch queue parity error.		
3	<b>UopQ</b> . Read-write. Reset: 0. Micro-op queue parity error.		
2	<b>Ibq</b> . Read-write. Reset: 0. Instruction buffer parity error.		
1	OcDat. Read-write. Reset: 0. Micro-op cache data parity error.		
0	OcTag. Read-write. Reset: 0. Micro-op cache tag parity error.		

### MSR0000\_040D...MSRC000\_2031 [DE Machine Check Status Thread 0] (MCA::DE::MCA\_STATUS\_DE)

Reset: Cold,0000\_0000\_0000\_0000h.

I ogs i	nformation associated with errors.				
_lthree[1:0]_core[3:0]_thread[1:0]_inst3_aliasMSRLEGACY; MSR0000_040D					
	ee[1:0]_core[3:0]_thread[1:0]_inst3_aliasMSR; MSRC000_2031				
Bits	Description				
63	<b>Val</b> . Reset: Cold,0. 1=A valid error has been detected. This bit should be cleared by software after the register has				
	been Read.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.				
62	<b>Overflow</b> . Reset: Cold,0. 1=An error was detected while the valid bit (Val) was set; at least one error was not				
	logged. Overflow is set independently of whether the existing error is overwritten. See 3.1.3 [Machine Check				
	Errors].				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.				
61	UC. Reset: Cold,0. 1=The error was not corrected by hardware.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.				
60	<b>En</b> . Reset: Cold,0. 1=MCA error reporting is enabled for this error, as indicated by the corresponding bit in				
	MCA::DE::MCA_CTL_DE. This bit is a copy of the bit in MCA::DE::MCA_CTL_DE for this error.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.				
59	<b>MiscV</b> . Reset: Cold,0. 1=Valid thresholding in MCA::DE::MCA_MISC0_DE. In certain modes, MISC registers				
	are owned by platform firmware and will RAZ when Read by non-SMM code. Therefore, it is possible for MiscV				
	== 1 and the MISC register to Read as all zeros.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.				
58	AddrV. Reset: Cold,0. 1=MCA::DE::MCA_ADDR_DE contains address information associated with the error.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.				
57	<b>PCC</b> . Reset: Cold,0. 1=Hardware context held by the processor may have been corrupted. Continued operation of				
	the system may have unpredictable results. The error is not recoverable or survivable, and the system should be reinitialized.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.				
56	ErrCoreIdVal. Reset: Cold,0. 1=The ErrCoreId field is valid.				
30	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.				
55	<b>TCC</b> . Reset: Cold,0. 1=Hardware context of the process thread to which the error was reported may have been				
	corrupted. Continued operation of the thread may have unpredictable results. The thread must be terminated. Only				
	meaningful when MCA::DE::MCA_STATUS_DE[PCC] == 0.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.				
54	RESERV4. Reset: Cold,0. MCA_STATUS Register Reserved bit.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.				
53	<b>SyndV</b> . Reset: Cold,0. 1=This error logged information in MCA::DE::MCA_SYND_DE. If				
	MCA::DE::MCA_SYND_DE[ErrorPriority] is the same as the priority of the error in				
	MCA::DE::MCA_STATUS_DE, then the information in MCA::DE::MCA_SYND_DE is associated with the				
	error in MCA::DE::MCA_STATUS_DE.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.				
52	Reserved.				
51:47	RESERV3. Reset: Cold,00h. MCA_STATUS Register Reserved bits.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.				
46	<b>CECC.</b> Reset: Cold,0. 1=The error was a correctable ECC error according to the restrictions of the ECC				
	algorithm. UC indicates whether the error was actually corrected by the processor.				
45	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.				
45	<b>UECC</b> . Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC				
	algorithm. UC indicates whether the error was actually corrected by the processor.				
11	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.				
44	<b>Deferred.</b> Reset: Cold, 0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is				
	error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is				

	consumed.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
43	<b>Poison</b> . Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
42:41	RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
40	<b>Scrub</b> . Reset: Cold,0. 1=The error was the result of a scrub operation.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
39:38	RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
37:32	<b>ErrCoreId</b> . Reset: Cold,00h. When (ErrCoreIdVal == 1), this field indicates which core within the processor is
	associated with the error. Otherwise, this field is Reserved.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
31:22	RESERVO. Reset: Cold,000h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
21:16	<b>ErrorCodeExt</b> . Reset: Cold,00h. Extended Error Code. This field is used to identify the error type for root cause
	analysis. This field indicates which bit position in MCA::DE::MCA_CTL_DE enables error reporting for the
	logged error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
15:0	<b>ErrorCode</b> . Reset: Cold,0000h. Error code for this error. See 3.1.3.3 [Error Codes] for details on decoding this
	field.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.

# *Table 44: MCA\_STATUS\_DE*

Error Type	ErrorCode	UC	PCC	TCC	Deferred	Poison	AddrV
	Ext						
OcTag	0x0	0	0	0	0	0	0
OcDat	0x1	0	0	0	0	0	0
Ibq	0x2	1	1	1	0	0	0
UopQ	0x3	1	1	1	0	0	0
Idq	0x4	1	1	1	0	0	0
Faq	0x5	1	1	1	0	0	0
UcDat	0x6	1	1	1	0	0	0
UcSeq	0x7	1	1	1	0	0	0
OCBQ	0x8	1	1	1	0	0	0

MSR	MSR0000_040EMSRC000_2032 [DE Machine Check Address Thread 0] (MCA::DE::MCA_ADDR_DE)				
Read-	Read-only. Reset: Cold,0000_0000_0000_0000h.				
MCA:	:DE::MCA_ADDR_DE stores an address and other information associated with the error in				
MCA:	:DE::MCA_STATUS_DE. The register is only meaningful if MCA::DE::MCA_STATUS_DE[Val] == 1 and				
MCA:	:DE::MCA_STATUS_DE[AddrV] == 1.				
_lthree[1	:0]_core[3:0]_thread[1:0]_inst3_aliasMSRLEGACY; MSR0000_040E				
_lthree[1	:0]_core[3:0]_thread[1:0]_inst3_aliasMSR; MSRC000_2032				
Bits	Description				
63:62	Reserved.				
61:56	<b>LSB</b> . Read-only. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in				
	MCA::DE::MCA_ADDR_DE[ErrorAddr]. For example, a value of 0 indicates that				
	MCA::DE::MCA_ADDR_DE[55:0] contains a valid byte address. A value of 6 indicates that				
	MCA::DE::MCA_ADDR_DE[55:6] contains a valid cache line address and that				
	MCA::DE::MCA_ADDR_DE[5:0] are not part of the address and should be ignored by error handling software.				

	A value of 12 indicates that MCA::DE::MCA_ADDR_DE[55:12] contains a valid 4-KB memory page and that
	MCA::DE::MCA_ADDR_DE[11:0] should be ignored by error handling software.
55:0	<b>ErrorAddr</b> . Read-only. Reset: Cold,00_0000_0000_0000h. Contains the address, if any, associated with the error
	logged in MCA::DE::MCA_STATUS_DE.

### *Table 45: MCA\_ADDR\_DE*

Error Type	Bits	Description
OcTag	[55:0]	Reserved.
OcDat	[55:0]	Reserved.
Ibq	[55:0]	Reserved.
UopQ	[55:0]	Reserved.
Idq	[55:0]	Reserved.
Faq	[55:0]	Reserved.
UcDat	[55:0]	Reserved.
UcSeq	[55:0]	Reserved.
OCBQ	[55:0]	Reserved.

# MSR0000 040F...MSRC000 2033 [DE Machine Check Miscellaneous 0 Thread 0]

	:::DE::MCA_MISCO_DE)
	iscellaneous information associated with errors.
	:0]_core[3:0]_thread[1:0]_inst3_aliasMSRLEGACY; MSR0000_040F
	:0]_core[3:0]_thread[1:0]_inst3_aliasMSR; MSRC000_2033
	Description
63	<b>Valid</b> . Reset: 1. 1=A valid CntP field is present in this register.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.
62	<b>CntP</b> . Reset: 1. 1=A valid threshold counter is present.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.
61	<b>Locked</b> . Reset: 0. 1=Writes to this register are ignored. This bit is set by BIOS to indicate that this register is not
	available for OS use. BIOS should set this bit if ThresholdIntType is set to SMI.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.
60	<b>IntP</b> . Reset: 1. 1=ThresholdIntType can be used to generate interrupts. 0=ThresholdIntType and interrupt
	generation are not supported.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::DE::MCA_MISC0_DE[Locked]) ? Read-write :
	Read-only.
	Reserved.
55:52	<b>LvtOffset</b> . Reset: 0h. One per die. For error thresholding interrupts, specifies the address of the LVT entry in the
	APIC registers as follows: LVT address = (LvtOffset shifted left 4 bits) + 500h (see
	Core::X86::Apic::ExtendedInterruptLvtEntries).
	$Access Type: (Core::X86::Msr::HWCR[McStatusWrEn] \mid !MCA::DE::MCA\_MISC0\_DE[Locked]) ? Read-write: \\$
	Read-only.
51	<b>CntEn</b> . Reset: 0. 1=Count thresholding errors.
	$Access Type: (Core::X86::Msr::HWCR[McStatusWrEn] \mid !MCA::DE::MCA\_MISC0\_DE[Locked]) ? Read-write: \\$
	Read-only.
50:49	<b>ThresholdIntType</b> . Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1.
	00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI
	trigger event. 11b=Reserved.
	$AccessType: (Core::X86::Msr::HWCR[McStatusWrEn] \mid !MCA::DE::MCA\_MISC0\_DE[Locked]) ? Read-write: \\$
	Read-only.
48	<b>Ovrflw</b> . Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set,
	ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is

	generated.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::DE::MCA_MISC0_DE[Locked]) ? Read-write :
	Read-only.
47:44	Reserved.
43:32	<b>ErrCnt</b> . Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is
	incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The
	threshold value, written by software, is (FFFh - the desired error count (the number of errors necessary in order
	for an interrupt to be taken)); the desired error count of 0 (a write value of FFFh) is not supported.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::DE::MCA_MISC0_DE[Locked]) ? Read-write :
	Read-only.
31:24	<b>BlkPtr</b> . Read-write. Reset: 00h. 00h=Extended MISC MSR block is not valid. 01h=Extended MSR block is valid.
23:0	Reserved.

## MSRC000 2034 [DE Machine Check Configuration] (MCA::DE::MCA CONFIG DE)

MSRC	C000_2034 [DE Machine Check Configuration] (MCA::DE::MCA_CONFIG_DE)	
Reset:	0000_0002_0000_0021h.	
Controls configuration of the associated machine check bank.		
_lthree[1	:0]_core[3:0]_inst3_aliasMSR; MSRC000_2034	
Bits	Description	
63:39	Reserved.	
38:37	<b>DeferredIntType</b> . Read-write. Reset: 0h. Specifies the type of interrupt signaled when a deferred error is logged. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[DeferredLvtOffset]). 10b=SMI trigger event. 11b=Reserved.	
36:33	Reserved.	
32	<b>McaXEnable</b> . Read-write. Reset: 0. Init: BIOS,1. Check: 1. 1=Software has acknowledged support for the MCAX feature set. 0=Software has not acknowledged support for the MCAX feature set. All uncorrected and fatal errors will cause an ErrorEvent packet to be generated. Deferred error interrupts are configured via Core::X86::Msr::McaIntrCfg.	
31:6	Reserved.	
5	<b>DeferredIntTypeSupported</b> . Read-only. Reset: 1. 1=MCA::DE::MCA_CONFIG_DE[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if MCA::DE::MCA_CONFIG_DE[DeferredErrorLoggingSupported] == 1.	
4:3	Reserved.	
2	<b>DeferredErrorLoggingSupported</b> . Read-only. Reset: 0. 1=Deferred errors are supported in this MCA bank, and the LogDeferredInMcaStat field in this register controls the logging behavior of these errors. MCA_DESTAT and MCA_DEADDR are supported in this MCA bank. 0=Deferred errors are not supported in this bank.	
1	Reserved.	
0	<b>McaX</b> . Read-only. Reset: 1. 1=This bank provides Machine Check Architecture Extensions. Up to 4 additional MISC registers (MISC1-MISC4) are supported. MCA::DE::MCA_MISC0_DE[BlkPtr] indicates the presence of the additional MISC registers, but is not used to determine their MSR numbers. Deferred error interrupt type is specifiable by MCA bank. MCA::DE::MCA_STATUS_DE[TCC] is present.	

# MSRC000\_2035 [DE IP Identification] (MCA::DE::MCA\_IPID\_DE)

Reset:	Reset: 0003_00B0_0000_0000h.		
The M	CA::DE::MCA_IPID_DE register is used by software to determine what IP type and revision is associated with		
the MO	CA bank.		
_lthree[1	:0]_core[3:0]_inst3_aliasMSR; MSRC000_2035		
Bits	Description		
63:48	<b>McaType</b> . Read-only. Reset: 0003h. The McaType of the MCA bank within this IP.		
47:44	Reserved.		
43:32	<b>HardwareID</b> . Read-only. Reset: 0B0h. The Hardware ID of the IP associated with this MCA bank.		
31:0	<b>InstanceId</b> . Read-write. Reset: 0000_0000h. The instance ID of this IP. This is initialized to a unique ID per		

instance of this register.

# MSRC000\_2036 [DE Machine Check Syndrome Thread 0] (MCA::DE::MCA\_SYND\_DE)

1120211	2000_1000 [22 1/14cmine encen 5]		
Read-write, Volatile. Reset: Cold, 0000_0000_0000h.			
Logs p	Logs physical location information associated with the error in MCA::DE::MCA_STATUS_DE Thread 0.		
_lthree[1	:0]_core[3:0]_thread[1:0]_inst3_aliasMSR; MSRC000_2036		
Bits	Description		
63:33	Reserved.		
32	<b>Syndrome</b> . Read-write, Volatile. Reset: Cold, 0. Contains the syndrome, if any, associated with the error logged in		
	MCA::DE::MCA_STATUS_DE. The low-order bit of the syndrome is stored in bit[0], and the syndrome has a		
	length specified by MCA::DE::MCA_SYND_DE[Length]. The Syndrome field is only valid when		
	MCA::DE::MCA_SYND_DE[Length] != 0.		
31:27	Reserved.		
26:24	<b>ErrorPriority</b> . Read-write, Volatile. Reset: Cold, 0h. Encodes the priority of the error logged in		
	MCA::DE::MCA_SYND_DE. 000b=No error. 001b=Reserved. 010b=Corrected Error. 011b=Deferred Error.		
	100b=Uncorrected Error. 101b=Fatal Error. 111b-110b=Reserved.		
23:18	<b>Length.</b> Read-write, Volatile. Reset: Cold, 00h. Specifies the length in bits of the syndrome contained in		
	MCA::DE::MCA_SYND_DE[Syndrome]. A value of 0 indicates that there is no valid syndrome in		
	MCA::DE::MCA_SYND_DE. For example, a syndrome length of 9 means that		
	MCA::DE::MCA_SYND_DE[Syndrome] bits[8:0] contains a valid syndrome.		
17:0	<b>ErrorInformation</b> . Read-write, Volatile. Reset: Cold, 0_0000h. Contains error-specific information about the		
	location of the error. Decoding is available in Table 46 [MCA_SYND_DE].		

### Table 46: MCA\_SYND\_DE

Error Type	Bits	Description
OcTag	[17:16]	Reserved.
	[15:8]	Index.
	[7:0]	Way.
OcDat	[17:16]	Reserved.
	[15:8]	Index.
	[7:0]	Way.
Ibq	[17:0]	Reserved.
UopQ	[17:0]	Reserved.
Idq	[17:0]	Reserved.
Faq	[17:0]	Reserved.
UcDat	[17:0]	Reserved.
UcSeq	[17:0]	Reserved.
OCBQ	[17:0]	Reserved.

# MSRC001\_0403 [DE Machine Check Control Mask] (MCA::DE::MCA\_CTL\_MASK\_DE)

Read-	Read-write. Reset: 0000_0000_0000_0000h.	
Inhibit	t detection of an error source.	
_lthree[1	:0]_core[3:0]_inst3_aliasMSR; MSRC001_0403	
Bits	S Description	
63:9	Reserved.	
8	OCBQ. Read-write. Reset: 0. Micro-op buffer parity error.	
7	UcSeq. Read-write. Reset: 0. Patch RAM sequencer parity error.	
6	UcDat. Read-write. Reset: 0. Patch RAM data parity error.	
5	<b>Faq.</b> Read-write. Reset: 0. Fetch address FIFO parity error.	
4	<b>Idq</b> . Read-write. Reset: 0. Instruction dispatch queue parity error.	

3	UopQ. Read-write. Reset: 0. Micro-op queue parity error.
2	<b>Ibq</b> . Read-write. Reset: 0. Instruction buffer parity error.
1	OcDat. Read-write. Reset: 0. Micro-op cache data parity error.
0	OcTag. Read-write. Reset: 0. Micro-op cache tag parity error.

#### 3.2.5.5 $\mathbf{E}\mathbf{X}$

MSR0000_0414MSRC000_2050	[EX Machine Check Control] (MCA::EX::MCA_CTL_EX)
Read-write. Reset: 0000_0000_000	0_000h.

0=Disables error reporting for the corresponding error. 1=Enables error reporting via machine check exception for the corresponding error. The MCA::EX::MCA\_CTL\_EX register must be enabled by the corresponding enable bit in Core::X86::Msr::MCG\_CTL. Does not affect error detection, correction, or logging. \_lthree[1:0]\_core[3:0]\_inst5\_aliasMSRLEGACY; MSR0000\_0414

tillee[1.0]_cole[5.0]_illst5_allasivi5KLEGAC1, ivi5K00000_0414		
_lthree[1	:0]_core[3:0]_inst5_aliasMSR; MSRC000_2050	
Bits	Description	
63:12	Reserved.	
11	<b>HWA</b> . Read-write. Reset: 0. Hardware Assertion error.	
10	<b>BBQ</b> . Read-write. Reset: 0. Branch buffer queue parity error.	
9	<b>SQ</b> . Read-write. Reset: 0. Scheduling queue parity error.	
8	<b>STATQ</b> . Read-write. Reset: 0. Retire status queue parity error.	
7	<b>RETDISP</b> . Read-write. Reset: 0. Retire dispatch queue parity error.	
6	<b>CHKPTQ</b> . Read-write. Reset: 0. CHKPTQ. Checkpoint queue parity error.	
5	PLDAL. Read-write. Reset: 0. EX payload parity error.	
4	PLDAG. Read-write. Reset: 0. Address generator payload parity error.	
3	<b>IDRF</b> . Read-write. Reset: 0. Immediate displacement register file parity error.	
2	<b>FRF</b> . Read-write. Reset: 0. Flag register file parity error.	
1	<b>PRF</b> . Read-write. Reset: 0. Physical register file parity error.	
0	WDT. Read-write. Reset: 0. Watchdog Timeout error.	

#### MSR0000 0415 MSRC000 2051 [EX Machine Check Status Thread 0] (MCA··EX··MCA STATUS EX)

WISK	0000_0415MSRC000_2051 [EX Machine Check Status Thread 0] (MCA::EX::MCA_STATUS_EX)		
Reset:	Reset: Cold,0000_0000_0000_0000h.		
Logs i	information associated with errors.		
_lthree[1	l:0]_core[3:0]_thread[1:0]_inst5_aliasMSRLEGACY; MSR0000_0415		
	1:0]_core[3:0]_thread[1:0]_inst5_aliasMSR; MSRC000_2051		
Bits	Description		
63	<b>Val</b> . Reset: Cold,0. 1=A valid error has been detected. This bit should be cleared by software after the register has		
	been Read.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.		
62	<b>Overflow</b> . Reset: Cold,0. 1=An error was detected while the valid bit (Val) was set; at least one error was not		
	logged. Overflow is set independently of whether the existing error is overwritten. See 3.1.3 [Machine Check		
	Errors].		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.		
61	UC. Reset: Cold,0. 1=The error was not corrected by hardware.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.		
60	<b>En</b> . Reset: Cold,0. 1=MCA error reporting is enabled for this error, as indicated by the corresponding bit in		
	MCA::EX::MCA_CTL_EX. This bit is a copy of the bit in MCA::EX::MCA_CTL_EX for this error.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.		
59	<b>MiscV</b> . Reset: Cold,0. 1=Valid thresholding in MCA::EX::MCA_MISC0_EX. In certain modes, MISC registers		
	are owned by platform firmware and will RAZ when Read by non-SMM code. Therefore, it is possible for MiscV		
	== 1 and the MISC register to Read as all zeros.		

	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
58	<b>AddrV</b> . Reset: Cold,0. 1=MCA::EX::MCA_ADDR_EX contains address information associated with the error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
57	<b>PCC</b> . Reset: Cold,0. 1=Hardware context held by the processor may have been corrupted. Continued operation of
	the system may have unpredictable results. The error is not recoverable or survivable, and the system should be
	reinitialized.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
56	<b>ErrCoreIdVal</b> . Reset: Cold,0. 1=The ErrCoreId field is valid.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
55	<b>TCC</b> . Reset: Cold,0. 1=Hardware context of the process thread to which the error was reported may have been
	corrupted. Continued operation of the thread may have unpredictable results. The thread must be terminated. Only
	meaningful when MCA::EX::MCA_STATUS_EX[PCC] == 0.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
54	RESERV4. Reset: Cold,0. MCA_STATUS Register Reserved bit.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
53	<b>SyndV</b> . Reset: Cold,0. 1=This error logged information in MCA::EX::MCA_SYND_EX. If
	MCA::EX::MCA_SYND_EX[ErrorPriority] is the same as the priority of the error in
	MCA::EX::MCA_STATUS_EX, then the information in MCA::EX::MCA_SYND_EX is associated with the
	error in MCA::EX::MCA_STATUS_EX.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
52	Reserved.  DESERVE Passate Cold 00h, MCA, STATUS Passates Passates Passates beautiful hits.
51:4/	RESERV3. Reset: Cold,00h. MCA_STATUS Register Reserved bits.
10	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
46	<b>CECC</b> . Reset: Cold,0. 1=The error was a correctable ECC error according to the restrictions of the ECC
	algorithm. UC indicates whether the error was actually corrected by the processor.
45	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
45	<b>UECC</b> . Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
44	<b>Deferred</b> . Reset: Cold, 0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data
44	error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is
	consumed.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
43	<b>Poison</b> . Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
42:41	<b>RESERV2</b> . Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
40	Scrub. Reset: Cold,0. 1=The error was the result of a scrub operation.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
39.38	<b>RESERV1</b> . Reset: Cold,0h. MCA_STATUS Register Reserved bits.
33.30	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
37.32	<b>ErrCoreId</b> . Reset: Cold,00h. When (ErrCoreIdVal == 1), this field indicates which core within the processor is
37.32	associated with the error. Otherwise, this field is Reserved.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
31:22	<b>RESERVO</b> . Reset: Cold,000h. MCA_STATUS Register Reserved bits.
01,11	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
21:16	<b>ErrorCodeExt.</b> Reset: Cold,00h. Extended Error Code. This field is used to identify the error type for root cause
21,10	analysis. This field indicates which bit position in MCA::EX::MCA_CTL_EX enables error reporting for the
	logged error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.

15:0 **ErrorCode**. Reset: Cold,0000h. Error code for this error. See 3.1.3.3 [Error Codes] for details on decoding this field.

AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.

#### Table 47: MCA\_STATUS\_EX

Error Type	ErrorCode	UC	PCC	TCC	Deferred	Poison	AddrV
	Ext						
WDT	0x0	1	1	1	0	0	1
PRF	0x1	1	1	1	0	0	0
FRF	0x2	1	1	1	0	0	0
IDRF	0x3	1	1	1	0	0	0
PLDAG	0x4	1	1	1	0	0	0
PLDAL	0x5	1	1	1	0	0	0
CHKPTQ	0x6	1	1	1	0	0	0
RETDISP	0x7	1	1	1	0	0	0
STATQ	0x8	1	1	1	0	0	0
SQ	0x9	1	1	1	0	0	0
BBQ	0xA	1	1	1	0	0	0
HWA	0xB	1	1	1	0	0	0

#### MSR0000\_0416...MSRC000\_2052 [EX Machine Check Address Thread 0] (MCA::EX::MCA\_ADDR\_EX)

Read-only. Reset: Cold,0000\_0000\_0000\_0000h.

MCA::EX::MCA\_ADDR\_EX stores an address and other information associated with the error in

MCA::EX::MCA\_STATUS\_EX. The register is only meaningful if MCA::EX::MCA\_STATUS\_EX[Val] == 1 and

 $MCA::EX::MCA\_STATUS\_EX[AddrV] == 1.$ 

\_lthree[1:0]\_core[3:0]\_thread[1:0]\_inst5\_aliasMSRLEGACY; MSR0000\_0416

lthree[1:0] core[3:0] thread[1:0] inst5 aliasMSR: MSRC000 2052

_lthree[	re[1:0]_core[3:0]_thread[1:0]_inst5_aliasMSR; MSRC000_2052		
Bits	Description		
63:62	Reserved.		
61:56	LSB. Read-only. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in		
	MCA::EX::MCA_ADDR_EX[ErrorAddr]. For example, a value of 0 indicates that		
	MCA::EX::MCA_ADDR_EX[55:0] contains a valid byte address. A value of 6 indicates that		
	MCA::EX::MCA_ADDR_EX[55:6] contains a valid cache line address and that		
	MCA::EX::MCA_ADDR_EX[5:0] are not part of the address and should be ignored by error handling software.		
	A value of 12 indicates that MCA::EX::MCA_ADDR_EX[55:12] contains a valid 4-KB memory page and that		
	MCA::EX::MCA_ADDR_EX[11:0] should be ignored by error handling software.		
55:0	<b>ErrorAddr</b> . Read-only. Reset: Cold,00_0000_0000_0000h. Contains the address, if any, associated with the error		
	logged in MCA::EX::MCA STATUS EX.		

#### *Table 48: MCA\_ADDR\_EX*

Error Type	Bits	Description
WDT	55:49]	Reserved.
	[48:0]	RIP of thread triggering the watchdog timeout.
PRF	[55:0]	Reserved.
FRF	[55:0]	Reserved.
IDRF	[55:0]	Reserved.
PLDAG	[55:0]	Reserved.
PLDAL	[55:0]	Reserved.
СНКРТО	[55:0]	Reserved.

RETDISP	[55:0]	Reserved.
STATQ	[55:0]	Reserved.
SQ	[55:0]	Reserved.
BBQ	[55:0]	Reserved.
HWA	[55:0]	Reserved.

# MSR0000\_0417...MSRC000\_2053 [EX Machine Check Miscellaneous 0 Thread 0] (MCA::EX::MCA\_MISC0\_EX)

	::EX::MCA_MISCO_EX)				
_	iscellaneous information associated with errors.				
	_lthree[1:0]_core[3:0]_thread[1:0]_inst5_aliasMSRLEGACY; MSR0000_0417				
	:0]_core[3:0]_thread[1:0]_inst5_aliasMSR; MSRC000_2053				
Bits	Description				
63	<b>Valid</b> . Reset: 1. 1=A valid CntP field is present in this register.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.				
62	<b>CntP</b> . Reset: 1. 1=A valid threshold counter is present.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.				
61	<b>Locked</b> . Reset: 0. 1=Writes to this register are ignored. This bit is set by BIOS to indicate that this register is not				
	available for OS use. BIOS should set this bit if ThresholdIntType is set to SMI.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.				
60	<b>IntP</b> . Reset: 1. 1=ThresholdIntType can be used to generate interrupts. 0=ThresholdIntType and interrupt				
	generation are not supported.				
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::EX::MCA_MISC0_EX[Locked]) ? Read-write :				
	Read-only.				
	Reserved.				
55:52	<b>LvtOffset</b> . Reset: 0h. One per die. For error thresholding interrupts, specifies the address of the LVT entry in the				
	APIC registers as follows: LVT address = (LvtOffset shifted left 4 bits) + 500h (see				
	Core::X86::Apic::ExtendedInterruptLvtEntries).				
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::EX::MCA_MISC0_EX[Locked]) ? Read-write :				
F1	Read-only.				
51	CntEn. Reset: 0. 1=Count thresholding errors.				
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::EX::MCA_MISCO_EX[Locked]) ? Read-write : Read-only.				
50.40	<b>ThresholdIntType</b> . Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1.				
50.49	00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI				
	trigger event. 11b=Reserved.				
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::EX::MCA_MISC0_EX[Locked]) ? Read-write :				
	Read-only.				
48	<b>Ovrflw</b> . Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set,				
	ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is				
	generated.				
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::EX::MCA_MISC0_EX[Locked]) ? Read-write :				
	Read-only.				
47:44					
43:32	<b>ErrCnt</b> . Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is				
	incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The				
	threshold value, written by software, is (FFFh - the desired error count (the number of errors necessary in order				
	for an interrupt to be taken)); the desired error count of 0 (a write value of FFFh) is not supported.				
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::EX::MCA_MISC0_EX[Locked]) ? Read-write :				
	Read-only.				
31:24					
23:0	Reserved.				

MSR	C000_2054 [EX Machine Check Configuration] (MCA::EX::MCA_CONFIG_EX)			
Reset:	Reset: 0000_0002_0000_0021h.			
Contro	Controls configuration of the associated machine check bank.			
_lthree[1	:0]_core[3:0]_inst5_aliasMSR; MSRC000_2054			
Bits	Description			
63:39	Reserved.			
38:37	<b>DeferredIntType</b> . Read-write. Reset: 0h. Specifies the type of interrupt signaled when a deferred error is logged. 00b=No interrupt. 01b = APIC based interrupt (see Core::X86::Msr::McaIntrCfg[DeferredLvtOffset]). 10b=SMI trigger event. 11b=Reserved.			
36:33	Reserved.			
32	McaXEnable. Read-write. Reset: 0. Init: BIOS,1. Check: 1. 1=Software has acknowledged support for the MCAX feature set. 0=Software has not acknowledged support for the MCAX feature set. All uncorrected and fatal errors will cause an ErrorEvent packet to be generated. Deferred error interrupts are configured via Core::X86::Msr::McaIntrCfg.			
31:6	Reserved.			
5	<b>DeferredIntTypeSupported</b> . Read-only. Reset: 1. 1=MCA::EX::MCA_CONFIG_EX[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if MCA::EX::MCA_CONFIG_EX[DeferredErrorLoggingSupported] == 1.			
4:3	Reserved.			
2	<b>DeferredErrorLoggingSupported</b> . Read-only. Reset: 0. 1=Deferred errors are supported in this MCA bank, and the LogDeferredInMcaStat field in this register controls the logging behavior of these errors. MCA_DESTAT and MCA_DEADDR are supported in this MCA bank. 0=Deferred errors are not supported in this bank.			
1	Reserved.			
0	<b>McaX</b> . Read-only. Reset: 1. 1=This bank provides Machine Check Architecture Extensions. Up to 4 additional MISC registers (MISC1-MISC4) are supported. MCA::EX::MCA_MISC0_EX[BlkPtr] indicates the presence of the additional MISC registers, but is not used to determine their MSR numbers. Deferred error interrupt type is specifiable by MCA bank. MCA::EX::MCA_STATUS_EX[TCC] is present.			

### MSRC000 2055 [EX IP Identification] (MCA::EX::MCA IPID EX)

MISKCOOU_2035 [EX IF Identification] (MCAEXMCA_IFID_EX)			
Reset: 0005_00B0_0000_0000h.			
The MCA::EX::MCA_IPID_EX register is used by software to determine what IP type and revision is associated with			
the MCA bank.			
_lthree[1:0]_core[3:0]_inst5_aliasMSR; MSRC000_2055			
Bits Description			
63:48 <b>McaType</b> . Read-only. Reset: 0005h. The McaType of the MCA bank within this IP.			
4 Reserved.			
32 <b>HardwareID</b> . Read-only. Reset: 0B0h. The Hardware ID of the IP associated with this MCA bank.			
<b>InstanceId</b> . Read-write. Reset: 0000_0000h. The instance ID of this IP. This is initialized to a unique ID per			
instance of this register.			

# MSRC000\_2056 [EX Machine Check Syndrome Thread 0] (MCA::EX::MCA\_SYND\_EX)

Read-	Read-write, Volatile. Reset: Cold, 0000_0000_0000_0000h.			
Logs p	Logs physical location information associated with the error in MCA::EX::MCA_STATUS_EX Thread 0.			
_lthree[1	:0]_core[3:0]_thread[1:0]_inst5_aliasMSR; MSRC000_2056			
Bits	Description			
63:33	Reserved.			
32	<b>Syndrome</b> . Read-write, Volatile. Reset: Cold, 0. Contains the syndrome, if any, associated with the error logged in			
	MCA::EX::MCA_STATUS_EX. The low-order bit of the syndrome is stored in bit[0], and the syndrome has a			
	length specified by MCA::EX::MCA_SYND_EX[Length]. The Syndrome field is only valid when			
	MCA::EX::MCA_SYND_EX[Length] != 0.			
31:27	Reserved.			

26:24	<b>ErrorPriority</b> . Read-write, Volatile. Reset: Cold, 0h. Encodes the priority of the error logged in
	MCA::EX::MCA_SYND_EX. 000b=No error. 001b=Reserved. 010b=Corrected Error. 011b=Deferred Error.
	100b=Uncorrected Error. 101b=Fatal Error. 111b-110b=Reserved.
23:18	<b>Length</b> . Read-write, Volatile. Reset: Cold, 00h. Specifies the length in bits of the syndrome contained in
	MCA::EX::MCA_SYND_EX[Syndrome]. A value of 0 indicates that there is no valid syndrome in
	MCA::EX::MCA_SYND_EX. For example, a syndrome length of 9 means that
	MCA::EX::MCA_SYND_EX[Syndrome] bits[8:0] contains a valid syndrome.
17:0	<b>ErrorInformation</b> . Read-write, Volatile. Reset: Cold, 0_0000h. Contains error-specific information about the
	location of the error. Decoding is available in Table 49 [MCA_SYND_EX].

# *Table 49: MCA\_SYND\_EX*

Error Type	Bits	Description
WDT	[17:0]	Reserved.
PRF	[17:0]	Reserved.
FRF	[17:4]	Reserved.
	[3:0]	Reserved.
IDRF	[17:6]	Reserved.
	[5:4]	Reserved.
	[3:0]	Reserved.
PLDAG	[17:2]	Reserved.
	[1:0]	Reserved.
PLDAL	[17:4]	Reserved.
	[3:0]	Reserved.
CHKPTQ	[17:4]	Reserved.
	[3:2]	Reserved.
	[1:0]	Reserved.
RETDISP	[17:2]	Reserved.
	[1:0]	Reserved.
STATQ	[17:0]	Reserved.
SQ	[17:6]	Reserved.
	[5:0]	Reserved.
BBQ	[17:6]	Reserved.
	[5:0]	Reserved.
HWA	[17:6]	Reserved.
	[5:0]	Reserved.

# MSRC001\_0405 [EX Machine Check Control Mask] (MCA::EX::MCA\_CTL\_MASK\_EX)

Read-write. Reset: 0000_0000_0000_0000h.			
Inhibit	Inhibit detection of an error source.		
_lthree[1:	0]_core[3:0]_inst5_aliasMSR; MSRC001_0405		
Bits	Description		
63:12	Reserved.		
11	<b>HWA</b> . Read-write. Reset: 0. Hardware Assertion error.		
10	<b>BBQ</b> . Read-write. Reset: 0. Branch buffer queue parity error.		
9	<b>SQ</b> . Read-write. Reset: 0. Scheduling queue parity error.		
8	STATQ. Read-write. Reset: 0. Retire status queue parity error.		
7	<b>RETDISP</b> . Read-write. Reset: 0. Retire dispatch queue parity error.		
6	CHKPTQ. Read-write. Reset: 0. CHKPTQ. Checkpoint queue parity error.		
5	PLDAL. Read-write. Reset: 0. EX payload parity error.		

4	PLDAG. Read-write. Reset: 0. Address generator payload parity error.
3	IDRF. Read-write. Reset: 0. Immediate displacement register file parity error.
2	<b>FRF</b> . Read-write. Reset: 0. Flag register file parity error.
1	<b>PRF</b> . Read-write. Reset: 0. Physical register file parity error.
0	WDT. Read-write. Reset: 0. Watchdog Timeout error.

#### 3.2.5.6 FP

1 0

MSR0000_0418MSRC000_2060 [FP Machine Check Control] (MCA::FP::MCA_CTL_FP)			
Read-write. Reset: 0000_0000_0000_0000h.			
0=Disables error reporting for the corresponding error. 1=Enables error reporting via machine check exception for the			
corresponding error. The MCA::FP::MCA_CTL_FP register must be enabled by the corresponding enable bit in			
Core::X86::Msr::MCG_CTL. Does not affect error detection, correction, or logging.			
_lthree[1:0]_core[3:0]_inst6_aliasMSRLEGACY; MSR0000_0418			
_lthree[1:0]_core[3:0]_inst6_aliasMSR; MSRC000_2060			
Bits Description			
63:7 Reserved.			
6 <b>HWA</b> . Read-write. Reset: 0. Hardware assertion.			
5 <b>SRF</b> . Read-write. Reset: 0. Status register file (SRF) parity error.			
4 <b>RQ</b> . Read-write. Reset: 0. Retire queue (RQ) parity error.			
3 <b>NSQ</b> . Read-write. Reset: 0. NSQ parity error.			

### MSR0000\_0419...MSRC000\_2061 [FP Machine Check Status Thread 0] (MCA::FP::MCA\_STATUS\_FP)

**SCH**. Read-write. Reset: 0. Schedule queue parity error. **FL**. Read-write. Reset: 0. Freelist (FL) parity error.

**PRF**. Read-write. Reset: 0. Physical register file (PRF) parity error.

	····		
Reset:	Cold,0000_0000_0000_0000h.		
Logs information associated with errors.			
	_lthree[1:0]_core[3:0]_thread[1:0]_inst6_aliasMSRLEGACY; MSR0000_0419		
	:0]_core[3:0]_thread[1:0]_inst6_aliasMSR; MSRC000_2061		
Bits	Description		
63	<b>Val</b> . Reset: Cold,0. 1=A valid error has been detected. This bit should be cleared by software after the register has been Read.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.		
62	<b>Overflow</b> . Reset: Cold,0. 1=An error was detected while the valid bit (Val) was set; at least one error was not		
	logged. Overflow is set independently of whether the existing error is overwritten. See 3.1.3 [Machine Check Errors].		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.		
61	UC. Reset: Cold,0. 1=The error was not corrected by hardware.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.		
60	<b>En</b> . Reset: Cold,0. 1=MCA error reporting is enabled for this error, as indicated by the corresponding bit in MCA::FP::MCA_CTL_FP. This bit is a copy of the bit in MCA::FP::MCA_CTL_FP for this error.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.		
59	<b>MiscV</b> . Reset: Cold,0. 1=Valid thresholding in MCA::FP::MCA_MISCO_FP. In certain modes, MISC registers are owned by platform firmware and will RAZ when Read by non-SMM code. Therefore, it is possible for MiscV == 1 and the MISC register to Read as all zeros.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.		
58	<b>AddrV</b> . Reset: Cold,0. 1=MCA::FP::MCA_ADDR_FP contains address information associated with the error.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.		
57	<b>PCC</b> . Reset: Cold,0. 1=Hardware context held by the processor may have been corrupted. Continued operation of		

	the system may have unpredictable results. The error is not recoverable or survivable, and the system should be reinitialized.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
56	ErrCoreIdVal. Reset: Cold,0. 1=The ErrCoreId field is valid.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
55	TCC. Reset: Cold,0. 1=Hardware context of the process thread to which the error was reported may have been
	corrupted. Continued operation of the thread may have unpredictable results. The thread must be terminated. Only
	meaningful when MCA::FP::MCA_STATUS_FP[PCC] == 0.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
54	RESERV4. Reset: Cold,0. MCA_STATUS Register Reserved bit.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
53	<b>SyndV</b> . Reset: Cold,0. 1=This error logged information in MCA::FP::MCA_SYND_FP. If
	MCA::FP::MCA_SYND_FP[ErrorPriority] is the same as the priority of the error in
	MCA::FP::MCA_STATUS_FP, then the information in MCA::FP::MCA_SYND_FP is associated with the error
	in MCA::FP::MCA_STATUS_FP.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
52	Reserved.
51:47	RESERV3. Reset: Cold,00h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
46	<b>CECC</b> . Reset: Cold,0. 1=The error was a correctable ECC error according to the restrictions of the ECC
	algorithm. UC indicates whether the error was actually corrected by the processor.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
45	<b>UECC</b> . Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC
	algorithm. UC indicates whether the error was actually corrected by the processor.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
44	<b>Deferred</b> . Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data
	error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is
	consumed.
40	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
43	<b>Poison</b> . Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.
10.11	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
42:41	RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.
- 10	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
40	<b>Scrub</b> . Reset: Cold,0. 1=The error was the result of a scrub operation.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
39:38	RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
37:32	<b>ErrCoreId</b> . Reset: Cold,00h. When (ErrCoreIdVal == 1), this field indicates which core within the processor is
	associated with the error. Otherwise, this field is Reserved.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
31:22	RESERVO. Reset: Cold,000h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
21:16	<b>ErrorCodeExt</b> . Reset: Cold,00h. Extended Error Code. This field is used to identify the error type for root cause
	analysis. This field indicates which bit position in MCA::FP::MCA_CTL_FP enables error reporting for the
	logged error.
45.0	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
15:0	<b>ErrorCode</b> . Reset: Cold,0000h. Error code for this error. See 3.1.3.3 [Error Codes] for details on decoding this
	field.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.

Table 50: MCA\_STATUS\_FP

Error Type	ErrorCode	UC	PCC	TCC	Deferred	Poison	AddrV
	Ext						
PRF	0x0	1	1	1	0	0	0
FL	0x1	1	1	1	0	0	0
SCH	0x2	1	1	1	0	0	0
NSQ	0x3	1	1	1	0	0	0
RQ	0x4	1	1	1	0	0	0
SRF	0x5	1	1	1	0	0	0
HWA	0x6	1	1	1	0	0	0

# MSR0000\_041A...MSRC000\_2062 [FP Machine Check Address Thread 0] (MCA::FP::MCA\_ADDR\_FP)

Montovo_v4niimioncovo_zvoz [11 Macinic Oncentadaress 1meda v] (Montin 1				
Read-only. Reset: Cold,0000_0000_0000_0000h.				
MCA::FP::MCA_ADDR_FP stores an address and other information associated with the error in				
MCA::FP::MCA_STATUS_FP. The register is only meaningful if MCA::FP::MCA_STATUS_FP[Val] == 1 and				
$MCA::FP::MCA\_STATUS\_FP[AddrV] == 1.$				
_lthree[1:0]_core[3:0]_thread[1:0]_inst6_aliasMSRLEGACY; MSR0000_041A				
_lthree[1:0]_core[3:0]_thread[1:0]_inst6_aliasMSR; MSRC000_2062				
Bits Description				
63:62 Reserved.				
61:56 <b>LSB</b> . Read-only. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in				
MCA::FP::MCA_ADDR_FP[ErrorAddr]. For example, a value of 0 indicates that				
MCA::FP::MCA_ADDR_FP[55:0] contains a valid byte address. A value of 6 indicates that				
MCA::FP::MCA_ADDR_FP[55:6] contains a valid cache line address and that MCA::FP::MCA_ADDR_FP[5:0]				
are not part of the address and should be ignored by error handling software. A value of 12 indicates that				
MCA::FP::MCA_ADDR_FP[55:12] contains a valid 4-KB memory page and that				
MCA::FP::MCA_ADDR_FP[11:0] should be ignored by error handling software.				
55:0 <b>ErrorAddr</b> . Read-only. Reset: Cold,00_0000_0000_0000h. Contains the address, if any, associated with the error				
logged in MCA::FP::MCA_STATUS_FP.				

# Table 51: MCA\_ADDR\_FP

Error Type	Bits	Description
PRF	[55:0	Reserved.
FL	[55:0	Reserved.
SCH	[55:0	Reserved.
NSQ	[55:0	Reserved.
RQ	[55:0	Reserved.
SRF	[55:0	Reserved.
HWA	[55:0	Reserved.

### MSR0000\_041B...MSRC000\_2063 [FP Machine Check Miscellaneous 0 Thread 0] (MCA::FP::MCA\_MISC0\_FP)

Log miscellaneous information associated with errors.			
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]_inst6_aliasMSRLEGACY; MSR0000_041B		
_lthree[1	_lthree[1:0]_core[3:0]_thread[1:0]_inst6_aliasMSR; MSRC000_2063		
Bits	Bits Description		
63	<b>Valid</b> . Reset: 1. 1=A valid CntP field is present in this register.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.		
62	<b>CntP</b> . Reset: 1. 1=A valid threshold counter is present.		
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.		
61	<b>Locked</b> . Reset: 0. 1=Writes to this register are ignored. This bit is set by BIOS to indicate that this register is not		
	available for OS use. BIOS should set this bit if ThresholdIntType is set to SMI.		

1	
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.
60	<b>IntP</b> . Reset: 1. 1=ThresholdIntType can be used to generate interrupts. 0=ThresholdIntType and interrupt
	generation are not supported.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::FP::MCA_MISC0_FP[Locked]) ? Read-write :
	Read-only.
59:56	Reserved.
55:52	<b>LvtOffset</b> . Reset: 0h. One per die. For error thresholding interrupts, specifies the address of the LVT entry in the
	APIC registers as follows: LVT address = (LvtOffset shifted left 4 bits) + 500h (see
	Core::X86::Apic::ExtendedInterruptLvtEntries).
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::FP::MCA_MISC0_FP[Locked]) ? Read-write :
	Read-only.
51	<b>CntEn</b> . Reset: 0. 1=Count thresholding errors.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::FP::MCA_MISC0_FP[Locked]) ? Read-write :
	Read-only.
50:49	
	00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI
	trigger event. 11b=Reserved.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::FP::MCA_MISC0_FP[Locked]) ? Read-write :
	Read-only.
48	<b>Ovrflw</b> . Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set,
	ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is
	generated.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::FP::MCA_MISC0_FP[Locked]) ? Read-write :
	Read-only.
	Reserved.
43:32	<b>ErrCnt</b> . Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is
	incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The
	threshold value, written by software, is (FFFh - the desired error count (the number of errors necessary in order
	for an interrupt to be taken)); the desired error count of 0 (a write value of FFFh) is not supported.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::FP::MCA_MISC0_FP[Locked]) ? Read-write :
24.2	Read-only.
	<b>BlkPtr</b> . Read-write. Reset: 00h. 00h=Extended MISC MSR block is not valid. 01h=Extended MSR block is valid.
23:0	Reserved.

### MSRC000 2064 [FP Machine Check Configuration] (MCA::FP::MCA CONFIG FP)

WISIX	2000_2004 [FF Machine Check Configuration] (MCAFFMCA_CONFIG_FF)		
Reset:	0000_0002_0000_0021h.		
Contro	Controls configuration of the associated machine check bank.		
_lthree[1	_lthree[1:0]_core[3:0]_inst6_aliasMSR; MSRC000_2064		
Bits	Description		
63:39	Reserved.		
38:37	<b>DeferredIntType</b> . Read-write. Reset: 0h. Specifies the type of interrupt signaled when a deferred error is logged. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[DeferredLvtOffset]). 10b=SMI trigger event. 11b=Reserved.		
36:33	Reserved.		
32	<b>McaXEnable</b> . Read-write. Reset: 0. Init: BIOS,1. Check: 1. 1=Software has acknowledged support for the MCAX feature set. 0=Software has not acknowledged support for the MCAX feature set. All uncorrected and fatal errors will cause an ErrorEvent packet to be generated. Deferred error interrupts are configured via Core::X86::Msr::McaIntrCfg.		
31:6	Reserved.		
5	<b>DeferredIntTypeSupported</b> . Read-only. Reset: 1. 1=MCA::FP::MCA_CONFIG_FP[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if		

	MCA::FP::MCA_CONFIG_FP[DeferredErrorLoggingSupported] == 1.
4:3	Reserved.
2	<b>DeferredErrorLoggingSupported</b> . Read-only. Reset: 0. 1=Deferred errors are supported in this MCA bank, and
	the LogDeferredInMcaStat field in this register controls the logging behavior of these errors. MCA_DESTAT and
	MCA_DEADDR are supported in this MCA bank. 0=Deferred errors are not supported in this bank.
1	Reserved.
0	<b>McaX</b> . Read-only. Reset: 1. 1=This bank provides Machine Check Architecture Extensions. Up to 4 additional
	MISC registers (MISC1-MISC4) are supported. MCA::FP::MCA_MISC0_FP[BlkPtr] indicates the presence of
	the additional MISC registers, but is not used to determine their MSR numbers. Deferred error interrupt type is
	specifiable by MCA bank. MCA::FP::MCA_STATUS_FP[TCC] is present.

# MSRC000\_2065 [FP IP Identification] (MCA::FP::MCA\_IPID\_FP)

/
Reset: 0006_00B0_0000_0000h.
The MCA::FP::MCA_IPID_FP register is used by software to determine what IP type and revision is associated with the
MCA bank.
lthree[1:0]_core[3:0]_inst6_aliasMSR; MSRC000_2065
Bits Description
McaType. Read-only. Reset: 0006h. The McaType of the MCA bank within this IP.
77:44 Reserved.
HardwareID. Read-only. Reset: 0B0h. The Hardware ID of the IP associated with this MCA bank.
31:0 <b>InstanceId</b> . Read-write. Reset: 0000_0000h. The instance ID of this IP. This is initialized to a unique ID per
instance of this register.

MSR	C000_2066 [FP Machine Check Syndrome Thread 0] (MCA::FP::MCA_SYND_FP)
Read-	write, Volatile. Reset: Cold, 0000_0000_0000_0000h.
Logs p	physical location information associated with the error in MCA::FP::MCA_STATUS_FP Thread 0.
_lthree[1	L:0]_core[3:0]_thread[1:0]_inst6_aliasMSR; MSRC000_2066
Bits	Description
63:33	Reserved.
32	<b>Syndrome</b> . Read-write, Volatile. Reset: Cold, 0. Contains the syndrome, if any, associated with the error logged in
	MCA::FP::MCA_STATUS_FP. The low-order bit of the syndrome is stored in bit[0], and the syndrome has a
	length specified by MCA::FP::MCA_SYND_FP[Length]. The Syndrome field is only valid when
	MCA::FP::MCA_SYND_FP[Length] != 0.
31:27	Reserved.
26:24	ErrorPriority. Read-write, Volatile. Reset: Cold,0h. Encodes the priority of the error logged in
	MCA::FP::MCA_SYND_FP. 000b=No error. 001b=Reserved. 010b=Corrected Error. 011b=Deferred Error.
	100b=Uncorrected Error. 101b=Fatal Error. 111b-110b=Reserved.
23:18	<b>Length</b> . Read-write, Volatile. Reset: Cold, 00h. Specifies the length in bits of the syndrome contained in
	MCA::FP::MCA_SYND_FP[Syndrome]. A value of 0 indicates that there is no valid syndrome in
	MCA::FP::MCA_SYND_FP. For example, a syndrome length of 9 means that
	MCA::FP::MCA_SYND_FP[Syndrome] bits[8:0] contains a valid syndrome.
17:0	<b>ErrorInformation</b> . Read-write, Volatile. Reset: Cold, 0_0000h. Contains error-specific information about the
	location of the error. Decoding is available in Table 52 [MCA_SYND_FP].

# Table 52: MCA\_SYND\_FP

Error Type	Bits	Description
PRF	[17:0]	Reserved.
FL	[17:0]	Reserved.
SCH	[17:0]	Reserved.
NSQ	[17:0]	Reserved.
RQ	[17:0]	Reserved.

SRF	[17:0]	Reserved.
HWA	[17:0]	Reserved.

MSR	MSRC001_0406 [FP Machine Check Control Mask] (MCA::FP::MCA_CTL_MASK_FP)				
Read-	write. Reset: 0000_0000_0000_0000h.				
Inhibi	t detection of an error source.				
_lthree[1	1:0]_core[3:0]_inst6_aliasMSR; MSRC001_0406				
Bits	Description				
63:7	Reserved.				
6	<b>HWA</b> . Read-write. Reset: 0. Init: BIOS,1. Hardware assertion.				
5	<b>SRF</b> . Read-write. Reset: 0. Status register file (SRF) parity error.				
4	RQ. Read-write. Reset: 0. Retire queue (RQ) parity error.				
3	NSQ. Read-write. Reset: 0. NSQ parity error.				
2	SCH. Read-write. Reset: 0. Schedule queue parity error.				
1	<b>FL</b> . Read-write. Reset: 0. Freelist (FL) parity error.				
0	<b>PRF</b> . Read-write. Reset: 0. Physical register file (PRF) parity error.				

#### 3.2.5.7 L3 Cache

MSR0	0000_041CMSRC000_20E0 (MCA::L3::MCA_CTL_L3)
Read-v	write. Reset: 0000_0000_0000_0000h.
_lthree0_	inst7_n0_aliasMSRLEGACY; MSR0000_041C
_lthree0_	_inst8_n1_aliasMSRLEGACY; MSR0000_0420
_lthree0_	_inst9_n2_aliasMSRLEGACY; MSR0000_0424
	_inst10_n3_aliasMSRLEGACY; MSR0000_0428
	inst7_n4_aliasMSRLEGACY; MSR0000_042C
	inst8_n5_aliasMSRLEGACY; MSR0000_0430
	inst9_n6_aliasMSRLEGACY; MSR0000_0434
	inst10_n7_aliasMSRLEGACY; MSR0000_0438
	inst7_n0_aliasMSR; MSRC000_2070
	_inst8_n1_aliasMSR; MSRC000_2080
	_inst9_n2_aliasMSR; MSRC000_2090
	inst10_n3_aliasMSR; MSRC000_20A0 inst7_n4_aliasMSR; MSRC000_20B0
	inst8_n5_aliasMSR; MSRC000_20C0
	insto_ns_anaswisk, iviskcooo_2000 inst9_n6_aliasMSR; MSRC000_20D0
	inst2_n0_anasW3R; M3RC000_20D0 inst10_n7_aliasMSR; MSRC000_20E0
	Description
63:8	Reserved.
7	<b>Hwa</b> . Read-write. Reset: 0. L3 Hardware Assertion.
6	XiVictimQueue. Read-write. Reset: 0. L3 Victim Queue Parity Error.
5	<b>SdpParity</b> . Read-write. Reset: 0. SDP Parity Error from XI.
4	DataArray. Read-write. Reset: 0. L3M Data ECC Error.
3	MultiHitTag. Read-write. Reset: 0. L3M Tag Multi-way-hit Error.
2	<b>Tag.</b> Read-write. Reset: 0. L3M Tag ECC Error.
1	MultiHitShadowTag. Read-write. Reset: 0. Shadow Tag Macro Multi-way-hit Error.
0	ShadowTag. Read-write. Reset: 0. Shadow Tag Macro ECC Error.

# MSR0000\_041D...MSRC000\_20E1 [L3 Machine Check Status] (MCA::L3::MCA\_STATUS\_L3)

Reset: Cold,0000_0000_0000_0000h.	
Logs information associated with errors.	
_lthree0_inst7_n0_aliasMSRLEGACY; MSR0000_041D	
_lthree0_inst8_n1_aliasMSRLEGACY; MSR0000_0421	

	_lthree0_inst9_n2_aliasMSRLEGACY; MSR0000_0425					
_lthree0_inst10_n3_aliasMSRLEGACY; MSR0000_0429 _lthree1_inst7_n4_aliasMSRLEGACY; MSR0000_042D						
	_ttiree1_inst/_n4_dnasMSRLEGAC1; MSR0000_042D _tthree1_inst8_n5_aliasMSRLEGACY; MSR0000_0431					
	_tthree1_inst9_n6_aliasMSRLEGACY; MSR0000_0435					
	_lthree1_inst10_n7_aliasMSRLEGACY; MSR0000_0439					
	inst7_n0_aliasMSR; MSRC000_2071					
	_inst8_n1_aliasMSR; MSRC000_2081					
	_inst9_n2_aliasMSR; MSRC000_2091					
	_inst10_n3_aliasMSR; MSRC000_20A1					
	_inst7_n4_aliasMSR; MSRC000_20B1					
	inst8_n5_aliasMSR; MSRC000_20C1 inst9_n6_aliasMSR; MSRC000_20D1					
	_inst10_n7_aliasMSR; MSRC000_20E1					
	Description					
63	-					
0.5	<b>Val</b> . Reset: Cold,0. 1=A valid error has been detected. This bit should be cleared by software after the register has					
	been Read.					
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.					
62	<b>Overflow</b> . Reset: Cold,0. 1=An error was detected while the valid bit (Val) was set; at least one error was not					
	logged. Overflow is set independently of whether the existing error is overwritten. See 3.1.3 [Machine Check					
	Errors].					
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.					
61	<b>UC.</b> Reset: Cold,0. 1=The error was not corrected by hardware.					
01	, and the state of					
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.					
60	<b>En</b> . Reset: Cold,0. 1=MCA error reporting is enabled for this error, as indicated by the corresponding bit in					
	MCA::L3::MCA_CTL_L3. This bit is a copy of the bit in MCA::L3::MCA_CTL_L3 for this error.					
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.					
59	<b>MiscV</b> . Reset: Cold,0. 1=Valid thresholding in MCA::L3::MCA_MISCO_L3. In certain modes, MISC registers					
	are owned by platform firmware and will RAZ when Read by non-SMM code. Therefore, it is possible for MiscV					
	== 1 and the MISC register to Read as all zeros.					
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.					
F0	· · ·					
58	<b>AddrV</b> . Reset: Cold,0. 1=MCA::L3::MCA_ADDR_L3 contains address information associated with the error.					
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.					
57	<b>PCC</b> . Reset: Cold,0. 1=Hardware context held by the processor may have been corrupted. Continued operation of					
	the system may have unpredictable results. The error is not recoverable or survivable, and the system should be					
	reinitialized.					
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.					
56	ErrCoreIdVal. Reset: Cold,0. 1=The ErrCoreId field is valid.					
30	·					
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.					
55	<b>TCC</b> . Reset: Cold,0. 1=Hardware context of the process thread to which the error was reported may have been					
	corrupted. Continued operation of the thread may have unpredictable results. The thread must be terminated. Only					
	meaningful when MCA::L3::MCA_STATUS_L3[PCC] == 0.					
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.					
54	RESERV4. Reset: Cold,0. MCA_STATUS Register Reserved bit.					
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.					
53	SyndV. Reset: Cold, 0. 1=This error logged information in MCA::L3::MCA_SYND_L3. If					
55						
	MCA::L3::MCA_SYND_L3[ErrorPriority] is the same as the priority of the error in					
	MCA::L3::MCA_STATUS_L3, then the information in MCA::L3::MCA_SYND_L3 is associated with the error					
	in MCA::L3::MCA_STATUS_L3.					
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.					
52	Reserved.					
51:47	RESERV3. Reset: Cold,00h. MCA_STATUS Register Reserved bits.					
51.47	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.					
	Access type. CoreAoowsinw Ck[wcstatuswren] : Reau-write : Reau,write-0-only,Error-on-write-1.					

46	<b>CECC</b> . Reset: Cold,0. 1=The error was a correctable ECC error according to the restrictions of the ECC
	algorithm. UC indicates whether the error was actually corrected by the processor.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
45	<b>UECC</b> . Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC
	algorithm. UC indicates whether the error was actually corrected by the processor.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
44	<b>Deferred</b> . Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data
	error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is
	consumed.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
43	<b>Poison</b> . Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
42:41	RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
40	<b>Scrub</b> . Reset: Cold,0. 1=The error was the result of a scrub operation.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
39:38	<b>RESERV1</b> . Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
37:32	<b>ErrCoreId</b> . Reset: Cold,00h. When (ErrCoreIdVal == 1), this field indicates which core within the processor is
	associated with the error. Otherwise, this field is Reserved.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
31:22	<b>RESERV0</b> . Reset: Cold,000h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
21:16	<b>ErrorCodeExt</b> . Reset: Cold,00h. Extended Error Code. This field is used to identify the error type for root cause
	analysis. This field indicates which bit position in MCA::L3::MCA_CTL_L3 enables error reporting for the
	logged error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
15:0	<b>ErrorCode</b> . Reset: Cold,0000h. Error code for this error. See 3.1.3.3 [Error Codes] for details on decoding this
	field.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.

### Table 53: MCA\_STATUS\_L3

Error Type	ErrorCode	UC	PCC	TCC	Deferred	Poison	AddrV
	Ext						
ShadowTag	0x0					-	-
MultiHitSha	0x1					-	-
dowTag							
Tag	0x2					_	-
MultiHitTag	0x3					-	-
DataArray	0x4					-	-
SdpParity	0x5					-	-
XiVictimQu	0x6					-	-
eue							
Hwa	0x7					-	-

### MSR0000\_041E...MSRC000\_20E2 [L3 Machine Check Address] (MCA::L3::MCA\_ADDR\_L3)

Reset: Cold,0000\_0000\_0000\_0000h.

MCA::L3::MCA\_ADDR\_L3 stores an address and other information associated with the error in

MCA::L3::MCA\_STATUS\_L3. The register is only meaningful if MCA::L3::MCA\_STATUS\_L3[Val] == 1 and

MCA::L3::MCA_STATUS_L3[AddrV] ==	1.
_lthree0_inst7_n0_aliasMSRLEGACY; MSR0000_041E	
_lthree0_inst8_n1_aliasMSRLEGACY; MSR0000_0422	
_lthree0_inst9_n2_aliasMSRLEGACY; MSR0000_0426	
_lthree0_inst10_n3_aliasMSRLEGACY; MSR0000_042A	
_lthree1_inst7_n4_aliasMSRLEGACY; MSR0000_042E	
_lthree1_inst8_n5_aliasMSRLEGACY; MSR0000_0432	
_lthree1_inst9_n6_aliasMSRLEGACY; MSR0000_0436	
_lthree1_inst10_n7_aliasMSRLEGACY; MSR0000_043A	
_lthree0_inst7_n0_aliasMSR; MSRC000_2072	
_lthree0_inst8_n1_aliasMSR; MSRC000_2082	
_lthree0_inst9_n2_aliasMSR; MSRC000_2092	
_lthree0_inst10_n3_aliasMSR; MSRC000_20A2	
_lthree1_inst7_n4_aliasMSR; MSRC000_20B2	
_lthree1_inst8_n5_aliasMSR; MSRC000_20C2	
_lthree1_inst9_n6_aliasMSR; MSRC000_20D2	
_lthree1_inst10_n7_aliasMSR; MSRC000_20E2	
Bits Description	
63:62 Reserved.	
61:56 <b>LSB</b> . Read-write, Volatile. Reset: Col	d,00h. Specifies the least significant valid bit of the address contained in
$MC\Delta \cdot I \cdot I \cdot I \cdot MC\Delta  \Delta DDR  I \cdot 3[Error \Delta I \cdot I$	
	ddr]. For example, a value of 0 indicates that
MCA::L3::MCA_ADDR_L3[55:0] o	ontains a valid byte address. A value of 6 indicates that
MCA::L3::MCA_ADDR_L3[55:0] o MCA::L3::MCA_ADDR_L3[55:6] o	ontains a valid byte address. A value of 6 indicates that ontains a valid cache line address and that MCA::L3::MCA_ADDR_L3[5:0]
MCA::L3::MCA_ADDR_L3[55:0] of MCA::L3::MCA_ADDR_L3[55:6] of are not part of the address and should	ontains a valid byte address. A value of 6 indicates that ontains a valid cache line address and that MCA::L3::MCA_ADDR_L3[5:0] be ignored by error handling software. A value of 12 indicates that
MCA::L3::MCA_ADDR_L3[55:0] of MCA::L3::MCA_ADDR_L3[55:6] of are not part of the address and should MCA::L3::MCA_ADDR_L3[55:12]	ontains a valid byte address. A value of 6 indicates that ontains a valid cache line address and that MCA::L3::MCA_ADDR_L3[5:0] be ignored by error handling software. A value of 12 indicates that contains a valid 4-KB memory page and that
MCA::L3::MCA_ADDR_L3[55:0] of MCA::L3::MCA_ADDR_L3[55:6] of are not part of the address and should MCA::L3::MCA_ADDR_L3[55:12] MCA::L3::MCA_ADDR_L3[11:0] s	ontains a valid byte address. A value of 6 indicates that ontains a valid cache line address and that MCA::L3::MCA_ADDR_L3[5:0] be ignored by error handling software. A value of 12 indicates that contains a valid 4-KB memory page and that hould be ignored by error handling software.
MCA::L3::MCA_ADDR_L3[55:0] of MCA::L3::MCA_ADDR_L3[55:6] of are not part of the address and should MCA::L3::MCA_ADDR_L3[55:12] MCA::L3::MCA_ADDR_L3[11:0] of S5:0  ErrorAddr. Read-write, Volatile. Re	ontains a valid byte address. A value of 6 indicates that ontains a valid cache line address and that MCA::L3::MCA_ADDR_L3[5:0] be ignored by error handling software. A value of 12 indicates that contains a valid 4-KB memory page and that hould be ignored by error handling software.  Set: Cold,00_0000_0000_0000h. Unless otherwise specified by an error,
MCA::L3::MCA_ADDR_L3[55:0] of MCA::L3::MCA_ADDR_L3[55:6] of are not part of the address and should MCA::L3::MCA_ADDR_L3[55:12] MCA::L3::MCA_ADDR_L3[11:0] of ErrorAddr. Read-write, Volatile. Recontains the address associated with	ontains a valid byte address. A value of 6 indicates that ontains a valid cache line address and that MCA::L3::MCA_ADDR_L3[5:0] be ignored by error handling software. A value of 12 indicates that contains a valid 4-KB memory page and that hould be ignored by error handling software.

# Table 54: MCA\_ADDR\_L3

Error Type	Bits	Description
ShadowTag	[55:16]	Reserved.
	[15:0]	16'b{8'b{Index}, 2'b{Slice}, 6'b{0}}
MultiHitShadowTag [55:16]		Reserved.
	[15:0]	16'b{8'b{Index}, 2'b{Slice}, 6'b{0}}
Tag	[55:19]	Reserved.
	[18:0]	19'b{1'b{Bank[3]}, 7'b{Index}, 3'b{Bank[2:0]}, 2'b{slice},
		6'b{0}}
MultiHitTag	[55:19]	Reserved.
	[18:0]	19'b{1'b{Bank[3]}, 7'b{Index}, 3'b{Bank[2:0]}, 2'b{slice},
		6'b{0}}
DataArray	[55:48]	Reserved.
	[47:0]	Physical Address.
SdpParity	[55:48]	Reserved.
	[47:0]	Physical Address.
XiVictimQueue	[55:48]	Reserved.
	[47:0]	Physical Address.
Hwa	[55:34]	Reserved.
	[33:0]	Reserved.

# MSR0000\_041F...MSRC000\_20E3 [L3 Machine Check Miscellaneous 0] (MCA::L3::MCA\_MISC0\_L3)

Log miscellaneous information associated with errors.

	_inst7_n0_aliasMSRLEGACY; MSR0000_041F
	_inst8_n1_aliasMSRLEGACY; MSR0000_0423
	_inst9_n2_aliasMSRLEGACY; MSR0000_0427
	_inst10_n3_aliasMSRLEGACY; MSR0000_042B
	_inst7_n4_aliasMSRLEGACY; MSR0000_042F
	_inst8_n5_aliasMSRLEGACY; MSR0000_0433
	_inst9_n6_aliasMSRLEGACY; MSR0000_0437 _inst10_n7_aliasMSRLEGACY; MSR0000_043B
	inst7_n0_aliasMSR; MSRC000_2073
	inst8_n1_aliasMSR; MSRC000_2083
	inst9_n2_aliasMSR; MSRC000_2093
	_inst10_n3_aliasMSR; MSRC000_20A3
	inst7_n4_aliasMSR; MSRC000_20B3
	_inst8_n5_aliasMSR; MSRC000_20C3
	_inst9_n6_aliasMSR; MSRC000_20D3
	_inst10_n7_aliasMSR; MSRC000_20E3
Bits	Description
63	<b>Valid</b> . Reset: 1. 1=A valid CntP field is present in this register.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.
62	
62	CntP. Reset: 1. 1=A valid threshold counter is present.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.
61	<b>Locked</b> . Reset: 0. 1=Writes to this register are ignored. This bit is set by BIOS to indicate that this register is not
	available for OS use. BIOS should set this bit if ThresholdIntType is set to SMI.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.
60	<b>IntP</b> . Reset: 1. 1=ThresholdIntType can be used to generate interrupts. 0=ThresholdIntType and interrupt
00	
	generation are not supported.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISC0_L3[Locked]) ? Read-write :
	Read-only.
59:56	Reserved.
55.52	<b>LvtOffset</b> . Reset: 0h. One per die. For error thresholding interrupts, specifies the address of the LVT entry in the
00.02	APIC registers as follows: LVT address = (LvtOffset shifted left 4 bits) + 500h (see
	Core::X86::Apic::ExtendedInterruptLvtEntries).
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISC0_L3[Locked]) ? Read-write :
	Read-only.
51	CntEn. Reset: 0. 1=Count thresholding errors.
	Citch. Reset. 0. 1—Count thresholding chois.
	· ·
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISC0_L3[Locked]) ? Read-write :
F0.40	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISC0_L3[Locked]) ? Read-write : Read-only.
50:49	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISC0_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1.
50:49	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only. <b>ThresholdIntType</b> . Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI
50:49	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISC0_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1.
50:49	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only. <b>ThresholdIntType</b> . Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.
50:49	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only. <b>ThresholdIntType</b> . Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write :
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.
50:49	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Ovrflw. Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set,
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Ovrflw. Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Ovrflw. Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is generated.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Ovrflw. Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is generated.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write :
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Ovrflw. Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is generated.
48	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Ovrflw. Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is generated.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.
48	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Ovrflw. Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is generated.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Reserved.
48	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Ovrflw. Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is generated.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Reserved.  ErrCnt. Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is
48	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Ovrflw. Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is generated.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Reserved.  ErrCnt. Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The
48	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Ovrflw. Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is generated.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Reserved.  ErrCnt. Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The threshold value, written by software, is (FFFh - the desired error count (the number of errors necessary in order
48	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Ovrflw. Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is generated.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Reserved.  ErrCnt. Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The threshold value, written by software, is (FFFh - the desired error count (the number of errors necessary in order for an interrupt to be taken)); the desired error count of 0 (a write value of FFFh) is not supported.
48	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Ovrflw. Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is generated.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Reserved.  ErrCnt. Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The threshold value, written by software, is (FFFh - the desired error count (the number of errors necessary in order
48	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  ThresholdIntType. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI trigger event. 11b=Reserved.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Ovrflw. Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is generated.  AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::L3::MCA_MISCO_L3[Locked]) ? Read-write : Read-only.  Reserved.  ErrCnt. Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The threshold value, written by software, is (FFFh - the desired error count (the number of errors necessary in order for an interrupt to be taken)); the desired error count of 0 (a write value of FFFh) is not supported.

31:24	BlkPtr. Read-write. Reset: 00h. 00h=Extended MISC MSR block is not valid. 01h=Extended MSR block is valid.
23:0	Reserved.

23:0 Reserved.			
MSRO	C000_20[7E]4 [L3 Machine Check Configuration] (MCA::L3::MCA_CONFIG_L3)		
	0000_0000_0000_0025h.		
Controls configuration of the associated machine check bank.			
	inst7_n0_aliasMSR; MSRC000_2074		
_lthree0_	inst8_n1_aliasMSR; MSRC000_2084		
	inst9_n2_aliasMSR; MSRC000_2094		
	inst10_n3_aliasMSR; MSRC000_20A4		
	inst7_n4_aliasMSR; MSRC000_20B4 inst8_n5_aliasMSR; MSRC000_20C4		
	inst9_n6_aliasMSR; MSRC000_20D4		
	inst10_n7_aliasMSR; MSRC000_20E4		
Bits	Description		
63:39	Reserved.		
38:37	<b>DeferredIntType</b> . Read-write. Reset: 0h. Specifies the type of interrupt signaled when a deferred error is logged. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[DeferredLvtOffset]). 10b=SMI trigger event. 11b=Reserved.		
36:35	Reserved.		
34	LogDeferredInMcaStat. Read-write. Reset: 0. Init: BIOS,1. 1=Log deferred errors in MCA::L3::MCA_STATUS_L3 and MCA::L3::MCA_ADDR_L3 in addition to MCA::L3::MCA_DESTAT_L3 and MCA::L3::MCA_DEADDR_L3. 0=Only log deferred errors in MCA::L3::MCA_DESTAT_L3 and MCA::L3::MCA_DEADDR_L3. This bit does not affect logging of deferred errors in MCA::L3::MCA_SYND_L3, MCA::L3::MCA_MISCO_L3.		
33	Reserved.		
32	<b>McaXEnable</b> . Read-write. Reset: 0. Init: BIOS,1. Check: 1. 1=Software has acknowledged support for the MCAX feature set. 0=Software has not acknowledged support for the MCAX feature set. All uncorrected and fatal errors will cause an ErrorEvent packet to be generated. Deferred error interrupts are configured via Core::X86::Msr::McaIntrCfg.		
31:6	Reserved.		
5	<b>DeferredIntTypeSupported</b> . Read-only. Reset: 1. 1=MCA::L3::MCA_CONFIG_L3[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if MCA::L3::MCA_CONFIG_L3[DeferredErrorLoggingSupported] == 1.		
4:3	Reserved.		
2	<b>DeferredErrorLoggingSupported</b> . Read-only. Reset: 1. 1=Deferred errors are supported in this MCA bank, and MCA::L3::MCA_CONFIG_L3[LogDeferredInMcaStat] controls the logging behavior of these errors. MCA::L3::MCA_DESTAT_L3 and MCA::L3::MCA_DEADDR_L3 are supported in this MCA bank. 0=Deferred errors are not supported in this bank.		
1	Reserved.		
0	<b>McaX</b> . Read-only. Reset: 1. 1=This bank provides Machine Check Architecture Extensions. Up to 4 additional MISC registers (MISC1-MISC4) are supported. MCA::L3::MCA_MISC0_L3[BlkPtr] indicates the presence of the additional MISC registers, but is not used to determine their MSR numbers. Deferred error interrupt type is		

# MSRC000\_20[7...E]5 [L3 IP Identification] (MCA::L3::MCA\_IPID\_L3)

specifiable by MCA bank. MCA::L3::MCA\_STATUS\_L3[TCC] is present.

Reset: 0007_00B0_0000_0000h.
The MCA::L3::MCA_IPID_L3 register is used by software to determine what IP type and revision is associated with the
MCA bank.
_lthree0_inst7_n0_aliasMSR; MSRC000_2075
_lthree0_inst8_n1_aliasMSR; MSRC000_2085
_lthree0_inst9_n2_aliasMSR; MSRC000_2095
_lthree0_inst10_n3_aliasMSR; MSRC000_20A5
lthree1 inst7 n4 aliasMSR; MSRC000 20B5

_lthree1_inst8_n5_aliasMSR; MSRC000_20C5			
_lthree1_inst9_n6_aliasMSR; MSRC000_20D5			
_lthree1_	_lthree1_inst10_n7_aliasMSR; MSRC000_20E5		
Bits	Description		
63:48	<b>McaType</b> . Read-only. Reset: 0007h. The McaType of the MCA bank within this IP.		
47:44	Reserved.		
43:32	<b>HardwareID</b> . Read-only. Reset: 0B0h. The Hardware ID of the IP associated with this MCA bank.		
31:0	<b>InstanceId</b> . Read-write. Reset: 0000_0000h. The instance ID of this IP. This is initialized to a unique ID per		
	instance of this register.		
	Init: _lthree0_inst7_n0_aliasMSR: 2035_0000h		
	Init: _lthree0_inst8_n1_aliasMSR: 2035_0100h		
	Init: _lthree0_inst9_n2_aliasMSR: 2035_0200h		
	Init: _lthree0_inst10_n3_aliasMSR: 2035_0300h		
	Init: _lthree1_inst7_n4_aliasMSR: 2075_0000h		
	Init: _lthree1_inst8_n5_aliasMSR: 2075_0100h		
	Init: _lthree1_inst9_n6_aliasMSR: 2075_0200h		
	Init: _lthree1_inst10_n7_aliasMSR: 2075_0300h		

# MSRC000\_20[7...E]6 [L3 Machine Check Syndrome] (MCA::L3::MCA\_SYND\_L3)

Read-	write, Volatile. Reset: Cold, 0000_0000_0000_0000h.
Logs p	physical location information associated with the error in MCA::L3::MCA_STATUS_L3 Thread 0.
_lthree0_	_inst7_n0_aliasMSR; MSRC000_2076
	_inst8_n1_aliasMSR; MSRC000_2086
	_inst9_n2_aliasMSR; MSRC000_2096
	_inst10_n3_aliasMSR; MSRC000_20A6
	_inst7_n4_aliasMSR; MSRC000_20B6
	_inst8_n5_aliasMSR; MSRC000_20C6 _inst9_n6_aliasMSR; MSRC000_20D6
	inst10_n7_aliasMSR; MSRC000_20E6
	<b>Description</b>
63:49	Reserved.
48:32	<b>Syndrome</b> . Read-write, Volatile. Reset: Cold, 0_0000h. Contains the syndrome, if any, associated with the error
	logged in MCA::L3::MCA_STATUS_L3. The low-order bit of the syndrome is stored in bit[0], and the syndrome
	has a length specified by MCA::L3::MCA_SYND_L3[Length]. The Syndrome field is only valid when
	MCA::L3::MCA_SYND_L3[Length] != 0.
31:27	Reserved.
26:24	<b>ErrorPriority</b> . Read-write, Volatile. Reset: Cold,0h. Encodes the priority of the error logged in
	MCA::L3::MCA_SYND_L3. 000b=No error. 001b=Reserved. 010b=Corrected Error. 011b=Deferred Error.
	100b=Uncorrected Error. 101b=Fatal Error. 111b-110b=Reserved.
23:18	<b>Length</b> . Read-write, Volatile. Reset: Cold, 00h. Specifies the length in bits of the syndrome contained in
	MCA::L3::MCA_SYND_L3[Syndrome]. A value of 0 indicates that there is no valid syndrome in
	MCA::L3::MCA_SYND_L3. For example, a syndrome length of 9 means that
	MCA::L3::MCA_SYND_L3[Syndrome] bits[8:0] contains a valid syndrome.
17:0	·
26:24	Reserved.  ErrorPriority. Read-write, Volatile. Reset: Cold,0h. Encodes the priority of the error logged in MCA::L3::MCA_SYND_L3. 000b=No error. 001b=Reserved. 010b=Corrected Error. 011b=Deferred Error. 100b=Uncorrected Error. 101b=Fatal Error. 111b-110b=Reserved.  Length. Read-write, Volatile. Reset: Cold,00h. Specifies the length in bits of the syndrome contained in MCA::L3::MCA_SYND_L3[Syndrome]. A value of 0 indicates that there is no valid syndrome in MCA::L3::MCA_SYND_L3. For example, a syndrome length of 9 means that

# Table 55: MCA\_SYND\_L3

Error Type	Bits	Description
ShadowTag	[17:12]	Reserved.
	[11:8]	Pack.
	[7:3]	Reserved.
	[2:0]	Way.
MultiHitShadowTag	[17:12]	Reserved.
	[11:8]	Pack.

	[7:0]	Reserved.
Tag	[17:12]	Reserved.
	[11:8]	Bank.
	[7:0]	Way.
MultiHitTag	[17:0]	Reserved.
DataArray	[17:12]	Reserved.
	[11:8]	Bank[2:0].
	[7:3]	Reserved.
	[2:0]	Way.
SdpParity	[17:0]	Reserved.
XiVictimQueue	[17:0]	Reserved.
Hwa	[17:0]	Reserved.

## MSRC000\_20[7...E]8 [L3 Machine Check Deferred Error Status] (MCA::L3::MCA\_DESTAT\_L3)

MSR	C000_20[7E]8 [L3 Machine Check Deferred Error Status] (MCA::L3::MCA_DESTAT_L3)		
Read-	write, Volatile. Reset: Cold, 0000_0000_0000h.		
Holds	olds status information for the first deferred error seen in this bank.		
_lthree0_	_lthree0_inst7_n0_aliasMSR; MSRC000_2078		
_lthree0_inst8_n1_aliasMSR; MSRC000_2088			
	_lthree0_inst9_n2_aliasMSR; MSRC000_2098		
	_lthree0_inst10_n3_aliasMSR; MSRC000_20A8		
	_lthree1_inst7_n4_aliasMSR; MSRC000_20B8		
	inst8_n5_aliasMSR; MSRC000_20C8 inst9_n6_aliasMSR; MSRC000_20D8		
	_inst10_n7_aliasMSR; MSRC000_20E8		
Bits	Description		
63	<b>Val</b> . Read-write, Volatile. Reset: Cold, 0. 1=A valid error has been detected (whether it is enabled or not).		
62	<b>Overflow</b> . Read-write, Volatile. Reset: Cold, 0. 1=An error was detected while the valid bit (Val) was set; at least		
	one error was not logged. Overflow is set independently of whether the existing error is overwritten. (See the		
	section on overwrite priorities.)		
61:59	Reserved.		
58	<b>AddrV</b> . Read-write, Volatile. Reset: Cold, 0. 1=MCA::L3::MCA_DEADDR_L3 contains address information		
	associated with the error.		
57:54	Reserved.		
53	<b>SyndV</b> . Read-write, Volatile. Reset: Cold, 0. 1=This error logged information in MCA::L3::MCA_SYND_L3. If		
	MCA::L3::MCA_SYND_L3[ErrorPriority] is the same as the priority of the error in		
	MCA::L3::MCA_STATUS_L3, then the information in MCA::L3::MCA_SYND_L3 is associated with the error		
	in MCA::L3::MCA_DESTAT_L3.		
52:45	Reserved.		
44	<b>Deferred</b> . Read-write, Volatile. Reset: Cold, 0. 1=A deferred error was created. A deferred error is the result of an		
	uncorrectable data error which did not immediately cause a processor exception; poison is created and an		
	exception is deferred until the poison data is consumed.		
43:0	Reserved.		

MSRC000_20[7E]9 [L3 Deferred Error Address] (MCA::L3::MCA_DEADDR_L3)		
Reset: Cold,0000_0000_0000_0000h.		
The MCA::L3::MCA_DEADDR_L3 register stores the address associated with the error in		
MCA::L3::MCA_DESTAT_L3. The register is only meaningful if MCA::L3::MCA_DESTAT_L3[Val] == 1 and		
MCA::L3::MCA_DESTAT_L3[AddrV] == 1. The lowest valid bit of the address is defined by		
MCA::L3::MCA_DEADDR_L3[LSB].		
_lthree0_inst7_n0_aliasMSR; MSRC000_2079		
_lthree0_inst8_n1_aliasMSR; MSRC000_2089		
_lthree0_inst9_n2_aliasMSR; MSRC000_2099		
_lthree0_inst10_n3_aliasMSR; MSRC000_20A9		

_lthree1_inst7_n4_aliasMSR; MSRC000_20B9			
_lthree1_inst8_n5_aliasMSR; MSRC000_20C9			
_lthree1_	_lthree1_inst9_n6_aliasMSR; MSRC000_20D9		
_lthree1_	_lthree1_inst10_n7_aliasMSR; MSRC000_20E9		
Bits	Description		
63:62	Reserved.		
61:56	<b>LSB</b> . Read-write, Volatile. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in		
	MCA::L3::MCA_DEADDR_L3[ErrorAddr]. For example, a value of 0 indicates that		
	MCA::L3::MCA_DEADDR_L3[55:0] contains a valid byte address. A value of 6 indicates that		
	MCA::L3::MCA_DEADDR_L3[55:6] contains a valid cache line address and that		
	MCA::L3::MCA_DEADDR_L3[5:0] are not part of the address and should be ignored by error handling		
	software. A value of 12 indicates that MCA::L3::MCA_DEADDR_L3[55:12] contains a valid 4-KB memory		
	page and that MCA::L3::MCA_DEADDR_L3[11:0] should be ignored by error handling software.		
55:0	<b>ErrorAddr</b> . Read-write, Volatile. Reset: Cold,00_0000_0000h. Contains the address, if any, associated with		
	the error logged in MCA::L3::MCA_DESTAT_L3. The lowest-order valid bit of the address is specified in		
	MCA::L3::MCA_DEADDR_L3[LSB].		

# MSRC001\_040[7...E] [L3 Machine Check Control Mask] (MCA::L3::MCA\_CTL\_MASK\_L3)

Read-	Read-write. Reset: 0000_0000_0000h.		
Inhibi	t detection of an error source.		
_lthree0	_lthree0_inst7_n0_aliasMSR; MSRC001_0407		
_lthree0	_inst8_n1_aliasMSR; MSRC001_0408		
_lthree0	_inst9_n2_aliasMSR; MSRC001_0409		
	_inst10_n3_aliasMSR; MSRC001_040A		
	_inst7_n4_aliasMSR; MSRC001_040B		
	_inst8_n5_aliasMSR; MSRC001_040C		
	_inst9_n6_aliasMSR; MSRC001_040D		
	_inst10_n7_aliasMSR; MSRC001_040E		
Bits	Description		
63:8	Reserved.		
7	<b>Hwa</b> . Read-write. Reset: 0. Init: BIOS,1. L3 Hardware Assertion.		
6	XiVictimQueue. Read-write. Reset: 0. L3 Victim Queue Parity Error.		
5	SdpParity. Read-write. Reset: 0. SDP Parity Error from XI.		
4	DataArray. Read-write. Reset: 0. L3M Data ECC Error.		
3	MultiHitTag. Read-write. Reset: 0. L3M Tag Multi-way-hit Error.		
2	Tag. Read-write. Reset: 0. L3M Tag ECC Error.		
1	MultiHitShadowTag. Read-write. Reset: 0. Shadow Tag Macro Multi-way-hit Error.		
0	ShadowTag. Read-write. Reset: 0. Shadow Tag Macro ECC Error.		

#### 3.2.5.8 CS

#### MSR0000 044C...MSRC000 2140 [CS Machine Check Control] (MCA::CS::MCA\_CTL\_CS)

MOROUU [GO Machine Check Control] (MG/1COMG/1_G1E_GS)
Read-write. Reset: 0000_0000_0000_0000h.
0=Disables error reporting for the corresponding error. 1=Enables error reporting via machine check exception for the
corresponding error. The MCA::CS::MCA_CTL_CS register must be enabled by the corresponding enable bit in
Core::X86::Msr::MCG_CTL. Does not affect error detection, correction, or logging.
_instCS0_n0_aliasMSRLEGACY; MSR0000_044C
_instCS1_n1_aliasMSRLEGACY; MSR0000_0450
_instCS0_n0_aliasMSR; MSRC000_2130
_instCS1_n1_aliasMSR; MSRC000_2140
Bits Description
63:14 Reserved.
13 <b>CNTR_UNFL</b> . Read-write. Reset: 0. Counter underflow error.

12	CNTR_OVFL. Read-write. Reset: 0. Counter overflow error.
11	SDP_UNEXP_RETRY. Read-write. Reset: 0. SDP Read response had an unexpected RETRY error.
10	<b>SPF_ECC_ERR</b> . Read-write. Reset: 0. Probe Filter ECC Error: An ECC error occurred on a probe filter access.
9	<b>SPF_PRT_ERR</b> . Read-write. Reset: 0. Probe Filter Protocol Error: Indicates a Cache Coherence Issue.
8	<b>SDP_RSP_NO_MTCH</b> . Read-write. Reset: 0. SDP Read response had no match in the CS queue.
7	ATM_PAR_ERR. Read-write. Reset: 0. Atomic Request Parity Error: Parity error on Read of an atomic
	transaction.
6	SDP_PAR_ERR. Read-write. Reset: 0. Read Response Parity Error. Parity error on incoming Read response
	data.
5	<b>FTI_PAR_ERR</b> . Read-write. Reset: 0. Request or Probe Parity Error: Parity error on incoming request or probe
	response data.
4	<b>FTI_RSP_NO_MTCH</b> . Read-write. Reset: 0. Unexpected Response: A response was received from the transport
	layer which does not match any request.
3	<b>FTI_ILL_RSP</b> . Read-write. Reset: 0. Illegal Response: An illegal response was received from the transport layer.
2	<b>FTI_SEC_VIOL</b> . Read-write. Reset: 0. Security Violation: A security violation was received from the transport
	layer.
1	FTI_ADDR_VIOL. Read-write. Reset: 0. Address Violation: An address violation was received from the
	transport layer.
0	FTI_ILL_REQ. Read-write. Reset: 0. Illegal Request: An illegal request was received from the transport layer.

# MSR0000 044D...MSRC000 2141 [CS Machine Check Status] (MCA::CS::MCA STATUS CS)

MSR	0000_044DMSRC000_2141 [CS Machine Check Status] (MCA::CS::MCA_STATUS_CS)			
Reset:	Cold,0000_0000_0000_0000h.			
Logs information associated with errors.				
_	_n0_aliasMSRLEGACY; MSR0000_044D			
	_n1_aliasMSRLEGACY; MSR0000_0451			
	_n0_aliasMSR; MSRC000_2131 _n1_aliasMSR; MSRC000_2141			
	Description Called the Market State of the Mar			
63	<b>Val</b> . Reset: Cold,0. 1=A valid error has been detected. This bit should be cleared by software after the register has been Read.			
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.			
62	<b>Overflow</b> . Reset: Cold,0. 1=An error was detected while the valid bit (Val) was set; at least one error was not			
	logged. Overflow is set independently of whether the existing error is overwritten. See 3.1.3 [Machine Check Errors].			
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.			
61	UC. Reset: Cold,0. 1=The error was not corrected by hardware.			
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.			
60	<b>En</b> . Reset: Cold,0. 1=MCA error reporting is enabled for this error, as indicated by the corresponding bit in			
	MCA::CS::MCA_CTL_CS. This bit is a copy of the bit in MCA::CS::MCA_CTL_CS for this error.			
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.			
59	<b>MiscV</b> . Reset: Cold,0. 1=Valid thresholding in MCA::CS::MCA_MISCO_CS. In certain modes, MISC registers			
	are owned by platform firmware and will RAZ when Read by non-SMM code. Therefore, it is possible for MiscV			
	== 1 and the MISC register to Read as all zeros.			
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.			
58	<b>AddrV</b> . Reset: Cold,0. 1=MCA::CS::MCA_ADDR_CS contains address information associated with the error.			
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.			
57	<b>PCC</b> . Reset: Cold,0. 1=Hardware context held by the processor may have been corrupted. Continued operation of			
	the system may have unpredictable results. The error is not recoverable or survivable, and the system should be			
	reinitialized.			
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.			
56	ErrCoreIdVal. Reset: Cold,0. 1=The ErrCoreId field is valid.			
	ı			

	A googe Type, Cover, VOC, Marry HV/CD[McStatus WEn] 2 Dood verito, Dood Write O only Error on verite 1
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
55	<b>TCC</b> . Reset: Cold,0. 1=Hardware context of the process thread to which the error was reported may have been
	corrupted. Continued operation of the thread may have unpredictable results. The thread must be terminated. Only meaningful when MCA::CS::MCA_STATUS_CS[PCC] == 0.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
E 4	<b>RESERV4</b> . Reset: Cold,0. MCA_STATUS Register Reserved bit.
54	
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
53	<b>SyndV</b> . Reset: Cold,0. 1=This error logged information in MCA::CS::MCA_SYND_CS. If
	MCA::CS::MCA_SYND_CS[ErrorPriority] is the same as the priority of the error in MCA::CS::MCA_STATUS_CS, then the information in MCA::CS::MCA_SYND_CS is associated with the error
	in MCA::CS::MCA_STATUS_CS.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
52	Reserved.
51:47	RESERV3. Reset: Cold,00h. MCA_STATUS Register Reserved bits.
31.4/	Ţ
46	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.  CECC. Reset: Cold,0. 1=The error was a correctable ECC error according to the restrictions of the ECC
46	algorithm. UC indicates whether the error was actually corrected by the processor.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
45	<b>UECC.</b> Reset: Cold, 0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC
45	algorithm. UC indicates whether the error was actually corrected by the processor.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
44	<b>Deferred</b> . Reset: Cold, 0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data
7-7	error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is
	consumed.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
43	<b>Poison</b> . Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
42:41	RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
40	<b>Scrub</b> . Reset: Cold,0. 1=The error was the result of a scrub operation.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
39:38	RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
37:32	
	associated with the error. Otherwise, this field is Reserved.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
31:22	RESERVO. Reset: Cold,000h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
21:16	<b>ErrorCodeExt</b> . Reset: Cold,00h. Extended Error Code. This field is used to identify the error type for root cause
	analysis. This field indicates which bit position in MCA::CS::MCA_CTL_CS enables error reporting for the
	logged error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
15:0	<b>ErrorCode</b> . Reset: Cold,0000h. Error code for this error. See 3.1.3.3 [Error Codes] for details on decoding this field.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
	1. Tecus Type: Goten toom in the Grante Guide Titaling . Tecus write a feet of only, Entor-On-Wille-1.

# *Table 56: MCA\_STATUS\_CS*

Error Type ErrorCode Ext	JC PCC	TCC	Deferred	Poison	AddrV
--------------------------	--------	-----	----------	--------	-------

		,					
FTI_ILL_RE	0x0	0	0	0	1	0	1
Q							
FTI_ADDR_	0x1	0	0	0	1	0	1
VIOL							
FTI_SEC_V	0x2	0	0	0	1	0	1
IOL							
FTI_ILL_RS	0x3	1	1	1	0	0	0
P							
FTI_RSP_N	0x4	1	1	1	0	0	0
O_MTCH							
FTI_PAR_E	0x5	0	0	0	1	0	1
RR							
SDP_PAR_E	0x6	0	0	0	1	0	1
RR							
ATM_PAR_	0x7	0	0	0	1	0	1
ERR							
SDP_RSP_N	0x8	1	1	1	0	0	0
O_MTCH							
SPF_PRT_E	0x9	1	1	1	0	0	0
RR							
SPF_ECC_E	0xA	0	0	0	0	0	1
RR							
SDP_UNEX	0xB	1	1	1	0	0	1
P_RETRY							
CNTR_OVF	0xC	1	1	1	0	0	0
L							
CNTR_UNF	0xD	1	1	1	0	0	0
L							
· · · · · · · · · · · · · · · · · · ·	·	·	·	·	·	·	·

# MSR0000\_044E...MSRC000\_2142 [CS Machine Check Address] (MCA::CS::MCA\_ADDR\_CS)

Reset:	Cold,0000_0000_0000h.
MCA:	::CS::MCA_ADDR_CS stores an address and other information associated with the error in
MCA:	::CS::MCA_STATUS_CS. The register is only meaningful if MCA::CS::MCA_STATUS_CS[Val] == 1 and
MCA:	::CS::MCA_STATUS_CS[AddrV] == 1.
_instCS(	O_nO_aliasMSRLEGACY; MSR0000_044E
_instCS1	1_n1_aliasMSRLEGACY; MSR0000_0452
	0_n0_aliasMSR; MSRC000_2132
_instCS1	1_n1_aliasMSR; MSRC000_2142
Bits	Description
63:62	Reserved.
61:56	<b>LSB</b> . Read-write, Volatile. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in
	MCA::CS::MCA_ADDR_CS[ErrorAddr]. For example, a value of 0 indicates that
	MCA::CS::MCA_ADDR_CS[55:0] contains a valid byte address. A value of 6 indicates that
	MCA::CS::MCA_ADDR_CS[55:6] contains a valid cache line address and that
	MCA::CS::MCA_ADDR_CS[5:0] are not part of the address and should be ignored by error handling software. A
	value of 12 indicates that MCA::CS::MCA_ADDR_CS[55:12] contains a valid 4-KB memory page and that
	MCA::CS::MCA_ADDR_CS[11:0] should be ignored by error handling software.
55:0	<b>ErrorAddr</b> . Read-write, Volatile. Reset: Cold, 00_0000_0000_0000h. Unless otherwise specified by an error,
	contains the address associated with the error logged in MCA::CS::MCA_STATUS_CS. For physical addresses,
	the most significant bit is given by Core::X86::Cpuid::LongModeInfo[PhysAddrSize].

Error Type	Bits	Description
FTI_ILL_REQ	[47:2]	Address.
FTI_ADDR_VIOL	[47:2]	Address.
FTI_SEC_VIOL	[47:2]	Address.
FTI_ILL_RSP	[55:0]	Reserved.
FTI_RSP_NO_MTCH	[55:0]	Reserved.
FTI_PAR_ERR	[47:2]	Address.
SDP_PAR_ERR	[47:2]	Address.
ATM_PAR_ERR	[47:2]	Address.
SDP_RSP_NO_MTCH	[55:0]	Reserved.
SPF_PRT_ERR	[55:0]	Reserved.
SPF_ECC_ERR	[47:2]	Address.
SDP_UNEXP_RETRY	[47:2]	Address.
CNTR_OVFL	[55:0]	Reserved.
CNTR_UNFL	[55:0]	Reserved.

# MSR0000 044F...MSRC000 2143 [CS Machine Check Miscellaneous 0] (MCA::CS::MCA MISC0 CS)

MSR0	0000_044FMSRC000_2143 [CS Machine Check Miscellaneous 0] (MCA::CS::MCA_MISC0_CS)				
Log m	iscellaneous information associated with errors.				
	_instCS0_n0_aliasMSRLEGACY; MSR0000_044F				
	_n1_aliasMSRLEGACY; MSR0000_0453				
	_n1_aliasMSR; MSRC000_2143				
	Description				
63	<b>Valid</b> . Reset: 1. 1=A valid CntP field is present in this register.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.				
62	<b>CntP</b> . Reset: 1. 1=A valid threshold counter is present.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.				
61	<b>Locked</b> . Reset: 0. 1=Writes to this register are ignored. This bit is set by BIOS to indicate that this register is not available for OS use. BIOS should set this bit if ThresholdIntType is set to SMI.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.				
60	<b>IntP</b> . Reset: 1. 1=ThresholdIntType can be used to generate interrupts. 0=ThresholdIntType and interrupt				
	generation are not supported.				
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::CS::MCA_MISC0_CS[Locked]) ? Read-write :				
	Read-only.				
59:56	Reserved.				
55:52	<b>LvtOffset</b> . Reset: 0h. One per die. For error thresholding interrupts, specifies the address of the LVT entry in the				
	APIC registers as follows: LVT address = (LvtOffset shifted left 4 bits) + 500h (see				
	Core::X86::Apic::ExtendedInterruptLvtEntries).				
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::CS::MCA_MISC0_CS[Locked]) ? Read-write :				
	Read-only.				
51	CntEn. Reset: 0. 1=Count thresholding errors.				
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::CS::MCA_MISC0_CS[Locked]) ? Read-write :				
	Read-only.				
50:49	<b>ThresholdIntType</b> . Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1.				
	00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI				
	trigger event. 11b=Reserved.				
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::CS::MCA_MISC0_CS[Locked]) ? Read-write :				
	Read-only.				
48	<b>Ovrflw</b> . Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set,				
	ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is				
	generated.				

	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::CS::MCA_MISC0_CS[Locked]) ? Read-write :
	Read-only.
47:44	Reserved.
43:32	<b>ErrCnt</b> . Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is
	incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The
	threshold value, written by software, is (FFFh - the desired error count (the number of errors necessary in order
	for an interrupt to be taken)); the desired error count of 0 (a write value of FFFh) is not supported.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::CS::MCA_MISC0_CS[Locked]) ? Read-write :
	Read-only.
31:24	<b>BlkPtr</b> . Read-write. Reset: 00h. 00h=Extended MISC MSR block is not valid. 01h=Extended MSR block is valid.
23:0	Reserved.

### MSRC000\_21[3...4]4 [CS Machine Check Configuration] (MCA::CS::MCA\_CONFIG\_CS)

Reset:	0000_0000_0000_0025h.				
	Controls configuration of the associated machine check bank.				
	)_n0_aliasMSR; MSRC000_2134				
	_n1_aliasMSR; MSRC000_2144				
	Description				
	Reserved.				
	<b>DeferredIntType</b> . Read-write. Reset: 0h. Specifies the type of interrupt signaled when a deferred error is logged. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[DeferredLvtOffset]). 10b=SMI trigger event. 11b=Reserved.				
36:35	Reserved.				
34	LogDeferredInMcaStat. Read-write. Reset: 0. Init: BIOS,1. 1=Log deferred errors in MCA::CS::MCA_STATUS_CS and MCA::CS::MCA_ADDR_CS in addition to MCA::CS::MCA_DESTAT_CS and MCA::CS::MCA_DEADDR_CS. 0=Only log deferred errors in MCA::CS::MCA_DESTAT_CS and MCA::CS::MCA_DEADDR_CS. This bit does not affect logging of deferred errors in MCA::CS::MCA_SYND_CS, MCA::CS::MCA_MISCO_CS.				
33	Reserved.				
32	<b>McaXEnable</b> . Read-write. Reset: 0. Init: BIOS,1. Check: 1. 1=Software has acknowledged support for the MCAX feature set. 0=Software has not acknowledged support for the MCAX feature set. All uncorrected and fatal errors will cause an ErrorEvent packet to be generated. Deferred error interrupts are configured via Core::X86::Msr::McaIntrCfg.				
31:6	Reserved.				
5	<b>DeferredIntTypeSupported</b> . Read-only. Reset: 1. 1=MCA::CS::MCA_CONFIG_CS[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if MCA::CS::MCA_CONFIG_CS[DeferredErrorLoggingSupported] == 1.				
4:3	Reserved.				
2	<b>DeferredErrorLoggingSupported</b> . Read-only. Reset: 1. 1=Deferred errors are supported in this MCA bank, and MCA::CS::MCA_CONFIG_CS[LogDeferredInMcaStat] controls the logging behavior of these errors. MCA::CS::MCA_DESTAT_CS and MCA::CS::MCA_DEADDR_CS are supported in this MCA bank. 0=Deferred errors are not supported in this bank.				
1	Reserved.				
0	<b>McaX</b> . Read-only. Reset: 1. 1=This bank provides Machine Check Architecture Extensions. Up to 4 additional MISC registers (MISC1-MISC4) are supported. MCA::CS::MCA_MISC0_CS[BlkPtr] indicates the presence of the additional MISC registers, but is not used to determine their MSR numbers. Deferred error interrupt type is specifiable by MCA bank. MCA::CS::MCA_STATUS_CS[TCC] is present.				

# MSRC000\_21[3...4]5 [CS IP Identification] (MCA::CS::MCA\_IPID\_CS)

Reset: 0002\_002E\_0000\_0000h.

The MCA::CS::MCA\_IPID\_CS register is used by software to determine what IP type and revision is associated with the MCA bank.

_instCS0	_instCS0_n0_aliasMSR; MSRC000_2135		
_instCS1	_n1_aliasMSR; MSRC000_2145		
Bits	Description		
63:48	<b>McaType</b> . Read-only. Reset: 0002h. The McaType of the MCA bank within this IP.		
47:44	Reserved.		
43:32	<b>HardwareID</b> . Read-only. Reset: 02Eh. The Hardware ID of the IP associated with this MCA bank.		
31:0	<b>InstanceId</b> . Read-write. Reset: 0000_0000h. The instance ID of this IP. This is initialized to a unique ID per		
	instance of this register.		
	Init: _instCS0_n0_aliasMSR: 0000_0000h		
	Init: _instCS1_n1_aliasMSR: 0000_0100h		

### MSRC000 21[3...4]6 [CS Machine Check Syndrome] (MCA::CS::MCA SYND CS)

MSK	L000_21[54]6 [CS Machine Check Syndrome] (MCA::CS::MCA_SYND_CS)
Read-	write, Volatile. Reset: Cold, 0000_0000_0000_0000h.
Logs p	physical location information associated with the error in MCA::CS::MCA_STATUS_CS Thread 0.
_instCS(	)_n0_aliasMSR; MSRC000_2136
	_n1_aliasMSR; MSRC000_2146
Bits	Description
63:48	Reserved.
47:32	<b>Syndrome</b> . Read-write, Volatile. Reset: Cold,0000h. Contains the syndrome, if any, associated with the error
	logged in MCA::CS::MCA_STATUS_CS. The low-order bit of the syndrome is stored in bit[0], and the syndrome
	has a length specified by MCA::CS::MCA_SYND_CS[Length]. The Syndrome field is only valid when
	MCA::CS::MCA_SYND_CS[Length] != 0.
31:27	Reserved.
26:24	<b>ErrorPriority</b> . Read-write, Volatile. Reset: Cold,0h. Encodes the priority of the error logged in
	MCA::CS::MCA_SYND_CS. 000b=No error. 001b=Reserved. 010b=Corrected Error. 011b=Deferred Error.
	100b=Uncorrected Error. 101b=Fatal Error. 111b-110b=Reserved.
23:18	<b>Length</b> . Read-write, Volatile. Reset: Cold, 00h. Specifies the length in bits of the syndrome contained in
	MCA::CS::MCA_SYND_CS[Syndrome]. A value of 0 indicates that there is no valid syndrome in
	MCA::CS::MCA_SYND_CS. For example, a syndrome length of 9 means that
	MCA::CS::MCA_SYND_CS[Syndrome] bits[8:0] contains a valid syndrome.
17:0	<b>ErrorInformation</b> . Read-write, Volatile. Reset: Cold, 0_0000h. Contains error-specific information about the
	location of the error. Decoding is available in Table 58 [MCA_SYND_CS].

# Table 58: MCA\_SYND\_CS

Error Type	Bits	Description
FTI_ILL_REQ	[17:0]	
FTI_ADDR_VIOL	[17:0]	
FTI_SEC_VIOL	[17:0]	
FTI_ILL_RSP	[17:0]	
FTI_RSP_NO_MTCH	[17:0]	
FTI_PAR_ERR	[5:0]	
SDP_PAR_ERR	[5:0]	
ATM_PAR_ERR	[5:0]	
SDP_RSP_NO_MTCH	[6:0]	
SPF_PRT_ERR	[17:0]	
SPF_ECC_ERR	[17:0]	
SDP_UNEXP_RETRY	[5:0]	
CNTR_OVFL	[17:0]	
CNTR_UNFL	[17:0]	

# MSRC000\_21[3...4]8 [CS Machine Check Deferred Error Status] (MCA::CS::MCA\_DESTAT\_CS)

Read-	l-write,Volatile. Reset: Cold,0000_0000_0000_0000h.		
Holds	Holds status information for the first deferred error seen in this bank.		
_	_instCS0_n0_aliasMSR; MSRC000_2138		
_instCS1	_n1_aliasMSR; MSRC000_2148		
Bits	Description		
63	<b>Val</b> . Read-write, Volatile. Reset: Cold, 0. 1=A valid error has been detected (whether it is enabled or not).		
62	<b>Overflow</b> . Read-write, Volatile. Reset: Cold,0. 1=An error was detected while the valid bit (Val) was set; at least one error was not logged. Overflow is set independently of whether the existing error is overwritten. (See the section on overwrite priorities.)		
61:59	61:59 Reserved.		
58	<b>AddrV</b> . Read-write, Volatile. Reset: Cold, 0. 1=MCA::CS::MCA_DEADDR_CS contains address information associated with the error.		
57:54	Reserved.		
53	<b>SyndV</b> . Read-write, Volatile. Reset: Cold,0. 1=This error logged information in MCA::CS::MCA_SYND_CS. If MCA::CS::MCA_SYND_CS[ErrorPriority] is the same as the priority of the error in MCA::CS::MCA_STATUS_CS, then the information in MCA::CS::MCA_SYND_CS is associated with the error in MCA::CS::MCA_DESTAT_CS.		
52:45	Reserved.		
44	<b>Deferred</b> . Read-write, Volatile. Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data error which did not immediately cause a processor exception; poison is created and an exception is deferred until the poison data is consumed.		
43:0	Reserved.		

MSRC	C000_21[34]9 [CS Deferred Error Address] (MCA::CS::MCA_DEADDR_CS)		
Reset:	Cold,0000_0000_00000_0000h.		
The M	The MCA::CS::MCA_DEADDR_CS register stores the address associated with the error in		
MCA:	:CS::MCA_DESTAT_CS. The register is only meaningful if MCA::CS::MCA_DESTAT_CS[Val] == 1 and		
MCA:	:CS::MCA_DESTAT_CS[AddrV] == 1. The lowest valid bit of the address is defined by		
MCA:	:CS::MCA_DEADDR_CS[LSB].		
_instCS0	)_n0_aliasMSR; MSRC000_2139		
_instCS1	_n1_aliasMSR; MSRC000_2149		
Bits	Description		
63:62	Reserved.		
61:56	<b>LSB</b> . Read-write, Volatile. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in		
	MCA::CS::MCA_DEADDR_CS[ErrorAddr]. For example, a value of 0 indicates that		
	MCA::CS::MCA_DEADDR_CS[55:0] contains a valid byte address. A value of 6 indicates that		
	MCA::CS::MCA_DEADDR_CS[55:6] contains a valid cache line address and that		
	MCA::CS::MCA_DEADDR_CS[5:0] are not part of the address and should be ignored by error handling		
	software. A value of 12 indicates that MCA::CS::MCA_DEADDR_CS[55:12] contains a valid 4-KB memory		
	page and that MCA::CS::MCA_DEADDR_CS[11:0] should be ignored by error handling software.		
55:0	<b>ErrorAddr</b> . Read-write, Volatile. Reset: Cold,00_0000_0000_0000h. Contains the address, if any, associated with		
	the error logged in MCA::CS::MCA_DESTAT_CS. The lowest-order valid bit of the address is specified in		
	MCA::CS::MCA_DEADDR_CS[LSB].		

# MSRC001\_041[3...4] [CS Machine Check Control Mask] (MCA::CS::MCA\_CTL\_MASK\_CS)

Read-	Read-write. Reset: 0000_0000_0000_0000h.	
Inhibit	Inhibit detection of an error source.	
_instCS0	_n0_aliasMSR; MSRC001_0413	
_instCS1	_instCS1_n1_aliasMSR; MSRC001_0414	
Bits	Description	
63:14	:14 Reserved.	
13	3 <b>CNTR_UNFL</b> . Read-write. Reset: 0. Counter underflow error.	

12	CNTR_OVFL. Read-write. Reset: 0. Counter overflow error.
11	<b>SDP_UNEXP_RETRY</b> . Read-write. Reset: 0. SDP Read response had an unexpected RETRY error.
10	<b>SPF_ECC_ERR</b> . Read-write. Reset: 0. Probe Filter ECC Error: An ECC error occurred on a probe filter access.
9	<b>SPF_PRT_ERR</b> . Read-write. Reset: 0. Probe Filter Protocol Error: Indicates a Cache Coherence Issue.
8	<b>SDP_RSP_NO_MTCH</b> . Read-write. Reset: 0. SDP Read response had no match in the CS queue.
7	ATM_PAR_ERR. Read-write. Reset: 0. Atomic Request Parity Error: Parity error on Read of an atomic
	transaction.
6	SDP_PAR_ERR. Read-write. Reset: 0. Read Response Parity Error. Parity error on incoming Read response
	data.
5	<b>FTI_PAR_ERR</b> . Read-write. Reset: 0. Request or Probe Parity Error: Parity error on incoming request or probe
	response data.
4	<b>FTI_RSP_NO_MTCH</b> . Read-write. Reset: 0. Unexpected Response: A response was received from the transport
	layer which does not match any request.
3	<b>FTI_ILL_RSP</b> . Read-write. Reset: 0. Illegal Response: An illegal response was received from the transport layer.
2	<b>FTI_SEC_VIOL</b> . Read-write. Reset: 0. Security Violation: A security violation was received from the transport
	layer.
1	FTI_ADDR_VIOL. Read-write. Reset: 0. Address Violation: An address violation was received from the
	transport layer.
0	<b>FTI_ILL_REQ</b> . Read-write. Reset: 0. Illegal Request: An illegal request was received from the transport layer.

### 3.2.5.9 PIE

MSR0000_046CMSRC000_21B0 [PIE Machine Check Control] (MCA::PIE::MCA_CTL_PIE)		
Read-write. Reset: 0000_0000_0000_0000h.		
0=Disables error reporting for the corresponding error. 1=Enables error reporting via machine check excepti	on for the	
corresponding error. The MCA::PIE::MCA_CTL_PIE register must be enabled by the corresponding enable	bit in	
Core::X86::Msr::MCG_CTL. Does not affect error detection, correction, or logging.		
_instPIE0_n0_aliasMSRLEGACY; MSR0000_046C		
_instPIE0_n0_aliasMSR; MSRC000_21B0		
Bits Description	Description	
63:5 Reserved.		
4 <b>DEF</b> . Read-write. Reset: 0. A deferred error was detected in the DF.	<b>DEF</b> . Read-write. Reset: 0. A deferred error was detected in the DF.	
3 <b>FTI_DAT_STAT</b> . Read-write. Reset: 0. Poison data consumption: Poison data was written to an inte	rnal PIE	
register.		
2 <b>GMI</b> . Read-write. Reset: 0. Link Error: An error occurred on a GMI or xGMI link.		
1 <b>CSW</b> . Read-write. Reset: 0. Register security violation: A security violation was detected on an access	s to an	
internal PIE register.		

# Reset: Cold,0000\_0000\_0000\_0000h. Logs information associated with errors. \_instPIEO\_nO\_aliasMSRLEGACY; MSR0000\_046D \_instPIEO\_nO\_aliasMSR; MSRC000\_21B1 Bits Description 4 Val. Reset: Cold,0. 1=A valid error has been detected. This bit should be cleared by software after the register has been Read. AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1. Overflow. Reset: Cold,0. 1=An error was detected while the valid bit (Val) was set; at least one error was not logged. Overflow is set independently of whether the existing error is overwritten. See 3.1.3 [Machine Check]

**HW\_ASSERT**. Read-write. Reset: 0. Hardware Assert: A hardware assert was detected.

	Errors].
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
61	UC. Reset: Cold,0. 1=The error was not corrected by hardware.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
60	<b>En</b> . Reset: Cold,0. 1=MCA error reporting is enabled for this error, as indicated by the corresponding bit in MCA::PIE::MCA_CTL_PIE. This bit is a copy of the bit in MCA::PIE::MCA_CTL_PIE for this error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
59	<b>MiscV</b> . Reset: Cold,0. 1=Valid thresholding in MCA::PIE::MCA_MISCO_PIE. In certain modes, MISC registers
	are owned by platform firmware and will RAZ when Read by non-SMM code. Therefore, it is possible for MiscV == 1 and the MISC register to Read as all zeros.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
58	<b>AddrV</b> . Reset: Cold,0. 1=MCA::PIE::MCA_ADDR_PIE contains address information associated with the error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
57	<b>PCC</b> . Reset: Cold,0. 1=Hardware context held by the processor may have been corrupted. Continued operation of
	the system may have unpredictable results. The error is not recoverable or survivable, and the system should be
	reinitialized.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
56	ErrCoreIdVal. Reset: Cold,0. 1=The ErrCoreId field is valid.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
55	<b>TCC</b> . Reset: Cold,0. 1=Hardware context of the process thread to which the error was reported may have been
	corrupted. Continued operation of the thread may have unpredictable results. The thread must be terminated. Only
	meaningful when MCA::PIE::MCA_STATUS_PIE[PCC] == 0.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
54	RESERV4. Reset: Cold,0. MCA_STATUS Register Reserved bit.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
53	SyndV. Reset: Cold,0. 1=This error logged information in MCA::PIE::MCA_SYND_PIE. If
	MCA::PIE::MCA_SYND_PIE[ErrorPriority] is the same as the priority of the error in
	MCA::PIE::MCA_STATUS_PIE, then the information in MCA::PIE::MCA_SYND_PIE is associated with the
	error in MCA::PIE::MCA_STATUS_PIE.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
52	Reserved.
51:47	RESERV3. Reset: Cold,00h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
46	<b>CECC</b> . Reset: Cold,0. 1=The error was a correctable ECC error according to the restrictions of the ECC
	algorithm. UC indicates whether the error was actually corrected by the processor.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
45	<b>UECC</b> . Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC
	algorithm. UC indicates whether the error was actually corrected by the processor.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
44	<b>Deferred</b> . Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data
	error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is
	consumed.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
43	<b>Poison</b> . Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
42:41	RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
40	<b>Scrub</b> . Reset: Cold,0. 1=The error was the result of a scrub operation.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
39:38	RESERV1. Reset: Cold,0h. MCA_STATUS Register Reserved bits.

	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
37:32	<b>ErrCoreId</b> . Reset: Cold,00h. When (ErrCoreIdVal == 1), this field indicates which core within the processor is
	associated with the error. Otherwise, this field is Reserved.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
31:22	RESERVO. Reset: Cold,000h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
21:16	<b>ErrorCodeExt</b> . Reset: Cold,00h. Extended Error Code. This field is used to identify the error type for root cause
	analysis. This field indicates which bit position in MCA::PIE::MCA_CTL_PIE enables error reporting for the
	logged error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
15:0	<b>ErrorCode</b> . Reset: Cold,0000h. Error code for this error. See 3.1.3.3 [Error Codes] for details on decoding this
	field.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.

### *Table 59: MCA\_STATUS\_PIE*

Error Type	ErrorCode Ext	UC	PCC	TCC	Deferred	Poison	AddrV
HW_ASSER T	0x0	1	1	1	0	0	0
CSW	0x1	0	0	0	1	0	0
GMI	0x2	0/1	0/1	0/1	0	0	0
FTI_DAT_S TAT	0x3	1	1	1	0	0	0
DEF	0x4	0	0	0	1	0	0

# MSR0000\_046E...MSRC000\_21B2 [PIE Machine Check Address] (MCA::PIE::MCA\_ADDR\_PIE)

Dood only	Docot.	Cold.0000	0000	0000	በበበበቤ	
Reau-oniv.	Reset.	Cora.ooo	WWW	WWW	OOOOH.	

MCA::PIE::MCA\_ADDR\_PIE stores an address and other information associated with the error in

MCA::PIE::MCA\_STATUS\_PIE. The register is only meaningful if MCA::PIE::MCA\_STATUS\_PIE[Val] == 1 and

MCA::PIE::MCA\_STATUS\_PIE[AddrV] == 1.

_instPIE	_n0_aliasMSRLEGACY; MSR0000_046E		
_instPIE	_n0_aliasMSR; MSRC000_21B2		
Bits	its Description		
63:62	Reserved.		
61:56	<b>LSB</b> . Read-only. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in		
	MCA::PIE::MCA_ADDR_PIE[ErrorAddr]. For example, a value of 0 indicates that		
	MCA::PIE::MCA_ADDR_PIE[55:0] contains a valid byte address. A value of 6 indicates that		
	MCA::PIE::MCA_ADDR_PIE[55:6] contains a valid cache line address and that		
	MCA::PIE::MCA_ADDR_PIE[5:0] are not part of the address and should be ignored by error handling software.		
	A value of 12 indicates that MCA::PIE::MCA_ADDR_PIE[55:12] contains a valid 4-KB memory page and that		
	MCA::PIE::MCA_ADDR_PIE[11:0] should be ignored by error handling software.		
55:0	<b>ErrorAddr</b> . Read-only. Reset: Cold,00_0000_0000_0000h. Contains the address, if any, associated with the error		
	logged in MCA::PIE::MCA_STATUS_PIE.		

### Table 60: MCA\_ADDR\_PIE

Error Type	Bits	Description
HW_ASSERT	[55:0]	Reserved.
CSW	[55:0]	Reserved.
GMI	[55:0]	Reserved.
FTI_DAT_STAT	[55:0]	Reserved.

DEF	[55:0]	Reserved.

MSR0	000_046FMSRC000_21B3 [PIE Machine Check Miscellaneous 0] (MCA::PIE::MCA_MISC0_PIE)
	iscellaneous information associated with errors.
	O_nO_aliasMSRLEGACY; MSR0000_046F
	0_n0_aliasMSR; MSRC000_21B3
	Description  Valid Book 1 1- Applid Carp Caldia account in this preference
63	<b>Valid.</b> Reset: 1. 1=A valid CntP field is present in this register.
CD	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.
62	CntP. Reset: 1. 1=A valid threshold counter is present.
C1	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.
61	<b>Locked</b> . Reset: 0. 1=Writes to this register are ignored. This bit is set by BIOS to indicate that this register is not
	available for OS use. BIOS should set this bit if ThresholdIntType is set to SMI.
CO	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.
60	<b>IntP</b> . Reset: 1. 1=ThresholdIntType can be used to generate interrupts. 0=ThresholdIntType and interrupt
	generation are not supported.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::PIE::MCA_MISCO_PIE[Locked]) ? Readwrite : Read-only.
EO.EG	Reserved.
	<b>LvtOffset</b> . Reset: 0h. One per die. For error thresholding interrupts, specifies the address of the LVT entry in the
33.32	APIC registers as follows: LVT address = (LvtOffset shifted left 4 bits) + 500h (see
	Core::X86::Apic::ExtendedInterruptLvtEntries).
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::PIE::MCA_MISCO_PIE[Locked]) ? Read-
	write: Read-only.
51	CntEn. Reset: 0. 1=Count thresholding errors.
01	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::PIE::MCA_MISCO_PIE[Locked]) ? Read-
	write: Read-only.
50:49	v
	00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI
	trigger event. 11b=Reserved.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::PIE::MCA_MISC0_PIE[Locked]) ? Read-
	write: Read-only.
48	<b>Ovrflw</b> . Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set,
	ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is
	generated.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::PIE::MCA_MISC0_PIE[Locked]) ? Read-
	write: Read-only.
	Reserved.
43:32	<b>ErrCnt</b> . Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is
	incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The
	threshold value, written by software, is (FFFh - the desired error count (the number of errors necessary in order
	for an interrupt to be taken)); the desired error count of 0 (a write value of FFFh) is not supported.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::PIE::MCA_MISCO_PIE[Locked]) ? Readwrite : Read-only.
31.24	BlkPtr. Read-write. Reset: 00h. 00h=Extended MISC MSR block is not valid. 01h=Extended MSR block is valid.
23:0	Reserved.
23.0	IVEDET VEU.

# MSRC000\_21B4 [PIE Machine Check Configuration] (MCA::PIE::MCA\_CONFIG\_PIE)

Reset: 0000 0002 0000 0025h.
Reset. 0000_0002_0000_002511.
Controls configuration of the associated machine check bank.
instPIEO nO aliasMSR: MSRC000 21B4

Bits	Description
63:39	Reserved.
38:37	<b>DeferredIntType</b> . Read-write. Reset: 0h. Specifies the type of interrupt signaled when a deferred error is logged. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[DeferredLvtOffset]). 10b=SMI trigger event. 11b=Reserved.
36:35	Reserved.
34	LogDeferredInMcaStat. Read-write. Reset: 0. Init: BIOS,1. 1=Log deferred errors in MCA::PIE::MCA_STATUS_PIE and MCA::PIE::MCA_ADDR_PIE in addition to MCA::PIE::MCA_DESTAT_PIE and MCA::PIE::MCA_DEADDR_PIE. 0=Only log deferred errors in MCA::PIE::MCA_DESTAT_PIE and MCA::PIE::MCA_DEADDR_PIE. This bit does not affect logging of deferred errors in MCA::PIE::MCA_SYND_PIE, MCA::PIE::MCA_MISCO_PIE.
33	Reserved.
32	<b>McaXEnable</b> . Read-write. Reset: 0. Init: BIOS,1. Check: 1. 1=Software has acknowledged support for the MCAX feature set. 0=Software has not acknowledged support for the MCAX feature set. All uncorrected and fatal errors will cause an ErrorEvent packet to be generated. Deferred error interrupts are configured via Core::X86::Msr::McaIntrCfg.
31:6	Reserved.
5	<b>DeferredIntTypeSupported</b> . Read-only. Reset: 1. 1=MCA::PIE::MCA_CONFIG_PIE[DeferredIntType] controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if MCA::PIE::MCA_CONFIG_PIE[DeferredErrorLoggingSupported] == 1.
4:3	Reserved.
2	<b>DeferredErrorLoggingSupported</b> . Read-only. Reset: 1. 1=Deferred errors are supported in this MCA bank, and MCA::PIE::MCA_CONFIG_PIE[LogDeferredInMcaStat] controls the logging behavior of these errors. MCA::PIE::MCA_DESTAT_PIE and MCA::PIE::MCA_DEADDR_PIE are supported in this MCA bank. 0=Deferred errors are not supported in this bank.
1	Reserved.
0	<b>McaX</b> . Read-only. Reset: 1. 1=This bank provides Machine Check Architecture Extensions. Up to 4 additional MISC registers (MISC1-MISC4) are supported. MCA::PIE::MCA_MISC0_PIE[BlkPtr] indicates the presence of the additional MISC registers, but is not used to determine their MSR numbers. Deferred error interrupt type is specifiable by MCA bank. MCA::PIE::MCA_STATUS_PIE[TCC] is present.

# MSRC000\_21B5 [PIE IP Identification] (MCA::PIE::MCA\_IPID\_PIE)

Reset:	0001_002E_0000_0000h.
The M	ICA::PIE::MCA_IPID_PIE register is used by software to determine what IP type and revision is associated with
the MO	CA bank.
_instPIE(	.0_n0_aliasMSR;
Bits	Description
63:48	<b>McaType</b> . Read-only. Reset: 0001h. The McaType of the MCA bank within this IP.
47:44	Reserved.
43:32	<b>HardwareID</b> . Read-only. Reset: 02Eh. The Hardware ID of the IP associated with this MCA bank.
31:0	<b>InstanceId</b> . Read-write. Reset: 0000_0000h. Init: 0000_0000h. The instance ID of this IP. This is initialized to a
	unique ID per instance of this register.

### MSRC000 21B6 [PIE Machine Check Syndrome] (MCA::PIE::MCA SYND PIE)

MSK	WISKCOOU_21D0 [FIE WIRCHING CHECK SYNDTONIE] (WICAFIEWICA_STND_FIE)	
Read-	Read-write, Volatile. Reset: Cold, 0000_0000_0000h.	
Logs p	Logs physical location information associated with the error in MCA::PIE::MCA_STATUS_PIE Thread 0.	
_instPIE	_instPIE0_n0_aliasMSR; MSRC000_21B6	
Bits	Description	
63:33	Reserved.	
32	<b>Syndrome</b> . Read-write, Volatile. Reset: Cold, 0. Contains the syndrome, if any, associated with the error logged in	
	MCA::PIE::MCA_STATUS_PIE. The low-order bit of the syndrome is stored in bit[0], and the syndrome has a	

	length specified by MCA::PIE::MCA_SYND_PIE[Length]. The Syndrome field is only valid when
	MCA::PIE::MCA_SYND_PIE[Length] != 0.
31:27	Reserved.
26:24	<b>ErrorPriority</b> . Read-write, Volatile. Reset: Cold,0h. Encodes the priority of the error logged in
	MCA::PIE::MCA_SYND_PIE. 000b=No error. 001b=Reserved. 010b=Corrected Error. 011b=Deferred Error.
	100b=Uncorrected Error. 101b=Fatal Error. 111b-110b=Reserved.
23:18	<b>Length</b> . Read-write, Volatile. Reset: Cold, 00h. Specifies the length in bits of the syndrome contained in
	MCA::PIE::MCA_SYND_PIE[Syndrome]. A value of 0 indicates that there is no valid syndrome in
	MCA::PIE::MCA_SYND_PIE. For example, a syndrome length of 9 means that
	MCA::PIE::MCA_SYND_PIE[Syndrome] bits[8:0] contains a valid syndrome.
17:0	<b>ErrorInformation</b> . Read-write, Volatile. Reset: Cold, 0_0000h. Contains error-specific information about the
	location of the error. Decoding is available in Table 61 [MCA_SYND_PIE].

# Table 61: MCA\_SYND\_PIE

Error Type	Bits	Description
HW_ASSERT	[17:0]	Reserved.
CSW	[17:0]	
GMI	[17:0]	
FTI_DAT_STAT	[3:0]	
DEF	[17:0]	Reserved.

### MSRC000 21B8 [PIE Machine Check Deferred Error Status] (MCA::PIE::MCA DESTAT PIE)

MSR	C000_21B8 [PIE Machine Check Deferred Error Status] (MCA::PIE::MCA_DESTAT_PIE)		
Read-	Read-write, Volatile. Reset: Cold, 0000_0000_0000_0000h.		
Holds	Holds status information for the first deferred error seen in this bank.		
_instPIE	_instPIE0_n0_aliasMSR; MSRC000_21B8		
Bits	Description		
63	<b>Val</b> . Read-write, Volatile. Reset: Cold,0. 1=A valid error has been detected (whether it is enabled or not).		
62	<b>Overflow</b> . Read-write, Volatile. Reset: Cold, 0. 1=An error was detected while the valid bit (Val) was set; at least		
	one error was not logged. Overflow is set independently of whether the existing error is overwritten. (See the		
	section on overwrite priorities.)		
61:59	Reserved.		
58	<b>AddrV</b> . Read-write, Volatile. Reset: Cold, 0. 1=MCA::PIE::MCA_DEADDR_PIE contains address information		
	associated with the error.		
57:54	Reserved.		
53	<b>SyndV</b> . Read-write, Volatile. Reset: Cold, 0. 1=This error logged information in MCA::PIE::MCA_SYND_PIE. If		
	MCA::PIE::MCA_SYND_PIE[ErrorPriority] is the same as the priority of the error in		
	MCA::PIE::MCA_STATUS_PIE, then the information in MCA::PIE::MCA_SYND_PIE is associated with the		
	error in MCA::PIE::MCA_DESTAT_PIE.		
52:45	Reserved.		
44	<b>Deferred</b> . Read-write, Volatile. Reset: Cold, 0. 1=A deferred error was created. A deferred error is the result of an		
	uncorrectable data error which did not immediately cause a processor exception; poison is created and an		
	exception is deferred until the poison data is consumed.		
43:0	Reserved.		

# MSRC000\_21B9 [PIE Deferred Error Address] (MCA::PIE::MCA\_DEADDR\_PIE)

Reset: Cold,0000_0000_0000h.	
The MCA::PIE::MCA_DEADDR_PIE register stores the address associated with the error in	
MCA::PIE::MCA_DESTAT_PIE. The register is only meaningful if MCA::PIE::MCA_DESTAT_PIE[Val] == 1 and	
MCA::PIE::MCA_DESTAT_PIE[AddrV] == 1. The lowest valid bit of the address is defined by	
MCA::PIE::MCA_DEADDR_PIE[LSB].	
_instPIE0_n0_aliasMSR; MSRC000_21B9	

Bits	Description
63:62	Reserved.
61:56	<b>LSB</b> . Read-write, Volatile. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in
	MCA::PIE::MCA_DEADDR_PIE[ErrorAddr]. For example, a value of 0 indicates that
	MCA::PIE::MCA_DEADDR_PIE[55:0] contains a valid byte address. A value of 6 indicates that
	MCA::PIE::MCA_DEADDR_PIE[55:6] contains a valid cache line address and that
	MCA::PIE::MCA_DEADDR_PIE[5:0] are not part of the address and should be ignored by error handling
	software. A value of 12 indicates that MCA::PIE::MCA_DEADDR_PIE[55:12] contains a valid 4-KB memory
	page and that MCA::PIE::MCA_DEADDR_PIE[11:0] should be ignored by error handling software.
55:0	<b>ErrorAddr</b> . Read-write, Volatile. Reset: Cold,00_0000_0000_0000h. Contains the address, if any, associated with
	the error logged in MCA::PIE::MCA_DESTAT_PIE. The lowest-order valid bit of the address is specified in
	MCA::PIE::MCA_DEADDR_PIE[LSB].

# MSRC001\_041B [PIE Machine Check Control Mask] (MCA::PIE::MCA\_CTL\_MASK\_PIE)

Read-	Read-write. Reset: 0000_0000_0000_0000h.	
Inhibit	Inhibit detection of an error source.	
_instPIE	0_n0_aliasMSR; MSRC001_041B	
Bits	Description	
63:5	Reserved.	
4	<b>DEF</b> . Read-write. Reset: 0. A deferred error was detected in the DF.	
3	<b>FTI_DAT_STAT</b> . Read-write. Reset: 0. Poison data consumption: Poison data was written to an internal PIE	
	register.	
2	<b>GMI</b> . Read-write. Reset: 0. Link Error: An error occurred on a GMI or xGMI link.	
1	<b>CSW</b> . Read-write. Reset: 0. Register security violation: A security violation was detected on an access to an	
	internal PIE register.	
0	<b>HW_ASSERT</b> . Read-write. Reset: 0. Hardware Assert: A hardware assert was detected.	

### 3.2.5.10 **UMC**

M	SRU	UUU <u>.</u>	_0444	4MSRC00	0_212	0 (MCA::UMC::MCA_CTL_UMC)

1120210	WOULD THE WILLIAM CONTROL OF THE CON					
Read-	Read-write. Reset: 0000_0000_0000_0000h.					
_ch0_ins	_ch0_instUMC_n0_umc0_aliasMSRLEGACY; MSR0000_0444					
_ch0_ins	stUMC_n1_umc1_aliasMSRLEGACY; MSR0000_0448					
_ch0_ins	stUMC_n0_umc0_aliasMSR; MSRC000_2110					
_ch0_ins	stUMC_n1_umc1_aliasMSR; MSRC000_2120					
Bits	Description					
63:6	Reserved.					
5	<b>WriteDataCrcErr</b> . Read-write. Reset: 0. Write data CRC error. A write data CRC error occurred on the DRAM					
	data bus.					
4	<b>AddressCommandParityErr</b> . Read-write. Reset: 0. Address/Command parity error. A parity error occurred on					
	the DRAM address/command bus.					
3	<b>ApbErr</b> . Read-write. Reset: 0. Advanced peripheral bus error. An error occurred on the advanced peripheral bus.					
2	<b>SdpParityErr</b> . Read-write. Reset: 0. SDP parity error. A parity error was detected on write data from the data					
	fabric.					
1	WriteDataPoisonErr. Read-write. Reset: 0. Data poison error.					
0	<b>DramEccErr</b> . Read-write. Reset: 0. DRAM ECC error. An ECC error occurred on a DRAM Read.					

# MSR0000\_0445...MSRC000\_2121 [UMC Machine Check Status] (MCA::UMC::MCA\_STATUS\_UMC)

	 	_	 
Reset: Cold,0000_0000_0000_0000h.			
Logs information associated with errors.			
_ch0_instUMC_n0_umc0_aliasMSRLEGACY; MSR0000_0445			

ch0 in:	stUMC_n1_umc1_aliasMSRLEGACY; MSR0000_0449
	stUMC_n0_umc0_aliasMSR; MSRC000_2111
_ch0_in	stUMC_n1_umc1_aliasMSR; MSRC000_2121
Bits	Description
63	<b>Val</b> . Reset: Cold,0. 1=A valid error has been detected. This bit should be cleared by software after the register has been Read.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
62	<b>Overflow</b> . Reset: Cold,0. 1=An error was detected while the valid bit (Val) was set; at least one error was not logged. Overflow is set independently of whether the existing error is overwritten. See 3.1.3 [Machine Check Errors].
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
61	UC. Reset: Cold, 0. 1=The error was not corrected by hardware.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
60	<b>En</b> . Reset: Cold,0. 1=MCA error reporting is enabled for this error, as indicated by the corresponding bit in MCA::UMC::MCA_CTL_UMC. This bit is a copy of the bit in MCA::UMC::MCA_CTL_UMC for this error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
59	<b>MiscV</b> . Reset: Cold,0. 1=Valid thresholding in MCA::UMC::MCA_MISCO_UMC. In certain modes, MISC registers are owned by platform firmware and will RAZ when Read by non-SMM code. Therefore, it is possible for MiscV == 1 and the MISC register to Read as all zeros.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
58	<b>AddrV</b> . Reset: Cold,0. 1=MCA::UMC::MCA_ADDR_UMC contains address information associated with the error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
57	<b>PCC</b> . Reset: Cold,0. 1=Hardware context held by the processor may have been corrupted. Continued operation of
	the system may have unpredictable results. The error is not recoverable or survivable, and the system should be
	reinitialized.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
56	ErrCoreIdVal. Reset: Cold,0. 1=The ErrCoreId field is valid.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
55	TCC. Reset: Cold,0. 1=Hardware context of the process thread to which the error was reported may have been
	corrupted. Continued operation of the thread may have unpredictable results. The thread must be terminated. Only meaningful when MCA::UMC::MCA_STATUS_UMC[PCC] == 0.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
54	RESERV4. Reset: Cold,0. MCA_STATUS Register Reserved bit.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
53	SyndV. Reset: Cold,0. 1=This error logged information in MCA::UMC::MCA_SYND_UMC. If
	MCA::UMC::MCA_SYND_UMC[ErrorPriority] is the same as the priority of the error in
	MCA::UMC::MCA_STATUS_UMC, then the information in MCA::UMC::MCA_SYND_UMC is associated
	with the error in MCA::UMC::MCA_STATUS_UMC.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
52	Reserved.
51:47	RESERV3. Reset: Cold,00h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
46	<b>CECC</b> . Reset: Cold,0. 1=The error was a correctable ECC error according to the restrictions of the ECC algorithm. UC indicates whether the error was actually corrected by the processor.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
45	<b>UECC</b> . Reset: Cold,0. 1=The error was an uncorrectable ECC error according to the restrictions of the ECC
	algorithm. UC indicates whether the error was actually corrected by the processor.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
44	<b>Deferred</b> . Reset: Cold,0. 1=A deferred error was created. A deferred error is the result of an uncorrectable data
	error which did not immediately cause a processor exception; an exception is deferred until the erroneous data is

	consumed.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
43	<b>Poison</b> . Reset: Cold,0. 1=The error was the result of attempting to consume poisoned data.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
42:41	RESERV2. Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
40	<b>Scrub</b> . Reset: Cold,0. 1=The error was the result of a scrub operation.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
39:38	<b>RESERV1</b> . Reset: Cold,0h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
37:32	<b>ErrCoreId</b> . Reset: Cold,00h. When (ErrCoreIdVal == 1), this field indicates which core within the processor is
	associated with the error. Otherwise, this field is Reserved.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
31:22	RESERVO. Reset: Cold,000h. MCA_STATUS Register Reserved bits.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.
21:16	<b>ErrorCodeExt</b> . Reset: Cold,00h. Extended Error Code. This field is used to identify the error type for root cause
	analysis. This field indicates which bit position in MCA::UMC::MCA_CTL_UMC enables error reporting for the
	logged error.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read,Write-0-only,Error-on-write-1.
15:0	<b>ErrorCode</b> . Reset: Cold,0000h. Error code for this error. See 3.1.3.3 [Error Codes] for details on decoding this
	field.
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read,Write-0-only,Error-on-write-1.

# Table 62: MCA\_STATUS\_UMC

Error Type	ErrorCode	UC	PCC	TCC	Deferred	Poison	AddrV
	Ext						
DramEccErr	0x0	0/1	0/1	0/1	0/1	0	1
WriteDataPo isonErr	0x1	1	1	1	0	0	0
SdpParityErr	0x2	1	1	1	0	0	0
ApbErr	0x3	1	1	1	0	0	1
AddressCom mandParityE rr	0x4	0/1	0/1	0/1	0	0	1
WriteDataCr cErr	0x5	1	1	1	0	0	1

MSR0000_0446MSRC000_2122 [UMC Machine Check Address] (MCA::UMC::MCA_ADDR_UMC)						
Reset: Cold,0000_0000_0000_0000h.						
MCA::UMC::MCA_ADDR_UMC stores an address and other information associated with the error in						
MCA::UMC::MCA_STATUS_UMC. The register is only meaningful if MCA::UMC::MCA_STATUS_UMC[Val] == 1						
and MCA::UMC::MCA_STATUS_UMC[AddrV] == 1.						
_ch0_instUMC_n0_umc0_aliasMSRLEGACY; MSR0000_0446						
_ch0_instUMC_n1_umc1_aliasMSRLEGACY; MSR0000_044A						
_ch0_instUMC_n0_umc0_aliasMSR; MSRC000_2112						
_ch0_instUMC_n1_umc1_aliasMSR; MSRC000_2122						
Bits Description						
63:62 Reserved.						
<b>LSB</b> . Read-write, Volatile. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in						
MCA::UMC::MCA_ADDR_UMC[ErrorAddr]. For example, a value of 0 indicates that						

	MCA::UMC::MCA_ADDR_UMC[55:0] contains a valid byte address. A value of 6 indicates that
	MCA::UMC::MCA_ADDR_UMC[55:6] contains a valid cache line address and that
	MCA::UMC::MCA_ADDR_UMC[5:0] are not part of the address and should be ignored by error handling
	software. A value of 12 indicates that MCA::UMC::MCA_ADDR_UMC[55:12] contains a valid 4-KB memory
	page and that MCA::UMC::MCA_ADDR_UMC[11:0] should be ignored by error handling software.
55:0	<b>ErrorAddr</b> . Read-write, Volatile. Reset: Cold,00_0000_0000_0000h. Unless otherwise specified by an error,
	contains the address associated with the error logged in MCA::UMC::MCA_STATUS_UMC. For physical
	addresses, the most significant bit is given by Core::X86::Cpuid::LongModeInfo[PhysAddrSize].

# *Table 63: MCA\_ADDR\_UMC*

Error Type	Bits	Description
DramEccErr	[55:39]	Reserved.
	[39:4]	Reserved.
WriteDataPoisonErr	[55:0]	Reserved.
SdpParityErr	[55:0]	Reserved.
ApbErr	[55:30]	Reserved.
	[29:0]	Reserved.
AddressCommandParityErr	[55:38]	Reserved.
	[37:36]	Reserved.
	[35:32]	Chip Select.
	[31:0]	Reserved.
WriteDataCrcErr	[55:38]	Reserved.
	[37:36]	Reserved.
	[35:32]	Chip Select.
	[31:0]	Reserved.

# MSR0000\_0447...MSRC000\_2123 [UMC Machine Check Miscellaneous 0] (MCA::UMC::MCA\_MISC0\_UMC)

WISIC	0000_0447WISKC000_2125 [OWG Machine Check Wiscentaneous 0] (WGAOWGWGA_WISCO_OWG)				
	iscellaneous information associated with errors.				
_ch0_instUMC_n0_umc0_aliasMSRLEGACY; MSR0000_0447					
	stUMC_n1_umc1_aliasMSRLEGACY; MSR0000_044B				
	stUMC_n0_umc0_aliasMSR; MSRC000_2113				
_ch0_ins	stUMC_n1_umc1_aliasMSR; MSRC000_2123				
Bits	Description				
63	<b>Valid</b> . Reset: 1. 1=A valid CntP field is present in this register.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.				
62	<b>CntP</b> . Reset: 1. 1=A valid threshold counter is present.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.				
61	<b>Locked</b> . Reset: 0. 1=Writes to this register are ignored. This bit is set by BIOS to indicate that this register is not				
	available for OS use. BIOS should set this bit if ThresholdIntType is set to SMI.				
	AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only.				
60	IntP. Reset: 1. 1=ThresholdIntType can be used to generate interrupts. 0=ThresholdIntType and interrupt				
	generation are not supported.				
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::UMC::MCA_MISC0_UMC[Locked]) ? Read-				
	write: Read-only.				
59.56	Reserved.				
55:52	<b>LvtOffset</b> . Reset: 0h. One per die. For error thresholding interrupts, specifies the address of the LVT entry in the				
	APIC registers as follows: LVT address = (LvtOffset shifted left 4 bits) + 500h (see				
	Core::X86::Apic::ExtendedInterruptLvtEntries).				
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::UMC::MCA_MISC0_UMC[Locked]) ? Read-				
write: Read-only.					
	wite. Redu-only.				

51	<b>CntEn</b> . Reset: 0. 1=Count thresholding errors.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::UMC::MCA_MISC0_UMC[Locked]) ? Read-
	write: Read-only.
50:49	<b>ThresholdIntType</b> . Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set and IntP == 1.
	00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]). 10b=SMI
	trigger event. 11b=Reserved.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::UMC::MCA_MISC0_UMC[Locked]) ? Read-
	write: Read-only.
48	<b>Ovrflw</b> . Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh. When this field is set,
	ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is
	generated.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::UMC::MCA_MISC0_UMC[Locked]) ? Read-
	write: Read-only.
47:44	Reserved.
43:32	<b>ErrCnt</b> . Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is
	incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The
	threshold value, written by software, is (FFFh - the desired error count (the number of errors necessary in order
	for an interrupt to be taken)); the desired error count of 0 (a write value of FFFh) is not supported.
	AccessType: (Core::X86::Msr::HWCR[McStatusWrEn]   !MCA::UMC::MCA_MISC0_UMC[Locked]) ? Read-
	write: Read-only.
31:24	<b>BlkPtr</b> . Read-write. Reset: 01h. 00h=Extended MISC MSR block is not valid. 01h=Extended MSR block is valid.
23:0	Reserved.

### MSRC000 21[1...2]4 [UMC Machine Check Configuration] (MCA::UMC::MCA CONFIG UMC)

MSRC	C000_21[12]4 [UMC Machine Check Configuration] (MCA::UMC::MCA_CONFIG_UMC)					
Reset:	0000_0002_0000_0025h.					
	Controls configuration of the associated machine check bank.					
	tUMC_n0_umc0_aliasMSR; MSRC000_2114					
	tUMC_n1_umc1_aliasMSR; MSRC000_2124					
Bits	Description					
63:39	Reserved.					
38:37	<b>DeferredIntType</b> . Read-write. Reset: 0h. Specifies the type of interrupt signaled when a deferred error is logged. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[DeferredLvtOffset]). 10b=SMI					
	trigger event. 11b=Reserved.					
36:35	Reserved.					
34	<b>LogDeferredInMcaStat</b> . Read-write. Reset: 0. Init: BIOS,1. 1=Log deferred errors in					
	MCA::UMC::MCA_STATUS_UMC and MCA::UMC::MCA_ADDR_UMC in addition to					
	MCA::UMC::MCA_DESTAT_UMC and MCA::UMC::MCA_DEADDR_UMC. 0=Only log deferred errors in					
	MCA::UMC::MCA_DESTAT_UMC and MCA::UMC::MCA_DEADDR_UMC. This bit does not affect logging					
	of deferred errors in MCA::UMC::MCA_SYND_UMC, MCA::UMC::MCA_MISC0_UMC.					
33	Reserved.					
32	<b>McaXEnable</b> . Read-write. Reset: 0. Init: BIOS,1. Check: 1. 1=Software has acknowledged support for the					
	MCAX feature set. 0=Software has not acknowledged support for the MCAX feature set. All uncorrected and					
	fatal errors will cause an ErrorEvent packet to be generated. Deferred error interrupts are configured via					
	Core::X86::Msr::McaIntrCfg.					
31:6	Reserved.					
5	<b>DeferredIntTypeSupported</b> . Read-only. Reset: 1. 1=MCA::UMC::MCA_CONFIG_UMC[DeferredIntType]					
	controls the type of interrupt generated on a deferred error. Deferred errors are supported in this bank only if					
	MCA::UMC::MCA_CONFIG_UMC[DeferredErrorLoggingSupported] == 1.					
4:3	Reserved.					
2	<b>DeferredErrorLoggingSupported</b> . Read-only. Reset: 1. 1=Deferred errors are supported in this MCA bank, and					
	MCA::UMC::MCA_CONFIG_UMC[LogDeferredInMcaStat] controls the logging behavior of these errors.					

		MCA::UMC::MCA_DESTAT_UMC and MCA::UMC::MCA_DEADDR_UMC are supported in this MCA	
		0=Deferred errors are not supported in this bank.	
	1	1 Reserved.	
	0	<b>McaX</b> . Read-only. Reset: 1. 1=This bank provides Machine Check Architecture Extensions. Up to 4 additional	
		MISC registers (MISC1-MISC4) are supported. MCA::UMC::MCA_MISC0_UMC[BlkPtr] indicates the	
		presence of the additional MISC registers, but is not used to determine their MSR numbers. Deferred error	
1		interrupt type is specifiable by MCA bank. MCA::UMC::MCA_STATUS_UMC[TCC] is present.	

### MSRC000 21[1...2]5 [UMC IP Identification] (MCA::UMC::MCA IPID UMC)

MSKC000_21[12]5 [OMC IF Identification] (MCAOMCMCA_IFID_OMC)		
Reset: 0000_0096_0000_0000h.		
The MCA::UMC::MCA_IPID_UMC register is used by software to determine what IP type and revision is associated		
with the MCA bank.		
.ch0_instUMC_n0_umc0_aliasMSR; MSRC000_2115		
_ch0_instUMC_n1_umc1_aliasMSR; MSRC000_2125		
Bits Description		
63:48 <b>McaType</b> . Read-only. Reset: 0000h. The McaType of the MCA bank within this IP.		
47:44 Reserved.		
43:32 <b>HardwareID</b> . Read-only. Reset: 096h. The Hardware ID of the IP associated with this MCA bank.		
31:0 <b>InstanceId</b> . Read-write. Reset: 0000_0000h. The instance ID of this IP. This is initialized to a unique ID per		
instance of this register.		
Init: _ch0_instUMC_n0_umc0_aliasMSR: 0005_0F00h		
Init: _ch0_instUMC_n1_umc1_aliasMSR: 0015_0F00h		

### MSRC000\_21[1...2]6 [UMC Machine Check Syndrome] (MCA::UMC::MCA\_SYND\_UMC)

Mister of the Miletine Check Syndrome (Microscottos, 1971)			
Read-	Read-write, Volatile. Reset: Cold,0000_0000_00000_0000h.		
Logs I	Logs physical location information associated with the error in MCA::UMC::MCA_STATUS_UMC Thread 0.		
_ch0_instUMC_n0_umc0_aliasMSR; MSRC000_2116			
_ch0_instUMC_n1_umc1_aliasMSR; MSRC000_2126			
Bits	Description		
63:48	Reserved.		
47:32	<b>Syndrome</b> . Read-write, Volatile. Reset: Cold,0000h. Contains the syndrome, if any, associated with the error		
	logged in MCA::UMC::MCA_STATUS_UMC. The low-order bit of the syndrome is stored in bit[0], and the		
	syndrome has a length specified by MCA::UMC::MCA_SYND_UMC[Length]. The Syndrome field is only valid		
	when MCA::UMC::MCA_SYND_UMC[Length] != 0.		
31:27	31:27 Reserved.		
26:24 <b>ErrorPriority</b> . Read-write, Volatile. Reset: Cold,0h. Encodes the priority of the error logged in			
	MCA::UMC::MCA_SYND_UMC. 000b=No error. 001b=Reserved. 010b=Corrected Error. 011b=Deferred Error.		
	100b=Uncorrected Error. 101b=Fatal Error. 111b-110b=Reserved.		
23:18 <b>Length</b> . Read-write, Volatile. Reset: Cold,00h. Specifies the length in bits of the syndrome contained in			
	MCA::UMC::MCA_SYND_UMC[Syndrome]. A value of 0 indicates that there is no valid syndrome in		
	MCA::UMC::MCA_SYND_UMC. For example, a syndrome length of 9 means that		
	MCA::UMC::MCA_SYND_UMC[Syndrome] bits[8:0] contains a valid syndrome.		
17:0	<b>ErrorInformation</b> . Read-write, Volatile. Reset: Cold, 0_0000h. Contains error-specific information about the		
	location of the error. Decoding is available in Table 64 [MCA_SYND_UMC].		

# Table 64: MCA\_SYND\_UMC

Error Type	Bits	Description
DramEccErr	[17:16]	Reserved.
	[15]	Software-Managed Bad Symbol ID Error.
	[14]	Reserved.
	[13:8]	Symbol. Only contains valid information for corrected errors.

	[7]	Reserved.
	[6:4]	CID. Specifies the rank multiply ID for supported DIMMs.
	[3]	Reserved.
	[2:0]	Chip Select.
WriteDataPoisonErr	[17:0]	Reserved.
SdpParityErr	[17:0]	Reserved.
ApbErr	[17:0]	Reserved.
AddressCommandParityErr	[17:0]	Reserved.
WriteDataCrcErr	[17:0]	Reserved.

MSR	MSRC000_21[12]8 [UMC Machine Check Deferred Error Status] (MCA::UMC::MCA_DESTAT_UMC)		
Read-	Read-write, Volatile. Reset: Cold, 0000_0000_0000_0000h.		
Holds status information for the first deferred error seen in this bank.			
_ch0_ins	_ch0_instUMC_n0_umc0_aliasMSR; MSRC000_2118		
_ch0_ins	stUMC_n1_umc1_aliasMSR; MSRC000_2128		
Bits	Description		
63	<b>Val</b> . Read-write, Volatile. Reset: Cold,0. 1=A valid error has been detected (whether it is enabled or not).		
62	<b>Overflow</b> . Read-write, Volatile. Reset: Cold, 0. 1=An error was detected while the valid bit (Val) was set; at least		
	one error was not logged. Overflow is set independently of whether the existing error is overwritten. (See the		
section on overwrite priorities.)			
61:59	1:59 Reserved.		
58	<b>AddrV</b> . Read-write, Volatile. Reset: Cold, 0. 1=MCA::UMC::MCA_DEADDR_UMC contains address		
	information associated with the error.		
57:54	7:54 Reserved.		
53	<b>SyndV</b> . Read-write, Volatile. Reset: Cold, 0. 1=This error logged information in		
	MCA::UMC::MCA_SYND_UMC. If MCA::UMC::MCA_SYND_UMC[ErrorPriority] is the same as the priority		
	of the error in MCA::UMC::MCA_STATUS_UMC, then the information in MCA::UMC::MCA_SYND_UMC is		
associated with the error in MCA::UMC::MCA_DESTAT_UMC.			
52:45	Reserved.		
44	<b>Deferred</b> . Read-write, Volatile. Reset: Cold, 0. 1=A deferred error was created. A deferred error is the result of an		
	uncorrectable data error which did not immediately cause a processor exception; poison is created and an		
	exception is deferred until the poison data is consumed.		
43:0	Reserved.		

MSRC000_21[12]9 [UMC Deferred Error Address] (MCA::UMC::MCA_DEADDR_UMC)		
Reset: Cold,0000_0000_0000_0000h.		
The MCA::UMC::MCA_DEADDR_UMC register stores the address associated with the error in		
MCA::UMC::MCA_DESTAT_UMC. The register is only meaningful if MCA::UMC::MCA_DESTAT_UMC[Val] =	= 1	
and MCA::UMC::MCA_DESTAT_UMC[AddrV] == 1. The lowest valid bit of the address is defined by		
MCA::UMC::MCA_DEADDR_UMC[LSB].		
_ch0_instUMC_n0_umc0_aliasMSR; MSRC000_2119		
_ch0_instUMC_n1_umc1_aliasMSR; MSRC000_2129		
Bits Description		
63:62 Reserved.		
61:56 <b>LSB</b> . Read-write, Volatile. Reset: Cold,00h. Specifies the least significant valid bit of the address contained in		
MCA::UMC::MCA_DEADDR_UMC[ErrorAddr]. For example, a value of 0 indicates that		
MCA::UMC::MCA_DEADDR_UMC[55:0] contains a valid byte address. A value of 6 indicates that		
MCA::UMC::MCA_DEADDR_UMC[55:6] contains a valid cache line address and that		
MCA::UMC::MCA_DEADDR_UMC[5:0] are not part of the address and should be ignored by error handling	3	
software. A value of 12 indicates that MCA::UMC::MCA_DEADDR_UMC[55:12] contains a valid 4-KB		
memory page and that MCA::UMC::MCA_DEADDR_UMC[11:0] should be ignored by error handling softw	are.	

write: Read-only.

23:0 Reserved.

**ErrorAddr**. Read-write, Volatile. Reset: Cold,00\_0000\_0000h. Contains the address, if any, associated with the error logged in MCA::UMC::MCA\_DESTAT\_UMC. The lowest-order valid bit of the address is specified in MCA::UMC::MCA\_DEADDR\_UMC[LSB].

### MSRC000 21[1...2]A [UMC Machine Check Miscellaneous 1] (MCA::UMC::MCA MISC1 UMC) Log miscellaneous information associated with errors, as defined by each error type. ch0\_instUMC\_n0\_umc0\_aliasMSR; MSRC000\_211A ch0\_instUMC\_n1\_umc1\_aliasMSR; MSRC000\_212A Bits Description **Valid.** Reset: 1. 1=A valid CntP field is present in this register. AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only. 62 **CntP**. Reset: 1. 1=A valid threshold counter is present. AccessType: Core::X86::Msr::HWCR[McStatusWrEn]? Read-write: Read-only. **Locked.** Reset: 0. 1=Writes to this register are ignored. This bit is set by BIOS to indicate that this register is not available for OS use. BIOS should set this bit if ThresholdIntType is set to SMI. AccessType: Core::X86::Msr::HWCR[McStatusWrEn] ? Read-write : Read-only. 60 **IntP**. Reset: 1. 1=ThresholdIntType can be used to generate interrupts. 0=ThresholdIntType and interrupt generation are not supported. AccessType: (Core::X86::Msr::HWCR[McStatusWrEn] | !MCA::UMC::MCA MISC1 UMC[Locked]) ? Readwrite: Read-only. 59:52 Reserved. 51 **CntEn**. Reset: 0. 1=Count thresholding errors. AccessType: (Core::X86::Msr::HWCR[McStatusWrEn] | !MCA::UMC::MCA MISC1 UMC[Locked]) ? Readwrite: Read-only. 50:49 **ThresholdIntType**. Reset: Cold,0h. Specifies the type of interrupt signaled when Ovrflw is set. 00b=No interrupt. 01b=APIC based interrupt (see Core::X86::Msr::McaIntrCfg[ThresholdLvtOffset]) to all cores. 10b=SMI trigger event. 11b=Reserved. AccessType: (Core::X86::Msr::HWCR[McStatusWrEn] | !MCA::UMC::MCA MISC1 UMC[Locked]) ? Readwrite: Read-only. Ovrflw. Reset: Cold,0. Set by hardware when ErrCnt transitions from FFEh to FFFh; also set by hardware if 48 ErrCnt is initialized to FFFh and transitions from FFFh to 000h. When this field is set, ErrCnt no longer increments. When this bit is set, the interrupt selected by the ThresholdIntType field is generated. AccessType: (Core::X86::Msr::HWCR[McStatusWrEn] | !MCA::UMC::MCA\_MISC1\_UMC[Locked]) ? Readwrite: Read-only. 47:44 Reserved. 43:32 **ErrCnt**. Reset: Cold,000h. This is written by software to set the starting value of the error counter. This is incremented by hardware when errors are logged. When this counter overflows, it stays at FFFh (no rollover). The threshold value, written by software, is (FFFh - the desired error count (the number of errors necessary in order for an interrupt to be taken)); the desired error count of 0 (a write value of FFFh) is not supported.

### MSRC001\_041[1...2] [UMC Machine Check Control Mask] (MCA::UMC::MCA\_CTL\_MASK\_UMC)

Read-write. Reset: 0000_0000_0000_0000h.		
Inhibit detection of an error source.		
_ch0_instUMC_n0_umc0_aliasMSR; MSRC001_0411		
_ch0_instUMC_n1_umc1_aliasMSR; MSRC001_0412		
Bits Description		
63:6 Reserved.		

AccessType: (Core::X86::Msr::HWCR[McStatusWrEn] | !MCA::UMC::MCA MISC1 UMC[Locked]) ? Read-

31:24 **BlkPtr**. Read-write. Reset: 01h. 00h=Extended MISC MSR block is not valid. 01h=Extended MSR block is valid.

5	<b>WriteDataCrcErr</b> . Read-write. Reset: 0. Write data CRC error. A write data CRC error occurred on the DRAM
	data bus.
4	AddressCommandParityErr. Read-write. Reset: 0. Address/Command parity error. A parity error occurred on
	the DRAM address/command bus.
3	<b>ApbErr</b> . Read-write. Reset: 0. Advanced peripheral bus error. An error occurred on the advanced peripheral bus.
2	<b>SdpParityErr</b> . Read-write. Reset: 0. SDP parity error. A parity error was detected on write data from the data
	fabric.
1	WriteDataPoisonErr. Read-write. Reset: 0. Data poison error.
0	<b>DramEccErr</b> . Read-write. Reset: 0. DRAM ECC error. An ECC error occurred on a DRAM Read.

### 4 System Management Unit (SMU)

### 4.1 SMU Registers

The system management unit (SMU) is a subcomponent of the processor that is responsible for a variety of system and power management tasks during boot and runtime.

### 4.2 Thermal (THM)

The thermal block contains all the features related to temperature sensing, control, and reporting. It includes:

- Temperature collection and calculation using TCON (digital control logic) and TMON and Remote Diode Interface macros.
- Fan speed control for off-chip fans.
- Temperature reporting through the SMBUS interface.

### *Table 65: List of Acronyms and Terms used in Thermal (THM)*

Term	Definition
CTF	Critical Temperature Fault or ThermTrip.
TMON	Thermal Monitor

### 4.2.1 Registers

# GPUF ORE Gx59800 (SMU::THM::THM\_TCON\_CUR\_TMP) Read-write. Reset: 0000\_0000h. \_aliasHOSTGPU; GPUFOREGx59800; GPUFOREG=0000\_0000h Bits Description 31:21 CUR\_TEMP. Read-write. Reset: 000h. Provides current control temperature. 20 Reserved. 19 CUR\_TEMP\_RANGE\_SEL. Read-write. Reset: 0. 0=Report on 0C to 225C scale range. 1=Report on -49C to 206C scale range. 18:0 Reserved.

### GPUF0REGx59B14 (SMU::THM::SMUSBI\_ERRATA\_STAT\_REG)

Read-only. Reset: 0000_0000h.		
_aliasHC	_aliasHOSTGPU; GPUF0REGx59B14; GPUF0REG=0000_0000h	
Bits	Bits Description	
31:0	ERRATA_STAT_REG. Read-only. Reset: 0000_0000h. Errata status.	

### 5 Advanced Platform Management Link (APML)

### 5.1 Overview

The Advanced Platform Management Link (APML) is a SMBus v2.0 compatible 2-wire processor slave interface. APML is also referred as the sideband interface (SBI).

APML is used to communicate with the SBI Temperature Sensor Interface (SB-TSI). For related specifications, see 1.2 [Reference Documents].

### 5.1.1 **Definitions**

Table 66: APML Definitions

Term	Description
ARA	Alert response address.
ARP	Address Resolution Protocol
EC	Embedded Controller.
KBC	Keyboard Controller.
Master or SMBus	The device that initiates and terminates all communication and drives the clock, SCL.
Master	
PEC	Packet error code.
POR	Power on reset.
RTS	Remote temperature sensor, typical examples are ADM1032, LM99, MAX6657, EMC1002.
Slave or SMBus slave	The slave cannot initiate SMBus communication and cannot drive the clock but can drive the
	data signal SDA and the alert signal ALERT_L.
TSI	Temperature sensor interface.

### 5.2 SBI Bus Characteristics

The SBI largely follows SMBus v2.0. This section describes the exceptions.

### 5.2.1 SMBus Protocol Support

The SBI follows SMBus protocol except:

- The processor does not implement SMBus master functionality.
- The SBI implements the Send Byte/Receive Byte, Read Byte/Write Byte. Block Read/Block Write and
- Block Write-Block Read Process Call SMBus protocols. The Send Byte/Receive Byte SMBus protocol is only supported by SB-TSI.
- Packet error checking (PEC) is not supported by SB-TSI.
- Address Resolution Protocol (ARP) is not implemented.
- Cumulative clock extensions are not enforced.

### 5.2.2 I2C Support

The processor supports higher I2C-defined speeds as specified in the Physical Layer Characteristics section. The processor supports the I2C master code transmission in order to reach the high-speed bus mode. Multiple SBI commands

may be sent within a single high-speed mode session. Ten-bit addressing is not supported.

### 5.3 SBI Processor Information

### 5.3.1 SBI Processor Pins

Up to six processor pins are used for SBI support: two for data transfer, three for address determination and one for an interrupt output. Of the three address pins, one bit is socket\_id used to determine which package is addressed. These pins do not have changeable pinstrap. The Serial Interface Clock (SIC) and Serial Interface Data (SID) pins function as the SMBus clock and data pins respectively. The SMBus alert pin (ALERT\_L) is used to signal interrupts to the SMBus master.

### **5.3.1.1** Physical Layer Characteristics

The SIC and SID pins differ from the SMBus specification with regard to voltage. System board voltage translators are necessary to convert the SIC and SID pin voltage levels to that of the SMBus specification. SBI supports frequencies of 100 KHz, 400 KHz over SIC.

### **5.3.2** Processor States

SBI responds to SMBus traffic except when PWROK is de-asserted (and for a brief period after it is de-asserted).

### 5.4 SBI Protocols

### 5.4.1 SBI Modified Block Write-Block Read Process Call

SBI uses a modified SMBus PEC-optional Block Write-Block Read Process Call protocol. The change from the SMBus protocol is support for an optional intermediate PEC byte and ACK after the ACK for Data Byte M. The PEC byte after Data Byte N covers all previous bytes excluding the first PEC byte. Figure below shows the transmission protocol. Each byte in the protocol is sent with the most significant bit first (bit[7]). The master may reset the bus by holding the clock low for 25ms as specified by the SMBus Specification.




Figure 23: SBI Transmission Protocol

### 5.4.2 SBI Error Detection and Recovery

This section describes the various error detection and recovery methods that can be used on the SBI bus. The important item in providing a high reliability SBI connection is the ability to detect when an error occurs and to gracefully recover from that error. When the SBI connections are noisy, messages can become garbled which, in turn, may cause undefined behavior on the SBI bus. The most common noise sources are cross-talk and clock skew. Cross-talk results when the SBI connections are routed too close to other signal carrying lines. Clock skew is usually a result of higher than expected capacitance, between the SBI signals (clock and / or data) and ground, which causes the master and slave devices to disagree on when data should be stable and when it is allowed to be changing.

### 5.4.2.1 Error Detection

SBI provides several methods of error detection: protocol ACK/NAK, packet error correction (PEC) fields, and timeouts. The ACK/NAK mechanism is always active in SBI, but the PEC and timeouts are optional.

### 5.4.2.1.1 ACK/NAK Mechanism

After each byte of an SBI message, the device receiving that byte must either acknowledge (ACK) that it received the byte correctly, or deny (NAK) that the byte was correctly received. This is most easily seen in the case of the address bytes which follow a START (or REPEATED START) sequence, but can be used anywhere in the message. In the case of an address byte, if a slave device recognizes the address, it will respond with an ACK and await the rest of the message. If a slave device does not recognize the message, it will respond with a NAK and ignore the rest of the message.

### **5.4.2.1.2 Bus Timeouts**

Bus timeouts should be enabled to prevent a device waiting indefinitely on a message that may not be coming. Some timeouts are used to prevent the SBI bus from waiting for a response from a CPU that is in a power-saving idle mode. Other timeouts are used to allow the slave device to recognize that the bus master is attempting to reset all of the devices on the SBI bus. Either way, when a device recognizes a timeout, it should abort its current message transfer.

### 5.4.2.2 Error Recovery

The simplest form of error recovery is a retry. When the bus master detects an unexpected NAK, it should abort the current transfer and retry the message sequence. In some cases, however, a message can be so garbled that a simple retry is insufficient. This can occur, if there are multiple devices on the bus and a garbled address byte has caused the wrong slave device to be selected. That slave device may even continue to transmit during the retry. In those cases, it will be necessary to force a reset of all devices on the SBI bus, before retrying the message transfer.

### **5.4.2.2.1 SBI Bus Reset**

The bus master can hold the clock low for a period longer the standard timeout in order to force slave devices off the bus (see docSMB section 3.1.1.3 of the System Management Bus (SMBus) Specification, version 2.0). All SBI slave devices are required to reset their communications if another device holds the clock line low for longer than TTimeout, min (25 milliseconds). The devices are required to complete their reset within TTimeout, max (35 milliseconds). SBI bus masters should use the extended timeout to force a reset of all slave devices if a simple retry does not remove an error condition.

### 5.5 SBI Physical Interface

### 5.5.1 SBI SMBus Address

The SMBus address is really 7 bits. Some vendors and the SMBus specification show the address as 8 bits: bits[7:1] as the left-justified address, and bit[0] as the Read/Write flag, where 0 indicates a Write and 1 indicates a Read. Some vendors use only the 7 bits to describe the address.

### 5.5.2 SBI Bus Timing

SBI supports 100KHz standard-mode and 400 KHz fast-mode I2C operation. Refer to the standard-mode and fast-mode timing parameters in the I2C specification.

### 5.5.3 Pass-FET Option

There is a possibility that a device with a standard SMBus interface will not be able to directly interface to SBI. Therefore, pass FETs must be used to create two SMBus segments, see the following figure.




Figure 24: Pass FET Implementation

### Notes:

- SCL and SDA pull-up resistors are the normal pull-up resistors for a SMBus segment, and are not part of the translation circuit. They are shown for completeness.
- The gates of the FETs are tied to a voltage approximately Vgs above the lower rail voltage. A resistive divider is shown, but a convenient power rail will also work.
- Care must be taken to install the FETs so that any body diode does not conduct.
- The key requirement is the high side drive low enough to register as low on the low side (High side Vol < Vil on low side)

### **6** SB Temperature Sensor Interface (SB-TSI)

### 6.1 Overview

The SBI temperature sensor interface (SB-TSI) is an emulation of the software and physical interface of a typical 8-pin remote temperature sensor (RTS), see Figure 25 [RTS Thermal Management Example]. The goal is to resemble a typical RTS so that KBC or BMC firmware requires minimal changes for future AMD products, see Figure 26 [SB-TSI Thermal Management Example]. SB-TSI supports the SMBus protocols that typical RTS supports.




Figure 25: RTS Thermal Management Example




Figure 26: SB-TSI Thermal Management Example

Refer to the following external sources for additional information.

- System Management Bus (SMBus) specification. See docSMB.
- I2C-bus Specification and User Manual, Revision 03. See docI2C.

### 6.1.1 Definitions

*Table 67: SB-TSI Definitions* 

Term	Description
BMC	Base management controller.
TCC	Temperature calculation circuit.
Tctl	Processor temperature control value.

TSM	Temperature sensor macro.
SB-TSI	Sideband Internal Temperature Sensor Interface. See APML.

### 6.2 SB-TSI Protocol

The SB-TSI largely follows SMBus v2.0 specification except:

- The combined-format repeated start sequence is not supported in standard-mode and fast-mode. The response of the processor's SB-TSI to the sequence in undefined.
- Only 7-bit SMBus addresses are supported.
- SB-TSI implements the Send/Receive Byte and Read/Write Byte protocols.
- SB-TSI registers can only be written by using a write byte command.
- Address Resolution Protocol (ARP) is not supported.
- Packet Error Checking (PEC) is not supported.
- The usage of unsupported protocols may lead to an undefined bus condition.
- To release the bus from an undefined condition and to reset the SB-TSI slave, the bus master must hold the clock low for a duration of time that is longer than Ttimeout.max, as specified for SMBus. The time-out needs to be enabled by SBTSI::TimeoutConfig[TimeoutEn] = 1.

### 6.2.1 SB-TSI Send/Receive Byte Protocol

A SMBus master can Read SB-TSI registers by issuing a send byte command with the address of the register to be read as the data byte followed by a receive byte command.

### 6.2.1.1 SB-TSI Address Pointer

The SB-TSI controller has an internal address pointer that is updated when a register is accessed using a Read or Write byte command or when a send byte command is received. This address pointer is used to determine the address of the register being read when a receive byte command is processed by the controller.

### 6.2.2 SB-TSI Read/Write Byte Protocol

An SMBus master can Read or Write SB-TSI registers by issuing a Read or a Write byte command with the address of the register to be read or written in the command code field.

### 6.2.3 Alert Behavior

The ALERT\_L pin is asserted if (SBTSI::Status[TempHighAlert] || SBTSI::Status[TempLowAlert]) && ~SBTSI::Config[AlertMask] as shown in Figure 3. The following registers also affect temperature alert behavior.

- SBTSI::Config[AraDis]: Disables ARA response.
- SBTSI::UpdateRate[UpRate]: Specifies rate at which temperature thresholds are checked.
- {SBTSI::HiTempInt[HiTempInt], SBTSI::HiTempDec[HiTempDec]}: Sets high temperature threshold.
- {SBTSI::LoTempInt[LoTempInt], SBTSI::LoTempDec[LoTempDec]}: Sets low temperature threshold.
- SBTSI::AlertThreshold[AlertThr]: Specifies number of consecutive temperature samples to assert an alert.
- SBTSI::AlertConfig[AlertCompEn]: Specifies ALERT\_L pin to be in latched or comparator mode. Affects ARA.




Figure 27: Alert Assertion Diagram

### 6.2.4 Atomic Read Mechanism

To ensure that the two required Reads (integer and decimal) for reading the CPU temperature are always originated from one temperature value, atomic reading procedures are required. SB-TSI offers functions to maintain atomicity between the temperature integer and decimal bytes.

[The SB-TSI Configuration Register] SBTSI::Config[ReadOrder] specifies the order for reading integer and decimal part of the CPU temperature value for atomic CPU temperature Reads. If SBTSI::Config[ReadOrder] is 0, then a Read of the integer part (SBTSI::CpuTempInt) of the CPU temperature triggers a latch of the decimal part (SBTSI::CpuTempDec) until the next Read of the integer part. This latch syncs the decimal part with the integer part. The integer part is continuously updated.

If SBTSI::Config[ReadOrder] is 1, then the Read order to ensure atomicity is reversed, i.e., decimal part = first, integer part = second.

If it is not possible to ensure a dedicated read order as described above, the Run/Stop bit ([The SB-TSI Configuration Register] SBTSI::Config[RunStop]) may be used to provide atomicity of reading the CPU temperature. If this bit is 0, the CPU temperature registers are updated continuously. If it is 1, they get frozen and always deliver their last value on Read requests.

- Set SBTSI::Config[RunStop].
- Read the integer (SBTSI::CpuTempInt) or the decimal (SBTSI::CpuTempDec) part of the CPU temperature.
- Read the remaining part of the CPU temperature.
- Clear SBTSI::Config[RunStop].

### 6.2.5 SB-TSI Temperature and Threshold Encodings

SB-TSI CPU temperature readings and limit registers encode the temperature in increments of 0.125 from 0 to 255.875. The high byte represents the integer portion of the temperature from 0 to 255. One increment in the high byte is equivalent to a step of one. The upper three bits of the low byte represent the decimal portion of the temperature. One increment of these bits is equivalent to a step of 0.125.

*Table 68: SB-TSI CPU Temperature and Threshold Encoding Examples* 

Temperature	Temperature High Byte	Temperature Low Byte
	SBTSI::CpuTempInt[CpuTempInt]	SBTSI::CpuTempDec[CpuTempDec]
	SBTSI::HiTempInt[HiTempInt]	SBTSI::HiTempDec[HiTempDec]

	SBTSI::LoTempInt[LoTempInt]	SBTSI::LoTempDec[LoTempDec]
0.000 °C	0000_0000Ь	0000_0000Ь
1.000 °C	0000_0001b	0000_0000Ь
25.125 °C	0001_1001b	0010_0000b
50.875 °C	0011_0010b	1110_0000b
90.000 °C	0101_1010b	0000_0000b

### 6.2.6 SB-TSI Temperature Offset Encoding

By default, SBTSI::CpuTempInt and SBTSI::CpuTempDec provide Tctl from the processor. The temperature offset registers allow the system to adjust the SB-TSI temperature from Tctl.

The SB-TSI temperature offset registers use a different encoding in order to provide negative temperature values. SBTSI::CpuTempOffInt[CpuTempOffInt] and SBTSI::CpuTempOffDec[CpuTempOffDec] form an 11-bit, 2's complement value representing the temperature offset. The high byte encodes the integer portion of the temperature and the upper three bits of the low byte represent the fractional portion of the temperature offset. One increment of these bits is equivalent to a step of 0.125 °C. After reset the offset is always set to 0 °C. Software needs to adjust the offset to the appropriate level.

Table 69: SB-TSI Temperature Offset Encoding Examples

	- i	·
Temperature	Temperature High Byte	Temperature Low Byte
	SBTSI::CpuTempOffIn	SBTSI::CpuTempOffDe
	t[CpuTempOffInt]	c[CpuTempOffDec]
-10.375 °C	1111_0101b	1010_0000b
-0.250 °C	1111_1111b	1100_000b
0.000 °C	0000_0000b	0000_0000Ь
0.875 °C	0000_0000b	1110_0000b
10.000 °C	0000_1010b	0000_0000Ь

### **6.3** SB-TSI Physical Interface

This chapter describes the physical interface of the SB-TSI.

### 6.3.1 SB-TSI SMBus Address

The SMBus address is really 7 bits. Some vendors and the SMBus specification show the address as 8 bits: bits[7:1] as the left-justified address, and bit[0] as the Read/Write flag, where 0 indicates a Write and 1 indicates a Read. Some vendors use only the 7 bits to describe the address. The addresses can vary with address select pins.

*Table 70: SB-TSI Address Encodings* 

Socket ID	SB-TSI Address
0b	98h for 8 bit or 4Ch for 7 bit.
1b	90h for 8 bit or 48h for 7 bit.

### 6.3.2 SB-TSI Bus Timing

SB-TSI supports standard-mode (100 kHz) and fast-mode (400 kHz) according to the I2C-bus Specification and User Manual.

### **6.3.3** SB-TSI Bus Electrical Parameters

SB-TSI conforms to most of the I2C fast-mode electrical parameters. See the Electrical Data Sheet for the processor family for electrical parameters.

### 6.3.4 Pass-FET Option

The KBC may not have the capability to directly interface to SB-TSI. Pass FETs may be used to create two SMBus segments, see Figure 4.




Figure 28: Pass FET Implementation

### Notes:

- SCL and SDA pull-up resistors (R5 and R6, respectively) are the normal pull-up resistors for an SMBus segment and are not part of the translation circuit. They are shown for completeness.
- The gates of the FETs are tied to a voltage approximately Vgs above the lower rail voltage. A resistive divider is shown, but a convenient power rail would do nicely.
- Care must be taken to install the FETs so that any body diode does not conduct.
- The key requirement is that the high side drive low enough to register as a low on the low side. (High side Vol < Vil on low side)

### 6.4 SB-TSI Registers

Reads to unimplemented registers return 00h. Writes to unimplemented registers are discarded.

### SBTSIx01 [CPU Integer Temperature] (SBTSI::CpuTempInt)

# Read-only.

The CPU temperature is calculated by adding the CPU temperature offset (SBTSI::CpuTempOffInt,

SBTSI::CpuTempOffDec) to the processor control temperature (Tctl). SBTSI::CpuTempInt and SBTSI::CpuTempDec combine to return the CPU temperature. For the temperature encoding, see 6.2.5 [SB-TSI Temperature and Threshold Encodings]

Bits	Description	n

7:0 **CpuTempInt**: **integer CPU temperature value**. Read-only. Reset: Cold,XXh. This field returns the integer

portion of the CPU temperature.

### SBTSIx02 [SB-TSI Status] (SBTSI::Status)

### Read-only, Volatile.

If SBTSI::AlertConfig[AlertCompEn] == 0 , the temperature alert is latched high until the alert is Read. If SBTSI::AlertConfig[AlertCompEn] == 1, the alert is cleared when the temperature does not meet the threshold conditions for temperature and number of samples. See 6.2.3 [Alert Behavior].

Contan	conditions for temperature and number of samples. See 6.2.3 [Afert Benavior].		
Bits	Description		
7:5	Reserved.		
4	<b>TempHighAlert</b> : <b>temperature high alert</b> . Read-only, Volatile. Reset: Cold, X. 1=Indicates that the CPU		
	temperature is greater than or equal to the high temperature threshold (SBTSI::HiTempInt, SBTSI::HiTempDec)		
	for SBTSI::AlertThreshold[AlertThr] consecutive samples. 0=Indicates that the CPU temperature is less than the		
	high temperature threshold (SBTSI::HiTempInt, SBTSI::HiTempDec) for SBTSI::AlertThreshold[AlertThr]		
	samples and SBTSI::AlertConfig[AlertCompEn] == 1. Hardware will clear this bit when Read if		
	SBTSI::AlertConfig[AlertCompEn] == 0.		
3	<b>TempLowAlert</b> : <b>temperature low alert</b> . Read-only, Volatile. Reset: Cold, X. 1=Indicates that the CPU		
	temperature is less than or equal to the low temperature threshold (SBTSI::LoTempInt, SBTSI::LoTempDec) for		
	SBTSI::AlertThreshold[AlertThr] consecutive samples. 0=Indicates the CPU temperature is greater than the low		
	temperature threshold (SBTSI::LoTempInt, SBTSI::LoTempDec) for SBTSI::AlertThreshold[AlertThr] samples		
	and SBTSI::AlertConfig[AlertCompEn] == 1. Hardware will clear this bit when Read if		
	SBTSI::AlertConfig[AlertCompEn] == 0.		
2:0	Reserved.		

### SBTSIx03 [SB-TSI Configuration] (SBTSI::Config)

Reset: Cold,00h.

The bits in this register are Read-only and can be written by Writing to the corresponding bits in SBTSI::ConfigWr. See 6.2.3 [Alert Behavior] and 6.2.4 [Atomic Read Mechanism].

Bits	Description
7	<b>AlertMask</b> : <b>alert mask</b> . Read-only, Volatile. Reset: Cold, 0. 0=ALERT_L pin enabled. 1=ALERT_L pin disabled
	and does not assert. IF (SBTSI::Config[AraDis] == 0) THEN Read-only; set-by-hardware. ELSE Read-only
	ENDIF. Hardware sets this bit if SBTSI::Config[AraDis] == 0, either SBTSI::Status[TempHighAlert] == 1 or
	SBTSI::Status[TempLowAlert] == 1, and a successful ARA is sent.
6	<b>RunStop</b> : <b>run stop</b> . Read-only. Reset: Cold,0. 0=Updates to SBTSI::CpuTempInt and SBTSI::CpuTempDec and
	the alert comparisons are enabled; Alert history counters (specified by SBTSI::AlertThreshold[AlertThr]) and the
	corresponding timer (specified by SBTSI::UpdateRate[UpRate]) continue to update. 1=Updates to
	SBTSI::CpuTempInt and SBTSI::CpuTempDec and the alert comparisons are disabled; Alert history counters
	(specified by SBTSI::AlertThreshold[AlertThr]) and the corresponding timer (specified by
	SBTSI::UpdateRate[UpRate]) are stopped. See 6.2.4 [Atomic Read Mechanism] for further details.

- ReadOrder: atomic read order. Read-only. Reset: Cold,0. 0=Reading SBTSI::CpuTempInt causes the state of SBTSI::CpuTempDec to be latched. 1=Reading SBTSI::CpuTempDec causes the state of SBTSI::CpuTempInt to be latched. See 6.2.4 [Atomic Read Mechanism] for further details.
- 4:2 Reserved.
- 1 **AraDis: ARA disable.** Read-only. Reset: Cold,0. Read-only. 1=ARA response disabled.
- 0 Reserved.

### SBTSIx04 [Update Rate] (SBTSI::UpdateRate)

Read-write. Reset: Cold,08h	R	Rea	ad-v	write.	Reset:	Cold	1,08h	
-----------------------------	---	-----	------	--------	--------	------	-------	--

### Bits Description

7:0 **UpRate: update rate.** Read-write. Reset: Cold,08h. This field specifies the rate at which CPU temperature is compared against the temperature thresholds to determine if an alert event has occurred. Write access causes a reset of the alert history counters (specified by SBTSI::AlertThreshold[AlertThr]) and the corresponding timer (specified by SBTSI::UpdateRate[UpRate]).

ValidVal	ues:
Value	Description
00h	0.0625 Hz
01h	0.125 Hz
02h	0.25 Hz
03h	0.5 Hz
04h	1 Hz
05h	2 Hz
06h	4 Hz
07h	8 Hz
08h	16 Hz
09h	32 Hz
0Ah	64 Hz
FFh-	Reserved.
0Bh	

### SBTSIx07 [High Temperature Integer Threshold] (SBTSI::HiTempInt)

Read-write. Reset: Cold,46h.

The high temperature threshold specifies the CPU temperature that causes ALERT\_L to assert if the CPU temperature is greater than or equal to the threshold. SBTSI::HiTempInt and SBTSI::HiTempDec combine to specify the high temperature threshold. See 6.2.5 [SB-TSI Temperature and Threshold Encodings]. Reset value equals 70 °C. Write access causes a reset of the alert history counters (specified by SBTSI::AlertThreshold[AlertThr]) and the corresponding timer (specified by SBTSI::UpdateRate[UpRate]). See 6.2.3 [Alert Behavior].

Bits	Description
7:0	<b>HiTempInt:</b> high temperature integer threshold. Read-write. Reset: Cold,46h. This field specifies the integer
	portion of the high temperature threshold.

### SBTSIx08 [Low Temperature Integer Threshold] (SBTSI::LoTempInt)

Read-write. Reset: Cold.00h.

The low temperature threshold specifies the CPU temperature that causes ALERT\_L to assert if the CPU temperature is less than or equal to the threshold. SBTSI::LoTempInt and SBTSI::LoTempDec combine to specify the low temperature threshold. See 6.2.5 [SB-TSI Temperature and Threshold Encodings]. Write access causes a reset of the alert history counters (specified by SBTSI::AlertThreshold[AlertThr]) and the corresponding timer (specified by SBTSI::UpdateRate[UpRate]). See 6.2.3 [Alert Behavior].

	Bits	Description		
Ī	7:0	<b>LoTempInt</b> : <b>low temperature integer threshold</b> . Read-write. Reset: Cold,00h. This field specifies the integer		
		portion of the low temperature threshold.		

### SBTSIx09 [SB-TSI Configuration Write] (SBTSI::ConfigWr)

- 0 - 1			
Read-	Read-write. Reset: Cold,00h.		
This r	This register provides write access to SBTSI::Config.		
Bits	Description		
7	AlertMask: alert mask. Read-write. Reset: Cold,0. See SBTSI::Config[AlertMask].		
6	RunStop: run stop. Read-write. Reset: Cold,0. See SBTSI::Config[RunStop].		
5	ReadOrder: atomic read order. Read-write. Reset: Cold,0. See SBTSI::Config[ReadOrder].		
4:2	Reserved.		
1	AraDis: ARA disable. Read-write. Reset: Cold,0. See SBTSI::Config[AraDis].		
0	Reserved.		

### SBTSIx10 [CPU Decimal Temperature] (SBTSI::CpuTempDec)

Read-only.

See SBTSI::CpuTempInt.			
Bits	S Description		
7:5	<b>CpuTempDec</b> : <b>decimal CPU temperature value</b> . Read-only. Reset: Cold,XXXb. Read-only. This field returns		
	the decimal portion of the CPU temperature.		
4:0	Reserved.		

### SBTSIx11 [CPU Temperature Offset High Byte] (SBTSI::CpuTempOffInt)

Read-write. Reset: Cold,00h.

SBTSI::CpuTempOffInt and SBTSI::CpuTempOffDec combine to specify the CPU temperature offset. See 6.2.6 [SB-TSI Temperature Offset Encoding] for encoding details.

### Bits Description

7:0 **CpuTempOffInt: CPU temperature integer offset.** Read-write. Reset: Cold,00h. This field specifies the integer portion of the CPU temperature offset added to Tctl to calculate the CPU temperature. Write access causes a reset of the alert history counters (specified by SBTSI::AlertThreshold[AlertThr]) and the corresponding timer (specified by SBTSI::UpdateRate[UpRate]).

### SBTSIx12 [CPU Temperature Decimal Offset] (SBTSI::CpuTempOffDec)

Read-write. Reset: Cold,00h.

See SBTSI::CpuTempOffInt.

Bits Description

7:5 CpuTempOffDec: CPU temperature decimal offset. Read-write. Reset: Cold,0h. This field specifies the decimal/fractional portion of the CPU temperature offset added to Tctl to calculate the CPU temperature. Write access causes a reset of the alert history counters (specified by SBTSI::AlertThreshold[AlertThr]) and the

4:0 Reserved.

### SBTSIx13 [High Temperature Decimal Threshold] (SBTSI::HiTempDec)

corresponding timer (specified by SBTSI::UpdateRate[UpRate]).

Read-write. Reset: Cold,00h.

See SBTSI::HiTempInt.

### **Bits Description**

- 7:5 **HiTempDec**: **high temperature decimal threshold**. Read-write. Reset: Cold,0h. This field specifies the decimal portion of the high temperature threshold.
- 4:0 Reserved.

### SBTSIx14 [Low Temperature Decimal Threshold] (SBTSI::LoTempDec)

Read-write. Reset: Cold,00h.

See SBTSI::LoTempInt.

### Bits Description

- 7:5 **LoTempDec: low temperature decimal threshold**. Read-write. Reset: Cold,0h. This field specifies the decimal portion of the low temperature threshold.
- 4:0 Reserved.

### SBTSIx22 [Timeout Configuration] (SBTSI::TimeoutConfig)

Read-write. Reset: Cold,80h.		
Bits	its Description	
7	<b>TimeoutEn</b> : <b>SMBus timeout enable</b> . Read-write. Reset: Cold,1. 0=SMBus defined timeout support disabled.	
	1=SMBus defined timeout support enabled. SMBus timeout enable.	
6:0	Reserved.	

### SBTSIx32 [Alert Threshold Register] (SBTSI::AlertThreshold)

Read-write. Reset: Cold,00h.

See 6.	See 6.2.3 [Alert Behavior].				
Bits	Description				
7:3	Reserved.				
2:0	<b>AlertThr: alert threshold</b> . Read-write. Reset: Cold,0h. Specifies the number of consecutive CPU temperature				
	samples for which a temperature alert condition needs to remain valid before the corresponding alert bit is set. For				
	SBTSI::AlertConfig[AlertCompEn] == 1, it specifies the number of consecutive CPU temperature samples for				
	which a temperature alert condition need to remain not valid before the corresponding alert bit gets cleared. Write				
	access resets the alert history counters (specified by SBTSI::AlertThreshold[AlertThr]) and the corresponding				
	timer (specified by SBTSI::UpdateRate[UpRate]). Details in SBTSI::Status.				
	ValidValues:				
	Value Description				
	0h 1 Sample				
	6h-1h <value+1> Samples</value+1>				
	7h 8 Samples				

# SBTSIxBF [Alert Configuration] (SBTSI::AlertConfig)

Read-	Read-write.		
Bits	Description		
7:1	Reserved.		
0	AlertCompEn: alert comparator mode enable. Read-write. Reset: Cold,X. 0=SBTSI::Status[TempHighAlert]		
	and SBTSI::Status[TempLowAlert] are Read to clear. 1=SBTSI::Status[TempHighAlert] and		
SBTSI::Status[TempLowAlert] are Read-only; ARA response disabled. Write access does not change			
history counters (specified by SBTSI::AlertThreshold[AlertThr]) or the corresponding timer (specified by SBTSI::UpdateRate[UpRate]). See SBTSI::Status.			

# SBTSIxFE [Manufacture ID] (SBTSI::ManId)

Read-only. Reset: Cold,00h.		
Bits	Description	
7:1	Reserved.	
0	ManId: Manufacture ID. Read-only. Reset: Cold,0. Returns the AMD manufacture ID.	

### SBTSIxFF [Revision] (SBTSI::Revision)

0210	(DETOTALL [REVISION]		
Read-only. Reset: Cold,04h.			
Bits	Description		
7:0	<b>Revision</b> : <b>SB-TSI revision</b> . Read-only. Reset: Cold,04h. Specifies the SBI temperature sensor interface revision.		

# **List of Namespaces**

Namespace	Heading(s)
Core::X86::Apic	2.1.12.2.2 [Local APIC
·	Registers]
Core::X86::Cpuid	2.1.13.1 [CPUID Instruction
	Functions]
Core::X86::Msr	2.1.14.1 [MSRs -
	MSR0000_xxxx]
	2.1.14.2 [MSRs -
	MSRC000_0xxx]
	2.1.14.3 [MSRs -
	MSRC001_0xxx]
	2.1.14.4 [MSRs -
C VOC D C	MSRC001_1xxx]
Core::X86::Pmc::Core	2.1.15.2 [Large Increment per
	Cycle Events]
	2.1.15.3.1 [Floating Point (FP) Events]
	2.1.15.3.2 [LS Events]
	2.1.15.3.3 [IC and BP Events]
	2.1.15.3.4 [DE Events]
	2.1.15.3.5 [EX (SC) Events]
	2.1.15.3.6 [L2 Cache Events]
Core::X86::Pmc::L3	2.1.15.4.1 [L3 Cache PMC
	Events]
Core::X86::Smm	2.1.12.1.6 [System
	Management State]
IO	2.1.8 [PCI Configuration
	Legacy Access]
MCA::CS	3.2.5.8 [CS]
MCA::DE	3.2.5.4 [DE]
MCA::EX	3.2.5.5 [EX]
MCA::FP	3.2.5.6 [FP]
MCA::IF	3.2.5.2 [IF]
MCA::L2	3.2.5.3 [L2]
MCA::L3	3.2.5.7 [L3 Cache]
MCA::LS	3.2.5.1 [LS]
MCA::PIE	2.0.F.0.[DIE]
WICAPIL	3.2.5.9 [PIE]
MCA::UMC	3.2.5.10 [UMC]

# **List of Definitions**

ABS: ABS(integer expression): Remove sign from signed value.

**AGESA™**: AMD Generic Encapsulated Software Architecture.

AM4: Desktop, single die, single socket. For client desktop platform (uPGA)

DDR4. AM4 = (Core::X86::Cpuid::BrandId[PkgType] == 02h).

APML: Advanced Platform Management Link.

**APP**: Accelerated Processor Platform. **APU**: Accelerated Processing Unit.

**ARA**: Alert response address.

ARP: Address Resolution Protocol

**BAR**: The BAR, or base address register, physical register mnemonic format

is of the form PREFIXxZZZ.

**BatteryPower**: The system is running from a limited energy or battery power source or otherwise undocked from a continuous power supply. Setting using this definition may be required to change during run time.

**BCD**: Binary Coded Decimal number format.

**BCS**: Base Configuration Space.

**BIST**: Built-In Self-Test. Hardware within the processor that generates test patterns and verifies that they are stored correctly (in the case of memories) or received without error (in the case of links).

BMC: Base management controller.

**Boot VID**: Boot Voltage ID. This is the VDD and VDDNB voltage level that the processor requests from the external voltage regulator during the initial phase of the cold boot sequence.

**BSC**: Boot strap core. Core 0 of the BSP.

BSP: Boot strap processor.

**C-states**: These are ACPI defined core power states. C0 is operational. All other C-states are low-power states in which the processor is not executing code. See docACPI.

**Canonical-address:** An address in which the state of the most-significant implemented bit is duplicated in all the remaining higher-order bits, up to bit 631

CCX: Core Complex where more than one core shares L3 resources.

CEIL: CEIL(real expression): Rounds real number up to nearest integer.

**CMP**: Specifies the core number.

**COF**: Current operating frequency of a given clock domain.

**Cold reset**: PWROK is de-asserted and RESET\_L is asserted.

**Configurable**: Indicates that the access type is configurable as described by the documentation.

**CoreCOF**: Core current operating frequency in MHz. CoreCOF = (Core::X86::Msr::PStateDef[CpuFid[7:0]]/Core::X86::Msr::PStateDef[CpuD fsId])\*200. A nominal frequency reduction can occur if spread spectrum

clocking is enabled. **COUNT**: COUNT(integer expression): Returns the number of binary 1's in the integer.

**CpuCoreNum**: Specifies the core number.

**CPUID**: The CPUID, or x86 processor identification state, physical register mnemonic format is of the form CPUID FnXXXX\_XXXX\_EiX[\_xYYY], where XXXX\_XXXX is the hex value in the EAX and YYY is the hex value in ECX.

**DID**: Divisor Identifier. Specifies the post-PLL divisor used to reduce the COF.

**docACPI**: Advanced Configuration and Power Interface (ACPI)

Specification. <a href="http://www.acpi.info">http://www.acpi.info</a>. docAM4: Socket AM4 Processor Functional Data Sheet, order# 55509.

**docAPM1**: AMD64 Architecture Programmer's Manual Volume 1: Application Programming, order# 24592.

**docAPM2**: AMD64 Architecture Programmer's Manual Volume 2: System Programming, order# 24593.

**docAPM3**: AMD64 Architecture Programmer's Manual Volume 3: Instruction-Set Reference, order# 24594.

**docAPM4**: AMD64 Architecture Programmer's Manual Volume 4: 128-Bit and 256-Bit Media Instructions, order# 26568.

**docAPM5**: AMD64 Architecture Programmer's Manual Volume 5: 64-Bit Media and x87 Floating-Point Instructions, order# 26569.

**docASF**: Alert Standard Format Specification. <a href="http://dmtf.org/standards/asf.docATA">http://dmtf.org/standards/asf.docATA</a>: AT Attachment with Packet Interface. <a href="http://www.t13.org">http://www.t13.org</a>.

docDP: VESA DisplayPort Standard. <a href="http://www.vesa.org/vesa-standards">http://www.vesa.org/vesa-standards</a>. docI2C: I2C Bus Specification.

http://www.nxp.com/documents/user\_manual/UM10204.pdf

docIOMMU: AMD I/O Virtualization Technology Specification, order#

48882.

docJEDEC: JEDEC Standards. http://www.jedec.org.

docPCIe: PCI Express® Specification. <a href="http://www.pcisig.org.docPCIIb">http://www.pcisig.org.docPCIIb</a>: PCI Local Bus Specification. <a href="http://www.pcisig.org.docPCIIb">http://www.pcisig.org.docPCIIb</a>: PCI Local Bus Specification. <a href="http://www.pcisig.org">http://www.pcisig.org</a>.

docRevG: Revision Guide for AMD Family 17h Models 60h-6Fh Processors

**docSATA**: Serial ATA Specification. <a href="https://www.sata-io.org">http://www.sata-io.org</a>, **docSDHC**: Secure Digital Host Controller Standard Specification. <a href="https://www.sdcard.org">https://www.sdcard.org</a>.

docSFP6: AMD FP6 Processor Functional Data Sheet, order# 56177.

docSMB: System Management Bus (SMBus) Specification.

http://www.smbus.org.

docUSB: Universal Serial Bus Specification. http://www.usb.org.

**Doubleword**: A 32-bit value.

**DW**: Doubleword.

**EC**: Embedded Controller.

**ECS**: Extended Configuration Space.

**EDC**: Electrical design current. Indicates the maximum current the voltage

rail can demand for a short, thermally insignificant time.

**Error-on-read**: Error occurs on read. **Error-on-write**: Error occurs on write.

**Error-on-write-0**: Error occurs on bitwise write of 0.

**Error-on-write-1**: Error occurs on bitwise write of 1.

**FCH**: The integrated platform subsystem that contains the IO interfaces and bridges them to the system BIOS. Previously included in the Southbridge. **FDS**: Functional Data Sheet. There is one FDS for each package type. See

docAM4 or docSFP6.

**FID**: Frequency Identifier. Specifies the PLL frequency multiplier for a given

clock domain.

**FLOOR**: FLOOR(integer expression): Rounds real number down to nearest integer.

neger.

**FP6**: Notebook package for direct solder boards (uPGA). FP6 =

(Core::X86::Cpuid::BrandId[PkgType] == 00h).

**FreeRunSampleTimer**: An internal free running timer used by many power management features.

GB: Gbyte or Gigabyte; 1,073,741,824 bytes.

**GT/s**: Giga-Transfers per second.

HTC: Hardware Thermal Control.

**HTC-active state**: Hardware-controlled lower-power, lower performance state used to reduce temperature.

**IBS**: Instruction based sampling.

**IFCM**: Isochronous flow-control mode, as defined in the link specification. **Inaccessible**: Not readable or writable (e.g., Hide? Inaccessible: Read-

Write). **IO configuration**: Access to configuration space though IO ports CF8h and

IORR: IO range register.

KB: Kbyte or Kilobyte; 1024 bytes.

**KBC**: Keyboard Controller.

**L1 cache**: The level 1 caches (instruction cache and the data cache).

L2 cache: The level 2 caches.

L3: Level 3 Cache. The L3 term is also in Addrmaps to enumerate CCX

L3 cache: Level 3 Cache.

**Linear (virtual) address:** The address generated by a core after the segment is applied.

LINT: Local interrupt.

**Logical address:** The address generated by a core before the segment is applied

**logical mnemonic**: The register mnemonic format that describes the register functionally, what namespace to which the register belongs, a name for the register that connotes its function, and optionally, named parameters that indicate the different function of each instance (e.g.,

Link::Phy::PciDevVendIDF3). See XX [Logical Mnemonic].

**LVT**: Local vector table. A collection of APIC registers that define interrupts for local events (e.g., APIC[530:500] [Extended Interrupt [3:0] Local Vector

**Master abort**: This is a PCI-defined term that is applied to transactions on other than PCI buses. It indicates that the transaction is terminated without affecting the intended target; reads return all 1s; write are discarded; the master abort error code is returned in the response, if applicable; master abort error bits are set if applicable.

**Master or SMBus Master**: The device that initiates and terminates all communication and drives the clock, SCL.

**MAX**: MAX(integer expression list): Picks maximum integer or real value of comma separated list.

MB: Megabyte; 1024 KB.

MCA: Machine Check Architecture.

MCAX: Machine Check Architecture eXtensions.

**MergeEvent**: A PMC event that is capable of counter increments greater than 15, thus requiring merging a pair of even/odd performance monitors. **MIN**: MIN(integer expression list): Picks minimum integer or real value of comma separated list.

**MMIO**: Memory-Mapped Input-Output range. This is physical address space that is mapped to the IO functions such as the IO links or MMIO configuration.

**MMIO configuration**: Access to configuration space through memory space.

MSR: The MSR, or x86 model specific register, physical register mnemonic format is of the form MSRXXXX\_XXXX, where XXXX\_XXXX is the hexadecimal MSR number. This space is accessed through x86 defined RDMSR and WRMSR instructions.

**MTRR**: Memory-type range register. The MTRRs specify the type of memory associated with various memory ranges.

**NBC**: NBC = (CPUID Fn00000001\_EBX[LocalApicId[3:0]]==0). Node Base Core. The lowest numbered core in the node.

**Node**: A node, is an integrated circuit device that includes one to 8 cores (one or two Core Complexes).

NTA: Non-Temporal Access. **OW**: Octword. An 128-bit value.

**PCICFG**: The PCICFG, or PCI defined configuration space, physical register mnemonic format is of the form DXFYxZZZ.

PCIe®: PCI Express.

PCS: Physical Coding Sublayer.

PEC: Packet error code.

**physical mnemonic**: The register mnemonic that is formed based on the physical address used to access the register (e.g., D18F3x00). See XX [Physical Mnemonic].

**PMC**: The PMC, or x86 performance monitor counter, physical register mnemonic format is any of the forms {PMCxXXX, L2IPMCxXXX, NBPMCxXXX}, where XXX is the performance monitor select.

POR: Power on reset.

**POW**: POW(base, exponent): POW(x,y) returns the value x to the power of y.

**Processor**: A package containing one or more Nodes. See Node.

PTE: Page table entry.

QW: Quadword. A 64-bit value.

**REFCLK**: Reference clock. Refers to the clock frequency (100 MHz) or the clock period (10 ns) depending on the context used.

**register instance parameter specifier**: A register instance parameter specifier is of the form \_register parameter name[register parameter value list] (e.g., The register instance parameter specifier \_dct[1:0] has a register parameter name of dct (The DCT PHY instance name) and a register parameter value list of "1:0" or 2 instances of DCT PHY).

**register instance specifier:** The register instance specifier exists when there is more than one instance for a register. The register instance specifier consists of one or more register instance parameter specifier (e.g., The register instance specifier \_dct[1:0]\_chiplet[BCST,3:0]\_pad[BCST,11:0] consists of 3 register instance parameter specifiers, \_dct[1:0], \_chiplet[BCST,3:0], and \_pad[BCST,11:0]).

**register name**: A name that cannotes the function of the register.

**register namespace**: A namespace for which the register name must be unique. A register namespace indicates to which IP it belongs and an IP may have multiple namespaces. A namespace is a string that supports a list of "::" separated names. The convention is for the list of names to be hierarchical, with the most significant name first and the least significant name last (e.g., Link::Phy::Rx is the RX component in the Link PHY).

register parameter name: A register parameter name is the name of the number of instances at some level of the logical hierarchy (e.g., The register parameter name dct specifies how many instances of the DCT PHY exist). register parameter value list: The register parameter value list is the logical name for each instance of the register parameter name (e.g., For \_dct[1:0], there are 2 DCT PHY instances, with the logical names 0 and 1, but it should be noted that the logical names 0 and 1 can correspond to physical values other than 0 and 1). It is the purpose of the AddressMappingTable to map these register parameter values to physical address values for the register. Reserved-write-as-0: Reads are undefined. Must always write 0.

Reserved-write-as-1: Reads are undefined. Must always write 1.

**ROUND**: ROUND(real expression): Rounds to the nearest integer; halfway rounds away from zero.

RTS: Remote temperature sensor, typical examples are ADM1032, LM99, MAX6657, EMC1002.

SB-TSI: Sideband Internal Temperature Sensor Interface. See APML.

**Shutdown**: A state in which the affected core waits for either INIT, RESET, or NMI. When shutdown state is entered, a shutdown special cycle is sent on the IO links.

**Slave or SMBus slave:** The slave cannot initiate SMBus communication and cannot drive the clock but can drive the data signal SDA and the alert signal ALERT L.

**SMAF**: System Management Action Field. This is the code passed from the SMC to the processors in STPCLK assertion messages.

**SMI**: System management interrupt.

SMM: System Management Mode. SMT: Simultaneous multithreading. See

Core::X86::Cpuid::CoreId[ThreadsPerCore].

**Speculative event**: A performance monitor event counter that counts all occurrences of the event even if the event occurs during speculative code execution.

SVM: Secure virtual machine.

TCC: Temperature calculation circuit.

Tctl: Processor temperature control value.

TDC: Thermal Design Current.

**TDP**: Thermal Design Power. A power consumption parameter that is used in conjunction with thermal specifications to design appropriate cooling solutions for the processor.

Thread: One architectural context for instruction execution.

**Token:** A scheduler entry used in various DF queues to track outstanding requests.

**TOM2**: Top of extended Memory. **TSI**: Temperature sensor interface.

**TSM**: Temperature sensor macro.

**UMI**: Unified Media Interface. The link between the processor and the FCH. **UNIT**: UNIT(register field reference): Input operand is a register field reference that contains a valid values table that defines a value with a unit (e.g., clocks, ns, ms, etc). This function takes the value in the register field and returns the value associated with the unit (e.g., If the field had a valid value definition where 1010b was defined as 5 ns). Then if the field had the value of 1010b, then UNIT() would return the value 5.

**Unpredictable**: The behavior of both reads and writes is unpredictable.

**VDD**: Main power supply to the processor core logic.

VID: Voltage level identifier.

**Volatile**: Indicates that a register field value may be modified by hardware, firmware, or microcode when fetching the first instruction and/or might have read or write side effects. No read may depend on the results of a previous read and no write may be omitted based on the value of a previous read or write.

Warm reset: RESET\_L is asserted only (while PWROK stays high).

**WDT**: Watchdog timer. A timer that detects activity and triggers an error if a specified period of time expires without the activity.

WRIG: Writes Ignored.

**Write-0-only**: Writing a 0 clears to a 0; Writing a 1 has no effect. If not associated with Read, then reads are undefined.

**Write-1-only**: Writing a 1 sets to a 1; Writing a 0 has no effect. If not associated with Read, then reads are undefined.

**Write-1-to-clear**: Writing a 1 clears to a 0; Writing a 0 has no effect. If not associated with Read, then reads are undefined.

**Write-once**: Capable of being written once; all subsequent writes have no effect. If not associated with Read, then reads are undefined.

X2APICEN: x2 APIC is enabled. X2APICEN = (Core::X86::Msr::APIC\_BAR[ApicEn] && Core::X86::Msr::APIC\_BAR[x2ApicEn]). XBAR: Cross bar; command packet switch.

# **Memory Map - MSR**

Physical Mnemonic	Namespace
0000_0000h0000_0001h	MCA::LS
0000_0010h0000_02FFh	Core::X86::Msr
0000_0400h0000_0403h	MCA::LS
0000_0404h0000_0407h	MCA::IF
0000_0408h0000_040Bh	MCA::L2
0000_040Ch0000_040Fh	MCA::DE
0000_0414h0000_0417h	MCA::EX
0000_0418h0000_041Bh	MCA::FP
0000_041Ch0000_043Bh	MCA::L3
0000_0444h0000_044Bh	MCA::UMC
0000_044Ch0000_0453h	MCA::CS
0000_046Ch0000_046Fh	MCA::PIE
0000_0802hC000_0410h	Core::X86::Msr
C000_2000hC000_2009h	MCA::LS
C000_2010hC000_2016h	MCA::IF
C000_2020hC000_2029h	MCA::L2
C000_2030hC000_2036h	MCA::DE
C000_2050hC000_2056h	MCA::EX
C000_2060hC000_2066h	MCA::FP
C000_2070hC000_20E9h	MCA::L3
C000_2110hC000_212Ah	MCA::UMC
C000_2130hC000_2149h	MCA::CS
C000_21B0hC000_21B9h	MCA::PIE
C001_0000hC001_02F1h	Core::X86::Msr
C0010400	MCA::LS
C0010401	MCA::IF
C0010402	MCA::L2
C0010403	MCA::DE
C0010405	MCA::EX
C0010406	MCA::FP
C001_0407hC001_040Eh	MCA::L3
C001_0411hC001_0412h	MCA::UMC
C001_0413hC001_0414h	MCA::CS
C001041B	MCA::PIE
C001_1002hC001_103Ch	Core::X86::Msr

# **Memory Map - Main Memory**

Physical Mnemonic	Namespace
00000000: GPUF0REGx59800x59B14	SMU::THM