

F43314B

REAR FLOOR CROSSMEMBER NO. 2 (ASSY)



REMOVAL-INSTALLATION



INSTALLATION POINT

- Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- 2 After welding, apply the foamed sealing material to the corresponding parts. (See the paint coating)
- 3 After welding, apply body sealer to the corresponding parts. (See the paint coating)
- 4 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.


Symbol meaning

: Remove Weld Points **REMOVAL**

INSTALLATION : Plug Weld

F43314B

F43315



INSTALLATION POINT

- 1 Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- 2 After welding, apply the foamed sealing material to the corresponding parts. (See the paint coating)
- After welding, apply body sealer to the corresponding parts. (See the paint coating)
- 4 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.