Tandy 1000 Internal FDD Adapter Instructions

WARNING: Please check your Tandy 1000 cable config **BEFORE** using my adapters - Some Tandy 1000's (eg TL/3) have both the **HX Style "Flipped / Rotated" connector** and Standard Shugart connector orientation on the same Floppy Cable. Many 1000's have **12v** in the Floppy cable and it will damage your drives and or system if you use these Adapters incorrectly!

--> Here's how you can Check <--

If your **SL/2, TX, TL, TL/2, TL/3, RL, RLX or RSX** Floppy cable has the Ground pins on any of its connectors "flipped" relative to the notch, you can remove the notch with a pair of side cutters:

And then insert the connector into the adapter "upside down" so what's left of the notch, is on the bottom relative to the gap in the shroud.

The Adapter is Keyed and can only be installed one way – most brands of 3.5” Floppy drives have the notch at bottom integrated into the PCB itself.

Make sure you select the correct drive letter for your Floppy Drive before installation – on most drives, DS0 = A, DS1 = B. The Power Cable needed is the same as those used on Amiga 500 and Atari ST Computers.

Thanks for buying my product, I hope it provides you with as much enjoyment as I had making them.
Regards dJOS