G54MDP Mobile Device Programming

Power and Batteries




Batteries

- Mobile devices get their power from a battery
- More sophisticated devices require more power
 - Larger screens
 - Faster CPUs
 - Faster network communications
- ... however battery technology evolving relatively slowly

Batteries

- Batteries have a limited power capacity
 - Power is the rate at which energy is used
 - Capacity measured in milliamp hours (mAh)
 - The amount of current that the battery can provide for one hour, before running out of charge
 - More "powerful" components draw more current
- 1000mAh battery can provide 1000mA (or 1A) for one hour
 - iPhone 4 has a 1420mAh battery
 - Laptop may have a 5800mAh battery
 - But more powerful components

Where does it all go?



Example Battery Usage


- Watching YouTube: 340mA = 3.4 hours
- Browsing 3G web: 225mA = 5 hours

- Typical usage: 42mA average = 32 hours
- EDGE completely idle: 5mA = 9.5 days
- Airplane mode idle: 2mA = 24 days

What is "typical" usage?

Android Power Management

- Designed specifically for mobile devices
 - Goal is to maximise battery life
 - How?
- Build on top of Linux Power Management
 - Not directly suitable for a mobile device
- Designed for devices that have a default off behaviour
 - The phone is not supposed to be on when not in use
 - Think about how often the phone is in a pocket / bag / etc
 - Powered on only when requested to be run
 - Off by default
 - Unlike a PC
 - **Default on** behaviour



Linux Power Management


- APM Advanced Power Management (1992)
- Power control resides in the PC BIOS
- Uses timeouts to determine when to power down a device
 - Monitor, HDD etc
- Makes power management decisions without informing the OS / individual applications

Linux Power Management

- ACPI Advanced Configuration and Power Interface (1996)
 - Successor to APM
- Control divided between BIOS and OS
 - Decisions managed by the OS
- Enables power policies for general purpose computers with standard usage patterns and hardware
- No knowledge of device specific scenarios
 - Predictable response times
 - Respond to critical events over an extended period

Linux Power Management

- ACPI States
- G0 (working)
- G1 (sleeping)
 - S1 (CPU stops executing instructions, power to CPU and RAM maintained)
 - S2 (CPU powered off, cache is flushed)
 - S3 (Standby / sleep / suspend to powered RAM)
 - S4 (Hibernate / suspend to disk, RAM powered off)
- G2 (S5, soft off)
- G3 (mechanical off)



Android Power Management


- Built as a wrapper around Linux Power Management
- In the kernel
 - Added Early Suspend mechanism
 - Added Partial Wake Lock mechanism
- Apps and services must request CPU resource in order to keep power on
 - Otherwise Android will shut down the CPU
 - Suspend operational RAM to NAND
- Wake locks and timeouts constantly switch the state of the system's power
 - Overall system power consumption decreases
 - "Better" use of battery capacity

Wake Locks

- By default Android tries to put the system into suspend mode as soon as possible
 - After a period of no activity / interaction
- Running apps can prevent the system from suspending
 - The screen stays on
 - The CPU stays awake to react quickly to interactions
- Applications ask for wake locks
 - If there are no wake locks, CPU will be turned off
 - If there are partial wake locks, display and touch screen will be turned off


Wake Locks

- Types of Wake Lock
- PARTIAL_WAKE_LOCK
 - Ensures the the CPU is running
 - The screen might not be on (off after timeout)
- SCREEN_DIM_WAKE_LOCK
 - Ensures that the screen is on
 - Backlight will be allowed to go off (after timeout)
- SCREEN_BRIGHT_WAKE_LOCK
 - Screen is on at full brightness
 - Keyboard backlight will be allowed to go off
- FULL_WAKE_LOCK
 - Full device on, including backlight and screen



Suspended Android

- Running applications / services are suspended
- CPU is powered down
 - Phone is not off
- Other components (SOC) continue to operate
 - CPU is periodically woken to handle scheduled tasks
 - Real time clock manifests as /dev/alarm
 - AlarmManager Alarms, email polling...
 - GSM modem will wake CPU on call / SMS notifications
- Why use a PARTIAL_WAKE_LOCK?
 - Playing music does not require screen to be on
 - Avoid suspension during period tasks
 - Android will try to suspend even when it is checking whether the alarm clock should sound
 - AlarmManager acquires, then releases a PARTIAL_WAKE_LOCK




Application Wake Locks

- Provides user-space (application) ability to manage power indirectly
 - Request a wake lock
- Application flow
 - Acquire a handle to the static PowerManager service with Context.getSystemService()
 - Create a wake lock and specify flags for screen, backlight etc
 - Acquire the wake lock
 - Perform the operation
 - Play MP3
 - Release the wake lock
- Must be used carefully
 - Keeping a wake lock for a long period of time will trash battery life
 - The CPU will not be allowed to sleep
- Tasks scheduled using the AlarmManager do not require a wake lock
 - AlarmManager acquires the lock while calling our scheduled task

Kernel Wake Locks

- Used to prevent the system entering suspended mode
 - Can be acquired and released by native code, or directly from within the kernel
 - Partial Wake Locks all reside in the kernel as they keep the CPU processing
- A single kernel wake lock manages multiple user mode (java) wake locks
 - PowerManagerService native kernel code partial wake lock
 - Audio driver partial wake lock while playing audio
 - Kernel has one last partial wake lock that exists to keep the kernel alive while other wake locks exist



Acquiring a Wake Lock

- Request sent to PowerManager (java) to acquire a wake lock
- PowerManagerService notified to take a wake lock
 - Add wake lock to an internal list
 - Set the requested power state
 - If this is the first partial wake lock take a kernel partial wake lock
 - This will protect all the partial wake locks
 - For subsequent wake locks simply add to the list

Releasing a Wake Lock

- Request sent to PowerManager (java) to release the wake lock
- Wake lock removed from the internal list
- If the wake lock is the last partial wake lock in the list
 - Release the kernel wake lock
- If kernel main wake lock is the only wake lock
 - Release main kernel wake lock
 - Device moves to suspend

Early Suspend / Late Resume

- More modifications to the Linux kernel
- In standard Linux all modules are suspended / resumed at the same time
 - Suspend
 - Freeze all user processes and kernel tasks
 - Call the suspend function for all devices
 - Suspend the kernel and suspend the CPU
 - Resume
 - Wake up the kernel
 - Wake up the registered devices
 - Unfreeze user processes and resume kernel tasks

Early Suspend / Late Resume

- Suspend as much as possible even if the kernel is still operating
- Early suspend
 - Between screen-off and full suspension
 - Tells devices to attempt to suspend even though a wake lock may be keeping the kernel awake
 - Stop screen, touch screen, backlight, close drivers
 - Note difference between "screen is on" and "kernel screen device is awake"!
- Cannot achieve full suspension (stop CPU, RAM -> NAND) until all wake locks are released
 - However attempts to suspend as much as possible
- Late resume
 - Kernel devices that were early_suspended are subsequently late_resumed
 - Can wake the kernel without waking up the entire device
 - Resume suspended devices once the kernel is awake and working

System Sleep

- API to put the device to sleep when the power button is pressed
- Requires DEVICE_POWER permission
- goToSleep()
 - Force release all wake locks
 - Turns off screen
 - The kernel immediately attempts to suspend

Summary

- Android Power Management
 - Why?
- Wake locks
- Early suspend, late resume
- System sleep

References

- http://developer.android.com/reference/ android/os/PowerManager.html
- http://os.ibds.kit.edu/downloads/ sa 2010 braehler-stefan androidarchitecture.pdf