# Advance Programming in C

Yugo Kashiwagi
Microcomputer Tool Marketing
Dept./RSO

# Prerequisits and Objective

#### Prerequisites

- Basic programming skills in C
- Some experience of program development
- Familiarity with some CPU architecture

#### Objectives

- Basic knowledge of software engineering
- Principles of algorithm design
- Techniques of cache/pipeline optimization

## **Table of Contents**

- Program Design
  - Structured Design
  - Modelling Techniques
- Algorithm Design
- Program Tuning
  - Assembler-level tuning
    - Pipeline
    - Cache

# Program Design

- Structured Program Design
  - Abstraction and Encapsulation
  - Parametrization
  - Modular Program Design
    - Strength/Cohesion of Modules
    - Coupling of Modules
- Modelling
  - State Transition
  - Syntactic Modelling

### Abstraction

- Abstraction gives an abstract description of a concrete representation (such as words and instructions).
  - Control Abstraction
    - Abstracts program structures
    - Main purpose of programming languages
  - Data Abstraction
    - Abstracts interface out of data representation
    - Supported by some high level languages (C++)
    - Should be considered while designing programs (independent of implementation language).

### **Control Abstraction**

- Programming language is a tool to give an abstract description of concrete program and data.
  - Machine words and registers -> Vriables
  - Instruction sequence -> Procedures/Functions
  - Common pattern of branching -> control statements (if, while, for, etc.)

#### Data Abstraction

- Interface to a data structure should be independent from its inplementation.
  - You can improve the implementation of the data structure, without affecting its use.
  - You can develop the implementation of the data structure and its use in parallel.
  - Clear interface makes the program more maintainable.

# Data Abstraction Example

#### Stack of integers

#### Interface:

```
void push(int x);
int pop(void);
int isEmpty(void);
```

#### usage:

```
f() {
    if (!isEmpty()) {
        x=pop();
    }
    push(10);
}
```

#### Implementation:

```
#define MAXSTACK 100
int sp=0;
int stack[MAXSTACK];
void push(int x){
  stack[sp++]=x;
int pop(void){
  return stack[--sp];
int isEmpty(void){
  return sp==0;
```

# Data Abstraction Example

Stack of integers: Alternative implementation (Same interface)

```
struct node{
  int data;
  struct node *next;
};

struct node *root=NULL;

void push(int x){
  struct node *p;
  p=malloc(sizeof(struct node));
  p->data=x;
  p->next=root;
  root=p;
}
```

```
int pop(void){
  int val;
  struct node *p;
  p=root;
  root=p->next;
  val=p->data;
  free(p);
  return val;
}

int isEmpty(void){
  return root==NULL;
}
```

# Data Encapsulation

- Abstracting data is not enough. You should prohibit illegal access to the implementation of the data.
  - Use header files to share the interface among the modules.
  - Declare everything but the interface as "static"

# Data Encapsulation Example

as "static"

#### Interface: "stack.h"

```
extern void push(int x);
extern int pop(void);
extern int isEmpty(void);
```

#### Implementation:

```
#include "stack.h"
              #define MAXSTACK 100
              static int sp=0;
              static int stack[MAXSTACK];
              void push(int x){
                stack[sp++]=x;
Declare concrete
data and other
              int pop(void){
auxiliary functions
                return stack[--sp];
              int isEmpty(void){
                return sp==0;
```

#### usage:

```
#include "stack.h"
f(){
  if (!isEmpty()){
    x = pop();
  push(10);
```

### Parametrization

- Find common patterns in your program and implement it as a subroutine.
- When you copy-and-paste a segment of code, it is a good chance of parametrization.
- Parametrization make your code more compact and maintainable.
- Caution: Too much parametrization might complicate your code.

## Parametrization Example

```
int a[100];
                                int a[100];
                                int b[1000];
void init_a(void){
  int i;
                                void init_array(int *p, int size){
  for (i=0; i<100; i++){
                                  int i;
    a[i]=0;
                                  for (i=0; i<size; i++){
                                    p[i]=0;
int b[1000];
void init_b(void){
                                      init_array(a, 100);
  int i;
                                      init_array(b, 1000);
  for (i=0; i<1000; i++){
    b[i]=0;
```

# More Sophisticated Parametrization Example

C Library Function "bsearch" searches an item from an array in which data elements are sorted. It is applicable to any size of data, any scheme of data comparison:

key: Pointer to a data to be sought.

base: Base address of the array.

nmemb: Number of elements in a table.

size: Size of the data.

compar: Comparison function of two data

# Modular Program Design

- Modularity can be measured by two ways
  - Cohesion or Strength
    - Strength of relation inside a module
  - Coupling or Independence
    - Weakness of the relation among modules

- Coincidental Cohesion
- Logical Cohesion
- Procedural Cohesion
- Temporal Cohesion
- Communicational Cohesion
- Sequential Cohesion
- Functional Cohesion
- Informational Cohesion

Worst

**Best** 

- Coincidental Cohesion
  - Routines have no relation at all.
- Logical Cohesion
  - Routines are collected, because they are in the same category, and selected by a "function code".
    - e.g. Input routine for various data, and the kind of data is selected by a "function code"

- Procedural Cohesion
  - Routines are collected, because they happen to be executed in a sequence (otherwise unrelated).
- Temporal Cohesion
  - Routines are collected, because they are done at the same time.
    - e.g. Initialization, shut down process, etc.

- Communicational Cohesion
  - Routines are collected, because they happen to access to the same data
    - Various operation to the same table
- Sequential Cohesion
  - Routines are collected, because the output of a routine becomes an input of another
    - e.g. Read\_data, process\_data, write\_data.

- Functional Cohesion
  - None of the above
  - The module have well-defined clear description
- Informational Cohesion
  - Collection of functional-cohesion modules under well-defined description
    - e.g. Mathematical function library (sin, cos, tan, etc), Access modules to a single abstract data.

# Module Coupling

- Content Coupling
- Common Coupling
- External Coupling
- Stamp Coupling
- Data Coupling
- No direct Coupling

Worst

Best

# Module Coupling

- Content Coupling
  - One module modifies or relies on other module's internals
- Common Coupling
  - Two modules share (unrestricted) common global data
- External Coupling
  - Two modules share some specific common global data (interface is well-defined)

# Module Coupling


- Control Coupling
  - One module passes "function code" to another module
- Stamp Coupling
  - Passes and returns structured data
    - Changing data structure affects another module
- Data coupling
  - Passes and returns only simple data
- No direct coupling
  - None of the above

# Modelling Techniques

 It is useful to model your problem in some abstract manner before you start the program design.

# Modelling Technique: State Chart

Desk Calculator Example:



# Program from State Chart

```
c=getchar();
switch (state){
case INIT:
  if (isdigit(c)){
    mem=c-'0';
    state=READ1;
  break;
case READ1:
  if (isdigit(c)){
    mem=mem*10+c-'0';
  else if (c=='C'){
    mem=0;
    state=INIT;
  else if (c=='+' || ...){
    op=c;
    operand=0;
    state=READ2;
 break;
```

```
case READ2:
  if (isdigit(c)){
    operand=operand*10+c-'0';
  else if (c=='C'){
    mem=0;
    state=INIT;
  else if (c=='='){
    mem=compute(op, mem, operand);
    printf("%d\forall n", mem);
    state=READ1;
 break;
```

# Syntactic Modelling

 Programming languages are described by a grammar called BNF (Backus-Naur Form).

 You can formalize your input data using BNF and structure your program.

# Modelling using BNF

<input>::=<header> <data record>\* <trailer>

Suppose the header includes the number of data records.

```
count=read_header();    /* This returns number of records */
for (i=0; i<count; i++){
    read_data_record();
}
read_trailer();
...</pre>
```

# Algorithm Design O notation

- O (big-O) notation
  - The execution time of an algorithm is a function of its input size. The order of this function (ignoring constant factor) is expressed using O notation.
    - O(n): Linear time
    - O(n log n): Frequently appears in many algorithms, sorting, FFT
    - O(n²): Impractical for large inputs
    - O(n<sup>3</sup>): e.g. Matrix Multiplication
    - O(e<sup>n</sup>): Impractival even for medium sized inputs
  - Constant factor is sometimes important (too large constant factor makes some algorithms impractical).

# Example: Searching Linear Search (O(n))

```
key
                                                              name
                                       Searches the table
#include <stdio.h>
                                       from the beginning
struct record{
  int key;
  char *name;
};
char *search(struct record *a, int size, int key){
  int i;
  for (i=0; i<size; i++){
    if (key==a[i].key){
      return a[i].name;
  return NULL;
```

# Binary Search (O(log n))

```
char *search(struct record *a, int size, int key){
  int lo, hi, mid;
                                            lo
  10=0;
  hi=size-1;
  while (lo<=hi){</pre>
    mid=(lo+hi)/2;
    if (a[mid].key<key){</pre>
       lo=mid+1;
    else if (a[mid].key>key){
                                            hi
       hi=mid-1;
                                      Assumes that the
    else{
                                      keys in the table are
       return a[mid].name;
                                      already sorted.
                                      Divide the search
  return NULL;
                                      range by two in each
                                      step.
```

# Simple Insertion Sort (O(n²))

```
/* Sorts the index range [start..end] of array "a" */
void sort(int *a, int start, int end){
  int i, j, k;
  int tmp;
  for (i=start+1; i<=end; i++){
    /* At each step, the range [start..i-1] is */
                                                  * /
    /* already sorted
    tmp=a[i];
    j=i-1;
    /* Insert a[i] at appropriate place.
                                                  * /
    while (j>=start && tmp<a[j]){</pre>
      a[j+1]=a[j];
      j--;
    a[j+1]=tmp;
```


## Quicksort (O(n log n) (in average)

```
if (i<j){
void sort(int *a, int start, int end){
  int i, j;
                                                         tmp=a[j];
                                                         a[j]=a[i];
  int pivot;
                                                         a[i]=tmp;
  int tmp;
  if (start+1<end){</pre>
                                                         i++;
    pivot=a[end];
                                                         j--;
    i=start;
    j=end-1;
    while (i<j){
                                                     a[end]=a[i];
      while (i<j && a[i]<=pivot){
                                                     a[i]=pivot;
                                                     sort(a, start, i-1);
        i++;
                                                     sort(a, i+1, end);
      while (i < j \&\& a[j] > = pivot)
        j--;
```

# Quicksort (Explanation)

- Pick up one element (pivot) in the table (a[end]), and arrange the array so that elements before the pivot is smaller than the pivot, and those after the pivot is larger than the pivot. Thus the table is divided into two parts, in which the lower half has smaller elements, and the upper half has larger elements.
- Apply the same algorithm to both part of the table.
- Each step takes time proportional to n.
- The expected number of steps are log n.

# Quicksort (Explanation)



# Problem of the Quicksort (1)

- Worst case: If the partition is not even, the execution time can be O(n²).
   (In the example program, the worst case happens when the data is already sorted).
  - Select the pivot randomly, or
  - Select several pivots, and take medium sized one.

## Problem of the Quicksort (2)

- Recursive calls wastes the stack area.
- In the worst case, the recursion depth is proportional to the table size n (impractical for large n).
  - Transform the function, and remove the tail recursion (there is still one recursive call left).
  - Do the smaller part first, so that recursion cannot be so deep (less than log<sub>2</sub> n)

## Improvement of Quicksort

```
void sort(int *a, int start, int end){
  int i, j;
  int pivot;
  int tmp;
  while (start+1<end){</pre>
    pivot=a[end];
    i=start;
    j=end-1;
    while (i<j){
      while (i<j && a[i]<=pivot){
        i++;
      while (i < j \&\& a[j] > = pivot)
        j--;
```

```
if (i<j){
    tmp=a[j];
    a[j]=a[i];
    a[i]=tmp;
    i++;
    j--;
a[end]=a[i];
a[i]=pivot;
if (i-start>end-i){
  sort(a, i+1, end);
  end=i-1;
else{
  sort(a, start, i-1);
  start=i+1;
```

## Hints on Algorithm Design

- Divide and Conquer: Divide the problem into smaller sized subproblems (e.g. Quicksort).
- Recursive Design: You may be able to apply the same algorithm to the subproblem (but try to remove recursion when implementing).
- Consider the order of execution time.
- Sophisticated algorithms are hard to invent. Consult textbooks.
- Don't apply the textbook algorithm as it is.
   Consider the assumption of your own algorithm (data structure, imput assumption, etc.)

# Programming Exercise Project 1

- 1. Run the quicksort and exchange sort for arrays of various size and measure execution cycles.
- 2. Remove the recursion of the quicksort and do the same thing.
- 3. [Bonus Problem] For smaller tables, exchange sort should run faster. Change the quicksort so that small-sized range is sorted using exchange sort. Which value is the optimal?

## **Hew Operation Demo**

- Building and running programs
- Counting machine cycles
- Using trace to observe pipeline status

## Report

- Organization of the report
  - Give the summary and conclusion in the first page, then show details.
    - Summary includes:
      - Cycle counts before and after improvement (table or preferabry a graph)
      - Show what improvement you have done
      - Compare your expectation (based on what you have learnt) and the result.
    - Details:
      - Details of the program code (where you have changed)
      - Detailed observation and discussion
      - Questinos or suggestions
- Scoring policy
  - If your summary includes the required items, you get 70 pts.
  - Good discussion, question, suggestion gives extra pts.

## Program Tune-up

- Introduction to Assembler
- Pipeline
- Cache
- Programming Exercise

### Introductio to SH Assembler

- In embedded programs, knowledge of assembler is helpful for
  - Writing operations not supported by C
  - Understanding hardware behavior
  - Tuning up programs (extracting full performance of the CPU)
  - Debugging optimized C code

# Use of Assembler Programs "To C or not to C"

- The following operations cannot be written in standard C:
  - Reading/Writing special registers (e.g. Stack Pointer)
  - Interrupt handling (a process returning with RTE instruction)
- Some compiler have language extensions to do this (check SH C Compiler Manual). But they are not portable.
- We recommend you to first understand what is happening with assembler programs, and then use nonportable features of each compiler.

## Assembler Syntax

Instructions

```
[<label>:] <operation> [<operand>[,<operand>]...]
e.g.
```

```
func: MOV.L R4,R0 ADD #2,R0
```

- Labels starts at the beginning of line, and represents the location (address) of the instruction
- First operand is source, second operand is destination

### **Assembler Directives**

- Directives (operation starting with ".")
  - DATA allocates data

```
.DATA.L H'100 .L, .W, .B specifies the size of data .DATA.B H'FF (4, 2, 1 byte, respectively)
```

- .RES reserves area

```
.RES.L H'100 Specifies memory area to be reserved.
.RES.B H'FF Unit is 4, 2, 1 byte, according to its size.
```

- .SECTION defines a section (contiguous memory area) and its attribute

```
.SECTION P, CODE, ALIGN=4 P, C are the name of the sections.
.SECTION C, DATA, ALIGN=4 Other operands specifies the attribute of the section.
```

END specifies the end of the program.

### **Assembler Directives**

IMPORT refers to a label defined in another module.

```
.EXPORT _a
```

.EXPORT makes the label available from other modules.

```
.IMPORT _a
```

• .ALIGN alignes next instruction/data.

```
.ALIGN 4 ; aligns next data to 4-byte ; boundary
```

## Assembler Program Structure

```
; External declaration of labels
    .EXPORT f
    .SECTION P, CODE, ALIGN=4; Start of program
f: MOV.L R4,R0
                           ; _f is the function entry
   MOV.L L,R1
   ADD R1,R0
   RTS
                            ; delayed branch
   NOP
    .ALIGN 4
                            ; Alignes next data to 4-byte
L: .DATA.L LABEL
    .SECTION C, DATA, ALIGN=4; Start of data
LABEL:
    .DATA.L H'1000
    , END
                            ; End of program
```

- Load/Store Architecture
  - SH is a RISC. Only MOV instructions can access memory. Other operations (e.g. ADD) are performed between registers, or small constant and register.

```
MOV.L @R4,R0
MOV.L @R5,R1
ADD R0,R1
ADD #1,R1
MOV.L R1,@R4
```

- Addressing Modes
  - Addressing modes specifies the location of an operand. The following addressing modes are frequently used.

#immediate	Constant value.
Rn	Register
@Rn	Register indirect (* operator in C)
@Rn+	Like @Rn, but increment Rn (by operand size) after the access, used to pop data from the stack
@-Rn	Like @Rn, but increment Rn before the access, used to push a data into a stack
@(disp,Rn)	"disp" bytes from the address specified by Rn
@(R0,Rn)	Add R0 and Rn to get the operaand address (array
@(disp,PC)	indexing: we: "disp" bytes from PC (the address of current instruction). Can also be specified by a label in

the program

#### Registers

Туре	Registers	Initial Value*	General Registers (R0-R15) can		
General registers	R0_BANK0-R7_BANK0, R0_BANK1-R7_BANK1, R8-R15	Undefined	be used in MOV or other operations (R15 is a stack pointer)		
Control registers	SR	MD bit = 1, RB bit = 13–10 = 1111 (H'F), r undefined			
	GBR, SSR, SPC, SGR, DBR	Undefined	SR (status register) holds flags.		
	VBR	H'00000000			
System registers	MACH, MACL, PR, FPUL	Undefined	Contain Designation of the master and 1		
	PC	H'A0000000	System Registers are transferred		
	FPSCR	H'00040001	using LDS/STS instructions.		
Floating-point registers	FR0-FR15, XF0-XF15	Undefined	PC is a program counter. PR holds the return address of a		
Note: * Initialized by a power-on reset and m		nanual reset.	function.  MACH, MACL holds result of multiplication.		

- Literal Pool: How to load large constants?
  - SH instructions have 16-bit fixed format. So they cannot include 16/32-bit constants.
  - These constants should be located in a program (after unconditional jump instructon so as not to interfere program execution), and should be loaded using PC-relative addressign mode.

#### Literal pool example:

```
f_addr,R0 ; Load constant f
   MOV.L
   JSR
            @R0
                ; Calls function f
   NOP
                        ; Load constant H'100
   W.VOM
          dat1,R1
            R1,R0
   ADD
   RTS
   NOP
; Start of Literal Pool (after unconditional branch)
                        ; Don't forget to align data
    .ALIGN
f addr:
                        ; Address of function " f"
    .DATA.L
    .ALIGN
dat1:
    .DATA.W H'100
```

#### Delayed Branch

- When branch instruction is executed, CPU must wait until the instruction from branch target is fetched.
- Delayed branch mechanism executes the next instruction, which is already fetched when the branch instruction is executed.
- The instruction next to the branch instruction is called the instruction in "delay slot".
- There are restrictions for instructions in "delay slot", for example, you cannot put an instruction using PC in delay slot.
- If you cannot put an instruction in delay slot, you should put NOP in the delay slot.
- Typical delayed branch instructions are: BRA, BSR, JMP, JSR, RTS, RTE.

Delayed branch example:

```
f:
       BSR
              _g
              #1,R4 ; Delay slot for BSR
       MOV
                      ; Passes parameter 1 through R4
       RTS
       NOP
                     ; Delay slot for RTS
            R4,R0 ; R0 holds return value
       VOM
q:
       RTS
       ADD
              #1,R0 ; Delay slot for RTS
                      ; Increments the return value
```

- Comparison
  - SH have only one flag (T) to indicate comparison result. We have several comparison instructions for various comparison operation.
  - BT or BF instruction is used to jump according to comparison result.

CMP/EQ	#imm,R0	When R0 = imm, $1 \rightarrow T$ Otherwise, $0 \rightarrow T$	10001000iiiiiiii	-	Comparison result
CMP/EQ	Rm,Rn	When Rn = Rm, 1 $\rightarrow$ T Otherwise, 0 $\rightarrow$ T	0011nnnnmmmm0000	_	Comparison result
CMP/HS	Rm,Rn	When Rn $\geq$ Rm (unsigned), 1 $\rightarrow$ T Otherwise, 0 $\rightarrow$ T	0011nnnnmmmm0010	_	Comparison result
CMP/GE	Rm,Rn	When Rn $\geq$ Rm (signed), 1 $\rightarrow$ T Otherwise, 0 $\rightarrow$ T	0011nnnnmmmm0011	_	Comparison result
CMP/HI	Rm,Rn	When Rn > Rm (unsigned), $1 \rightarrow T$ Otherwise, $0 \rightarrow T$	0011nnnnmmmm0110	_	Comparison result
CMP/GT	Rm,Rn	When Rn > Rm (signed), $1 \rightarrow T$ Otherwise, $0 \rightarrow T$	0011nnnnmmmm0111	_	Comparison result
CMP/PZ	Rn	When Rn $\geq$ 0, 1 $\rightarrow$ T Otherwise, 0 $\rightarrow$ T	0100nnnn00010001	_	Comparison result
CMP/PL	Rn	When Rn > 0, 1 $\rightarrow$ T Otherwise, 0 $\rightarrow$ T	0100nnnn00010101	_	Comparison result
		•	•	,	-

Comparison example (if statement)

```
CMP/GT R4,R5 ; Compare R4 and R5
BT L1 ; if R5>R4, go to L1
MOV R4,R0 ; R0=R4
BRA L2 ; go to L2
NOP
L1: MOV R5,R0 ; R0=R5
L2:
```

Of course, you can eliminate NOP after BRA, by moving previous MOV instruction to delay slot.

Comparison example (for loop)

```
MOV #10,R1 ; R1=10
L1: CMP/EQ #0,R1 ; Compare R1 with 0
BT         L2 ; if R1==0 then exit loop
         JSR         _f ; Call subroutine f
         NOP
         SUB #1,R1 ; R1=R1-1
         BRA     L1 ; Repeat
         NOP
L2:
```

- How to write a function in Assembler:
  - Parameter convention (defined by C)
    - Parameters: R4-R7 (up to 4 parameters on registers)
    - Return value: R0
  - Register saving/restoring
    - R8-R14 must be saved and restored if used in the function
    - PR holds the return address (set by JSR instruction). PR must be saved and restored when the function calls another funtion.

Function example (Empty function)

Function example (Parameters and Return Value)


Function example (Register saving/restoring)

```
MOV R8,@-R15; Save register R8 and R9
q:
        MOV R9,@-R15; on Stack.
                       ; Register R8-R14 must be
                       ; saved if it is used, by C
                       ; calling convention
        STS PR,@-R15
                       ; Save PR if the function calls
                       ; another function.
        . . .
                       ; Calls another function
        JSR f
        NOP
        . . .
        LDS
             @R15+,PR ; Restores registers
             @R15+,R9 ; Note that regsiters are
        VOM
             @R15+,R8 ; restored in reverse order
        VOM
        RTS
        NOP
```

## Assembler Program Comments

- Assembler programs are more difficult to read. So you should write more comments in the program.
  - Comment on every line.
  - Comment on register usage.
  - Comment on function interface (interface registers).
  - Comment on flag usage (if used).

## SH4A Pipeline Structure



7 Stage Pipeline

11/I2: Instruction Fetch

ID: Instruction Decode

E1-E3: Execution WB: Write Back

Each stage is executed in parallel in different unit. So each instruction is executed in one cycle.

## Pipeline: Branch Penalty

(1-1) BF, BF/S, BT, BT/S, BRA, BSR:1 issue cycle + 0 to 2 branch cycles Note: In branch instructions that are categorized as (1-1), the number of branch cycles may be reduced by prefetching. (Branch destination instruction) (1-2) JSR, JMP, BRAF, BSRF: 1 issue cycle + 3 branch cycles (Branch destination instruction) (1-3) RTS: 1 issue cycle + 0 to 3 branch cycles Note: The number of branch cycles may be 0 by prefetching instruction.

Branch requires the instructions to be fetched from another place. So there are 2-3 cycles before next instruction can be executed

- -> Use delay slot.
- -> Reduce the number of branches (loop unrolling, etc.)

(Branch destination instruction)

## Pipeline: Superscalar

SH4A is a superscalar architecture, and can issue two instructions at a time.

However, same type instructions (except MT) cannot be done in parallel (because they use the same resources).

-> Interleave arithmetics and moves

#### Preceding Instruction (addr)

		EX	MT	BR	LS	FE	СО
Following	EX	No	Yes	Yes	Yes	Yes	
Instruction (addr+2)	MT	Yes	Yes	Yes	Yes	Yes	
(auui+z)	BR	Yes	Yes	No	Yes	Yes	<del></del>
	LS	Yes	Yes	Yes	No	Yes	
	FE	Yes	Yes	Yes	Yes	No	<del></del>
	CO						No

EX: Arithmetic

MT: Move (R-R or immediate-R)

**BR: Branch** 


LS: Load/store

FE: Floating Point

CO: Control

## Pipeline: Pipeline Stall

- SH4A Software Manual doesn't have examples. Here examples from SH4 (5-stage pipline) are shown to explain ideas.
- (a) Serial execution: non-parallel-executable instructions



EX-group SHAD and EX-group ADD cannot be executed in parallel. Therefore, SHAD is issued first, and the following ADD is recombined with the next instruction.


(b) Parallel execution: parallel-executable and no dependency

	 ++	1 issue	1 issue cycle		
ADD R2,R1	D	EX	NA	S	
MOV.L @R4,R5	D	EX	MA	S	

EX-group ADD and LS-group MOV.L can be executed in parallel. Overlapping of stages in the 2nd instruction is possible.

Serial/Parallel execution of superscalar. The instructions of the same group cannot be executed in parallel.


## Pipeline: Pipeline Stall



No pipeline stall if the branch is not taken

 Design the program so that frequent path takes less branches (e.g. then-part of if includes frequent processing)

## Pipeline: Pipeline Stall



Don't use register immediately after it is operated or loaded (except register-register move).

## Pipeline Consideration in C Programming

- How can we improve pipeline performance in C programs?
  - Reduce the number of "taken" branches
  - Improve instruction-level parallelism (don't make the loop too "tight", so that the compiler can find several things which can be done in parallel.

### - Macros vs Functions -

Macros and inline functions reduces number of branches

```
int abs(int x) {
  return x>=0 ? x : -x;
}
f() {
  a=abs(b);
  c=abs(d);
}
#define abs(x)

((x)>=0 ? (x) : -(x))

f() {
  a=abs(b);
  c=abs(c);
  }
```

Macros don't have function call overhead. But extensive use of macros make your program size very large.

C++ and C99 provides inline function declarations.

#### - Loop Unrolling -

```
extern int a[100];
void f(void)
{
  int i;
  for (i=0; i<100; i++)
    a[i]=0;
}

extern int a[100];
void f(void)
{
  int i;
  for (i=0; i<50; i+=2) {
    a[i]=0;
    a[i+1]=0;
  }
}</pre>
```

Reduce the number of loops by unrolling loops reduces the number of branch instructions.

# - Put Error Processing in else Clause -

```
int x(int a)
{
  if (a==0)
    error_proc();
  else
    g(a);
}

int x(int a)
{
  if (a!=0)
    g(a);
  else
  else
  error_proc();
}
```

Putting normal processing in if clause (instead of else clause), you can save one branch instruction in the normal processing. Don't sacrifice the speed of normal processing for error checking.

This reduces the number of "taken" branches.

#### Distribution of Accumulators

```
for (i=0; i<1000; i++)
s+=a[i]*b[i];
```

In the old code, \* waits until the array elements are loaded.

In the new code, they can run in parallel.

```
s0=0;
s1=0;
s2=0;
s3=0;
for (i=0; i<1000; i+=4) {
    s0+=a[i]*b[i];
    s1+=a[i+1]*b[i+1];
    s2+=a[i+2]*b[i+2];
    s3+=a[i+3]*b[i+3];
}
s=s0+s1+s2+s3;</pre>
```

### Software Pipelining

- If a loop contains a long operation (e.g. division or square root), you must wait until the operation is complete.
- Software pipelining is a technique to reconstruct the loop so that the long operation is started in the previous operation, and improve parallelism.

### Software Pipelining

```
for (i=0; i<N; i++) {
    x=X[i];
    y=Y[i];
    t=x/y;
    Z[i]=t;
}</pre>
```

Division waits data load, and store waits division.

If you fetch the data in the previous iteration, these operations can be executed in parallel.


```
x=X[0];
y=Y[0];
t=x/y;
for (i=1; i<N; i++) {
    x=X[i];
    y=Y[i];
    Z[i-1]=t;
    t=x/y;
}
Z[i]=t;</pre>
```

#### Cache Optimization

- Cache is a small but fast memory, which buffers the memory.
- Programs run fast when memory access hits the cache. Otherwise slow memory access with large penalty occurs.


#### Cache

SH4A Operand Cache: 32K bytes, 4-way set associative, Line size=32



#### Cache

SH4A Instruction Cache: 32K bytes, 4-way set associative, Line size=32 (similar to operand cache)



#### Cache: Things to consider

- Line size (32 byte) is a unit to be loaded into the cache.
- 256 entries in each way can hold 256\*32 (=8K) bytes of consecutive memory area.
- Up to 4 lines of the same address (modulo 8K bytes) can be kept in cache. If another data with the same address (modulo 8K) is accessed, the least recently used line is purged.

#### Cache: Basic Techniques

- Align data and program to 32-byte (line size) boundary
- Improve data/program locality
- Prefer sequential data access to random access
- Use prefetch (instruction or data, implemented as a intrinsic function in Renesas C) some time before data is needed (or function is called).

#### Exchanging Loop Variables


```
for (j=0; j<N; j++)
  for (i=0; i<M; i++)
    a[i][j]=b[i][j]+
        c[i][j];</pre>
for (i=0; i<M; i++)
    for (j=0; j<N; j++)
    a[i][j]=b[i][j]+
    c[i][j];
```

Change the rightmost index in the inner loop, so that adjacent data are accessed in the innermost loop.

This reduces the number of cache misses.

### Tiling

• When an array is too large to fit into a cache, and if you must travers the array many times, do the processing page by page.



## Tiling

```
typedef struct {
  float a,b,c,d;
} data t;
f(data_t data[], int n)
  data_t *p,*q;
  data_t *p_end = &data[n];
  data_t *q_end = p_end;
  float a,d;
  for (p = data; p < p_end; p++)
   a = p->a;
   d = 0.0f;
   for (q = data; q < q_end; q++)
      d += q -> b -a;
   p->d=d;
```

This program computes the sum of difference of data[i].a and data[j].b (for all j) and stores into data[i].d.

```
#define STRIDE 512
f(data t data[], int n)
  data_t *p,*q, *end=&data[n];
  data_t *pp, *qq;
  data_t *pp_end, *qq_end;
  float a,d;
  for (p = data; p < end; p = pp_end){</pre>
    pp_end = p + STRIDE;
    i0.0 = b < -qq
    for (q = data; q < end; q = qq_end)
      qq_end = q + STRIDE;
      for (pp = p; pp < pp_end &&
                    pp < end; pp++){
        a = pp->ai
        d = pp -> d;
        for (qq = q; qq < qq_end \&\&
                      qq < end; qq++){
          d += qq -> b -a;
        p->d=di
```

## Tiling

#### Before Tiling:

For each entry data[i], all the data[j] is scanned.

Data in cache changes n\*(n/cache size) times.

#### After Tiling:

Inner two level loops runs without changing cache.

Data in cache changes (n/cache size)\*(n/cache size) times.

#### Cache Prefetching (data)

```
#include <machine.h> /* Renesas header for intrinsic instructions */
int a[2096];

prefetch(a);
:
for (i=0; i<2096; i+=8){
   prefetch(&a+i+8); /* Prefetch next set of memory data. */
   sum+=a[i];
   sum+=a[i+1];
   sum+=a[i+2];
   :
   sum+=a[i+7];
}</pre>
```

### Cache Prefetching (instruction)

```
#include <machine.h> /* Renesas header for intrinsic instructions */
int a[2096];

prefi(&f);
  :
f();
  :
:
```

# Programming Exercise Project 2

 The program sums up the elements of big (larger than cache size: 32K Byte) array.

```
int a[ARRAY_SIZE];

void f(void){
  int i;
  long sum;
  sum=0;
  for (i=0; i<ARRAY_SIZE; i++){
    sum+=a[i];
  }
}</pre>
```

# Programming Exercise Project 2

- 1. Apply "loop unrolling". Unroll it by 2, 4, 8 and measure their execution cycles.
- 2. Apply "distribution of accumulators". Try 2, 4, 8 accumulators and measure the execution cycles.
- 3. Using the best result from 1 and 2, insert "prefetch" for cache optimization.
- 4. [Bonus Problem] Study compiler-generated assembly program. Try more optimization in assembler level.

#### Requests for Contribution

- This is the first trial of "Advanced Programming Course"
- I'd like to include more examples. When you solve a hard programming problem, please write the summary and send it to me.
- Any volunteer teaching assistant next time?