CS466 Lab 3 -- Simple Queues, Producer/Consumer, Serial IOand gdb debugging Due by Midnight Friday 2-17-2023.

!!! Must use provided lab format!!!

You may hand in a team lab per, Individual or Two members to a team only.

Overview:

• This lab is similar in thread structure to Lab 2, I suggest that you start with a working lab2 solution.

Lab Preparation:

- Review your Lab 2 thread structure.
- Read over the the FreeRTOS API documentation for queues
 (http://www.freertos.org/a00018.html). Specifically look at the documentation for xQueueCreate(), xQueueSend(), and xQueueReceive() in detail. Like semaphores you have to create the queue structure before you can call the queue api operations.
- Look at the xTaskCreate api and note how priority works as well.
- Look at the use of the assert() function. Since the pico environment defines assert() so we define myAssert(). See
 https://www.tutorialspoint.com/c standard library/c macro assert.htm
 For some explination.

Objective:

- To work a very simple Queue example.
- To add Serial debugging IO to your code.
- To analyze assert failures in your code.

Lab Work

- 1. Copy your Lab02 code to this lab03. Name the main program lab3.c. You will need to modify the CmakeLists.txt to adjust the lab2 code file name to lab3. Delete all the interrupt and semaphore code that dealt with switches, keep the heartbeat task.
- **2.** Rename your green thread to 'heartbeat' and have it run at idle priority. This thread should always run and keep the green LED blinking at around 1 Hz if SW1 and SW2 are not being pressed.
 - a) Lab-report-question-1: How much effort did it take to get this basic heartbeat-only task working?
- **3.** Put a printf() in your heartbeat task that outputs the text 'tick <count> and current button state for SW1 and SW2. Verify that you can receive the text using a serial terminal of your choice.

- **4.** Add the myAssert.c to you project in the CMakeLists.txt file and include the header myAssert.h in your lab3.c file.
- 5. test calling the myAssert function a while after your main() program.. Note that you have to have the printf() working if you want to see the assert output. See if you can make the assert print the programmed failure message...
- **6.** What does the Linux command do?

```
$ make && cp lab3.uf2 /media/miller/RPI-RP2/ && sleep 2 \    && kermit ~/kermACM0
```

- a) Lab-report-question-2: What does failing the assert do?
- **7.** ☐ Create a Queue with 20 entries before you start the scheduler.
 - a) For now we will just be passing a uint32_t through the queue.. Normally you would use a structure as your queue entry element.
- **8.** Add a consumer thread and a producer thread. Pass the handle of the queue to each thread as part of its thread parameters, do not use global variables. (to do this you will need to cast the queue handle to a (void *) and pass as pvParameters)

I used an array of structures...

```
typedef strut {
    int priority;
    char *name;
    queue_t theQueue;
} property_t;

property_t taskProperties[] = {
    {1, "task1", theQueue},
    {2, "task2", theQueue}
    };
```

Then I can reference the individual array elements through taskProperties[] or if I say needed the address (pointer) of/to a single structure element I could say &taskProperties[1]; for example.

- **9.** \square Make the consumer thread block on queue receive so and if SW1 is pressed, momentarily light the led whenever a message is received. Use a frequency that works visually.
- **10.** ☐ Make your producer thread block for a random delay then send a message, If the queue is full assert(). Try to hit about 10 messages per second for a starting

average rate. If you assert you are probably holding the LED on too long and overflowing the queue.

- **11.** ☐ Move all of your producer characterization data (thread-name, mean-delay, priority) to a single structure definition and initialize a struct with the data in main. Instead of just passing the queue handle as you did with the consumer thread, Pass a pointer to the struct to the producer.
- **12.** ☐ Add a second producer that will also insert messages into the queue. When the consumer thread receives a consumer2 message light the LED if SW2 is pressed momentarily. Also time the random message generation rate to average about 10 Hz. Assert if the queue send fails. This second producer thread should use the same function as the first.
- **13.** \square Re-arrange the priorities so that the consumer thread has a lower priority then the two producer threads. If the program does not assert after a while, increase the period of the LED indication in the consumer to slow it down. Why do I expect an assert here?
 - a) Lab-report-question-3: Describe your verification for SW1 and SW2 reporting the two producer rates using only the single LED?
 - b) Lab-report-question-4: Describe the usefulness of using your own assert code as opposed to the default pico implementation.