1 Installation

- 1. Supported compilers: gcc and MSVS
- 2. Prerequisite: EIGEN3, which is available at

http://eigen.tuxfamily.org/index.php?title=Main_Page

- 3. Unzip the source code of StackSizer and EIGEN3 and add the directory of EIGEN3 to the compiler's include path.
- 4. Turn on the compiler's OpenMP support (optional)

2 Input file

The input file is composed by the following 5 parts:

1) Line1:

 N_{bay} , N_{subcase} , N_{size} , N_{lock} , MS

	Type	Meaning
$N_{ m bay}$	int	Number of laminate bays
$N_{ m subcase}$	int	Number of subcases
N _{size}	int	Number of input lines for defining bay sizes
N _{lock}	int	Number of input lines for defining bay thickness
MS	float	Target margin of safety

2) Line2:

 N_{round} , $N_{\text{inner_loop}}$, $N_{\text{outer_loop}}$, $Switch_{\text{trim}}$

	Type	
$N_{ m round}$	int	Number of rounds
$N_{ m inner_loop}$	int	Outer loop size of each round
$N_{ m outer_loop}$	int	Inner loop size within each outer loop
Switch _{trim}	int	Switch to open 90/0 flip

3) Load define part

 N_{subcase} input blockes, each block contains $1+N_{\text{bay}}$ lines. The block for each subcase is:

SUBCASE: S	(1 line)			
ElemID 1	$N_{\rm xx}$	$N_{\rm yy}$	$N_{\rm xy}$	
ElemID 2	$N_{\rm xx}$	$N_{\rm yy}$	$N_{\rm xy}$	
ElemID 3	$N_{\rm xx}$	$N_{ m yy}$	$N_{\rm xy}$	(M. lines)
ElemID 3	$N_{\rm xx}$	$N_{ m yy}$	$N_{\rm xy}$	$(N_{\rm bay} \ {\rm lines})$
•••				
ElemID N_{bay}	$N_{\rm xx}$	$N_{\rm yy}$	N_{xy}	

The symbols are defined as:

	Type	Meaning
SUBCASEID	int	Subcase id
ElemID	int	Element id
$N_{\rm xx}$	double	In-plane normal force along the X-direction with the unit of N/mm
$N_{ m yy}$	double	In-plane normal force along the Y-direction with the unit of N/mm
N_{xy}	double	In-plane shear force with the unit of N/mm

4) Size define part

Consist of N_{size} lines, in each line,

ElemID₁: ElemID₂:PACE a b

ElemID ₁	int	Start element id							
ElemID ₂	int	End element id							
PACE	int	stride							
а	double	Plate length in mm							
b	double	Plate width in mm							




Fig: sizes of a plate

This line attributes a-by-b to elements $ElemID_1$, $ElemID_1+PACE$, $ElemID_1+2PACE$, $ElemID_1+3PACE$,..., $ElemID_2$.

If the stride is 1, then use:

ElemID₁: ElemID₂:PACE a b

If only one bay is to be defined, then use:

ElemID₁ a b

5) Thickness define part

If certain bays are to be excluded from the optimization, then its thickness should be fixed a priori. There are N_{lock} lines defining fixed bay thickness, the formation is:

ElemID₁: ElemID₂:PACE num

or

ElemID₁: ElemID₂ num

Num is the number of layers.

6) Connection define part

Connection relations are defined in pairs till the end of the input file. For example, the connection of the following bays are given as:

1 2

13

24

3 4

1	2
3	4

Fig A sample with 4 zones

3 Result

Plate No.	.: 1,	FEM	ELEMENT	ID:	01,	RANK:	1,	Subcase:	10,	Layers:	12,	M.S:	2.39,	FailMode:	1,	45,	-45,	,	90,	,
Plate No.	.: 2,	FEM	ELEMENT	ID:	02,	RANK:	2,	Subcase:	10,	Layers:	12,	M.S:	2.36,	FailMode:	1,	45,	-45,	,	90,	,
Plate No.	.: 3,	FEM	ELEMENT	ID:	03,	RANK:	3,	Subcase:	10,	Layers:	12,	M.S:	2.35,	FailMode:	1,	45,	-45,	,	90,	,
Plate No.	.: 4,	FEM	ELEMENT	ID:	04,	RANK:	4,	Subcase:	10,	Layers:	12,	M.S:	2.35,	FailMode:	1,	45,	-45,	,	90,	,
Plate No.	.: 5,	FEM	ELEMENT	ID:	05,	RANK:	5,	Subcase:	10,	Layers:	12,	M.S:	2.35,	FailMode:	1,	45,	-45,	,	90,	,
Plate No.	.: 6,	FEM	ELEMENT	ID:	06,	FANK:	6,	Subcase:	10,	Layers:	12,	M.S:	2.35,	FailMode:	1,	45,	-45,	,	90,	,
Plate No.	.: 7,	FEM	ELEMENT	ID:	07,	FANK:	7,	Subcase:	10,	Layers:	12,	M.S:	2.35,	FailMode:	1,	45,	-45,	,	90,	,
Plate No.	.: 8,	FEM	ELEMENT	ID:	08,	RANK:	8,	Subcase:	10,	Layers:	12,	M.S:	2.36,	FailMode:	1,	45,	-45,	,	90,	,
Plate No.	.: 9,	FEM	ELEMENT	ID:	09,	FANK:	9,	Subcase:	10,	Layers:	12,	M.S:	2.38,	FailMode:	1,	45,	-45,	,	90,	,
Plate No.	.: 10,	FEM	ELEMENT	ID:	10,	RANK:	10,	Subcase:	10,	Layers:	12,	M.S:	2.01,	FailMode:	1,	45,	-45,	,	90,	,
Plate No.	.: 11,	FEM	ELEMENT	ID:	11,	RANK:	11,	Subcase:	10,	Layers:	12,	M.S:	2.40,	FailMode:	1,	45,	-45,	,	90,	,
Plate No.	.: 12,	FEM	ELEMENT	ID:	12,	FANK:	12,	Subcase:	11,	Layers:	12,	M.S:	2.27,	FailMode:	1,	45,	-45,	,	90,	,
Plate No.	.: 13,	FEM	ELEMENT	ID:	13,	RANK:	13,	Subcase:	11,	Layers:	12,	M.S:	1.79,	FailMode:	1,	45,	-45,	,	90,	,
Plate No.	.: 14,	FEM	ELEMENT	ID:	14,	RANK:	14,	Subcase:	14,	Layers:	12,	M.S:	1.04,	FailMode:	2,	45,	-45,		90,	,
Plate No.	.: 15,	FEM	ELEMENT	ID:	15,	RANK:	15,	Subcase:	10,	Layers:	12,	M.S:	0.82,	FailMode:	3,	45,	-45,	,	90,	,
Plate No.	.: 16,	FEM	ELEMENT	ID:	16,	RANK:	16,	Subcase:	10,	Layers:	12,	M.S:	1.34,	FailMode:	3,	45,	-45,	,	90,	,
Plate No.	.: 17,	FEM	ELEMENT	ID:	17,	RANK:	17,	Subcase:	10,	Layers:	12,	M.S:	1.41,	FailMode:	3,	45,	-45,	,	90,	,
Plate No.	.: 18,	FEM	ELEMENT	ID:	18,	FANK:	18,	Subcase:	10,	Layers:	12,	M.S:	1.33,	FailMode:	3,	45,	-45,	,	90,	,
Plate No.	.: 19,	FEM	ELEMENT	ID:	19,	RANK:	19,	Subcase:	10,	Layers:	12,	M.S:	1.22,	FailMode:	3,	45,	-45,	,	90,	,
Plate No.	.: 20,	FEM	ELEMENT	ID:	20,	RANK:	20,	Subcase:	10,	Layers:	12,	M.S:	1.08,	FailMode:	3,	45,	-45,	,	90,	,
Plate No.	.: 21,	FEM	ELEMENT	ID:	21,	FANK:	21,	Subcase:	10,	Layers:	12,	M.S:	0.78,	FailMode:	3,	45,	-45,	,	90,	,
Plate No.	.: 22,	FEM	ELEMENT	ID:	22,	RANK:	22,	Subcase:	10,	Layers:	12,	M.S:	0.73,	FailMode:	3,	45,	-45,	,	90,	,
Plate No.	.: 23,	FEM	ELEMENT	ID:	23,	RANK:	23,	Subcase:	10,	Layers:	12,	M.S:	0.50,	FailMode:	3,	45,	-45,	,	90,	,

Fig Screen shot of the example result