

Deleting failed plexes owned by the surviving site (MetroCluster IP configurations)

ONTAP MetroCluster

Paula Carrigan, Thom Illingworth June 21, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap-metrocluster/disaster-recovery/task_delete_plexes_mcip.html on September 24, 2021. Always check docs.netapp.com for the latest.

Table of Contents

Deleting failed plexes owned by the surviving site (MetroCluster IP configurations)

After replacing hardware and assigning disks, you must delete failed remote plexes that are owned by the surviving site nodes but located at the disaster site.

About this task

These steps are performed on the surviving cluster.

Steps

1. Identify the local aggregates: storage aggregate show -is-home true

```
cluster B::> storage aggregate show -is-home true
cluster B Aggregates:
Aggregate Size Available Used% State #Vols Nodes
                                                       RAID
Status
_____ ____
node B 1 aggr0 1.49TB 74.12GB 95% online 1 node B 1
raid4,
mirror
degraded
node_B_2_aggr0 1.49TB 74.12GB 95% online 1 node_B_2
raid4,
mirror
degraded
node B 1 aggr1 2.99TB 2.88TB 3% online 15 node B 1
raid dp,
mirror
degraded
node_B_1_aggr2 2.99TB 2.91TB 3% online 14 node_B_1
raid tec,
mirror
degraded
node_B_2_aggr1 2.95TB 2.80TB 5% online 37 node_B_2
raid dp,
```

```
mirror

degraded
node_B_2_aggr2 2.99TB 2.87TB 4% online 35 node_B_2
raid_tec,

mirror

degraded
6 entries were displayed.

cluster_B::>
```

2. Identify the failed remote plexes:

```
storage aggregate plex show
```

The following example calls out the plexes that are remote (not plex0) and have a status of "failed":

```
cluster B::> storage aggregate plex show -fields aggregate, status, is-
online, Plex, pool
aggregate
                                 is-online pool
           plex status
node B 1 aggr0 plex0 normal, active true
                                             0
node B 1 aggr0 plex4 failed, inactive false - <<<---Plex at remote site
node B 2 aggr0 plex0 normal, active true
                                            0
node B 2 aggr0 plex4 failed,inactive false - <<<<---Plex at remote site</pre>
node B 1 aggr1 plex0 normal, active true
                                             0
node B 1 aggr1 plex4 failed, inactive false - <<<<---Plex at remote site
node B 1 aggr2 plex0 normal, active true
node B 1 aggr2 plex1 failed,inactive false - <<<<---Plex at remote site</pre>
node B 2 aggr1 plex0 normal, active true
                                             0
node B 2 aggr1 plex4 failed, inactive false - <<<---Plex at remote site
node B 2 aggr2 plex0 normal, active true
node B 2 aggr2 plex1 failed,inactive false - <<<<---Plex at remote site</pre>
node A 1 aggr1 plex0 failed, inactive false -
node A 1 aggr1 plex4 normal, active true
                                             1
node A 1 aggr2 plex0 failed, inactive false
node A 1 aggr2 plex1 normal, active true
node A 2 aggr1 plex0 failed, inactive false
node A 2 aggr1 plex4 normal, active true
                                             1
node A 2 aggr2 plex0 failed, inactive false -
node A 2 aggr2 plex1 normal, active true
20 entries were displayed.
cluster B::>
```

- 3. Take offline each of the failed plexes, and then delete them:
 - a. Take offline the failed plexes:

```
storage aggregate plex offline -aggregate aggregate-name -plex plex-id

The following example shows the aggregate "node B 2 aggr1/plex1" being taken offline:
```

```
cluster_B::> storage aggregate plex offline -aggregate node_B_1_aggr0
-plex plex4

Plex offline successful on plex: node_B_1_aggr0/plex4
```

b. Delete the failed plex:

storage aggregate plex delete -aggregate aggregate-name -plex plex-id You can destroy the plex when prompted.

The following example shows the plex node_B_2_aggr1/plex1 being deleted.

```
cluster B::> storage aggregate plex delete -aggregate  node B 1 aggr0
-plex plex4
Warning: Aggregate "node B 1 aggr0" is being used for the local
management root
        volume or HA partner management root volume, or has been
marked as
        the aggregate to be used for the management root volume
after a
        reboot operation. Deleting plex "plex4" for this aggregate
could lead
        to unavailability of the root volume after a disaster
recovery
        procedure. Use the "storage aggregate show -fields
        has-mroot, has-partner-mroot, root" command to view such
aggregates.
Warning: Deleting plex "plex4" of mirrored aggregate "node B 1 aggr0"
on node
         "node B 1" in a MetroCluster configuration will disable its
        synchronous disaster recovery protection. Are you sure you
want to
        destroy this plex? {y|n}: y
[Job 633] Job succeeded: DONE
cluster B::>
```

You must repeat these steps for each of the failed plexes.

4. Confirm that the plexes have been removed:

storage aggregate plex show -fields aggregate, status, is-online, plex, pool

```
cluster B::> storage aggregate plex show -fields aggregate, status, is-
online, Plex, pool
aggregate
           plex status
                                is-online pool
----- ---- ----
node B 1 aggr0 plex0 normal, active true
                                            0
node B 2 aggr0 plex0 normal, active true
                                            0
node B 1 aggr1 plex0 normal, active true
node B 1 aggr2 plex0 normal, active true
                                            0
node B 2 aggr1 plex0 normal, active true
                                            0
node B 2 aggr2 plex0 normal, active true
                                            0
node A 1 aggr1 plex0 failed, inactive false
node A 1 aggr1 plex4 normal, active true
                                            1
node A 1 aggr2 plex0 failed, inactive false
node A 1 aggr2 plex1 normal, active true
                                            1
node A 2 aggr1 plex0 failed, inactive false
node A 2 aggr1 plex4 normal, active true
                                            1
node A 2 aggr2 plex0 failed, inactive false
node A 2 aggr2 plex1 normal, active true
                                            1
14 entries were displayed.
cluster B::>
```

5. Identify the switched-over aggregates:

```
storage aggregate show -is-home false
```

You can also use the storage aggregate plex show -fields aggregate, status, is-online, plex, pool command to identify plex 0 switched-over aggregates. They will have a status of "failed, inactive".

The following commands show four switched-over aggregates:

- ∘ node A 1 aggr1
- node_A_1_aggr2
- ∘ node A 2 aggr1
- o node_A_2_aggr2

```
cluster B::> storage aggregate show -is-home false
cluster A Switched Over Aggregates:
Aggregate Size Available Used% State #Vols Nodes RAID
Status
_____ ____
node A 1 aggr1 2.12TB 1.88TB 11% online 91 node B 1
raid_dp,
mirror
degraded
node A 1 aggr2 2.89TB 2.64TB 9% online 90 node B 1
raid tec,
mirror
degraded
node A 2 aggr1 2.12TB 1.86TB 12% online 91 node B 2
raid dp,
mirror
degraded
node A 2 aggr2 2.89TB 2.64TB 9% online 90 node B 2
raid_tec,
mirror
degraded
4 entries were displayed.
cluster B::>
```

6. Identify switched-over plexes:

storage aggregate plex show -fields aggregate, status, is-online, Plex, pool

You want to identify the plexes with a status of "failed, inactive".

The following commands show four switched-over aggregates:

```
cluster B::> storage aggregate plex show -fields aggregate, status, is-
online, Plex, pool
aggregate plex status
                              is-online pool
_____ ____
node B 1 aggr0 plex0 normal, active true
                                          0
node B 2 aggr0 plex0 normal, active true
                                          0
node B 1 aggr1 plex0 normal, active true
node B 1 aggr2 plex0 normal, active true
node B 2 aggr1 plex0 normal, active true
node B 2 aggr2 plex0 normal, active true
node A 1 aggr1 plex0 failed,inactive false - <<<-- Switched over</pre>
aggr/Plex0
node A 1 aggr1 plex4 normal, active true
node A 1 aggr2 plex0 failed,inactive false - <<<-- Switched over</pre>
aggr/Plex0
node A 1 aggr2 plex1 normal, active true 1
node A 2 aggr1 plex0 failed,inactive false - <<<-- Switched over</pre>
aggr/Plex0
node A 2 aggr1 plex4 normal, active true 1
node A 2 aggr2 plex0 failed,inactive false - <<<-- Switched over</pre>
aggr/Plex0
node A 2 aggr2 plex1 normal,active true 1
14 entries were displayed.
cluster B::>
```

7. Delete the failed plex:

storage aggregate plex delete -aggregate node A 1 aggr1 -plex plex0

You can destroy the plex when prompted.

The following example shows the plex node_A_1_aggr1/plex0 being deleted:

```
cluster B::> storage aggregate plex delete -aggregate node A 1 aggr1
-plex plex0
Warning: Aggregate "node A_1aggr1" hosts MetroCluster metadata volume
         "MDV CRS e8457659b8a711e78b3b00a0988fe74b A". Deleting plex
"plex0"
         for this aggregate can lead to the failure of configuration
         replication across the two DR sites. Use the "volume show
-vserver
         <admin-vserver> -volume MDV_CRS*" command to verify the
location of
         such volumes.
Warning: Deleting plex "plex0" of mirrored aggregate "node A 1 aggr1" on
node
         "node A 1" in a MetroCluster configuration will disable its
         synchronous disaster recovery protection. Are you sure you want
to
         destroy this plex? \{y|n\}: y
[Job 639] Job succeeded: DONE
cluster B::>
```

You must repeat these steps for each of the failed aggregates.

8. Verify that there are no failed plexes remaining on the surviving site.

The following output shows that all plexes are normal, active, and online.

cluster_B::> storage aggregate plex show -fields aggregate, status, isonline, Plex, pool
aggregate plex status is-online pool

node_B_1_aggr0 plex0 normal, active true 0
node_B_2_aggr0 plex0 normal, active true 0
node_B_1_aggr1 plex0 normal, active true 0
node_B_2_aggr2 plex0 normal, active true 0
node_B_1_aggr1 plex0 normal, active true 0
node_B_1_aggr1 plex0 normal, active true 0

0

node_A_1_aggr1 plex4 normal,active true 1
node_A_1_aggr2 plex1 normal,active true 1
node_A_2_aggr1 plex4 normal,active true 1
node A 2 aggr2 plex1 normal,active true 1

node_B_2_aggr2 plex0 normal,active true

10 entries were displayed.

cluster B::>

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.