

Testing the MetroCluster configuration

ONTAP MetroCluster

Thom Illingworth, Zachary Wambold August 25, 2021

This PDF was generated from https://docs.netapp.com/us-en/ontap-metrocluster/install-ip/task_test_the_mcc_configuration.html on September 24, 2021. Always check docs.netapp.com for the latest

Table of Contents

Testing the MetroCluster configuration	 	 	 1
Verifying negotiated switchover	 	 	 1
Verifying healing and manual switchback	 	 	 2
Verifying operation after power line disruption	 	 	 6
Verifying operation after loss of a single storage shelf	 	 	 8

Testing the MetroCluster configuration

You can test failure scenarios to confirm the correct operation of the MetroCluster configuration.

Verifying negotiated switchover

You can test the negotiated (planned) switchover operation to confirm uninterrupted data availability.

About this task

This test validates that data availability is not affected (except for Microsoft Server Message Block (SMB) and Solaris Fibre Channel protocols) by switching the cluster over to the second data center.

This test should take about 30 minutes.

This procedure has the following expected results:

• The metrocluster switchover command will present a warning prompt.

If you respond yes to the prompt, the site the command is issued from will switch over the partner site.

For MetroCluster IP configurations:

- For ONTAP 9.4 and earlier:
 - Mirrored aggregates will become degraded after the negotiated switchover.
- For ONTAP 9.5 and later:
 - Mirrored aggregates will remain in normal state if the remote storage is accessible.
 - Mirrored aggregates will become degraded after the negotiated switchover if access to the remote storage is lost.
- For ONTAP 9.8 and later:
 - Unmirrored aggregates that are located at the disaster site will become unavailable if access to the remote storage is lost. This might lead to a controller outage.

Steps

1. Confirm that all nodes are in the configured state and normal mode:

metrocluster node show

2. Begin the switchover operation:

```
metrocluster switchover
```

```
cluster_A::> metrocluster switchover
Warning: negotiated switchover is about to start. It will stop all the
data Vservers on cluster "cluster_B" and
automatically re-start them on cluster "cluster_A". It will finally
gracefully shutdown cluster "cluster_B".
```

3. Confirm that the local cluster is in the configured state and switchover mode:

metrocluster node show

4. Confirm that the switchover operation was successful:

metrocluster operation show

```
cluster_A::> metrocluster operation show

cluster_A::> metrocluster operation show
   Operation: switchover
        State: successful
Start Time: 2/6/2016 13:28:50
   End Time: 2/6/2016 13:29:41
        Errors: -
```

5. Use the vserver show and network interface show commands to verify that DR SVMs and LIFs have come online.

Verifying healing and manual switchback

You can test the healing and manual switchback operations to verify that data availability is not affected (except for SMB and Solaris FC configurations) by switching back the cluster to the original data center after a negotiated switchover.

About this task

This test should take about 30 minutes.

The expected result of this procedure is that services should be switched back to their home nodes.

The healing steps are not required on systems running ONTAP 9.5 or later, on which healing is performed automatically after a negotiated switchover. On systems running ONTAP 9.6 and later, healing is also performed automatically after unscheduled switchover.

Steps

1. If the system is running ONTAP 9.4 or earlier, heal the data aggregate:

```
metrocluster heal aggregates
```

The following example shows the successful completion of the command:

```
cluster_A::> metrocluster heal aggregates
[Job 936] Job succeeded: Heal Aggregates is successful.
```

2. If the system is running ONTAP 9.4 or earlier, heal the root aggregate:

```
metrocluster heal root-aggregates
```

This step is required on the following configurations:

- MetroCluster FC configurations.
- MetroCluster IP configurations running ONTAP 9.4 or earlier. The following example shows the successful completion of the command:

```
cluster_A::> metrocluster heal root-aggregates
[Job 937] Job succeeded: Heal Root Aggregates is successful.
```

3. Verify that healing is completed:

```
metrocluster node show
```

The following example shows the successful completion of the command:

If the automatic healing operation fails for any reason, you must issue the metrocluster heal commands manually as done in ONTAP versions prior to ONTAP 9.5. You can use the metrocluster operation show and metrocluster operation history show -instance commands to monitor the status of healing and determine the cause of a failure.

4. Verify that all aggregates are mirrored:

```
storage aggregate show
```

The following example shows that all aggregates have a RAID Status of mirrored:

```
cluster A::> storage aggregate show
cluster Aggregates:
Aggregate Size Available Used% State #Vols Nodes RAID
______ _____
_____
data cluster
        4.19TB 4.13TB 2% online 8 node_A_1 raid_dp,
                                            mirrored,
                                            normal
root cluster
       715.5GB 212.7GB 70% online 1 node A 1 raid4,
                                            mirrored,
                                            normal
cluster B Switched Over Aggregates:
Aggregate Size Available Used% State #Vols Nodes RAID
_____ ______
data cluster B
        4.19TB 4.11TB 2% online 5 node_A_1 raid_dp,
                                            mirrored,
                                            normal
root_cluster_B - - - unknown - node_A_1 -
```

- 5. Boot nodes from the disaster site.
- 6. Check the status of switchback recovery:

metrocluster node show

Perform the switchback:

metrocluster switchback

```
cluster_A::> metrocluster switchback
[Job 938] Job succeeded: Switchback is successful.Verify switchback
```

8. Confirm status of the nodes:

metrocluster node show

9. Confirm status of the MetroCluster operation:

```
metrocluster operation show
```

The output should show a successful state.

```
cluster_A::> metrocluster operation show
  Operation: switchback
      State: successful
Start Time: 2/6/2016 13:54:25
  End Time: 2/6/2016 13:56:15
      Errors: -
```

Verifying operation after power line disruption

You can test the MetroCluster configuration's response to the failure of a PDU.

About this task

The best practice is for each power supply unit (PSU) in a component to be connected to separate power supplies. If both PSUs are connected to the same power distribution unit (PDU) and an electrical disruption occurs, the site could down or a complete shelf might become unavailable. Failure of one power line is tested to confirm that there is no cabling mismatch that could cause a service disruption.

This test should take about 15 minutes.

This test requires turning off power to all left-hand PDUs and then all right-hand PDUs on all of the racks containing the MetroCluster components.

This procedure has the following expected results:

- Errors should be generated as the PDUs are disconnected.
- · No failover or loss of service should occur.

Steps

- 1. Turn off the power of the PDUs on the left-hand side of the rack containing the MetroCluster components.
- 2. Monitor the result on the console:

```
system environment sensors show -state fault
storage shelf show -errors
```

```
cluster A::> system environment sensors show -state fault
Node Sensor
            State Value/Units Crit-Low Warn-Low Warn-Hi
Crit-Hi
node A 1
      PSU1
            fault
                      PSU OFF
      PSU1 Pwr In OK fault
                      FAULT
node A 2
      PSU1
                  fault
                      PSU OFF
      PSU1 Pwr In OK fault
                      FAULT
4 entries were displayed.
cluster A::> storage shelf show -errors
   Shelf Name: 1.1
    Shelf UID: 50:0a:09:80:03:6c:44:d5
Serial Number: SHFHU1443000059
Error Type
           Description
_____
              Critical condition is detected in storage shelf
power supply unit "1". The unit might fail. Reconnect PSU1
```

3. Turn the power back on to the left-hand PDUs.

- 4. Make sure that ONTAP clears the error condition.
- 5. Repeat the previous steps with the right-hand PDUs.

Verifying operation after loss of a single storage shelf

You can test the failure of a single storage shelf to verify that there is no single point of failure.

About this task

This procedure has the following expected results:

- An error message should be reported by the monitoring software.
- · No failover or loss of service should occur.
- Mirror resynchronization starts automatically after the hardware failure is restored.

Steps

1. Check the storage failover status:

storage failover show

```
Cluster_A::> storage failover show

Node Partner Possible State Description

------
node_A_1 node_A_2 true Connected to node_A_2
node_A_2 node_A_1 true Connected to node_A_1
2 entries were displayed.
```

2. Check the aggregate status:

storage aggregate show

```
cluster A::> storage aggregate show
cluster Aggregates:
Aggregate Size Available Used% State #Vols Nodes RAID
Status
_____ _____
-----
node A 1data01 mirrored
        4.15TB 3.40TB 18% online 3 node A_1
raid dp,
mirrored,
normal
node A 1root
       707.7GB 34.29GB 95% online 1 node A_1
raid dp,
mirrored,
normal
node_A_2_data01_mirrored
        4.15TB 4.12TB 1% online 2 node_A_2
raid_dp,
mirrored,
normal
node A 2 data02 unmirrored
        raid_dp,
normal
node A 2 root
       707.7GB 34.27GB 95% online 1 node_A_2
raid dp,
mirrored,
normal
```

3. Verify that all data SVMs and data volumes are online and serving data:

vserver show -type data

volume show !vol0,!MDV*

cluster_A			=	Operations	1 Poot
Januar	Tima	Subtine		Operationa State	
vserver Aggregate		Subtype	State	State	VOIUME
	·				
	· -				
SVM1	data	sync-sour	ce	running	SVM1_root
	data01_mi				
		sync-sour	ce	running	SVM2_root
10de_A_2_	_data01_mi:	rrored			
luster A	··> netwo	rk interface	e show -fie	elds is-home	false
_		es matching			14150
	_		1 1 1 1 1		
cluster_A	::> volume	e show !vol	0,!MDV*		
server	Volume	Aggrega	ate Stat	te Type	Size
vailable	used%				
77741					
 SVM1	SVM1 roo	+			
 SVM1	SVM1_roo				
SVM1	 SVM1_roo		_1data01_mi		10GB
 SVM1 9.50GB	 SVM1_roo		_1data01_mi	.rrored	10GB
9.50GB	_		_1data01_mi	.rrored	10GB
	_	node_A	_1data01_mi	.rrored	10GB
9.50GB	5%	node_A a_vol	_1data01_mi onli _1data01_mi	rrored ne RW	10GB
9.50GB SVM1	5% SVM1_data	node_A a_vol	_1data01_mi onli	rrored ne RW	10GB
9.50GB SVM1 9.49GB	5%	node_A a_vol	_1data01_mi onli _1data01_mi	rrored ne RW	
9.50GB	5% SVM1_data 5%	node_A a_vol node_A	_1data01_mi onli _1data01_mi	rrored ne RW	
9.50GB SVM1 9.49GB	5% SVM1_data	node_A_a_volnode_A_	_1data01_mi onli _1data01_mi onli	rrored ne RW rrored ne RW	
9.50GB SVM1 9.49GB	5% SVM1_data 5%	node_A_a_volnode_A_	_1data01_mi onli _1data01_mi onli _2_data01_m	rrored ne RW rrored ne RW	10GB
9.50GB SVM1 9.49GB SVM2	5% SVM1_data 5% SVM2_roo	node_A_a_volnode_A_	_1data01_mi onli _1data01_mi onli	rrored ne RW rrored ne RW	
9.50GB SVM1 9.49GB SVM2 9.49GB	5% SVM1_data 5%	node_A_a_volnode_A_	_1data01_mi onli _1data01_mi onli _2_data01_m	rrored ne RW rrored ne RW	10GB
9.50GB SVM1 9.49GB SVM2	5% SVM1_data 5% SVM2_room	node_A_a_volnode_A_t t	_1data01_mi onli _1data01_mi onli _2_data01_m	rrored ne RW rrored ne RW	10GB
9.50GB SVM1 9.49GB SVM2 9.49GB	5% SVM1_data 5% SVM2_roo	node_A_a_vol t node_A_a_t a_vol	_1data01_mi onli _1data01_mi onli _2_data01_m	rrored ne RW rrored ne RW	10GB
9.50GB SVM1 9.49GB SVM2 9.49GB	5% SVM1_data 5% SVM2_room	node_A_a_vol t node_A_a_t a_vol	_1data01_mi onli _1data01_mi onli _2_data01_m onli	errored ene RW errored ene RW enirrored ene RW	10GB

4. Identify a shelf in Pool 1 for node "node_A_2" to power off to simulate a sudden hardware failure:

The shelf you select must contain drives that are part of a mirrored data aggregate.

In the following example, shelf ID "31" is selected to fail.

_	storage aggregate show -r -n	ode n	ode A 2	!*root	
Owner Node: n	ode A 2				
Aggregate: n	 ode_A_2_data01_mirrored (onl	ine,	raid_dp	, mirro	red) (block
checksums)			_		
Plex: /node	_A_2_data01_mirrored/plex0 (onlin	e, norma	al, act	ive, pool0)
RAID Group	/node_A_2_data01_mirrored/p	lex0/	rg0 (no:	cmal, b	lock
checksums)					
					Usable
Physical					
Position	Disk	Pool	Type	RPM	Size
Size Status					
dparity	2.30.3	0	BSAS	7200	827.7GB
828.0GB (norm					
parity	2.30.4	0	BSAS	7200	827.7GB
828.0GB (norm	al)				
data	2.30.6	0	BSAS	7200	827.7GB
828.0GB (norm	al)				
data	2.30.8	0	BSAS	7200	827.7GB
828.0GB (norm	al)				
data	2.30.5	0	BSAS	7200	827.7GB
828.0GB (norm	7 \				
1 = 0 . 0 0 2 (110 1111	al)				
	al) _A_2_data01_mirrored/plex4 (onlin	e, norma	al, act	ive, pool1)
Plex: /node					
Plex: /node	_A_2_data01_mirrored/plex4 (
Plex: /node RAID Group	_A_2_data01_mirrored/plex4 (
Plex: /node RAID Group	_A_2_data01_mirrored/plex4 (lex4/	rg0 (no:	rmal, b	lock Usable
Plex: /node RAID Group checksums) Physical Position	_A_2_data01_mirrored/plex4 (/node_A_2_data01_mirrored/p	lex4/		rmal, b	lock Usable
Plex: /node RAID Group checksums) Physical Position	_A_2_data01_mirrored/plex4 (/node_A_2_data01_mirrored/p	lex4/	rg0 (no:	rmal, b	lock Usable
Plex: /node RAID Group checksums) Physical	_A_2_data01_mirrored/plex4 (/node_A_2_data01_mirrored/p	lex4/	rg0 (no:	rmal, b	lock Usable
Plex: /node RAID Group checksums) Physical Position Size Status	_A_2_data01_mirrored/plex4 (/node_A_2_data01_mirrored/p Disk	Pool	rg0 (no: Type	RPM	lock Usable Size
Plex: /node RAID Group checksums) Physical Position Size Status dparity	_A_2_data01_mirrored/plex4 (/node_A_2_data01_mirrored/p Disk 1.31.7	Pool	rg0 (no:	RPM	lock Usable
Plex: /node RAID Group checksums) Physical Position Size Status dparity 828.0GB (norm	_A_2_data01_mirrored/plex4 (/node_A_2_data01_mirrored/p Disk 1.31.7 al)	Pool 1	Type	RPM 7200	Usable Size 827.7GB
Plex: /node RAID Group checksums) Physical Position Size Status dparity 828.0GB (normal	_A_2_data01_mirrored/plex4 (/node_A_2_data01_mirrored/p Disk 1.31.7 al) 1.31.6	Pool 1	rg0 (no: Type	RPM 7200	lock Usable Size
Plex: /node RAID Group checksums) Physical Position Size Status dparity 828.0GB (normality 828.0GB (normality	_A_2_data01_mirrored/plex4 (/node_A_2_data01_mirrored/p Disk 1.31.7 al) 1.31.6 al)	Pool 1	Type BSAS BSAS	RPM 7200	Usable Size 827.7GB
Plex: /node RAID Group checksums) Physical Position Size Status dparity 828.0GB (normal parity 828.0GB (normal parity	_A_2_data01_mirrored/plex4 (/node_A_2_data01_mirrored/p Disk 1.31.7 al) 1.31.6 al) 1.31.3	Pool 1	Type	RPM 7200	Usable Size 827.7GB
Plex: /node RAID Group checksums) Physical Position Size Status dparity 828.0GB (normality 828.0GB (normality	_A_2_data01_mirrored/plex4 (/node_A_2_data01_mirrored/p Disk 1.31.7 al) 1.31.6 al) 1.31.3 al)	Pool 1 1	Type BSAS BSAS	RPM 7200 7200 7200	Usable Size 827.7GB

```
1.31.5
                                                      7200 827.7GB
                                              BSAS
     data
828.0GB (normal)
 Aggregate: node A 2 data02 unmirrored (online, raid dp) (block
checksums)
  Plex: /node A 2 data02 unmirrored/plex0 (online, normal, active,
pool0)
   RAID Group /node A 2 data02 unmirrored/plex0/rg0 (normal, block
checksums)
                                                             Usable
Physical
     Position Disk
                                         Pool Type RPM
                                                               Size
Size Status
     dparity 2.30.12
                                          0
                                              BSAS
                                                      7200 827.7GB
828.0GB (normal)
     parity 2.30.22
                                          0
                                              BSAS
                                                      7200 827.7GB
828.0GB (normal)
     data
             2.30.21
                                          0
                                              BSAS
                                                      7200 827.7GB
828.0GB (normal)
             2.30.20
                                              BSAS
                                                      7200 827.7GB
     data
                                          \Omega
828.0GB (normal)
             2.30.14
     data
                                              BSAS
                                                      7200 827.7GB
828.0GB (normal)
15 entries were displayed.
```

- 5. Physically power off the shelf that you selected.
- 6. Check the aggregate status again:

```
storage aggregate show
storage aggregate show -r -node node_A_2 !*root
```

The aggregate with drives on the powered-off shelf should have a "degraded" RAID status, and drives on the affected plex should have a "failed" status, as shown in the following example:

```
mirrored,
normal
node A 1root
         707.7GB 34.29GB 95% online 1 node A 1
raid dp,
mirrored,
normal
node A 2 data01 mirrored
         4.15TB 4.12TB 1% online 2 node A 2
raid dp,
mirror
degraded
node_A_2_data02_unmirrored
          raid dp,
normal
node A 2 root
        707.7GB 34.27GB 95% online 1 node A 2
raid dp,
mirror
degraded
cluster_A::> storage aggregate show -r -node node_A_2 !*root
Owner Node: node A 2
Aggregate: node A 2 data01 mirrored (online, raid dp, mirror degraded)
(block checksums)
 Plex: /node_A_2_data01_mirrored/plex0 (online, normal, active, pool0)
  RAID Group /node A 2 data01 mirrored/plex0/rg0 (normal, block
checksums)
                                                       Usable
Physical
                                    Pool Type RPM Size
   Position Disk
Size Status
                                     0 BSAS 7200 827.7GB
    dparity 2.30.3
828.0GB (normal)
   parity 2.30.4
                                 0 BSAS 7200 827.7GB
828.0GB (normal)
```

data 2.30.6	0	BSAS	7200	827.7GB
828.0GB (normal)				
data 2.30.8	0	BSAS	7200	827.7GB
828.0GB (normal)				
data 2.30.5	0	BSAS	7200	827.7GB
828.0GB (normal)				
		_		
Plex: /node_A_2_data01_mirrored/plex4 (offli	ne, ia	iled, in	active,
pool1)	1 0 1 1 /	· ~ ~ (~ ~	antial :	2020
RAID Group /node_A_2_data01_mirrored/pchecksums)	ilex4/	rgo (þ	altial,	none
Checks units)				Usable
Physical				OBADIC
Position Disk	Pool	Tvpe	RPM	Size
Size Status		- 71-		
dparity FAILED	_	-	_	827.7GB
- (failed)				
parity FAILED	-	-	-	827.7GB
- (failed)				
data FAILED	-	_	_	827.7GB
- (failed)				
data FAILED	-	-	-	827.7GB
- (failed)				
data FAILED	-	-	_	827.7GB
- (failed)				
Accesses and A 2 data02 upminnand /o	n1 i no		dn) (bl	o alt
Aggregate: node_A_2_data02_unmirrored (content checksums)	III TII E	e, lalu	_αb) (pr	JCK
Plex: /node A 2 data02 unmirrored/plex0	(on 1	ine n	ormal a	at i we
pool0)	(0111	. 1110, 11	Olmal, a	CC1 VC ,
RAID Group /node A 2 data02 unmirrored	l/plex	:0/ra0	(normal,	block
checksums)	, 1	., 5:	,	
				Usable
Physical				
Position Disk	Pool	Туре	RPM	Size
Size Status				
dparity 2.30.12	0	BSAS	7200	827.7GB
828.0GB (normal)				
parity 2.30.22	0	BSAS	7200	827.7GB
828.0GB (normal)				
data 2.30.21	0	BSAS	7200	827.7GB
828.0GB (normal)				

data 2.30.20		BSAS	7200	827.7GB	
828.0GB (normal)					
data 2.30.14	0	BSAS	7200	827.7GB	
828.0GB (normal)					

7. Verify that the data is being served and that all volumes are still online:

```
vserver show -type data
network interface show -fields is-home false
volume show !vol0,!MDV*
```

15 entries were displayed.

cluster A::> vserver show -type data cluster A::> vserver show -type data Admin Operational Root Vserver Type Subtype State State Volume Aggregate SVM1 data sync-source running SVM1_root node_A_1_data01_mirrored SVM2 data sync-source running SVM2 root node A 1 data01 mirrored cluster A::> network interface show -fields is-home false There are no entries matching your query. cluster_A::> volume show !vol0,!MDV* Vserver Volume Aggregate State Type Size Available Used% ______ ____ ____ SVM1 SVM1 root node A 1data01 mirrored online RW 10GB 9.50GB 5% SVM1 SVM1 data_vol node A 1data01 mirrored online RW 10GB 9.49GB 5% SVM2 SVM2 root node A 1data01 mirrored online RW 10GB 9.49GB 5% SVM2 SVM2 data vol node A 2 data02 unmirrored online RW 1GB 972.6MB 5%

8. Physically power on the shelf.

Resynchronization starts automatically.

9. Verify that resynchronization has started:

```
storage aggregate show
```

The affected aggregate should have a RAID status of "resyncing", as shown in the following example:

```
cluster A::> storage aggregate show
cluster Aggregates:
Aggregate Size Available Used% State #Vols Nodes RAID
Status
___________
_____
node A 1 data01 mirrored
       4.15TB 3.40TB 18% online 3 node A_1
raid dp,
mirrored,
normal
node A 1 root
       707.7GB 34.29GB 95% online 1 node A 1
raid dp,
mirrored,
normal
node A 2 data01 mirrored
       4.15TB 4.12TB 1% online 2 node_A_2
raid dp,
resyncing
node A 2 data02 unmirrored
       raid dp,
normal
node_A_2_root
       707.7GB 34.27GB 95% online 1 node A 2
raid dp,
resyncing
```

10. Monitor the aggregate to confirm that resynchronization is complete:

```
storage aggregate show
```

The affected aggregate should have a RAID status of "normal", as shown in the following example:

```
cluster A::> storage aggregate show
cluster Aggregates:
Aggregate Size Available Used% State #Vols Nodes RAID
_____ ____
_____
node A 1data01 mirrored
      4.15TB 3.40TB 18% online 3 node_A_1
raid_dp,
mirrored,
normal
node A 1root
     707.7GB 34.29GB 95% online 1 node_A_1
raid dp,
mirrored,
normal
node A 2 data01 mirrored
      4.15TB 4.12TB 1% online 2 node_A_2
raid dp,
normal
node A 2 data02 unmirrored
       raid_dp,
normal
node A 2 root
       707.7GB 34.27GB 95% online 1 node_A_2
raid_dp,
resyncing
```

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.