

Item # 1005-864-326 Model # AL-TP-RGBCW-60-2232

USE AND CARE GUIDE


32 FT SMART TUNABLE **TAPE LIGHT**


Pre-Installation

PACKAGE CONTENTS









Care and Cleaning

- Before attempting to clean the light strip, unplug the adaptor from the power outlet.
- □ To clean the light strip, use a clean, dry, or slightly damp cloth.
- Do not use any cleaners with chemicals, solvents, or harsh abrasives, as damage to the tape light may occur.
- □ Allow the light strip and components to dry thoroughly before plugging the power adaptor back into the outlet.

Warranty

2-YEARS LIMITED WARRANTY

The manufacturer warrants this lighting fixture against defects in materials and workmanship for a period of two years from the date of purchase. If within this period the product is found to be defective in material or workmanship, the product must be returned, with a copy of the bill of sale as proof of purchase, to the original place of purchase. The manufacturer will, at its option, repair, replace, or refund the purchase price to the original purchaser or consumer. This warranty does not cover light bulbs or the fixture becoming damaged due to misuse, accidental damage, improper handling and/or installation, and specifically excludes liability for direct, incidental, or consequential damages. As some states do not allow exclusions or limitation on an implied warranty, so the above exclusions and limitations may not apply. This warranty gives you specific rights and you may also have other rights that vary from state to state. Contact the Customer Service Team at (877) 592-5233 or visit WWW.HOMEDEPOT.COM/HUBSPACE.



Questions, problems, missing parts? Please call Hubspace Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday and 9 a.m. - 6 p.m., EST, Saturday at (877) 592-5233

WWW.HOMEDEPOT.COM/HUBSPACE

Retain this manual for future use

Safety Information

IMPORTANT SAFETY INSTRUCTIONS **Read All Instructions** (SAVE THESE INSTRUCTIONS)



WARNING: Do not connect more than or 32 ft. tape tape light to this single adaptor.

WARNING: Do not submerge the flexible light in liquids or use the product in the vicinity of standing water or other liquids.



WARNING: Do not secure this product with staples, nails, or other sharp objects that may

covering may cause the next or ignite. WARNING: Risk of Electric Shock. When used outdoors, install only to a covered service receptacle that has a weatherproof enclosure. outdoors, install only to a covered Class A GECL

WARNING: Do not use if there is any damage to **WARNING:** Do not use if there is any damage to the light or cord insulation. Inspect periodically.

WARNING: Do not cover this product as the

covering may cause the flexible light to

WARNING: When using outdoor portable lighting products, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following:

• Use only three-wire outdoor extension cords that have three-prong grounding plugs and grounding receptacles that accord the produced color.

Use only three-wire outdoor extension cords unan larve unex-printy grounding progs and grounding progs and grounding progs and grounding programs.
 Lise ground fault circuit interrupter (GFCI) protection on the circuit(s) or outlet(s) when using outdoors.
 Use only UL approved outdoor extension cords, such as type SOW, STW, STOW, SJW, SJW, SJW, SJW, STW, or SJTOW. This designation is marked on the jacket of the extension cord. Receptacles are available having built-in GFCI protection and are able to be used for this measure of safety.

of compliance statement in the second state of the second states and the second state of the following two conditions:

This device may not cause harmful interference, and
 This device must accept any interference received, including interference that may cause undesired operation.
 CO WARNING

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and the receiver.
 Connect the equipment into an outlet different from that to which the receiver is connected.
 Consult the dealer or an experienced radio/TV technician for help.

- Consider the Carles of an experienced radio 1 technical for field.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Responsible Party: American Lighting Inc.

Address: 11775 E.45th Ave. Denver, 20 80239

ber: 1 800 880 1180

Connect the Smart Device

Let's Get Started!

- □ Download the **Hubspace[™]** app from the App Store or the Google Play Store to your mobile device.
- Launch the app.
- □ To register, enter your email address and a password. Or, log-in if you already have an account.
- Bluetooth access is required for device setup.

Verify Your Network

- □ This Hubspace™ device requires a 2.4GHz Wi-Fi channel.
- Most routers provide a 2.4GHz Wi-Fi channel.
- ☐ Hubspace™ only shows Wi-Fi networks that your device can use.
- □ If you do not see your Wi-Fi netowrk name when you attempt to connect your device, please check your router settings.

3 Add a Device

- In the Hubspace™ app, tap the plus sign in the upper right corner.
- □ Scan your product's QR code. You can find a copy of the QR code on the device itself and in the Quick Start Guide.
 - i. Scan problem?
 - ii. If the QR code cannot be scanned for some reason, you can enter the code manually. Tap **Enter Code** and follow the instructions.
- □ Connect your device to power and follow the instructions on screen.
- ☐ If you are unable to access the QR code for your light, you can put it into discovery mode with the following sequence:

Switch the device OFF and ON 5 times. The light will pulse to show that it can now be discovered. In the Hubspace™ app, tap the plus sign in the upper right corner and follow the instructions to discover devices. More than one device can be added at a time using this method.

4 Set up Your Voice Assistant

- □ In the **HubspaceTM** app, tap the **Hubspace** button.
- □ Select the Integrations tab, choose your voice assistant and follow the instructions.



CAUTION: Do not operate tape light while coiled

able through walls, doors, windows, or any milar part of a building structure. CAUTION: Do not subject flexible lighting to

CAUTION: Do not install near or around

CAUTION: This product is rated for outdoor.

CAUTION: Do not install the flexible lighting within 2.9 m/9.5 ft. of a pool or spa.


Installation

- Determine the desired location and length of the LED light strip needed for
- □ Lightly mark the desired starting location of the tape light. Make sure there is adequate room for the tape light with power adaptor and controller (A) in this space and that the power adaptor can reach an appropriate power receptacle without being pulled tightly.
- Ensure surface is clean, sturdy, and mechanically sound.

Installing the light strip

Layout Considerations

- Clean the location in which the light strip (A) is to be mounted to make sure it is free from dirt, dust, and oil, or anything that will inhibit the adhesive from making solid contact to the mounting surface.
- Peel off the adhesive backing on the light strip (A), and secure the light strip (A) to the desired location by pressing firmly for 30 seconds
- □ Place the mounting clip (C) over the light strip and secure with mounting screws (D)





CAUTION: To avoid damage to the light strip, do not twist the tape light or bend past the bend radius of 60 degrees.





Operation

Operating the remote

- □ Remove the plastic tab from the back of the handheld remote (B).
- Ensure the battery contacts are clean prior to battery installation.
- □ Remove batteries from equipment when not in use for an extended period to time.
- □ Aim the remote directly at the controller cable.
- When light is turned OFF, the controller will remember the last setting.




CAUTION: The remote control included utilizes a 3V CR2025 battery; Do not dispose of batteries in fire as they may explode or leak. Please dispose of used batteries immediately and safely. Only replace with the same battery type. Examine devices and make sure the battery compartment is correctly secured, e.g. that the screw or other mechanical fastener is tightened. Do not use if compartment is not secure.



WARNING: KEEP BATTERIES OUT OF THE REACH OF CHILDREN! BATTERIES ARE NOT A TOY! If swallowed, they can cause severe injury or death within 2 hours. In case of swallowing, call emergency services immediately. Tell others of the risks associated with button batteries to keep kids safe

Buπon	Description
M+ M-	Functions options (jump, fade)
OFF	Turn OFF tape light
(8)	Turn ON tape light (last status)
S+ S-	Speed +/- adjust
СН	More Color Options
9	ON/OFF, RGB LEDs
R G B	Red / Green / Blue
(V) (C) (V)	Yellow / Cyan / Violet
BN+ BN-	Brightness +/- adjust, RGB LEDs
(8)	6500K CCT Full ON
(\{\}	2200K CCT Full ON
œ	6500K & 2200K CCTs Full ON
C†	CCT Tuning, + Cool White
W+	CCT Tuning, + Warm White
2	ON/OFF for White LEDs
BN+ BN-	Brightness +/- adjust, White LEDs





Installation - Continued

Troubleshooting

My Hubspace device is not

My device cannot find any Wi-Fi

My device is in a location that does

not have Wi-Fi. Can I still use it with

The QR code has become damaged.

A device is on another account.

My device is offline for long periods

The device is on an I scanned the

Can I scan the same QR code to

add multiple products?

QR code, but the app cannot

connecting to Wi-Fi.

the Hubspace app?

I cannot find the QR code.

How do I add the device?

How do I transfer it?

networks.

The tape light strip does not turn on.

Solution

the QR code.

No. Each product has a unique QR code

Problem

Ensure the power adaptor is plugged into a live 120V receptacle. Check the connections and make sure the power adaptor wire is securely connected to the copper connections of the tape light. Check to make sure the plastic tab has been removed from the battery compartment on the back of the handheld remote control Check to make sure the polarity of the batteries is correct. Check to make sure the batteries are not dead. Check the line of sight and move the IR eve on the controller accordingly. Make sure that the distance between the handheld remote control and the IR eye on the driver is within 5 m (16.4 ft.) Make sure your device is connected to a power source. Your Internet connection or Wi-Fi network may be down. Check your router and internet connection. Make sure you have a 2.4GHz capable Wi-Fi network within range of the device you are trying to add. - Use the app on a phone with an Internet connection like LTE. - The phone must be within Bluetooth range of your Hubspace device ☐ It is on the plug adaptor. A copy of the QR code is also included in vour device's documentation Under the OR code are numbers. You can enter those numbers manually instead of scanning the code. Scan the OR code and it will transfer to your account. Make sure your Wi-Fi signal strength is sufficient. You may need to move your router, use mesh Wi-Fi, or Wi-Fi extenders Turn off Bluetooth on your phone and turn it back on. Then, scan

2 Installing the controller cable

Plug the 24V DC power adaptor into an appropriate 120V power outlet.

