
IoT Engineering Project Example

CC BY-SA, Thomas Amberg, FHNW (unless noted otherwise)



Use cases

Measure temperature and humidity.

Display (historic) measurements.

Set a temperature or humidity alert threshold.

Get a temperature or humidity alert.

Confirm an alert.

Why? "Cellar is too humid", "Oven is ready", ...

Interface documentation

```
HTTP API to write to ThingSpeak
$ curl -vX POST
https://api.thingspeak.com/update --data
'key=WRITE_API_KEY&field1=23&field2=42'
```

MQTT API to read from ThingSpeak \$ mqtt sub -t 'channels/CHANNEL_ID/subscribe/ json/READ_API_KEY' -h 'mqtt.thingspeak.com' -u 'DEVICE_ID' -P 'MQTT_API_KEY' -p 1883 -q 0

Issues

ESP8266 programming works without adapter only.

Pin collision, D5 used by both, DHT11 and RFM95W.

Connecting to ThingSpeak MQTT API, -u, -P, QoS 0.

Getting the state machine right on actuator device.

For details, see issues on GitHub.