

COMPUTER ORGANIZATION


Lecture 11 Memory Hierarchy (1)

2025 Spring

This PowerPoint is for internal use only at Southern University of Science and Technology. Please do not repost it on other platforms without permission from the instructor.



Recap





Chapter 5 Overview

- Storage Technology
 - Memory hierarchy
 - Principle of locality
- Cache(/'kæʃ/)
 - The basics of caches
 - Measuring cache performance
 - Improving cache performance
- Virtual memory
- Dependability
 - Hamming code



Storage Technology

- Random access memory: Access time same for all locations
 - SRAM: Static Random Access Memory (caches)
 - Low density, high power, expensive, fast
 - Static: content will last (forever until lose power)
 - DRAM: Dynamic Random Access Memory (main memory)
 - High density, low power, cheap, slow
 - Dynamic: need to be refreshed regularly
 - Double data rate (DDR) DRAM (Transfer on rising/falling edges)
- Flash
- Magnetic disk

Ideal memory


- Access time of SRAM
- Capacity and cost/GB of disk

Memory technology	Typical access time	\$ per GiB in 2012
SRAM semiconductor memory	0.5–2.5 ns	\$500-\$1000
DRAM semiconductor memory	50–70 ns	\$10-\$20
Flash semiconductor memory	5,000–50,000 ns	\$0.75-\$1.00
Magnetic disk	5,000,000-20,000,000 ns	\$0.05-\$0.10



Memory Hierarchy

- An Illusion of a large, fast, cheap memory
 - Fact: Large memories slow, fast memories small
 - How to achieve: hierarchy, parallelism
- An expanded view of memory system:



Larger, slower, cheaper, denser



Why Hierarchy Works?

- Principle of Locality:
 - Program access a relatively small portion of the address space at any instant of time
 - Loops
 - Arrays
 - Sequential instructions
 - 90/10 rule: 10% of code executed 90% of time
- Two types of locality:
 - Temporal locality: if an item is referenced, it will tend to be referenced again soon
 - Spatial locality: if an item is referenced, items whose addresses are close by tend to be referenced soon


A widely held rule of thumb is that a program spends 90% of its execution time in only 10% of the code.

—— Hennessy & Patterson. Computer Architecture, A quantitative Approch



Memory Hierarchy: Principle


- At any given time, data is copied between only two adjacent levels:
 - Upper level: the one closer to the processor
 - Smaller, faster, uses more expensive technology
 - Lower level: the one away from the processor
 - Bigger, slower, uses less expensive technology
- Block: basic unit of information transfer
 - Minimum unit of information that can either be present or not present in a level of the hierarchy





Memory Hierarchy: Terminology

- Block (or line): unit of copying
 - May be multiple words
- Hit: data appears in upper level
 - Hit rate(ratio): hits/accesses
 - Hit time: time to access the upper level
- Miss: data needs to be retrieved from a block in the lower level
 - Miss rate(ratio) = misses/accesses = 1 hit rate
 - Miss Penalty: time to fetch a block into a level of the memory hierarchy from the lower level
- Hit Time << Miss Penalty






Processor

Data is transferred

Cache Memory

- Cache memory
 - The level of the memory hierarchy closest to the CPU
- Given accesses X₁, ..., X_{n-1}
 - and how about X_n



X ₄
X ₁
X _{n-2}
X _{n-1}
X ₂
X_n
X ₃

Questions for Hierarchy Design

Q1: Where can a block be placed in the upper level?

=> block placement

Q2: How is a block found if it is in the upper level?

=> block finding

Q3: Which block should be replaced on a miss?

=> block replacement

Q4: What happens on a write?

=> write policy


b. After the reference to X_n a. Before the reference to X_n cache content example baivh@sustech.edu.cn



Direct Mapped Cache

- Example:
- Memory size: 32 bytes, cache size: 8 byte, block size: 1 byte
- The address is in unit of byte
- Which mapping method?


Noted: the cache block size is usually multiple words.
We use 1 byte/block here as an example just for better understanding.





Direct Mapped Cache

- Location determined by address
- One data in memory is mapped to only one location in cache
- Use low order address bits or high order bits?
 - The lower bits defines the address of the cache
- Index: which block to select
 - index = (Block address) modulo (#Blocks in cache)
- e.g.: address 29_{ten} (11101_{two}) in the memory is mapped to index 5_{ten} (101_{two}) in the cache
 - 29_{ten} mod 8 \rightarrow 5_{ten}
 - 11101_{two} (take lower $log_2 8 bits$) \rightarrow 101_{two}





Tags and Valid Bits

- Block Finding: How do we know which particular block is stored in a cache location?
 - Store block address as well as the data
 - Actually, only need the high-order bits
 - Called the tag
- What if there is no data in a location?
 - Valid bit: 1 = present, 0 = not present
 - Initially 0



- 8-blocks, 1 byte/block, direct mapped
- Initial state

Index	V	Tag	Data
000	N		
001	Ν		
010	N		
011	N		
100	N		
101	N		
110	N		
111	N		



Decimal addr	Binary addr	Hit/miss	Cache block
22	10 110	Miss	110

Index	V	Tag	Data
000	N		
001	N		
010	N		
011	N		
100	N		
101	N		
110	Υ	10	Mem[10110]
111	N		



Decimal addr	Binary addr	Hit/miss	Cache block
26	11 010	Miss	010

Index	V	Tag	Data
000	N		
001	N		
010	Y	11	Mem[11010]
011	N		
100	N		
101	N		
110	Υ	10	Mem[10110]
111	N		



Decimal addr	Binary addr	Hit/miss	Cache block
22	10 110	Hit	110
26	11 010	Hit	010

Index	V	Tag	Data
000	N		
001	N		
010	Υ	11	Mem[11010]
011	N		
100	N		
101	N		
110	Υ	10	Mem[10110]
111	N		



Decimal addr	Binary addr	Hit/miss	Cache block
16	10 000	Miss	000
3	00 011	Miss	011
16	10 000	Hit	000

Index	V	Tag	Data
000	Υ	10	Mem[10000]
001	N		
010	Υ	11	Mem[11010]
011	Y	00	Mem[00011]
100	N		
101	N		
110	Υ	10	Mem[10110]
111	N		



Decimal addr	Binary addr	Hit/miss	Cache block
18	10 010	Miss	010
16	10 000	Hit	000

Index	V	Tag	Data
000	Υ	10	Mem[10000]
001	N		
010	Υ	11 10	Mem[11010] Mem[10010]
011	Υ	00	Mem[00011]
100	N		
101	N		
110	Υ	10	Mem[10110]
111	N		




- 8-blocks, 1 byte/block, direct mapped
- Sequence of 9 memory references to an empty 8-block cache

Decimal address of reference	Binary address of reference	Hit or miss in cache	Assigned cache block (where found or placed)
22	10110 _{two}	miss	$(10110_{\text{two}} \text{ mod } 8) = 110_{\text{two}}$
26	11010 _{two}	miss	$(11010_{\text{two}} \text{ mod } 8) = 010_{\text{two}}$
22	10110 _{two}	hit	$(10110_{two} \mod 8) = 110_{two}$
26	11010 _{two}	hit	$(11010_{\text{two}} \text{ mod } 8) = 010_{\text{two}}$
16	10000 _{two}	miss	$(10000_{\text{two}} \text{ mod } 8) = 000_{\text{two}}$
3	00011 _{two}	miss	$(00011_{two} \text{ mod } 8) = 011_{two}$
16	10000 _{two}	hit	$(10000_{\text{two}} \text{ mod } 8) = 000_{\text{two}}$
18	10010 _{two}	miss	$(10010_{\text{two}} \text{ mod } 8) = 010_{\text{two}}$
16	10000 _{two}	hit	$(10000_{\text{two}} \text{ mod } 8) = 000_{\text{two}}$



Address Subdivision


- 1K blocks,
 - 1-word block:
 - Bytes offset within a block: 2 bits
 - Cache index: $log_2(1K) = 10 bits$
 - Cache tag: 32-10-2 = 20 bits
 - Valid bit (When start up, valid is 0)







Example: Larger Block Size

- 64 blocks, 16 bytes/block
 - To what block number does address 1200 map?





- Or calculate using decimal:
 - Block address = \[1200/16 \] = 75
 - Block number(index) = 75 modulo 64 = 11





Larger Block Size

Assume:

- 32-bit address
- Direct mapped cache
- 2ⁿ number of blocks, so n bit for index
- Block size: 2^m words, so m bit for the word within the block

Calculate:

- Size of tag field: 32-(n+m+2)
- Size of cache: 2^{n*}(block size + tag size +valid field size)
- = $2^{n*}(2^{m*}32+(32-n-m-2)+1)$



Example: Bits required for a Cache

- 16 KB of data (cache capacity), 4-word blocks, assume a 32-bit address
 - Each block has 16Byte → Offset within a block: 4 bits
 - or your can consider: each word has 4 byte → byte offset: 2bits
 - each block has 4 word → word offset : 2 bits
 - total offset : 2+2 = 4 bits
 - Total no of blocks = 16KB cache data size/16Byte→ = 1K → Index: 10 bits
 - Tag: 32-10-4 = 18 bits
 - Valid: 1 bit
 - Total cache size: 2^{10} x $(4 \times 32 + 18 + 1) = 2^{10}$ x 147 = 147 Kb = 18.375KB




Block Size Considerations

- Larger blocks should reduce miss rate
 - Due to spatial locality
- But in a fixed-sized cache
 - Larger blocks ⇒ fewer of them
 - More competition ⇒ increased miss rate
 - Larger blocks ⇒ pollution
- Larger miss penalty
 - Can override benefit of reduced miss rate
 - Early restart and critical-word-first can help



Block Size Considerations

Increase block size tends to decrease miss rate





Cache Misses

- Miss categories
 - Compulsory misses (cold-start misses)
 - Capacity misses
 - Conflict misses
- Read Hit and Miss:
 - On cache hit, CPU proceeds normally
 - On cache miss
 - Stall the CPU pipeline
 - Fetch block from next level of hierarchy
 - Instruction cache miss
 - Restart instruction fetch
 - Data cache miss
 - Complete data access



Write Hit: Write-Through

- On data-write hit, could just update the block in cache
 - But then cache and memory would be inconsistent
- Write through: also update memory
- But makes writes take longer
 - e.g., if base CPI = 1, 10% of instructions are stores, write to memory takes 100 cycles
 - Effective CPI = Base CPI + Memory-stall cycles/instruction =1 + 0.1 × 100 = 11
- Solution: write buffer
 - Holds data waiting to be written to memory
 - CPU continues immediately
 - Only stalls on write if write buffer is already full



Write Hit: Write-Back

- Alternative: On data-write hit, just update the block in cache
 - Keep track of whether each block is dirty
- When a dirty block is replaced
 - Write it back to memory
 - Can use a write buffer to allow replacing block to be read first



Write Miss: Write Allocation

- What should happen on a write miss?
- Alternatives for write-through
 - Allocate on miss: fetch the block
 - Write around: don't fetch the block (no write allocate)
 - Since programs often write a whole block before reading it (e.g., initialization)
- For write-back
 - Allocate on miss: fetch the block (write allocate)



Write Policies Summary

- If the block is found in the cache
 - Update that block, Then...
 - Update immediately → write-through policy
 - or, wait until kicking block out → write-back policy
- If the block is not in the cache
 - Allocate a block in the cache → write allocate policy
 - or, Write directly to memory without allocation → no write allocate policy



Intrinsity FastMATH

- Embedded RISC-V processor
 - 12-stage pipeline
 - Instruction and data access on each cycle
- Split cache: separate I-cache and D-cache
 - Each 16KB: 256 blocks × 16 words/block
 - D-cache: write-through or write-back
- SPEC2000 miss rates


• I-cache: 0.4%

• D-cache: 11.4%

Weighted average: 3.2%




Example: Intrinsity FastMATH Processor





DRAM Technology/Organization


- Data stored as a charge in a capacitor
 - Single transistor used to access the charge
 - Must periodically be refreshed
 - Read contents and write back
 - Performed on a DRAM "row"
- Bits in a DRAM are organized as a rectangular array
 - DRAM accesses an entire row
 - Burst mode: supply successive words from a row with reduced latency
- Double data rate (DDR) DRAM
 - Transfer on rising and falling clock edges
- Quad data rate (QDR) DRAM
 - Separate DDR inputs and outputs





DRAM Generations

Year	Capacity	\$/GB
1980	64Kbit	\$1500000
1983	256Kbit	\$500000
1985	1Mbit	\$200000
1989	4Mbit	\$50000
1992	16Mbit	\$15000
1996	64Mbit	\$10000
1998	128Mbit	\$4000
2000	256Mbit	\$1000
2004	512Mbit	\$250
2007	1Gbit	\$50





Flash Storage

- Nonvolatile semiconductor storage
 - $100 \times -1000 \times$ faster than disk
 - Smaller, lower power, more robust
 - But more \$/GB (between disk and DRAM)
- Flash bits wears out after 1000's of accesses
 - Not suitable for direct RAM or disk replacement
 - Wear leveling: remap data to less used blocks








Disk Storage

• Nonvolatile, rotating magnetic storage





Disk Sectors and Access

- Each sector records
 - Sector ID
 - Data (512 bytes, 4096 bytes proposed)
 - Error correcting code (ECC)
 - Used to hide defects and recording errors
 - Synchronization fields and gaps
- Access to a sector involves
 - Queuing delay if other accesses are pending
 - Seek: move the heads
 - Rotational latency
 - Data transfer
 - Controller overhead