

Pipeline Data Hazards

Warning, warning, warning!


Dealing With Data Hazards

- In Software
 - inserting independent instructions
- In Hardware
 - inserting bubbles (stalling the pipeline)
 - data forwarding

Data Hazards are caused by *instruction dependences*. For example, the add is data-dependent on the subtract:

```
subi $5, $4, #45  
add $8, $5, $2
```

Dealing with Data Hazards in Software



How Many No-ops?

sub \$2, \$1,\$3

and \$4, \$2,\$5

or \$8, \$2,\$6

add \$9, \$4,\$2

slt \$1, \$6,\$7

Are No-ops Really Necessary?

sub \$2, \$1,\$3

and \$4, \$2,\$5


or \$8, \$3,\$6

add \$9, \$2,\$8


slt \$1, \$6,\$7

Dealing with Data Hazards in Hardware

Part II-Pipeline Stalls




Pipeline Stalls




Pipeline Stalls

- We must:
 - Detect the hazard
 - Stall the pipeline


Knowing When to Stall



- 6 types of data hazards
 - two reg reads * 3 reg writes



The Pipeline





Stalling the Pipeline

- Once we detect a hazard, then we have to be able to stall the pipeline (insert a bubble).
- Stalling the pipeline is accomplished by
 - (1) preventing the IF and ID stages from making progress
 - the ID stage because it cannot proceed until the dependent instruction completes
 - the IF stage because we do not want to lose any instructions.
 - (2) inserting “nops”


Stalling the Pipeline

- Preventing the IF and ID stages from proceeding
 - don't write the PC (PCWrite = 0)
 - don't rewrite IF/ID register (IF/IDWrite = 0)
- Inserting “nops”
 - set all control signals propagating to EX/MEM/WB to zero

Reducing Data Hazards Through Forwarding



Reducing Data Hazards Through Forwarding



EX Hazard:

```

if (EX/MEM.RegWrite
and (EX/MEM.RegisterRd != 0)
and (EX/MEM.RegisterRd = ID/EX.RegisterRs)) ForwardA = 10

```

```

if (EX/MEM.RegWrite
and (EX/MEM.RegisterRd != 0)
and (EX/MEM.RegisterRd = ID/EX.RegisterRt)) ForwardB = 10


```

(similar for the MEM stage)

Data Forwarding

- The Previous Data Path handles two types of data hazards
 - EX hazard
 - MEM hazard
- We assume the register file handles the third (WB hazard)
 - if the register file is asked to read and write the same register in the same cycle, we assume that the reg file allows the write data to be forwarded to the output

Eliminating Data Hazards via Forwarding



Forwarding in Action


add \$1, \$12, \$12

sub \$12, \$3, \$4

add \$3, \$10, \$11

Memory Access

Write Back



Forwarding in Action


Instruction Fetch

add \$1, \$12, \$12

sub \$12, \$3, \$4

add \$3, \$10, \$11

Write Back




Forwarding in Action

Instruction Fetch


Instruction Decode

add \$1, \$12, \$12


sub \$12, \$3, \$4




Eliminating Data Hazards via Forwarding??



Eliminating Data Hazards via Forwarding and stalling



Eliminating Data Hazards via Forwarding and stalling



Try this one...

Show stalls and forwarding for this code


add \$3, \$2, \$1

lw \$4, 100(\$3)

and \$6, \$4, \$3

sub \$7, \$6, \$2

Datapath with Hazard-Detection




if (ID/EX.MemRead and
 ((ID/EX.RegisterRt = IF/ID.RegisterRs) or
 (ID/EX.RegisterRt = IF/ID.RegisterRt)))
 then stall the pipeline

Hazard Detection

and \$4, \$2, \$5

lw \$2, 20(\$1)




Hazard Detection

and \$4, \$2, \$5

nop (bubble)

lw \$2, 20(\$1)



Data Hazard Key Points

- Pipelining provides high throughput, but does not handle data dependencies easily.
- Data dependences cause *data hazards*.
- Data hazards can be solved by:
 - software (nops)
 - hardware stalling
 - hardware forwarding
- Our processor, and indeed all modern processors, use a combination of forwarding and stalling.