
6ELEN018W - Applied Robotics Lecture 3: Robot Motion - 2D Velocity Kinematics

Dr Dimitris C. Dracopoulos

Previously - Homogeneous Transformations Matrices


2D case:



$$\begin{pmatrix} A_{x} \\ A_{y} \\ 1 \end{pmatrix} = \begin{pmatrix} \cos(\theta) & -\sin(\theta) & t_{x} \\ \sin(\theta) & \cos(\theta) & t_{y} \\ 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} {}^{B}x \\ {}^{B}y \\ 1 \end{pmatrix}$$
(1)

Dimitris C. Dracopoulos 2/22

Pose of the End-Effector - 1-Joint 2D Robot Arm



$$E = \boldsymbol{R}(q_1) \cdot \boldsymbol{T}_{\scriptscriptstyle X}(a_1)$$

$$E = \begin{pmatrix} \cos(q_1) & -\sin(q_1) & 0 \\ \sin(q_1) & \cos(q_1) & 0 \\ 0 & 0 & 1 \end{pmatrix} \begin{pmatrix} 1 & 0 & a_1 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{pmatrix}$$

$$= \begin{pmatrix} \cos(q_1) & -\sin(q_1) & a_1\cos(q_1) \\ \sin(q_1) & \cos(q_1) & a_1\sin(q_1) \\ 0 & 0 & 1 \end{pmatrix}$$

Dimitris C. Dracopoulos


Pose of the End-Effector - 1-Joint 2D Robot Arm (cont'd)

In Python Robotics Toolbox:

```
>>> from sympy import *
>>> q1 = Symbol('q1')
>>> trot2(q1)
>>> a1=Symbol('a1')
>>> trans12(a1,0)
>>> E = trot2(q1) @ trans12(a1, 0)
or equivalently as a ETS2 object:
>>> e = ET2.R()*ET2.tx(a1)
>> e.plot(0) # plot the ETS2 object with q1 = 0 degrees
>> e.plot(math.pi/4) # plot the ETS2 object with q1 = 45 degrees
```

Dimitris C. Dracopoulos 4/22

Pose of the End-Effector - 2-Joint 2D Robot Arm



$$E = \mathbf{R}(q_1) \cdot \mathbf{T}_{\scriptscriptstyle X}(a_1) \cdot \mathbf{R}(q_2) \cdot \mathbf{T}_{\scriptscriptstyle X}(a_2)$$

$$E = \left(egin{array}{ccc} cos(q_1+q_2)) & -sin(q_1+q_2) & a_1cos(q_1)+a_2cos(q_1+q_2) \ sin(q_1+q_2) & cos(q_1+q_2) & a_1sin(q_1)+a_2sin(q_1+q_2) \ 0 & 0 & 1 \end{array}
ight)$$

Dimitris C. Dracopoulos

Pose of the End-Effector - 2-Joint 2D Robot Arm (cont'd)


In Python Robotics Toolbox:

```
>>> from sympy import *
>>> q1 = Symbol('q1')
>>> trot2(q1)
>>> a1=Symbol('a1')
>>> trans12(a1,0)
>>> q2 = Symbol('q2')
>>> a2 = Symbol('a2')
>>> E = trot2(q1) @ transl2(a1, 0) @ trot2(q2) @ transl2(a2, 0)
E = simplify(E)
```


Dimitris C. Dracopoulos 6/22

Pose of the End-Effector - 2-Joint 2D Robot Arm (cont'd)

The configuration for a pose of the end-effector of the 2-joint robot arm is not unique:



Pose of the End-Effector - 3-Joint 2D Robot Arm



$$E = \mathbf{R}(q_1) \cdot \mathbf{T}_{x}(a_1) \cdot \mathbf{R}(q_2) \cdot \mathbf{T}_{x}(a_2) \cdot \mathbf{R}(q_3) \cdot \mathbf{T}(a_3)$$

Dimitris C. Dracopoulos 8/22

Pose of the End-Effector - 3-Joint 2D Robot Arm (cont'd)

In Python Robotics Toolbox:

```
>>> from sympy import *
>>> q1 = Symbol('q1')
>>> trot2(q1)
>>> a1=Symbol('a1')
>>> trans12(a1,0)
>>> q2 = Symbol('q2')
>>> a2 = Symbol('a2')
>>> q3 = Symbol('q3')
>>> a3 = Symbol('a3')
>>> E = trot2(q1)@trans12(a1, 0)@trot2(q2)@trans12(a2, 0) \setminus
                   @ trot2(q3) @ trans12(a3, 0)
E = simplify(E)
```

Dimitris C. Dracopoulos 9/2

Pose of the End-Effector - 3-Joint 2D Robot Arm (cont'd)

▶ Unlike the 1 and 2-joint robot arms, the 3-joint robot arm has 3 degrees of freedom and therefore it can achieve different orientations.

The *x* coordinate of the end-effector is given by:

The y coordinate of the end-effector is given by:

The orientation of the end-effector is given by: $q_1 + q_2 + q_3$

Dimitris C. Dracopoulos 10/22

The Problem of Forward Kinematics

The calculation of the position and orientation of a robot's end-effector from its joint coordinates θ_i .

- In the previous slides it has been shown how to do this in 2D spaces for:
 - ▶ 1-joint robot arms
 - 2-joint robot arms
 - 3-joint robot arms

using simple transformations in Mathematics which correspond to real operations in Physics!

imitris C. Dracopoulos 11/22

Velocity of the End-Effector

The Problem:

► If the joints move at specific velocities, what is the velocity of the end-effector?

Extremely important to control the operation of the end-effector (hand) of robots!

<u>Calculation needed</u>: Given the \dot{q} (time rate of change of joints angles) calculate the time rate of change of the pose of the end-effector $\dot{\xi}_E$.

- $ightharpoonup \dot{q}$ is the derivative of q
- $\dot{\xi}_E$ is the derivative of the pose (position and orientation) ξ_E of the end-effector

imitris C. Dracopoulos 12/22

What is a Derivative?

The derivative of a function measures the sensitivity of changes to the output (value) of the function, based on changes of the input (independent variable) of the function.

▶ The slope of the tangent line is equal to the derivative.



— It is also used to show the direction we need to follow and the magnitude of the step we need to take, in order to reduce an error (machine learning, etc).

Dimitris C. Dracopoulos 13/2

Simple Numerical Calculation of Derivatives

In a numerical simulation, if we take small enough time steps, the derivative can be calculated as:

$$\frac{f(x_{t+1}) - f(x_t)}{\Delta t} \tag{2}$$

where

- ▶ $f(x_{t+1})$ is the value of function f at time t+1
- $ightharpoonup f(x_t)$ is the value of function f at time t
- $ightharpoonup \Delta t$ is the time step, i.e. the difference (time elapsed) between the two successive time steps.


When a function f involves more than one independent variables, e.g. $f(x_1, x_2)$ the derivative with respect to one of these variables is called *partial derivative* and it is denoted as $\frac{\partial f}{\partial x_1}$, $\frac{\partial f}{\partial x_2}$, etc.:

mitris C. Dracopoulos 14/22

Velocity of End-Effector in a 2-Joint Robot Arm (2D)

Relationship of the velocities of individual joints q_1 and q_2 and the velocity of the end-effector.

▶ It can be shown that instantaneously the velocity of the end-effector is the sum of the end effector velocity components due to motion of joint 1 and the motion due to joint 2.



nitris C. Dracopoulos 15/22

Velocity of End-Effector in a 2-Joint Robot Arm (2D) - cont'd

The position of the end-effector is given (see previous slides) by:

$$\begin{pmatrix} x \\ y \end{pmatrix} = \begin{pmatrix} a_1 \cos(q_1) + a_2 \cos(q_1 + q_2) \\ a_1 \sin(q_1) + a_2 \sin(q_1 + q_2) \end{pmatrix}$$
(3)

If joint angles change over time (the robot moves):

$$q_1 = q_1(t), \quad q_2 = q_2(t)$$

► The velocity of the end-effector can be calculated by computing the derivative (using the chain rule):

$$\dot{x} = -a_1 \dot{q}_1 \sin(q1) - a_2 (\dot{q}_1 + \dot{q}_2) \sin(q1 + q2)$$
 (4)

$$\dot{y} = a_1 \dot{q}_1 \cos(q_1) + a_2 (\dot{q}_1 + \dot{q}_2) \cos(q_1 + q_2) \tag{5}$$

where
$$\dot{q_1}=rac{\partial q_1}{\partial t}$$
, $\dot{q_2}=rac{\partial q_2}{\partial t}$

limitris C. Dracopoulos 16/2

Velocity of End-Effector in a 2-Joint Robot Arm (2D) - cont'd

Equations (4), (5):

$$\dot{x} = -a_1 \dot{q}_1 \sin(q1) - a_2 (\dot{q}_1 + \dot{q}_2) \sin(q1 + q2) \tag{6}$$

$$\dot{y} = a_1 \dot{q}_1 \cos(q_1) + a_2 (\dot{q}_1 + \dot{q}_2) \cos(q_1 + q_2)$$
 (7)

can be written in matrix form:


$$\left(\begin{array}{c} \dot{x} \\ \dot{y} \end{array} \right) = \left(\begin{array}{cc} -a_1 sin(q1) - a_2 sin(q1+q2) & -a_2 sin(q1+q2) \\ a_1 cos(q_1) + a_2 cos(q1+q2) & a_2 cos(q1+q2) \end{array} \right) \left(\begin{array}{c} \dot{q}_1 \\ \dot{q}_2 \end{array} \right)$$

or

$$\mathbf{v} = \mathbf{J}(\mathbf{q})\dot{\mathbf{q}} \tag{8}$$

Dimitris C. Dracopoulos 17/22

Velocity of End-Effector in a 2-Joint Robot Arm (2D) - cont'd



J(q) is the Jacobian matrix of the joint angles q_1 and q_2 :

$$J(q) = \begin{pmatrix} -a_1 sin(q1) - a_2 sin(q1+q2) & -a_2 sin(q1+q2) \\ a_1 cos(q_1) + a_2 cos(q1+q2) & a_2 cos(q1+q2) \end{pmatrix}$$

mitris C. Dracopoulos 18

More on Jacobian

For a scalar value x and a scalar function f:

$$y = f(x)$$

the derivative of f is:

$$\frac{df}{dx} = \frac{dy}{dx}$$

The Jacobian is the equivalent for the derivative of a matrix:

▶ the derivative of a function which has a vector as an argument and returns a vector as its result:

$$\mathbf{J} = \frac{\partial \mathbf{F}}{\partial \mathbf{x}} = \begin{pmatrix} \frac{\partial y_1}{\partial x_1} & \cdots & \frac{\partial y_1}{\partial x_n} \\ \vdots & \cdots & \vdots \\ \frac{\partial y_m}{\partial x_1} & \cdots & \frac{\partial y_m}{\partial x_n} \end{pmatrix}$$

imitris C. Dracopoulos 19/22

The Chain Rule for Calculating Derivatives

The *chain rule* is used to differentiate a function which has an argument another function (i.e. a composite function).

Assuming a function: y = f(g(x))

The chain rule states that the derivative of y with respect to x, i.e. $\frac{dy}{dx}$ can be calculated as follows:

1. Substitute u = g(x). Then:

$$y = f(u)$$

2. Chain rule:

$$\frac{dy}{dx} = \frac{dy}{du} \cdot \frac{du}{dx} \tag{9}$$

Example:

Differentiate $y = sinx^2$:

- 1. $u = x^2$ then:
- 2. y = sin(u)

3.

$$\frac{dy}{dx} = \frac{dy}{du} \cdot \frac{du}{dx} = \cos(u) \cdot 2x = \cos(x^2) \cdot 2x \tag{10}$$

Calculating the Joint Velocities for a Desired End-Effector Velocity

In real world, we need to specify a velocity for the end-effector.

► How do I achieve this, what velocities do I need to apply to the joints of the robot using my actuators (control motors in the joints)?

From Equation (8):

$$\mathbf{v} = \mathbf{J}(\mathbf{q})\dot{\mathbf{q}} \tag{11}$$

Multiplying both sides of the equation from the left by the inverse of the Jacobian matrix:

$$\dot{\mathbf{q}} = \mathbf{J}(\mathbf{q})^{-1} \cdot \mathbf{v} \tag{12}$$

Dimitris C. Dracopoulos 21/22

Calculating the Derivatives using SymPy

```
>>> x, y = symbols('x y')
>>> f = x**2
>>> f.subs(x, 3) # substitute (evaluate f at x for x = 3
Converting a string a SymPy expression:
>>> s = 'x**3 + 2*x + 5'
>>> e = sympify(s)
>>> print(e)
>>> e.subs(x, 4) # evaluate for x=4
Differentiation:
>>> diff(f, x)
>>> diff(e, x)
>>> diff(e, y)
>>> diff('y**2', y)
```