Asterix category 002 - Transmission of Monoradar Service Messages

edition: 1.0

date: 1997-11-01

Preamble

Surveillance data exchange.

Description of standard data items

I002/000 - Message Type

Definition: This Data Item allows for a more convenient handling of the messages at the receiver side by further defining the type of transaction.

Structure:

- 8 bits [.....]
- values:
 - 1: North marker message
 - 2: Sector crossing message
 - 3: South marker message
 - 8: Activation of blind zone filtering
 - 9: Stop of blind zone filtering

Notes: 1. In application where transactions of various types are exchanged, the Message Type Data Item facilitates the proper message handling at the receiver side.

2. Message Type values 1-127 are reserved for common standard use, whereas the values 128-255 are application dependent.

I002/010 - Data Source Identifier

Definition: Identification of the system sending the data.

Structure:

I002/010/SAC - System Area Code

- 8 bits [.....]
- raw value

I002/010/SIC - System Identification Code

- 8 bits [.....]
- raw value

Notes:

- 1. The defined SACs are listed in Part 1, Table 2 [Ref. 2]
- 2. The defined SICs are listed in Part 1, Annex B [Ref. 2]

1002/020 - Sector Number

Definition: Eight most significant bits of the antenna azimuth defining a particular azimuth sector.

Structure:

• 8 bits [......] • unsigned quantity • scaling factor: 360 • fractional bits: 8 • unit: "°" • LSB = $360/2^8$ ° = 360/256 ° ≈ 1.40625 °

The use of the antenna azimuth as sector number has the advantage of being independent of the number of sectors implemented.

1002/030 - Time of Day

Definition: Absolute time stamping expressed as UTC time.

Structure:

• 24 bits [.....] • unsigned quantity • scaling factor: 1 • fractional bits: 7 • unit: "s" • LSB = $1/2^7$ s = 1/128 s $\approx 7.8125e - 3$ s

Notes:

- 1. The time of day value is reset to zero each day at midnight.
- 2. For time management in radar transmission applications, refer to Part 1, paragraph 5.4 [Ref.2].
- 3. Data Item I002/030 can have various logical meanings. In a particular message, the logical meaning is implicit from its context (e.g. in a North marker message it represents the antenna North crossing time; in a sector message it represents the antenna sector crossing time).

I002/041 - Antenna Rotation Speed

Definition: Antenna rotation period as measured between two consecutive North crossings or as averaged during a period of time.

Structure:

- 16 bits [.....]
- unsigned quantity
- scaling factor: 1
- fractional bits: 7
- unit: "s"
- LSB = $1/2^7$ s = 1/128 s $\approx 7.8125e 3$ s

I002/050 - Station Configuration Status

Definition: Information concerning the use and status of some vital hardware components of the radar system.

Structure:

Repetitive item with FX extension

- 7 bits [.....]
- raw value

Due to the diversity in hardware design and requirement of present and future radar stations, it is felt impractical to attempt to define the individual bits.

I002/060 - Station Processing Mode

Definition: Details concerning the present status with respect to processing parameters and options.

Structure:

Repetitive item with FX extension

- 7 bits [.....]
- · raw value

NOTES:

- 1. Typical information conveyed within this Data Item includes inter alia type of polarisation in use, Moving Target Indicator (MTI) in use and/or definition of the range to which MTI is applied, presence of overload conditions and the type of load reduction measures in use.
- 2. Only the structure of this Data Item is defined, no attempt is made to standardise its contents, in order not to hamper any application or future development.

I002/070 - Plot Count Values

Definition: Plot count values according to various plot categories, either for the last full antenna scan or for the last sector processed.

Structure:

Repetitive item, repetition factor 8 bits.

I002/070/A - Aerial Identification

- 1 bit [.]
- · values:
 - 0: Counter for antenna 1
 - 1: Counter for antenna 2

I002/070/IDENT

- 5 bits [.....]
- · values:
 - 1: Sole primary plots
 - 2: Sole SSR plots
 - 3: Combined plots

I002/070/COUNTER

- 10 bits [.....]
- · unsigned integer

I002/080 - Warning/Error Conditions

Definition: Warning/error conditions affecting the functioning of the radar system itself.

Structure:

Repetitive item with FX extension

- 7 bits [.....]
- · raw value

NOTE: Warning/error condition values 1-63 are reserved for common Standard use, whereas the values 64-127 are application dependent.

I002/090 - Collimation Error

Definition: Averaged difference in range and in azimuth for the primary target position with respect to the SSR target position as calculated by the radar station.

Structure:

I002/090/RE - Range Error

- 8 bits [.....]
- signed quantity
- scaling factor: 1
- fractional bits: 7
- unit: "NM"
- LSB = $1/2^7$ NM = 1/128 NM $\approx 7.8125e 3$ NM

I002/090/AE - Azimuth Error

- 8 bits [.....]
- signed quantity
- scaling factor: 360
- fractional bits: 14
- unit: "°"
- LSB = $360/2^{14}$ ° = 360/16384 ° $\approx 2.197265625e 2$ °

NOTES

- 1. LSB of RE is calculated as 2^{16-f} .
- 2. A default quantisation unit of 0.022° and a range between -2.8125° and +2.7905° is obtained for a value of f=2.

I002/100 - Dynamic Window Type 1

Definition: Signals the activation of a certain selective filtering function and in a polar coordinates system the respective geographical areas.

Structure:

I002/100/RS - Rho Start

- 16 bits [.....]
- unsigned quantity
- scaling factor: 1
- fractional bits: 7
- unit: "NM" LSB = $1/2^7$ NM = 1/128 NM $\approx 7.8125e 3$ NM
- value < 512 NM

I002/100/RE - Rho End

- 16 bits [.....]
- unsigned quantity
- scaling factor: 1
- fractional bits: 7
- unit: "NM"
- LSB = $1/2^7$ NM = 1/128 NM $\approx 7.8125e 3$ NM
- value < 512 NM

1002/100/TS - Theta Start

- 16 bits [.....]
- · unsigned quantity
- scaling factor: 360
- fractional bits: 16
- unit: "°"
- LSB = $360/2^{16}$ ° = 360/65536 ° $\approx 5.4931640625e 3$ °

I002/100/TE - Theta End

- 16 bits [.....]
- unsigned quantity
- scaling factor: 360
- fractional bits: 16
- unit: "°"
- LSB = $360/2^{16}$ ° = 360/65536 ° $\approx 5.4931640625e 3$ °

The logical meaning of the polar window is defined by its context, given by the Message Type (Data Item I002/000) in the record concerned.

1002/SP - Special Purpose Field

Definition: Special Purpose Field

Structure:

Explicit item (SP)

1002/RFS - Random Field Sequencing

Definition: Random Field Sequencing

Structure:

Rfs

User Application Profile for Category 002

- (1) I002/010 Data Source Identifier
- (2) I002/000 Message Type
- (3) I002/020 Sector Number
- (4) I002/030 Time of Day
- (5) I002/041 Antenna Rotation Speed
- (6) I002/050 Station Configuration Status
- (7) I002/060 Station Processing Mode

- (FX) Field extension indicator
- (8) I002/070 Plot Count Values
- (9) I002/100 Dynamic Window Type 1
- \bullet (10) I002/090 Collimation Error
- ullet (11) I002/080 Warning/Error Conditions
- •(12) (spare)
- (13) I002/SP Special Purpose Field
- (14) I002/RFS Random Field Sequencing
- (FX) Field extension indicator