# ECE 375 Lab 5

Data Manipulation & the LCD

Lab Time: Wednesday 10a-12n

Robert Detjens

David Headrick

#### Introduction

In this lab, we implemented three large number functions for the ATMega128: ADD16, SUB16, and MUL26. the AVR instruction set can only work with 8 bits at a time, so working with multi-byte values needs to be done in 1-byte chunks. This means the functions written in this lab have to coordinate multiple 8 bit instructions to operate on 16 or 24 bits at a time.

## **Program Overview**

Within the ADD16 function, data is loaded in from program memory. Next, the lower 8 bits are added using ADD. Then, the high byte is added with ADC, which will also bring in the carry bit from the first add. Finally, the high and low results of these two operations is stored into the result in data memory.

The SUB16 function works very much the same as the ADD16 function, except using SUB and SBC for subtracting the 8 bit high and low values.

The MUL24 function uses the shift-and-add challenge algorithm to perform a multiplication on two 24 bit numbers. The result of this function was stored in a 42 bit space in data memory.

## **Additional Questions**

• Although this lab dealt with unsigned numbers, the ATmega128 microcontroller has features for performing signed arithmetic. What does the V flag in the status register indicate? Give an example (in binary) of two 8-bit values that will cause the V flag to be set when they are added together.

The V flag in the status register is an indication that there was a two's complement overflow. For example, if two positive, signed numbers were added together and the result were negative, then the V flag in the status register would become set due to the two's complement overflow during addition.

This 8 bit signed binary addition example would set the V flag:

- 0b 01100000
- + 0b 01000000
- = 0b 10100000
- In the skeleton file for this lab, the .BYTE directive was used to allocate some data memory locations for MUL16's input operands and result. What are some benefits of using this directive to organize your data memory, rather than just declaring some address constants using the .EQU directive?

One advantage to using the .BYTE directive vs. many .EQU directives is that human error can interfere with correct address reservation. If you accidentally declare the wrong address, it could write over the data of the previous operand. With the .ORG

and .BYTE directives, the assembler automatically declares the correct addresses for you, given the number of bytes you need. This reduces the risk of error.

## **Difficulties**

One difficulty in this lab was organizing the memory for MUL24. Many different locations in memory were involved, so we had to sit down and write out a plan for where it all was going to end up.

We also were not clearing the addition overflow byte when there was no overflow, so any calculations after one that overflowed into the third byte would have that bit set regardless if the current calculation overflowed or not.

#### Conclusion

In conclusion, we have learned the basics of large number operations on the ATMega128 by writing multiple large number functions in assembly. In addition, we also learned how to better manage our memory to efficiently store and compute large numbers.

#### Source Code

```
;*********************
  Robert Detjens and David Headrick Lab5 sourcecode.asm
;*
;*
;* This is the skeleton file for Lab 5 of ECE 375
; *********************
  Author: Robert Detjens
  David Headrick
;*
   Date: 10/27/21
.include "m128def.inc"
              ; Include definition file
;* Internal Register Definitions and Constants
.def mpr = r16 ; Multipurpose register
```

```
.def rlo = r0 ; Low byte of MUL result
.def rhi = r1 ; High byte of MUL result
.def zero = r2 ; Zero register, set to zero in INIT, useful for calculations
.def A = r3; A variable
.def B = r4
          ; Another variable
.def oloop = r17 ; Outer Loop Counter
.def iloop = r18 ; Inner Loop Counter
;* Start of Code Segment
;*********************
; Interrupt Vectors
;-----
.org $0000
 rjmp INIT ; Reset interrupt
.org $0046
:-----
; Program Initialization
;-----
INIT:
  ; Initialize the Stack Pointer
  ldi
         mpr,low(RAMEND)
  out
         SPL, mpr
         mpr, high (RAMEND)
  ldi
  out
          SPH, mpr
 clr zero ; Set the zero register to zero, maintain
         ; these semantics, meaning, don't
         ; load anything else into it.
:-----
; Main Program
;-----
MAIN: ; The Main program
 ; Setup the ADD16 function direct test
 ; Move values 0xFCBA and 0xFFFF in program memory to data memory memory
```

; locations where ADD16 will get its inputs from (see "Data Memory Allocation"

```
; section below)
; source addr in prog memory
      ZL,
            low(ADD16_D1 << 1)
ldi
ldi
      ZH,
            high(ADD16_D1 << 1)
; store in data memory
            low(ADD16 OP1)
ldi
      YL,
            high(ADD16_OP1)
ldi
      YH,
; store two bytes
lpm
        mpr,
              Z+
        Y+,
st
              mpr
lpm
        mpr,
              Ζ+
st
        Y+,
              mpr
; store the second operand (directly contiguous)
lpm
        mpr,
              Z+
st
        Υ+,
              mpr
        mpr, Z+
lpm
st
        Υ+,
              mpr
                 ; Check load ADD16 operands (Set Break point here #1)
nop
rcall
        ADD16
                 ; (calculate FCBA + FFFF)
                 ; Check ADD16 result (Set Break point here #2)
nop
; Setup the SUB16 function direct test
; source addr in prog memory
ldi
            low(SUB16 D1 << 1)
            high(SUB16_D1 << 1)
ldi
      ZH,
; store in data memory
            low(SUB16 OP1)
ldi
      YL,
            high(SUB16 OP1)
ldi
      YH,
; store two bytes
              Z+
lpm
        mpr,
st
        Υ+,
              mpr
              Ζ+
lpm
        mpr,
st
        Υ+,
              mpr
; store two more bytes for the second operand (directly contiguous)
lpm
        mpr,
              Ζ+
        Υ+,
st
              mpr
lpm
        mpr,
              Ζ+
st
        Υ+,
              mpr
                 ; Check load SUB16 operands (Set Break point here #3)
nop
                 : (calculate FCB9 - E420)
rcall
        SUB16
                 ; Check SUB16 result (Set Break point here #4)
nop
; Setup the MUL24 function direct test
```

```
; source addr in prog memory
 ldi
       ZL,
            low(MUL24_D1 << 1)
 ldi
       ZH,
            high(MUL24_D1 << 1)
 ; store in data memory
            low(MUL24 OP1)
 ldi
       YL,
            high(MUL24_OP1)
 ldi
       YH,
  ; store three bytes
 lpm
         mpr,
              Ζ+
        Υ+,
 st
              mpr
 lpm
         mpr, Z+
 st
        Υ+,
              mpr
              Z+
 lpm
         mpr,
 st
         Υ+,
              mpr
  ; discard padding byte
         mpr,
 lpm
              Ζ+
 ; load addr of dest (contiguous in program memory)
 ldi
            low(MUL24 OP2)
 ldi
            high(MUL24_OP2)
       YH,
 ; store second operand
        mpr,
              Z+
 lpm
 st
         Υ+,
              mpr
         mpr, Z+
 lpm
 st
         Υ+,
              mpr
        mpr, Z+
 lpm
 st
        Υ+,
              mpr
                ; Check load MUL24 operands (Set Break point here #5)
 nop
               ; (calculate FFFFFF * FFFFFF)
         MUL24
 rcall
 nop
                ; Check MUL24 result (Set Break point here #6)
                ; Check load COMPOUND operands (Set Break point here)
 nop
         COMPOUND; (calculate )
 rcall
                ; Check COMPOUND result (Set Break point here)
 nop
                ; Create an infinite while loop to signify the
DONE: rjmp DONE
       ; end of the program.
;* Functions and Subroutines
; Func: ADD16
; Desc: Adds two 16-bit numbers and generates a 24-bit number
```

```
; where the high byte of the result contains the carry
; out bit.
ADD16:
 push A ; Save A register
 push B ; Save B register
 push mpr
 push XH ; Save X-ptr
 push XL
 push YH
         ; Save Y-ptr
 push YL
 push ZH
         ; Save Z-ptr
 push ZL
 ; Load beginning address of first operand into X
 ldi XL, low(ADD16 OP1)
 ldi XH, high(ADD16_OP1)
 ; Load beginning address of second operand into Y
 ldi YL, low(ADD16_OP2)
 ldi YH, high(ADD16_OP2)
 ; Load beginning address of result into Z
 ldi ZL, low(ADD16 Result)
 ldi ZH, high(ADD16_Result)
 ; add low bytes
 ld
       Α,
            Χ+
 ld
       Β,
            Y+
 add
       Α,
            В
       Z+,
 st
            Α
  ; add high bytes with carry
 ld
            χ+
       Α,
 ld
       Β,
             Υ+
             В
 adc
       Α,
 st
       Z+,
             Α
 ; store extra bit if carry
 brcc ADD nocarry
 ldi
       mpr, 1
           mpr ; if carry, set overflow in next byte
 st
       ADD end
 jmp
 ADD_nocarry:
 ldi
       mpr, 0
```

```
mpr ; if not carry, clear overflow in next byte
 st
      Ζ,
 ADD_end:
 pop ZL
 pop
     ZH
 pop
     YL
     YΗ
 pop
     XL
 pop
 pop
     XΗ
 pop
     mpr
     В
 pop
 pop
     Α
 ret
· _____
; Func: SUB16
; Desc: Subtracts two 16-bit numbers and generates a 16-bit
; result.
;-----
SUB16:
 push A ; Save A register
 push B ; Save B register
 push mpr
 push XH ; Save X-ptr
 push XL
 push YH ; Save Y-ptr
 push YL
 push ZH
        ; Save Z-ptr
 push ZL
 ; Load beginning address of first operand into X
 ldi XL, low(SUB16_OP1)
 ldi XH, high(SUB16_OP1)
 ; Load beginning address of second operand into \boldsymbol{Y}
 ldi YL, low(SUB16_OP2)
 ldi YH, high(SUB16 OP2)
 ; Load beginning address of result into Z
 ldi ZL, low(SUB16_Result)
 ldi ZH, high(SUB16_Result)
 ; Execute the function
```

```
; subract low bytes
 ld
       Α,
            χ+
 ld
       В,
            Y+
 sub
            В
       Α,
       Z+,
 st
            Α
 ; subtract high bytes with carry borrow
            Χ+
 ld
       Β,
            Υ+
 sbc
      Α,
           В
 st Z+, A
 pop ZL
 pop
      ZΗ
      ΥL
 pop
      YΗ
 pop
 pop
      XL
      XH
 pop
 pop
      mpr
 pop
      В
 pop
 ret
; Func: MUL24
; Desc: Multiplies two 24-bit numbers and generates a 48-bit
; result.
;-----
MUL24:
 ; Execute the function here
 ; make sure result is zero'd before doing computation
 ldi ZL, low(MUL24 Result)
 ldi ZH, high(MUL24_Result)
 ldi
       OLoop, 6
 MUL24_init_result:
   clr
          mpr
          Z+,
   st
                mpr
   dec
          OLoop
        MUL24_init_result
   brne
  ; make sure op1 shiftspace is also zero'd
 ldi XL, low(MUL24_OP1) + 3
```

```
ldi XH, high(MUL24 OP1)
 ldi
       OLoop,
             3
 MUL24_init_shift:
   clr
          mpr
   st
          X+,
                mpr
   dec
          OLoop
          MUL24_init_shift
   brne
 ; Load beginning address of first operand into X
 ldi XL, low(MUL24 OP1)
 ldi XH, high(MUL24_OP1)
 ; Load beginning address of second operand into Y
 ldi YL, low(MUL24_OP2)
 ldi YH, high(MUL24_OP2)
 ; Load beginning address of result into Z
 ldi ZL, low(MUL24 Result)
 ldi ZH, high(MUL24_Result)
 ldi OLoop,
              24
 MUL24_loop:
   ; shift current LSB out of op2
          LSR24
   rcall
   ; add op1 to total if that shifted bit is 1
          MUL24 noadd
   brcc
     rcall ADD48
   MUL24_noadd:
   ; shift op1 left
   rcall LSL48
   ; do this 24 times, one for each bit on op2
   dec
          OLoop
          MUL24_loop
   brne
 ret
· ______
; Func: LSR24
; Desc: Shifts one 24-bit value in memory right one bit.
```

```
LSR24:
 ; Execute the function here
 push OLoop
 push mpr
        ; Save X-ptr
 push XH
 push XL
 ; Load address of highest bute of operand into X
 ldi XL, low(MUL24_OP2) + 3
 ldi XH, high(MUL24_OP2)
 clc
 ldi
      OLoop, 3
 LSR24 loop:
   ; shift three bytes (using rotate to propagate carry)
        mpr, -X
   ror
        mpr
        X, mpr
   st
   dec OLoop
   brne LSR24_loop
 pop XL
 pop XH
 pop mpr
 pop OLoop
 ret
           -----
; Func: LSL48
; Desc: Shifts one 24-bit value in memory right one bit.
;-----
LSL48:
 ; Execute the function here
 push OLoop
 push mpr
 push XH ; Save X-ptr
 push XL
 ; Load beginning address operand into X
```

```
ldi XL, low(MUL24 OP1)
 ldi XH, high(MUL24_OP1)
 clc
 ldi
     OLoop, 6
 LSL48_loop:
   ; shift three bytes (using rotate to propagate carry)
        mpr,
            Χ
   rol
        mpr
        X+,
   st
             mpr
   dec OLoop
   brne LSL48_loop
 pop XL
 pop XH
 pop mpr
 pop OLoop
 ret
:------
; Func: ADD48
; Desc: Multiplies two 24-bit numbers in X and Y and stores
; the result in Z.
;-----
ADD48:
 ; Execute the function here
 push OLoop
 push A
 push B
 push mpr
 push XH ; Save X-ptr
 push XL
 push YH ; Save Y-ptr
 push YL
 ; Load beginning address of first operand into X
 ldi XL, low(MUL24 OP1)
 ldi XH, high(MUL24_OP1)
 ; Load beginning address of second operand / dest into Y
 ldi YL, low(MUL24 Result)
 ldi YH, high(MUL24_Result)
```

```
clc
 ldi
      OLoop, 6
 ADD48_loop:
   ; add all 6 bytes
   ld
        Α,
             χ+
   ld
        Β,
             Y
   adc
        Α,
             В
   st
        Υ+,
             Α
        OLoop
   dec
   brne ADD48_loop
 ; store extra bit if carry
 brcc ADD48_nocarry
   ldi
        mpr, 1
   st
        Υ,
             mpr ; if carry, set overflow in next byte
 ADD48_nocarry:
 pop YL
 pop YH
 pop XL
 pop XH
 pop mpr
 pop B
 pop A
 pop OLoop
 ret
:-----
; Func: COMPOUND
; Desc: Computes the compound expression ((D - E) + F)^2
 by making use of SUB16, ADD16, and MUL24.
; D, E, and F are declared in program memory, and must
 be moved into data memory for use as input operands.
 All result bytes should be cleared before beginning.
;-----
COMPOUND:
 ; Setup SUB16 with operands {\tt D} and {\tt E}
 ; Perform subtraction to calculate D - E
```

```
; source addr in prog memory
            low(OperandD << 1)</pre>
ldi
ldi
      ZH,
            high(OperandD << 1)
; store in data memory
            low(SUB16 OP1)
ldi
      YL,
      YH,
            high(SUB16 OP1)
ldi
; store two bytes
        mpr,
lpm
        Υ+,
st
              mpr
               Z+
lpm
        mpr,
st
        Υ+,
               mpr
; store two more bytes for the second operand (directly contiguous)
               Z+
lpm
        mpr,
        Υ+,
st
               mpr
               Ζ+
lpm
        mpr,
        Υ+,
st
              mpr
; do D - E
rcall
        SUB16
; Setup the ADD16 function with SUB16 result and operand F
; Perform addition next to calculate (D - E) + F
; load SUB16_Result into ADD16_OP1
; source addr in data memory
            low(SUB16 Result)
ldi
      ZL,
            high(SUB16_Result)
ldi
      ZH,
; store in data memory
            low(ADD16 OP1)
ldi
      YL,
ldi
      YH,
            high(ADD16 OP1)
; store two bytes
ld
        mpr,
               Ζ+
        Υ+,
st
               mpr
               Z+
ld
        mpr,
        Υ+,
st
               mpr
; load OperandF into ADD16_OP2
; source addr in prog memory
      ZL,
            low(OperandF << 1)</pre>
ldi
            high(OperandF << 1)
ldi
      ZH,
; store two more bytes for the second operand (directly contiguous)
        mpr,
               Z+
lpm
        Υ+,
st
               mpr
        mpr,
               Z+
lpm
```

```
Υ+,
st
              mpr
; do (ans) + F
rcall
        ADD16
; Setup the MUL24 function with ADD16 result as both operands
; Perform multiplication to calculate ((D - E) + F)^2
; copy ADD16_Result into MUL24_OP1
ldi
      ZL,
            low(ADD16_Result)
ldi
      ZH,
            high(ADD16_Result)
; store in data memory
ldi
      YL,
            low(MUL24_OP1)
ldi
      YH,
            high(MUL24 OP1)
; store three bytes
ld
        mpr,
              Ζ+
        Υ+,
st
              mpr
ld
             Ζ+
        mpr,
        Υ+,
st
              mpr
ld
        mpr,
              Z+
        Υ+,
st
              mpr
; copy ADD16_Result into MUL24_OP2
      ZL,
            low(ADD16_Result)
ldi
ldi
      ZH,
            high(ADD16_Result)
; store in data memory
      YL,
            low(MUL24 OP2)
ldi
ldi
      YH,
            high(MUL24_OP2)
; store three bytes
ld
        mpr,
              Ζ+
st
        Υ+,
              mpr
ld
              Ζ+
        mpr,
        Υ+,
st
              mpr
              Z+
ld
        mpr,
        Υ+,
st
              mpr
; do (ans) * (ans)
rcall
       MUL24
ret
```

```
; Func: MUL16
; Desc: An example function that multiplies two 16-bit numbers
   A - Operand A is gathered from address $0101:$0100
   B - Operand B is gathered from address $0103:$0102
   Res - Result is stored in address
     $0107:$0106:$0105:$0104
  You will need to make sure that Res is cleared before
  calling this function.
MUL16:
 push A ; Save A register
 push B ; Save B register
 push rhi ; Save rhi register
 push rlo ; Save rlo register
 push zero ; Save zero register
 push XH ; Save X-ptr
 push XL
 push YH ; Save Y-ptr
 push YL
          ; Save Z-ptr
 push ZH
 push ZL
 push oloop ; Save counters
 push iloop
 clr zero ; Maintain zero semantics
 ; Set Y to beginning address of B
 ldi YL, low(addrB); Load low byte
 ldi YH, high(addrB); Load high byte
 ; Set Z to begginning address of resulting Product
 ldi ZL, low(LAddrP); Load low byte
 ldi ZH, high(LAddrP); Load high byte
  ; Begin outer for loop
 ldi oloop, 2 ; Load counter
 MUL16 OLOOP:
    ; Set X to beginning address of A
   ldi XL, low(addrA); Load low byte
   ldi XH, high(addrA); Load high byte
    ; Begin inner for loop
   ldi iloop, 2 ; Load counter
   MUL16 ILOOP:
     ld A, X+ ; Get byte of A operand
```

```
ld B, Y ; Get byte of B operand
     mul A,B; Multiply A and B
    ld A, Z+ ; Get a result byte from memory
     ld B, Z+ ; Get the next result byte from memory
     add rlo, A ; rlo <= rlo + A
     adc rhi, B ; rhi <= rhi + B + carry
     ld A, Z ; Get a third byte from the result
     adc A, zero ; Add carry to A
     st Z, A ; Store third byte to memory
     st -Z, rhi ; Store second byte to memory
     st -Z, rlo ; Store first byte to memory
     adiw ZH:ZL, 1 ; Z \le Z + 1
     dec iloop ; Decrement counter
     brne MUL16_ILOOP ; Loop if iLoop != 0
   ; End inner for loop
   sbiw ZH:ZL, 1 ; Z \le Z - 1
   adiw YH:YL, 1 ; Y \leq Y + 1
   dec oloop ; Decrement counter
   brne MUL16 OLOOP ; Loop if oLoop != 0
 ; End outer for loop
 pop iloop
            ; Restore all registers in reverves order
 pop oloop
 pop
     ZL
 pop
     ZH
     ΥL
 pop
     YΗ
 pop
     XL
 pop
 pop
     XH
 pop zero
 pop rlo
 pop
     rhi
 pop
     В
 pop A
 ret
     ; End a function with RET
;* Stored Program Data
; Enter any stored data you might need here
; ADD16 operands
```

```
ADD16 D1:
  .DW OxFCBA
ADD16_D2:
  .DW OxFFFF
; SUB16 operands
SUB16_D1:
  .DW OxFCB9
SUB16 D2:
  .DW 0xE420
; MUL24 operands
MUL24 D1:
  .DB OxFF, OxFF, OxFF, O; extra byte for 16b alignment
MUL24_D2:
  .DB OxFF, OxFF, OxFF, O; extra byte for 16b alignment
; Compoud operands
OperandD:
  .DW OxFCBA ; test value for operand D
OperandE:
  .DW 0x2019 ; test value for operand E
OperandF:
  .DW 0x21BB ; test value for operand F
;* Data Memory Allocation
.dseg
.org $0100
          ; data memory allocation for MUL16 example
addrA: .byte 2
addrB: .byte 2
LAddrP: .byte 4
; Below is an example of data memory allocation for ADD16.
; Consider using something similar for SUB16 and MUL24.
.org $0110
           ; data memory allocation for operands
ADD16 OP1:
  .byte 2
           ; allocate two bytes for first operand of ADD16
ADD16_OP2:
           ; allocate two bytes for second operand of ADD16
  .byte 2
.org $0120
          ; data memory allocation for results
```

```
ADD16 Result:
  .byte 3
            ; allocate three bytes for ADD16 result
; SUB16 reservations
            ; data memory allocation for operands
.org $0130
SUB16_OP1:
  .byte 2
SUB16_OP2:
  .byte 2
.org $0140
            ; data memory allocation for results
SUB16 Result:
  .byte 2
; MUL24 reservations
           ; data memory allocation for operands
.org $0150
MUL24 OP1:
  .byte 3
           ; allocate three bytes for first operand
            ; allocate three more for the shift
  .byte 3
MUL24 OP2:
           ; allocate three bytes for second operand
  .byte 3
.org $0160
            ; data memory allocation for results
MUL24_Result:
           ; allocate 6 bytes for ADD16 result
  .byte 6
;* Additional Program Includes
```