ECE 375 Lab 7

External Interrupts

Lab Time: Wednesday 10a-12n

Robert Detjens

David Headrick

Introduction

In this lab, we learned how to use the Timer/Counters on the ATMega128 to perform PWM management on output pins. In addition, we also learned how to write to different portions of an I/O port at different times. The timers on the board can be used to generate square waves at a user-configured duty cycle, allowing for easy PWM output on some of the output pins.

Program Overview

As this lab does not require the full BumpBot functionality, this program is relatively simple in structure. This program uses interrupts to react to button inputs and adjusts the necessary outputs in the interrupt handlers. The main loop of this program does nothing, as all of the need functionality of this program is contained within those handlers.

This program keeps track of the current speed level in one of the chip registers. This level ranges from 0 to 15, the same as what is shown in the lower half of the LEDs. This makes updating the LED I/O port easy, as this is a direct store without any conversion necessary (aside from loading the current state of the other half of the pins). To convert this internal speed value into the correct value to store into the Timers, it is multiplied by 17 to convert to a range of 0 to 255. This multiplication is done manually via shifting (for $\times 16$) and an subsequent add to get the final $\times 17$ value. This is then stored into both of the timer count registers to set the new duty cycle.

As both the LED update and the timer update are the same across all of the interrupt handlers, these were broken out into subprocedures and called from each handler in order to de-duplicate code.

Additional Questions

1. In this lab, you used the Fast PWM mode of both 8-bit Timer/Counters, which is only one of many possible ways to implement variable speed on a TekBot. Suppose instead that you used just one of the 8-bit Timer/Counters in Normal mode, and had it generate an interrupt for every overflow. In the overflow ISR, you manually toggled both Motor Enable pins of the TekBot, and wrote a new value into the Timer/Counter's register. (If you used the correct sequence of values, you would be manually performing PWM.) Give a detailed assessment (in 1-2 paragraphs) of the advantages and disadvantages of this new approach, in comparison to the PWM approach used in this lab.

One advantage to doing this approach would be that you have an extra 8-bit Timer/Counter at your disposal for any other use case. Another advantage is that you'd have more control over the semantics of an overflow in relation to the motors.

Advantages to the PWM method used in this lab would be that you don't have to use an interrupt to control PWM for the motor pins, they just get controlled in the background after everything is set up. A drawback of this approach is that it occupies

- both 8-bit counters to essentially do the same operation. If you need more counters, and interrupts don't bother you, the previously mentioned method would be optimal.
- 2. The previous question outlined a way of using a single 8-bit Timer/Counter in Normal mode to implement variable speed. How would you accomplish the same task (variable TekBot speed) using one or both of the 8-bit Timer/Counters in CTC mode? Provide a rough-draft sketch of the Timer/Counter-related parts of your design, using either a flow chart or some pseudocode (but not actual assembly code).

One 8-bit timer in CTC mode and it's corresponding interrupt could be used to perform the same action. The interrupt would be manually changing OCR0 every time it overflows to manipulate the duty cycle. The OCR pin would be set to toggle every overflow.

```
INIT:
set timer/counter 0 to CTC mode
set OCRO to 0x08
set OCR pin to toggle every overflow

ISR for Timer/Counter0:
XOR OCRO and 0x88 to switch between duty cycle counts
```

Difficulties

We spent a large amount of time troubleshooting why our timer was not being updated by our button interrupts. We were using the mul instruction to convert our stored speed level (0 to 15) into the appropriate timer count level (0 to 255). This was done by multiplying the speed level by 15, and storing that result into the timer. However, we did not fully understand how the mul instruction worked and did not realize it stored the result in a different register pair instead of updating the first operand with the result. We eventually double checked how it worked and realized this, and decided instead to switch to a more efficient manual shift-and-add instead of using mul since 17 is very close to a power of two and easily done via shifting.

Aside from this one problem, no other components of this lab gave us much trouble.

Conclusion

Barring the one issue with using mul incorrectly, this lab went smoothly. We feel confident now in our ability to configure and use the 8-bit Tiemr/Counters functionality for both timing and PWM. There are several roughly-equivalent ways of performing PWM (as discussed in the previous Questions section), and in researching those for said questions, we are confident in our ability to use those approaches as well.

Source Code

```
;*
;*
 Robert Detjens & David Headrick Lab 7 Source Code
;*
  Author: Robert Detjens
;*
      David Headrick
;* Date: 11/16/21
.include "m128def.inc" ; Include definition file
;* Internal Register Definitions and Constants
= r16 ; Multipurpose register
.def curr speed = r17 ; current speed level (0-15) * 17
.def waitcnt = r20 ; WaitFunc Loop Counter
.def ilcnt = r21
           ; Inner Loop Counter
.equ EngDirR = 5 ; right Engine Direction Bit
.equ EngDirL = 6 ; left Engine Direction Bit
; Timer config bits
.equ FOCx = 1 << 7
.equ WGMxO = 1 << 6
.equ COMx1 = 1 << 5
.equ COMx0 = 1 << 4
.equ WGMx1 = 1 << 3
.equ CSx2 = 1 << 2
.equ CSx1 = 1 << 1
.equ CSx0 = 1 << 0
;* Start of Code Segment
```

```
; beginning of code segment
.cseg
:* Interrupt Vectors
.org $0000
 rjmp INIT ; reset interrupt
      $0002
.org
 rcall SpeedMax ; IRQO Handler - set maximum speed
 reti
      $0004
.org
 rcall SpeedInc
             ; IRQ1 Handler - increment speed
 reti
      $0006
.org
 rcall SpeedDec ; IRQ2 Handler - decrement speed
 reti
      $0008
.org
 rcall SpeedMin ; IRQ3 Handler - set minimum speed
 reti
.org $0046
         ; end of interrupt vectors
;* Program Initialization
INIT:
 ; Initialize the Stack Pointer
         mpr, low(RAMEND)
 ldi
         SPL, mpr
 out
                    ; Load SPL with low byte of RAMEND
 ldi
         mpr, high(RAMEND)
 out
         SPH, mpr
                     ; Load SPH with high byte of RAMEND
 ; Configure I/O ports
 ; Initialize Port B for output
 ldi
         mpr, $FF
                    ; Set Port B Directional Register
 out
                    ; for output
         DDRB, mpr
 ldi
         mpr, $00
                    ; Initialize Port B for outputs
         PORTB, mpr ; Port B outputs low
 out
 ; Initialize Port D for input
                    ; Set Port D Directional Register
 ldi
         mpr, $00
 out
         DDRD, mpr
                    ; for inputs
```

```
ldi
         mpr, $FF ; Initialize Port D for inputs
         PORTD, mpr ; with pull-up
 out
 ; Configure External Interrupts, if needed
 ; Set the Interrupt Sense Control to falling edge
 ; Set INTO:3 to be on falling edge
 ldi mpr, 0b10101010
 sts EICRA, mpr
 ; Configure the External Interrupt Mask
 ldi mpr, 0b00001111
 out EIMSK, mpr
 ; Configure 8-bit Timer/Counters
 ; Enable PWM with no prescaling, set on OCR clear on overflow.
          WGMx0 | WGMx1 | COMx1 | CSx0
 ldi mpr.
 out TCCRO, mpr ; T/C 0
 out TCCR2, mpr ; T/C 2
 ; Set TekBot to Move Forward (1<<EnqDirR/1<<EnqDirL)
         mpr, (1<<EngDirR|1<<EngDirL)
 ldi
 out
         PORTB, mpr ; Send command to motors
 ; Set initial speed, display on Port B pins 3:0
      curr_speed, 0 ; start at full speed
 rcall UpdateTimers
 ; Enable global interrupts (if any are used)
 sei
;* Main Program
MAIN:
 rjmp MAIN ; return to top of MAIN
;* Functions and Subroutines
***********************
; Func:
       SpeedMax
```

```
; Desc: GO TO PLAID
;-----
SpeedMax:
 ldi curr_speed, 15
 rcall UpdateTimers
 ; delay a bit for debounce
 ldi mpr, 1
 rcall WaitFunc
 ; clear interrupt
 ldi mpr, 0b00001111
 out EIFR, mpr
 ret
               _____
; Func: SpeedInc
; Desc: Increment speed level by one
SpeedInc:
 cpi curr_speed, 15
 brge Inc noop
  ; only increment if below max
  inc curr_speed
 Inc_noop:
 rcall UpdateTimers
 ; delay a bit for debounce
 ldi mpr, 1
 rcall WaitFunc
 ; clear interrupt
 ldi mpr, 0b00001111
 out EIFR, mpr
 ret
; Func: SpeedDec
; Desc: Decrement speed level by one
```

```
SpeedDec:
 cpi curr_speed, 0
 breq Dec_noop
   ; only decrement if above min
   dec curr speed
 Dec_noop:
 rcall UpdateTimers
 ; delay a bit for debounce
 ldi mpr, 1
 rcall WaitFunc
 ; clear interrupt
 ldi mpr, 0b00001111
 out EIFR, mpr
 ret
; Func: SpeedMin
; Desc: Set minimum speed
SpeedMin:
 ldi curr_speed, 0
 rcall UpdateTimers
 ; delay a bit for debounce
 ldi mpr, 1
 rcall WaitFunc
 ; clear interrupt
 ldi mpr, 0b00001111
 out EIFR, mpr
 ret
; Func: UpdateTimers
; Desc: Update timers and display with new speed value
UpdateTimers:
 push mpr
```

```
; update leds with current speed
          mpr, (1<<EngDirR|1<<EngDirL)
 ldi
       mpr, curr_speed
 or
 out
       PORTB, mpr
 ; convert speed level to timer match value
 ; mpr * 17 == mpr * 16 + mpr == mpr << 4 + mpr
             curr speed
 mov
       mpr,
 lsl
       mpr
 lsl
      mpr
 lsl
      mpr
 lsl
      mpr
 add
      mpr, curr speed
       OCRO, mpr
 out
       OCR2, mpr
 out
 pop
       mpr
 ret
; Sub: WaitFunc
; Desc: A wait loop that is 16 + 159975*waitcnt cycles or roughly
      waitcnt*10ms. Just initialize wait for the specific amount
      of time in 10ms intervals. Here is the general equation
      for the number of clock cycles in the wait loop:
      ((3 * ilcnt + 3) * olcnt + 3) * waitcnt + 13 + call
WaitFunc:
         waitcnt ; Save waitregister
 push
                           ; Save ilcntregister
 push
            ilcnt
 push
           olcnt
                         ; Save olcntregister
                           ; load olcnt register
 Loop: ldi olcnt, 224
                            ; load ilent register
   OLoop: ldi ilcnt, 50
                                ; decrement ilcnt
     ILoop: dec ilcnt
                                ; Continue InnerLoop
      brne
                ILoop
                               ; decrementolcnt
     dec
              olcnt
                              ; Continue OuterLoop
     brne
              OLoop
                            ; Decrementwait
             waitcnt
   dec
            Loop
   brne
                             ; Continue Functoop
                           ; Restore olcntregister
            olcnt
 pop
                     ; Restore ilcntregister
 pop
            ilcnt
```