Testing Upgrades to icestorm, yosys, zipcpu and nextpnr mypi3-20 pi400-2 pi400-1 09/29/21

devel@pi400-1:~/testbuilds \$ git clone git@github.com:develone/icozip.git -b catzip catzip

devel@pi400-1:~/testbuilds \$ cd catzip/

/home/devel/zipcpu/sw/install/cross-tools/bin:/home/devel/.local/bin:/usr/local/sbin:/usr/local/bin:/usr/local/bin:/usr/local/sbin:/usr/local/games:/usr/games

devel@pi400-1:~/testbuilds/catzip \$ make

Note: On pi400-1 it took over 6 times to get a cputest and lifting step to work devel@pi400-1:~/testbuilds/catzip/rtl/catzip \$ make clean; make cpudefs.h; make design.h; make verilated; make bin

Tested verilog & C++

commit 5df54b35ca8724fe0cf3149f1543cfa2dd66acd7 (HEAD -> catzip)

Author: Edward Vidal Jr <develone@sbcglobal.net>

Date: Wed Sep 29 06:23:55 2021 -0600

missing from last commit

yosys -V

Yosys 0.9+4081 (git sha1 83a21814, gcc 8.3.0-6+rpi1 -fPIC -Os)

nextpnr-ice40 -V

nextpnr-ice40 -- Next Generation Place and Route (Version 67bd349e)

verilator -V

Verilator 4.100 2020-09-07 rev v4.100-10-g39eea781

zipcpu

commit 0046fdc25422ed7b8c9e4ae08c0fe98c2b959f7 (HEAD -> master, upstream/master)

Author: ZipCPU <dgisselq@ieee.org> Date: Wed Sep 1 17:25:39 2021 -0400

Moved GCC patch from zipcore to master

Includes fix for genzipops

autofpga

devel@mypi3-20:~/autofpga \$ git log

commit 5b57538081d60a04cd32aeba2436816062cb0141 (HEAD -> master, upstream/master,

upstream/dev)

Author: ZipCPU <dgisselq@ieee.org> Date: Fri Aug 14 07:55:55 2020 -0400

Fixes MacOS build err--std::string vs char * in gbl_msg.err()

icestorm pi400-1

commit 83b8ef947f77723f602b706eac16281e37de278c (HEAD -> master, upstream/master)

Merge: 9880f6e 97b6e27

Author: Miodrag Milanović <mmicko@gmail.com>

Date: Mon Sep 6 11:14:46 2021 +0200

Merge pull request #282 from jkiv/iceprog-ignorig-fix

[iceprog] Fixed typo in error message: "Ignorig"

```
devel@mypi3-19:~/testbuilds/mypi3-20/catzip/sw/host $ sudo ./arm-netpport
Listening on port 8363
Listening on port 8364
  Four score and seven years ago our fathers brought forth on this
   continent, a new nation, conceived in Liberty, and dedicated to
   the proposition that all men are created equal.
   Now we are engaged in a great civil war, testing whether that
   nation, or any nation so conceived and so dedicated, can long
   endure. We are met on a great battle-field of that war. We have
   come to dedicate a portion of that field, as a final resting
   place for those who here gave their lives that that nation might
   live. It is altogether fitting and proper that we should do this.
   But, in a larger sense, we can not dedicate-we can not consecrate-
   we can not hallow-this ground. The brave men, living and dead,
   who struggled here, have consecrated it, far above our poor power
   to add or detract. The world will little note, nor long remember
   what we say here, but it can never forget what they did here. It
   is for us the living, rather, to be dedicated here to the unfinished work which they who fought here have thus far so nobly
   advanced. It is rather for us to be here dedicated to the great
   task remaining before us-that from these honored dead we take
   increased devotion to that cause for which they gave the last
   full measure of devotion-that we here highly resolve that these
   dead shall not have died in vain-that this nation, under God,
   shall have a new birth of freedom-and that government of the
   people, by the people, for the people, shall not perish from the
   earth.
  |-----
  ello, World!
 Hello, World!
 Hello, World!
devel@mypi3-19:~/testbuilds/mypi3-20/catzip/sw/host $ 📗
```

cputest

```
File Edit Tabs Help
> A04000005K00000000
< A04000001W41f
> A04000001K00000000
< A04000005W
> A04000005K00000000
< A04000001Wc00
> A04000001K00000000
< A04000001W40f
> A04000001K00000000
< A04000005W2000000
> A04000005
> K00000000
< A04000001R
> A04000001R0000060f
Command port disconnect
Command port is now connected
< A04000001Wf
> A04000001K00000000
Command port disconnect
# Running CPU self-test
# SIM Instructions Pass
# CIS Instructions Supported
# Break test #1 Pass
# Break test #2
                                   Pass
# Break test #3
                                   Pass
# Early Branch test
                                   Pass
# Trap test/AND
                                   Pass
# Trap test/CLR
                                    Pass
# Overflow test
                                    Pass
# Carry test
                                    Pass
# Loop test
                                   Pass
# Shift test
                                   Pass
# Pipeline test
                                   Pass
# Mem-Pipeline test
                                   Pass
# Conditional Execution test Pass
# No-waiting pipeline test Pass
# Conditional Branching test Pass
# Ill Instruction test, NULL PC Pass
# Ill Instruction test, two Pass
# Comparison test, ==
# Comparison test, !=
                                   Pass
                                   Pass
# CC Register test
# Multi-Arg test
                                   Pass
                                   Pass
# Multiply test
                                   Pass
# Multiply HI-word test
                                   Pass
# Divide test
                                   Pass
# All tests passed. Halting CPU.
```

hello

```
File Edit Tabs Help
 A04000005K00000000
 A04000001W417
> A04000001K00000000
< A04000005W
> A04000005K00000000
< A04000001W418
> A04000001K00000000
< A04000005W
> A04000005K00000000
< A04000001W419
> A04000001K00000000
< A04000005W
> A04000005K00000000
< A04000001W41a
> A04000001K00000000
< A04000005W
> A04000005K00000000
< A04000001W41b
> A04000001K00000000
< A04000005W
> A04000005K00000000
< A04000001W41c
> A04000001K00000000
< A04000005W
> A04000005K00000000
< A04000001W41d
> A04000001K00000000
< A04000005W
> A04000005K00000000
< A04000001W41e
> A04000001K00000000
< A04000005W
> A04000005K00000000
< A04000001W41f
> A04000001K00000000
< A04000005W
> A04000005K00000000
< A04000001Wc00
> A04000001K00000000
< A04000001W40f
> A04000001K00000000
< A04000005W2000000
> A04000005
> K00000000
< A04000001R
> A04000001R0000060f
Command port disconnect
Command port is now connected
< A04000001Wf
> A04000001K00000000
Command port disconnect
# Hello, World!
```

now using b.bin which was extracted from blu.pgm with wrpgm.m This does not need to use split.
./runjpeg.sh

01401000 ()-> 00000002 01401004 ()-> 00000001

```
01401008 (
              )-> 0000001
0140100c (
              )-> 00000000
              )-> 0000001
01401010 (
01401018 (
             )-> 0000001
Halting the CPU
Memory regions:
      Block RAM: 01400000 - 01402000
      SDRAM
                  : 02000000 - 03000000
Loading: ../board/jpeg
Section 0: 02000000 - 0204fe6c
Writing to MEM: 02000000-0204fe6c
Clearing the CPUs registers
Setting PC to 02000000
The CPU should be fully loaded, you may now
start it (from reset/reboot) with:
> wbregs cpu 0x0f
CPU Status is: 0000060f
04000000 ( CPU)-> 0000000f
# w=256 h=256
# 1401000 2
# flag 2 0x204fde8
# 1401004 1
# 140100c 200fde8
./arm-wrsdram b.bin or ./arm-wrsdram g.bin or ./arm-wrsdram r.bin
The size of the buffer is 0x010000 or 65536 words
READ-COMPLETE
./arm-wbregs 0x01401008 0
01401008 (
             )-> 00000000
# ptrs.alt 0x20544c8 0x200fde8
# 131072
./arm-wbregs 0x01401010 0
01401010 (
             )-> 00000000
./arm-wbregs 0x01401008 0
01401008 (
              )-> 00000000
./arm-wbregs 0x01401010 0
01401010 (
             )-> 00000000
# 0x200fde8 0x7e
# 0x200fdec 0x7d
# 0x200fdf0 0x7b
# 0x200fdf4 0x76
# 0x202fde8 0x6a
```

```
# 0x202fdec 0x6a

# 0x202fdf0 0x68

# 0x202fdf4 0x64

#

# 0x204fdd8 0x48

# 0x204fddc 0x4a

# 0x204fde0 0x4e

# 0x204fde4 0x50

# 256 0x200fde8 0x20544c8 0x 1401004

# 256
```

./arm-rdsdram dwt.bin

Write-COMPLETE The size of the buffer is 0x010000 or 65536 words

