## Pico\_w MQTT Client Mosquitto or Ultibo QEMU or Ultibo Hardware RPi3 Broker GPIO Control

Adding a 2<sup>nd</sup> socket to Pico\_W freertos iperf

To provide Debug information previously provided by a hard wired connection to the Pico\_W

UART 04/13/23

Mosquitto or Ultibo QEMU or Hardware RPi3 Broker

main\_task

watchdog\_task

mqtt\_task

gpio\_task

rtc\_task

socket\_task

blink task

Build Steps RTC time setting

Mosquitto Broker GPIO

**Build Steps** 

"git clone https://github.com/develone/pico\_w-mqtt.git -b dev"

"cd pico\_w-mqtt"

Modify the script "6remotes.sh" WIFI\_SSID with your SSID and WIFI\_PASSWORD with your PASSWORD.

Modify the file "pico\_w/wifi/freertos/iperf/picow\_freertos\_iperf.c" WIFI\_PASSWORD with your PASSWORD.

Depending on which broker is going to be used the there are several parameters that can be changed (port and ip of broker Mosquitto & Ultibo hardware port 1883 Ultibo QEMU 18830)

/\*192.168.1.212 0xc0a801d4 LWIP\_MQTT\_EXAMPLE\_IPADDR\_INIT pi4-50\*/
#define LWIP\_MQTT\_EXAMPLE\_IPADDR\_INIT =

IPADDR4 INIT(PP HTONL(0xc0a801d4))

/\*192.168.1.231 0xc0a801d4 LWIP\_MQTT\_EXAMPLE\_IPADDR\_INIT ultibo\*/
#define LWIP\_MQTT\_EXAMPLE\_IPADDR\_INIT =
IPADDR4\_INIT(PP\_HTONL(0xc0a801e7))

openocd -f interface/raspberrypi-swd.cfg -f target/rp2040.cfg -c "program pico\_w/wifi/freertos/iperf/picow\_freertos\_iperf\_server\_mqtt.elf verify reset exit"


<sup>&</sup>quot;./6remotes.sh" creates 6 copies of the program

<sup>&</sup>quot;remotex/pico\_w/wifi/freertos/iperf/picow\_freertos\_iperf\_server\_mqtt.elf" each with a different hostname. In addition copies "exe-ocd.sh" to each of the six folders remotex.


<sup>&</sup>quot;exe-ocd.sh" uses openocd to program the Pico\_W #!/bin/bash

It also runs the script "build\_cli.sh". The IP of the pico\_w remotes in the file client.c on your network need to modified to your network.

```
The script "build cli.sh" creates 6 programs (cli1, cli2, cli3, cli4, cli5, and cli6) in the folder
pi_tcp_tests.
#!/bin/bash
cd pi_tcp_tests
rm -f cli1 cli2 cli5 cli6
gcc -v client.c -Drem1 -o cli1
gcc -v client.c -Drem2 -o cli2
gcc -v client.c -Drem3 -o cli3
gcc -v client.c -Drem4 -o cli4
gcc -v client.c -Drem5 -o cli5
gcc -v client.c -Drem6 -o cli6
https://github.com/develone/Tools/blob/master/Installer/Core/Linux/ultiboinstaller.sh can be use to
installed Lazarus IDE (Ultibo Edition) on RPi. The script requires
requirePackage "libgtk2.0-dev"
requirePackage "libcairo2-dev"
requirePackage "libpango1.0-dev"
requirePackage "libgdk-pixbuf2.0-dev"
requirePackage "libatk1.0-dev"
requirePackage "libghc-x11-dev"
git clone https://github.com/develone/Ultibo Projects.git
The IP of the host needs to match your host system virtual bare metal RPi
        MQC.Host := '192.168.1.212';
        MQC.Username := 'testuser';
        MQC.Password := 'password123';
        MQC.LocalBounce := false;
        MQC.Activate (true);
        MQC.Publish ('pub_time', #0#11'hello there', qtEXACTLY_ONCE, false);
       end;
```



Depressing the Run/Compile or Run/Cleanup and Build



When the green bar appears the project is ready to run as virtual bare metal RPi.

## Mosquitto Broker

diff /usr/share/doc/mosquitto/examples/mosquitto.conf /etc/mosquitto/mosquitto.conf 512c512,522

< #allow\_anonymous false

---

> #listener 8883 192.168.1.211

- > #listener 1884 192.168.1.211
- > listener 9883
- > #listener 9883 192.168.1.175
- > listener 1883
- > user testuser
- > per\_listener\_settings true
- > #password\_file /etc/mosqitto/mosquitto-pw
- > password\_file /home/devel/mosquitto-pw
- > #acl\_file file /etc/mosquitto/acl\_file.conf
- > allow\_anonymous false

513a524

> #log\_dest stdout

mosquitto -c /etc/mosquitto/mosquitto.conf mosquitto\_sub -t 'update/memo' -u 'testuser' -P 'password123' mosquitto\_sub -h pi4-60 -p 1883 -t 'update/memo' -u 'testuser' -P 'password123'

Ultibo QEMU "https://github.com/develone/Ultibo\_Projects/tree/master/Pauls-ultibo-mqtt" u16\_t mqtt\_port = 18830; instead of default u16\_t mqtt\_port = 1883;

devel@pi4-50:~/Ultibo\_Projects/Pauls-ultibo-mqtt/QEMU \$ ./startqemu.sh #!/bin/bash


qemu-system-arm -machine versatilepb -cpu cortex-a8 -kernel kernel.bin \


user, host fwd = tcp:: 5080-: 80, host fwd = tcp:: 5023-: 23, host fwd = tcp:: 18830-: 18830, host fwd = udp:: 5069-: 18830 + 18830

-:69,hostfwd=tcp::6050-:5050 -net nic \


-drive file=disk.img,if=sd,format=raw

Starts a 3 pane Window. First step would be depressing '5': MQ.Activate (true);





This is a Ultibo RPi3B with 7in display.



https://en.wikipedia.org/wiki/MQTT

MQTT (originally an <u>initialism</u> of MQ Telemetry Transport[a]) is a lightweight, <u>publish-subscribe</u>, <u>machine to machine</u> network <u>protocol</u> for <u>message queue/message queuing service</u>. It is designed for connections with remote locations that have devices with resource constraints or limited network <u>bandwidth</u>, such as in the <u>Internet of Things</u> (IoT). It must run over a transport protocol that provides ordered, <u>lossless</u>, bi-directional connections—typically, <u>TCP/IP.[1]</u> It is an open OASIS standard and an ISO recommendation (ISO/IEC 20922).

## RTC time setting

In the process of converting my "https://github.com/develone/pico\_w-remotes.git".

This version used ntp for setting the RTC in Pico\_W. The new version

"<a href="https://github.com/develone/pico\_w-mqtt.git">https://github.com/develone/pico\_w-mqtt.git</a>" uses a RPI to publish date and time information to topic 'pub\_time' and the Pico\_W subscribes to topic 'pub\_time'.

../pub-time pi4-50

2023-04-07-05-38-18

In the function "mqtt\_incoming\_data\_cb" parses the received time information and sets the Pico\_W RTC.

t 0x0 &t 0x0 \*pt 0x200220a0

t\_ntp 0x0 &pt\_ntp 0x0 \*pt\_ntp 0x200220dc

2023

04

07

05

38

18

2023-04-07-05-38-18

2023/04/07 05:38:27

Time information is reported to users using tcp\_debug socket.


../pi\_tcp\_tests/cli1

Socket created successfully

Connected with server successfully

I have several pico\_w connected to my home Wifi. Currently a 512 byte debug is sent to RPi4-4GB using (cli1, cli2, cli3, cli4, cli5, and cli6).

## **GPIO**



The USB to UART is currently used to see the debug from pico\_w. This will be removed and debug will be available using programs (cli1, cli2, cli3, cli4, cli5, and cli6).

and connected to the RPi4B 4Gb USB to see the debug output.

Now this can be done with the programs (cli1, cli2, cli3, cli4, cli5, and cli6).

Examples of the programming & debug are found

"https://github.com/develone/pico w-mqtt/blob/dev/doc/info.txt".

Modified output "https://github.com/develone/pico\_w-mqtt/blob/dev/doc/info\_1.txt".

The buffer now is 512 bytes. The first 256 is used for booting information and the next 256 are used following the connection to WiFi. Note: mqtt\_connected 0 then mqtt\_connected 1 which is when the connection to the Mosquitto Broker.

devel@pi4-30:~/pico\_w-mqtt/remote5 \$ ../pi\_tcp\_tests/cli1 Socket created successfully Connected with server successfully Starting FreeRTOS on core 0: ver 0.0.02 remote1 Connecting to Wi-Fi... Connected. iperf server 192.168.1.176 4001 starting watchdog timer task mqtt\_ip = 0xd401a8c0 mqtt\_port = 1883 mqtt\_connect 0x0 mqtt\_connect 0x1 2023-04-07-05-38-18 2023/04/07 05:38:2nnect 0x1 2023/04/07 05:42:37 mqtt\_connect 0x1 mqtt\_connect 0x1 40:57 mqtt\_connect 0x1 mqtt\_connect 0x1 2023/04/07 05:41:22 mqtt ���

**GPIO** 

0 3f 0011 1111

```
1
       06
              0000 0110
2
              0101 1011
       5b
3
       4f
              0100 1111
4
       66
              0110 0110
5
       6d
              0110 1101
6
       7d
              0111 1101
7
       07
              0000 0111
8
       7f
              0111 1111
       67
9
              0110 0111
int bits[10] = {
    0x3f, // 0
    0x06, // 1
    0x5b, // 2
    0x4f, // 3
    0x66, // 4
    0x6d, // 5
    0x7d, // 6
    0x07, // 7
    0x7f, // 8
    0x67 // 9
};
GPIO2 pin 4 pico_w blue A
GPIO3 pin 5 pico w red B
GPIO4 pin 6 pico_w blue C
--A--
F B
--G--
E C
--D--
void gpio_task(__unused void *params) {
  //bool on = false;
  printf("gpio_task starts\n");
//We could use gpio_set_dir_out_masked() here
  for (int gpio = FIRST_GPIO; gpio < FIRST_GPIO + 7; gpio++) {
    gpio_init(gpio);
    gpio_set_dir(gpio, GPIO_OUT);
    // Our bitmap above has a bit set where we need an LED on, BUT, we are pulling low to light
    // so invert our output
    gpio_set_outover(gpio, GPIO_OVERRIDE_INVERT);
  }
  gpio_init(BUTTON_GPIO);
  gpio_set_dir(BUTTON_GPIO, GPIO_IN);
  // We are using the button to pull down to 0v when pressed, so ensure that when
  // unpressed, it uses internal pull ups. Otherwise when unpressed, the input will
  // be floating.
```

```
gpio_pull_up(BUTTON_GPIO);
//int val = 0;
while (true) {
  int val = 0;
  if (!gpio_get(BUTTON_GPIO)) {
     if (val == 9) {
       val = 0;
     } else {
       val++;
  } else if (val == 0) {
     val = 9;
  } else {
     val--;
  }
  // We are starting with GPIO 2, our bitmap starts at bit 0 so shift to start at 2.
  int32_t mask = bits[val] << FIRST_GPIO;</pre>
  gpio_set_mask(mask);
  sleep_ms(250);
  gpio_clr_mask(mask);
  vTaskDelay(200);
}
```

}