
Description of Infoboxes

Gateway



This infobox contains some basic informations about the gateway itself. This informations are taken from the gateway-configuration-file.

System Info




Here you can find live-infos about system-relevant states like temperature, CPU and Usage. Data-sources are system-sensors and/or system-counters.

Repeaters



This section lists all configured repeater-modules from gateway-configuration.

Links



Within these infoboxes link-states are listed. You can chose between showing all in one box or divice in- and outgoing links into two boxes.

Remote Control



This is the remote-control section used to control the linkage of your repeater-modules.

Currently Transmitting

Currently transmitting:						
Date & Time (UTC)	Call	ID	Yourcall	Repeater1	Repeater2	TX-Seconds
2015-09-23 19:05:32	DG9VH	INFO	cqcqcq	DG9VH G	DG9VH B	5s
THE RESIDENCE OF THE PARTY OF T	And the same of th	THE HOUSE OF THE STATE OF THE S	7,45774			CONTRACTOR OF THE PERSON OF TH


Here are informations about the currently transmitting station shown.

Currently maybe in QSO



Here are those stations listed that last transmit at least 3 seconds within the last 10 minutes. This parameters are defined to get those stations with a high accurate possibility to be in QSO together.

Last 15 calls heard on ...



This is the so called "last heard" list that shows the last 15 callsign/id-combinations that were heard on any port.

Last calls that used ...



Here are the calls listed that used the repeater-modules via RF.