
# **AREDN on Proxmox**

## Inhalt

| System Overview  | 3  |
|--|----|
| Needed Steps   | 4  |
| Proxmox  | 5  |
| Adjust the network of the node                         | 6  |
| Create an AREDN VM                                     | 7  |
| Creating the VM  | 7  |
| Configuring the VM                                     | 10 |
| Setting Up the AREDN Disk                              | 11 |
| Create a Debian VM as a Management Console             | 15 |
| Configure the AREDN Tunnel Server                      | 24 |
| Initial setup of the AREDN router                      | 24 |
| Connection to the configured Tunnel Server (incl. ssh) | 25 |
| Network mapping inside the AREDN VM                    | 27 |
| Backup of the VM                                       | 29 |
| Install QUEMU Agent                                    | 30 |
| AREDN Virtual Machine as a Telephone Server            | 32 |
| Overview   | 32 |
| Setup  | 32 |
| Final tip:   | 34 |

## System Overview

This is the setup we want to achieve:



## Needed Steps

- 1- Install Proxmox on an X.86 machine (PC)
- 2- Adjust network of the node
- 3- Create an AREDN VM
- 4- Create a Debian VM (or any other distribution that can run a terminal and a browser)
- 5- Connect to AREDN from Debian to setup the network configuration as well as the AREDN node

## Proxmox installation

You find many tutorials to install Proxmox on an X86 machine.

Find the IP address of your Proxmox server (using Advanced IP Scanner)


Open a web browser and navigate to the Proxmox web UI (e.g. https://192.168.0.230:8006/

## VLAN enabling of the Proxmox network

Navigate to pve8 → Network

vmbr0 is the same as port 1 on the hap router and is connected to the internet (for tunnels) It is default on Proxmox.

#### Make vmbr0 VLAN aware:



#### VLAN definition for this document

VLAN1: Used as "untagged" VLAN by AREDN

VLAN2: Used for Device-to-Device (DtD) communication by AREDN

VLAN10: Used as LAN network for the Tunnel Server (by the author, can be changed)

VLAN20: Used as LAN network for the Telephone Server (by the author, can be changed)

## Create an AREDN VM (Tunnel or Telephone Server)

Based on: https://i12bretro.github.io/tutorials/0405.html

and


https://youtu.be/8nsdrWeeg8o

### Creating the VM


Click the Create VM button at the top right:





And fill in a name and an ID for your VM (start at boot <u>not</u> ticked):





Start at boot can be ticked when everything works
















Add VLAN 20 (to prevent DHCP server interacting with your home network (and untick firewall):



Confirm the summary and wait till the VM is created


#### Configuring the AREDN VM

Change VLAN tag and remove firewall of Network device (net0) to create LAN port




VLAN 10 is used to insulate the DHCP server of the AREDN node. If you forget it, you can shut down your whole home network when you start the server!


#### Click the Add button > Network Device



#### to create the WAN port




#### Add the DtD interface in VLAN2



#### The result should look like that:


| ` '                     | , ,   |
|-------------------------|---|
| → Network Device (net0) | virtio=F2:E2:A4:3F:22:4A,bridge=vmbr0,tag=10      |
| → Network Device (net1) | virtio=CE:89:6D:54:3A:AC,bridge=vmbr0,link_down=1 |
| → Network Device (net2) | virtio=DE:D8:C2:12:53:D6,bridge=vmbr0,tag=3       |
|                         |   |

#### And finally, detach and remove harddisk (scsi0)



#### Setting Up the AREDN Disk

Go to the shell of the server and download the image



wget -0 aredn.img.gz
http://downloads.arednmesh.org/releases/3.23.8.0/targets/x86/64/aredn-3.23.8.0x86-64-generic-ext4-combined.img.gz

Adjust the release if you want. Or upgrade your VM later using the AREDN VM

extract the AREDN img

```
gunzip ./aredn.img.gz
```

rename the extracted img

```
mv ./aredn*.img ./aredn.raw
```


increase the raw disk to 512 MB

```
qemu-img resize -f raw ./aredn.raw 512M
```


import the disk to the openwrt VM (replace 104 with your VM number)

```
qm importdisk <mark>104</mark> /root/aredn.raw local-lvm
```


The disk is now visible as "Unused Disk 0". Add the disk (double click on it) to your VM:




#### Change boot order:



Double click Use tablet pointer > Uncheck the Enabled box > Click OK



#### Go to Console and press "Start Now"



Watch the boot process, wait for the text to stop scrolling and press "Enter"



Run the following command to change/set the root password

passwd

Type a new root password twice

For the moment we are done with the AREDN node. Because we had to separate the LAN from our home network, we only can manage the node in the Proxmox terminal (it does not offer a browser). To solve the problem, we add a VM with plain vanilla Debian and connect it to VLAN20, too. Like that we have a private connection to manage our AREDN node.

Of course, you can use any other VM that offers a browser and is connected to vmbr0/VLAN10.

Type

Ip addr

To check the address of your VM. It should be 192.168.1.1


```
root@NOCALL:/# ip addr
1: lo: <LOOPBACK,UP,LOWER_UP> mtu 65536 qdisc noqueue state UNKNOWN qlen 1000
     link/loopback 00:00:00:00:00:00 brd 00:00:00:00:00:00
     inet 127.0.0.1/8 scope host lo
valid_lft forever preferred_lft forever
2: eth0: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 1500 qdisc fq_codel master br-lan state UP qlen 1000
    link/ether f2:e2:a4:3f:22:4a brd ff:ff:ff:ff:ff
3: eth1: <BROADCAST,MULTICAST> mtu 1500 qdisc noop state DOWN qlen 1000
    link/ether ce:89:6d:54:3a:ac brd ff:ff:ff:ff:ff:ff
4: eth2: <BROADCAST, MULTICAST> mtu 1500 qdisc noop state DOWN qlen 1000
     link/ether de:d8:c2:12:53:d6 brd ff:ff:ff:ff:ff:ff
5: tunlogNONE: <NOARP> mtu 1480 qdisc noop state DOWN qlen 1000
6: br-lan: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 1500 qdisc noqueue state UP qlen 1000
    link/ether f2:e2:a4:3f:22:4a brd ff:ff:ff:ff:ff:ff
inet 192.168.1.1/24 brd 192.168.1.255 scope global br-lan
       valid_lft forever preferred_lft forever
  eth0.Z0eth0: <BRUADCAST,MULTICAST,UP,LUWER_UP> mtu 1500 qdisc noqueue state UP qlen 1000
    link/ether f2:e2:a4:3f:22:4a brd ff:ff:ff:ff:ff:ff
inet 192.168.2.1/24 brd 192.168.2.255 scope global eth0.2
       ualid_lft forever preferred_lft forever
8: eth0.10eth0: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 1500 qdisc noqueue state UP qlen 1000
    link/ether f2:e2:a4:3f:22:4a brd ff:ff:ff:ff:ff
```

## Create a Debian VM as a Management Console


https://youtu.be/OUC7DMBfR3Y?si=y4r3edcwzzpd2JHJ

#### Download the Debian 11 iso Download


https://cdimage.debian.org/debian-cd/current/amd64/iso-cd/ (debian-12.1.0-amd64netinst.iso)




#### Create VM




#### On the OS tab,




#### Leave the defaults on the System tab



#### On the Hard Disk tab, set the Disk size to 16 GiB or more




#### On the CPU tab



#### On the Memory tab



Network tab: Add the VLAN number of the LAN port of the AREDN server you want to connect to and untick the firewall.



Verify the summary and click Finish


#### Start the VM



**Graphical Install** 




### Select a language



### Select a Location (other →Europe→Switzerland)




#### Select locales (can be adapted later)



#### Select a keyboard layout (can be changed later)



#### Enter a hostname for the VM



#### Leave domain name empty

Configure the network

The domain name is the part of your internet address to the right of your host name. It is often something that ends in .com, .net, .edu, or .org. If you are setting up a home network, you can make something up, but make sure you use the same domain name on all your computers.

Domain name:

#### Leave root password empty

Set up users and passwords

You need to set a password for 'root', the system administrative account. A malicious or unqualified user with root access can have disastrous results, so you should take care to choose a root password that is not easy to guess. It should not be a word found in dictionaries, or a word that could be easily associated with you.

A good password will contain a mixture of letters, numbers and punctuation and should be changed at regular intervals.

The root user should not have an empty password. If you leave this empty, the root account will be disabled and the system's initial user account will be given the power to become root using the "sudo" command.

Note that you will not be able to see the password as you type it.

Root password:

Show Password in Clear

Please enter the same root password again to verify that you have typed it correctly.

Show Password in Clear

#### Enter the full name for the new user

ket up users and passwords


A user account will be created for you to use instead of the root account for non-administrative activities.

Please enter the real name of this user. This information will be used for instance as default origin for emails sent by this user as well as any program which displays or uses the user's real name. Your full name is a reasonable choice.

Full name for the new user:

sensorsiot

#### Enter the username for the new user



#### Enter and confirm a password for the new user



#### Select Disk



```
Partition disks

Note that all data on the disk you select will be erased, but not before you have confirmed that you really want to make the changes.

Select disk to partition:

SCSI3 (0,0,0) (sda) - 17.2 GB QEMU QEMU HARDDISK
```

```
Partition disks

Selected for partitioning:

SCSI3 (0,0,0) (sda) - QEMU QEMU HARDDISK: 17.2 GB

The disk can be partitioned using one of several different schemes. If you are unsure, choose the first one.

Partitioning scheme:

All files in one partition (recommended for new users)

Separate /home partition

Separate /home, /var, and /tmp partitions
```

#### Check and click Continue



Select Yes to confirm writing the changes


```
Partition disks


If you continue, the changes listed below will be written to the disks. Otherwise, you will be able to make further changes manually.

The partition tables of the following devices are changed:
SCSE3 (0.0,0 (10 da)

The following partitions are griegs to be formated:
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3 (0.0,0 (10 da) as extet
partition for 50 SCSE3
```

#### Wait for Debian to copy and install files









#### Wait

Participating in package survey

```
Configuring popularity-contest

The system may anonymously supply the distribution developers with statistics about the most used packages on this system. This information influences decisions such as which packages though go on the first distribution CO.

If you choose to participate, the automatic submission script will run once every week, sending statistics to the distribution developers. The collected statistics can be viewed on https://popcon.deblan.org/

This choice can be later modified by running "dpkg-reconfigure popularity-contest".

Participate in the package usage survey?

**No!

Yes
```

#### Select the software to install



#### Select (tick) "SSH server"

#### Wait

#### Select Yes to install GRUB

It seems that this new installation is the only operating system on this computer. If so, it should be safe to install the GRUB boot loader to your primary drive (UEFI partition/boot record).


Warning: If your computer has another operating system that the installer failed to detect, this will make that operating system temporarily unbootable, though GRUB can be manually configured later to boot it.

Install the GRUB boot loader to your primary drive?

No


Yes

#### Select drive for the boot loader




#### Reboot

Remove CD drive (it will only be removed after reboot)



#### Go to the Console and login



Start Firefox. On <a href="http://localnode.local.mesh">http://localnode.local.mesh</a> you should see your AREDN server on the same VLAN because your Management Console is connected via the vmbr0/10 interface.

## Configure the AREDN Tunnel Server

Because our Management Console VM is connected to our AREDN VM via vmbr0/VLAN10 it should get an IP.


```
sensorsiot@AREDN-Console:~$ ip addr
1: lo: <LOOPBACK,UP,LOWER_UP> mtu 65536 qdisc noqueue state UNKNOWN group default qlen 1000
    link/loopback 00:00:00:00:00:00 brd 00:00:00:00:00
    inet 127.0.0.1/8 scope host lo
        valid_lft forever preferred_lft forever
    inet6 ::1/128 scope host noprefixroute
        valid_lft forever preferred_lft forever
2: ens18: <BROADCAST,MULTICAST,UP,LOWER_UP> mtu 1500 qdisc fq_codel state UP group default qlen 1000
    link/ether 2e:72:31:08:aa:fa brd ff:ff:ff:ff;
    altname enp0s18
    inet 192.168.1.20/24 brd 192.168.1.255 scope global dynamic ens18
        valid_lft 41302sec preferred_lft 41302sec
    inet6 fe80::2c72:31ff:fe08:aafa/64 scope link noprefixroute
        valid_lft forever preferred_lft forever
```

To check the connection, you can ping the AREDN VM:


ping localnode.local.mesh

#### Initial setup of the AREDN router


Open the browser and call localnode.local.mesh



Press setup (password: hsmm)



Give it a name and a password, hit "Save changes" and "reboot"




After reboot, your AREDN VM should have an 10.x.x.x address

If the Management Console does not connect to the AREDN VM, it still has its old address.

So type these two commands to get a new address from the AREDN VM:

```
sudo dhclient -r
sudo dhclient
```

From now on, you can manage your AREDN node from the Management Console



Connection to the configured Tunnel Server (incl. ssh)

Connect again to your AREDN server (unfortunately, Proxmox does not allow copy-paste):

```
sensorsiot@AREDN-Console:~$

sensorsiot@AREDN-Console:~$

sensorsiot@AREDN-Console:~$

sensorsiot@AREDN-Console:~$

sensorsiot@AREDN-Console:~$

sensorsiot@AREDN-Console:~$

sensorsiot@AREDN-Console:~

sensorsiot@AREDN-Collode

sensorsiot@AREDN-Collo
```

#### Press yes, and enter the password hsmm


If you get a "man in the middle" warning, key in the suggested command:

```
sensorsiot@AREDN-Console:~$ ssh -l root -p 2222 localnode
WARNING: REMOTE HOST IDENTIFICATION HAS CHANGED!
IT IS POSSIBLE THAT SOMEONE IS DOING SOMETHING NASTY!
Someone could be eavesdropping on you right now (man-in-the-middle attack)!
It is also possible that a host key has just been changed.
The fingerprint for the ECDSA key sent by the remote host is
SHA256:in9jB/hOPyHlR26zc3jBTufKKWf3jFfWxIgxPdzV2qs.
Please contact your system administrator.
Add correct host key in /home/sensorsiot/.ssh/known_hosts to get rid of this message.
Offending ECDSA key in /home/sensorsiot/.ssh/known_hosts:3
 remove with:
 ssh-keygen -f "/home/sensorsiot/.ssh/known_hosts" -R "[localnode]:2222"
Password authentication is disabled to avoid man-in-the-middle attacks.
Keyboard-interactive authentication is disabled to avoid man-in-the-middle attacks.
UpdateHostkeys is disabled because the host key is not trusted.
root@localnode: Permission denied (publickey,password).
sensorsiot@AREDN-Console:~$
```

#### This is the correct answer:

```
sensorsiot@AREDN-Console:~$ ssh-keygen -f "/home/sensorsiot/.ssh/known_hosts" -R "[localnode]:2222"
# Host [localnode]:2222 found: line 3
/home/sensorsiot/.ssh/known_hosts updated.
Original contents retained as /home/sensorsiot/.ssh/known_hosts.old
sensorsiot@AREDN-Console:~$
```

#### Now you can try to ssh into your server as before



#### Network mapping inside the AREDN VM

In the end we would like the following mapping:

| → Network Device (net0) | virtio=F2:E2:A4:3F:22:4A,bridge=vmbr0,tag=10 | eth0 | LAN port (ports 2-4 on hap) |
|-------------------------|--|------|-----------------------------|
| → Network Device (net1) | virtio=CE:89:6D:54:3A:AC,bridge=vmbr0        | eth1 | LAN port (port 1 on hap     |
| → Network Device (net2) | virtio=DE:D8:C2:12:53:D6,bridge=vmbr0,tag=3  | eth2 | LAN port (port 5 on hap     |

The mapping of the nets has to be done now in the terminal of the Management Console.

Type:

```
vi /etc/config/network
```

and hit the "insert" key.

Leave the Wi-Fi configuration as it is:

```
### Loopback configuration
config interface loopback
        option device "lo"
option proto static
option ipaddr 127.0.0.1
        option netmask 255.0.0.0
#### WIFI configuration
config device
        option name 'br-nomesh'
        option type 'bridge'
        option bridge_empty '1'
config interface wifi
        option device 'br-nomesh'
        option proto 'static'
        option ipaddr '10.124.142.47'
        option netmask '255.255.255'
config interface wifi_mon
        option proto
```

#### Add two ports to the bridge configuration:

Adjust the LAN configuration:

```
#### LAN configuration
config bridge-vlan
        option device 'br0'
        option vlan '3'
       list ports 'eth0:u'
confia device
        option name 'br-lan'
        option type 'bridge
        option macaddr 02:40:B0:C3:7B:A5
       list ports 'br0.3'
config interface lan
        option device 'br-lan'
        option proto 'static'
        option ipaddr '10.61.86.209'
        option netmask '255.255.255.240'
        option dns '8.8.8.8 8.8.4.4
```

The LAN is connected to eth0 that is net0 in Proxmox on VLAN 20. Only our Management Console is connected to this network. So the DHCP server inside the AREDN server is insulated and does not harm your home network.

The WAN port has to be connected to the internet. Vmbr0 is connected to the RJ45 connector of your server. It uses the general purpose VLAN 1 and will get a DHCP address from your home network.

The DtD (device-to-device) port is connected to the RJ45 of your Proxmox server via vmbr0, but this time using VLAN 2. To avoid problems with the DHCP server of other AREDN devices like the hap routers, we have to add a managed switch where we only transfer VLAN 2 to the ports where we connect port 5 of the hap routers or any "antennas".

```
#### DtD configuration

config bridge-vlan
    option device 'br0'
    option vlan '2'
    list ports 'eth2:u'

config device
    option name 'br-dtdlink'
    option type 'bridge'
    list ports 'br0.2'

config interface dtdlink
    option proto 'static'
    option proto 'static'
    option netmask '255.0.0.0'
```

All networks have to marked "untagged" (e.g. "eth2:u"). They are tagged by Proxmox. And Proxmox does not like tagged stuff from the container.

The rest of the configuration file is only comments and is not changed for the moment.

Press the "escape" button and ":wq" to save your changes.

Reboot.

Now you can connect to localnode.local.mesh via browser and start to customize your server.

Give it the name: Callsign-VM-TUNNELSERVER (if not done before).

Connect it as a client to your Tunnel Server in the AREDN network. Make sure the administrator of your tunnel adjusts the name and the address of your new server. Maybe you want to run in parallel for a few days. After connecting to your Tunnel Server, you should see the other nodes in the net.

Now, you can add the tunnels you serve. Do not forget to forward port 5525 to the address of your Tunnel Server.




Now your Server should be connected to the SwissDigitalNet. Congratulations!



#### Backup of the VM

Backup machine to the local directory



You find this directory

cd /var/lib/vz/dump/

on the Proxmox server. It can be saved to the local disk using WinSCP

### Install QUEMU Agent

This step is needed to control (e.g. shut down) the AREDN VM from Proxmox

You have to be connected to the SwissDigitalNet for this task

In your Management Console, you go to mesh status and select HB9EDI's filerepo:




And copy this link (right mouse click):



Now you paste the link into your terminal and add the yellow command

curl http://hb9edi-vm-gw.local.mesh/filerepo/install\_qemu\_x86\_agents\_3.28.0.sh | ash


Finally, you enable Guest Agent and reboot the machine



Now your Tunnel Server can be controlled by Proxmox.

## AREDN Virtual Machine as a Telephone Server

#### Overview



#### Setup


We create a new VM in addition to the Tunnel Server. If you do not operate a Tunnel Server, you just create a VM for your Telephone Server.

#### Do not copy the VM of the Tunnel Server.

The basis setup has to be done the same way as for the Tunnel Server. The main difference is that we chose VLAN10 as the management connection:

| <ul> <li>         ⇒ Network Device (net1) virtio=0A:DC:B3:77:C5:08,bridge=vmbr0     </li> <li>         ⇒ Network Device (net2) virtio=3A:55:E2:13:D0:C1,bridge=vmbr0,tag=2     </li> </ul> | → Network Device (net0)                                       | virtio=AA:88:4A:2F:F5:D1,bridge=vmbr),tag=20 |
|--|---|--|
| → Network Device (net2) virtio=3A:55:E2:13:D0:C1,bridge=vmbr0,tag=2  | → Network Device (net1) virtio=0A:DC:B3:77:C5:08,bridge=vmbr0 |  |
|  |   |  |

And we have to change the network of the Management Console, too:



Do not assign the same VLAN to two AREDN management connections (you will get two concurrent DHCP servers)!


Now we should be able to manage the Telephone Server from the Management Console.

Maybe you have to reassign a new IP to the Management Console:

```
sudo dhclient -r
sudo dhclient
```

We can connect our phones to our home network instead of the hap router and they should get a normal address in the 192.168.xxx.xxx range.

Because our LAN of the VM is on VLAN 20, we must change the VLAN of the phone, too. We login and go to Network → Advanced and enable VLAN 20.



Now your phone should get a 10.xx.xx.xx address (instead of a 192.168.xxx.xxx) and you can install the phonebook and the SIP server as in every hap router and make the first test call.

The Tunnel Server VM and the telephone VM should be connected by a DtD link. You see this in the neighbour status:



Be aware that you can only manage your VMs (other than the Tunnel Server) and phones from the Management Console. They are not connected to your home network.

You can shut the Management Console VM down if you do not need it if you do not have too much resources on your server.

#### Final tip:

You can connect your Management Console to whatever AREDN VM you want (select VLAN 10 for the Tunnel and VLAN20 for the Telephone Server). From there, you can reach all your devices without changing the VLAN of the Management Console .