



ALVIS pro


Bauanleitung ODER-Gatter




Übersicht fischertechnik Bauteile

2x 35129		1x 32064		1x 36913		5x 36334	
9x 32879		4x 38423		3x 36952		5x 36324	
1x 32882		2x 37468		2x 36923			
2x 32881		1x 38242		9x 31060			
3x 32850		3x 38241		1x 31330			
2x 35049		2x 32330		1x 31690			
4x 37237		3x 38240		6x 31982			

1



2



2x




4x





1x




3



4




5




2x 

6




1x 

7



1x 


8



2x 


4x 

9



Die zwei Federnocken müssen unter die schwarzen Bausteine gesteckt werden, um sie mit der Basis zu verbinden.


10



11



12



2x



2x



1x



1x








1x



1x




13




14


15




16



17



18



3x



3x

Über den Streben noch die 3D-Druck-Teile anbringen. Dafür die roten 15 x 15 Steine nochmal entfernen und später erneut platzieren.

Anschließend Gummiband und Labels anbringen.



Ein Projekt von



FH MÜNSTER
University of Applied Sciences

Digitallabor
MÜNSTER

Ministerium für Wirtschaft,
Industrie, Klimaschutz und Energie
des Landes Nordrhein-Westfalen



Kofinanziert von der
Europäischen Union