






200-U\_row-4\_post-2












201-I\_row-1\_post-10 27.225922512026646 500 -400 -Wire deflection 300 -200 -100 -0 -5 1 20


10

Post deflection


15





201-I\_row-1\_post-12 16.90922719322436 700 -600 -500 -Wire deflection 400 -300 -200 -100 -0 -1 10 1 40 1 20 30 Post deflection





201-I\_row-1\_post-14 15.167107459066264 600 -500 -Wire deflection 200 -100 -0 -1 10 1 20 30 40 Post deflection






















202-I\_row-3\_post-24 13.052417312417823 500 -400 -Wire deflection 100 -0 -1 10 1 20 30 1 40


Post deflection




202-I\_row-4\_post-21 12.880682477271083 500 -400 -Wire deflection 300 -200 -100 -0 -1 10 20 30 1 40 Post deflection

202-I\_row-4\_post-22








202-I\_row-4\_post-24





202-I\_row-5\_post-22 600 -12.657000604834465 500 -400 -Wire deflection 300 -200 -100 -0 -1 10 1 40 1 20 30 Post deflection




















Modulus vs Average CNT Diameter 188-I 10<sup>9</sup> = 190-I 194-U 195-I 198-U 199-I 200-U 201-I 202-I 203-I Modulus (Pa) 10<sup>7</sup> = 10<sup>6</sup> = 1 10.0 1 22.5 1 12.5 1 15.0 20.0 7.5 17.5 Sample Average CNT Diameter (nm)

