GRIDOPT Documentation

Release 1.2

Tomas Tinoco De Rubira

CONTENTS

1	Getti	ing Started	3					
	1.1	Download	3					
	1.2	Installation	3					
	1.3	Docker	3					
	1.4	Example	4					
2	Powe	er Flow	7					
	2.1	DCPF	8					
	2.2	DCOPF	8					
	2.3	DCOPF_MP	9					
	2.4	DCOPF_Corr	10					
	2.5	DCOPF_Prev	11					
	2.6	NRPF	11					
	2.7	AugLPF	12					
	2.8	AugLOPF	12					
3	API 1	Reference	13					
	3.1	Power Flow Method	13					
	3.2	References	15					
4	Indic	ees and tables	17					
Bibliography								
Рy	thon N	Module Index	21					
Py	thon N	Module Index	23					
In	dex		25					

Welcome! This is the documentation for GRIDOPT, last updated October 01, 2016.

What is GRIDOPT?

GRIDOPT is a Python package that provides methods for solving power grid optimization problems.

License

GRIDOPT is released under the BSD 2-clause license.

Contributors

• Tomas Tinoco De Rubira (principal developer)

Documentation Contents

CONTENTS 1

2 CONTENTS

CHAPTER

ONE

GETTING STARTED

This section describes how to get started with GRIDOPT. In particular, it covers required packages, installation, and provides a quick example showing how to use this package.

- Numpy (>=1.8.2)
- Scipy (>=0.13.3)
- OPTALG (== 1.0)
- PFNET (>= 1.3)

1.1 Download

The latest version of GRIDOPT can be downloaded from https://github.com/ttinoco/GRIDOPT.

1.2 Installation

The GRIDOPT Python module can be installed using:

```
> sudo python setup.py install
```

from the root directory of the package.

The installation can be tested using nose as follows:

```
> nosetests -v
```

1.3 Docker

If GRIDOPT was obtained as a Docker image, say gridopt.tar, then one needs to first install Docker Engine. Then one can load the image using the command:

```
> docker load -i gridopt.tar
```

and enter the application environment with:

```
> docker run -i -t --entrypoint=/bin/bash gridopt
```

In the application environment, GRIDOPT and all its dependencies, *e.g.*, PFNET, are already installed and ready to go. There, one can navidate to the directory /gridopt/tests/resources and use the test cases available there to do the PFNET and GRIDOPT tutorials with Python.

1.3.1 Graphics in Linux

To display graphics within the application environment, the following command can be run for entering the application environment:

```
> docker run -i -t --entrypoint=/bin/bash -e DISPLAY -v /tmp/.X11-unix:/tmp/.X11-unix:ro gridopt
```

Then, on the host machine the command xhost + can be used to enable access to your host machine's display and then xhost - to disable it after usage. Inside the application environment, the command xeyes can be used to check whether graphics are working.

1.3.2 Graphics in Windows

Displaying graphics on Windows involves a few more steps. First, Xming, an X server for Windows, must be downloaded and installed. Then, the installed application XLaunch should be executed with the options Multiple windows, Display number 0, Start no client, Clipboard and No Access Control. Once this is done, the application environment can be entered using:

```
> docker run -i -t --entrypoint=/bin/bash -e DISPLAY=ip_address_taken_by_Xming:0 gridopt
```

where the IP address taken by Xming can be found in the file C:\Users\username\AppData\Local\Temp\Xming.0 next to XdmcpRegisterConnection. Again, graphics within the application environment can be tested using the command xeyes.

1.3.3 Graphics in Mac

Coming soon.

1.4 Example

The next example shows how to solve the power flow problem associated with a power grid using GRIDOPT:

```
>>> import pfnet
>>> import gridopt
>>> net = pfnet.Network()
>>> net.load('ieee14.mat')
>>> # max mismatches (MW, MVAr)
>>> print '%.2e %.2e' % (net.bus_P_mis, net.bus_Q_mis)
3.54e-01 4.22e+00
>>> method = gridopt.power_flow.new_method('NRPF')
>>> method.set_parameters({'quiet': True})
>>> method.solve(net)
>>> results = method.get_results()
>>> print results['status']
solved
>>> method.update_network(net)
```

```
>>> # max mismatches (MW, MVAr)
>>> print '%.2e %.2e' %(net.bus_P_mis, net.bus_Q_mis)
5.16e-04 5.67e-03
```

1.4. Example 5

CHAPTER

TWO

POWER FLOW

The Power Flow (PF) problem consists of determining steady-state voltage magnitudes and angles at every bus of the network as well as any unknown generator powers. On the other hand, the Optimal Power Flow (OPF) problem consists of determining generator and other network control settings that result in the optimal operation of the network according to some measure, *e.g.*, generation cost. In GRIDOPT, methods for solving PF and OPF problems are represented by objects derived from a method base class.

To solve a PF or OPF problem, one first needs to create an instance of a specific method subclass. This is done using the function <code>new_method()</code>, which takes as argument the name of an available power flow method. Available power flow methods are the following:

- DCPF
- DCOPF
- DCOPF MP
- DCOPF_Corr
- DCOPF_Prev
- NRPF
- AugLPF
- AugLOPF.

The following code sample creates an instance of the *NRPF* method:

```
>>> import gridopt
>>> method = gridopt.power_flow.new_method('NRPF')
```

Once a method has been instantiated, its parameters can be set using the function <code>set_parameters()</code>. This function takes as argument a dictionary with parameter name and value pairs. Valid parameters include parameters of the method, which are described in the sections below, and parameters from the numerical solver used by the method. The numerical solvers used by the methods of GRIDOPT belong to the Python package OPTALG. The following code sample sets a few parameters of the method created above:

```
>>> method.set_parameters({'quiet': True, 'feastol': 1e-4})
```

After configuring parameters, a method can be used to solve a problem using the function <code>solve()</code>. Typically, this function takes as argument a network object, as follows:

```
>>> import pfnet
>>> net = pfnet.Network()
>>> net.load('ieee14.mat')
```

```
>>> method.solve(net)
```

Information about the execution of the method can be obtained from the results attribute of the method object. This dictionary of results includes information such as 'status', e.g., 'solved' or 'error', any error message ('error_msg'), solver 'iterations', the optimization problem ('problem') constructed, and network properties at the point found by the method ('net_properties'). The following code sample shows how to extract some results:

```
>>> results = method.get_results()
>>> print results['status']
solved
>>> print results['iterations']
1
>>> problem = results['problem']
>>> problem.show()

Problem
functions : 0
constraints: 4
   type: FIX
   type: PAR_GEN_Q
   type: PAR_GEN_P
   type: PF
>>> print results['net_properties']['bus_v_max']
1.09
```

If desired, one can update the network object with the solution found by the method. This can be done with the function update_network(). This routine not only updates the network quantities treated as variables by the method, but also information about the sensitivity of the optimal objective function value with respect to perturbations of the constraints. The following code sample updates the power network with the results obtained by the method and shows the resulting maximum active and reactive bus power mismatches in units of MW and MVAr:

```
>>> method.update_network(net)
>>> print '%.2e %.2e' %(net.bus_P_mis,net.bus_Q_mis)
5.16e-04 5.67e-03
```

2.1 DCPF

This method is represented by an object of type DCPF and solves a DC power flow problem, which is just a linear system of equations representing DC power balance constraints. The system is solved using one of the linear solvers available in OPTALG.

2.2 DCOPF

This method is represented by an object of type DCOPF and solves a DC optimal power flow problem, which is just a quadratic program that considers active power generation cost, active power consumption utility, DC power balance constraints, variable limits, *e.g.*, generator and load limits, and DC power flow limits. For solving the problem, this method uses the IQP solver interior point solver from OPTALG.

The parameters of this method are the following:

Name	Description	Default
'quiet'	flag for suppressing output	False
'thermal_limits'	flag for considering branch flow limits	True
'thermal_factor'	scaling factor for branch flow limits	1.0
'inf_flow'	large constant for representing infinite flows in p.u.	1e4

The following example illustrates how to solve a DCOPF problem and extract the optimal generation cost:

```
>>> method = gridopt.power_flow.new_method('DCOPF')
>>> method.solve(net)
>>> print method.results['status']
solved
>>> method.update_network(net)
>>> # generation cost ($/hour)
>>> print net.gen_P_cost
4810.98
```

The sensitivity of the optimal objective function value with respect to the power balance constraints can be easily extracted from the network buses:

```
>>> bus = net.get_bus(4)
>>> print "bus %2d %.2e" %(bus.index,bus.sens_P_balance)
bus 4 2.13e+03
```

Similarly, the sensitivity with respect to branch flow limits can be easily extracted from the network branches:

Lastly, the sensitivity with respect to generator active power limits can be easily extracted from the network generators:

As the examples show, GRIDOPT and PFNET take care of all the details and allow one to extract solution information easily and intuitively from the network components.

2.3 DCOPF_MP

This method is represented by an object of type DCOPF_MP and solves a multi-period version of the problem solved by the *DCOPF* method above. Its parameters are the following:

2.3. DCOPF MP 9

Name	Description	Default
'quiet'	flag for suppressing output	False
'thermal_limits'	flag for considering branch flow limits	True
'thermal_factor'	scaling factor for branch flow limits	1.0
'fixed_total_load'	flag for fixing the total load over the time horizon	False
'inf_flow'	large constant for representing infinite flows in p.u.	1e4

Setting the parameter fixed_total_load to True ensures that the total load over the time horizon equals the sum of the nominal loads, which are given by the P attributes of the load objects.

An important difference between this method and the single-period *DCOPF* method is that the <code>solve()</code> and <code>update_network()</code> functions take on more arguments. More specifically, the <code>solve()</code> function takes as arguments a network, an integer T that represents the number of time periods, and a <code>network</code> modifier function. This <code>network</code> modifier function, which takes as arguments a network and a time t (integer) between 0 and T-1, allows the user to specify how the network should be modified at time t. The following example shows how to define a <code>network</code> modifier function that modifies load nominal active powers and limits according to some time series data:

```
>>> import pfnet
>>> import numpy as np
>>> net = pfnet.Network()
>>> net.load('ieee14.mat')
>>> T = 3
>>> # random load time series
>>> load_data = {}
>>> for load in net.loads:
       load_data[load.index] = np.random.rand(T)
>>> def net modifier(net,t):
       print 'modifying net for time %d' %t
       for load in net.loads:
            load.P = load_data[load.index][t]
            load.P_max = 1.05*load.P
            load.P_min = 0.95 * load.P
>>> # call network modifier for each time
>>> map(lambda t: net_modifier(net,t), range(T))
modifying net for time 0
modifying net for time 1
modifying net for time 2
```

Similarly, the update_network () function takes as arguments a network, a time t (integer) between 0 and T-1, and the network modifier function. This function updates the network with the part of the solution found that corresponds to time t. This allows extracting network information such as bus voltage angles or sensitivity information about the optimal objective function value with respect to the power balance constraints at a specific time.

2.4 DCOPF_Corr

This method is represented by an object of type DCOPF_Corr and solves a corrective DC optimal power flow problem. It considers active power generation cost for the base case, and DC power balance constraints, variable limits, and DC power flow limits for both the base- and post-contingency cases. For solving the problem, this method uses the IQP solver interior point solver from OPTALG.

The parameters	of this	method	are the	following:

Name	Description	Default
'quiet'	flag for suppressing output	False
'thermal_limits'	flag for considering branch flow limits	True
'thermal_factor'	scaling factor for branch flow limits	1.0
'max_ramping'	maximum generator output change as a fraction of maximum output	0.1
'inf_flow'	large constant for representing infinite flows in p.u.	1e4

The solve() function of this method requires in addition to a network argument a list of contingencies. The following example shows how to solve a corrective DCOPF problem considering a generator-outage contingency and a branch-outage contingency:

```
>>> import pfnet
>>> import gridopt

>>> net = pfnet.Network()
>>> net.load('ieee14.mat')

>>> gen = net.get_gen(0)
>>> branch = net.get_branch(0)

>>> c1 = pfnet.Contingency(gens=[gen])
>>> c2 = pfnet.Contingency(branches=[branch])

>>> method = gridopt.power_flow.new_method('DCOPF_Corr')
>>> method.solve(net,[c1,c2])
>>> method.update_network(net)

>>> print net.gen_P_cost
4849.11
```

2.5 DCOPF_Prev

This method is represented by an object of type DCOPF_Prev and solves a preventive DC optimal power flow problem. It considers active power generation cost for the base case, and DC power balance constraints, variable limits, and DC power flow limits for both the base- and post-contingency cases. For solving the problem, this method uses the IQP solver interior point solver from OPTALG.

The parameters of this method are the following:

Name	Description	Default
'quiet'	flag for suppressing output	False
'thermal_limits'	flag for considering branch flow limits	True
'thermal_factor'	scaling factor for branch flow limits	1.0
'inf_flow'	large constant for representing infinite flows in p.u.	1e4

As for the corrective DCOPF method, the solve() function of this method also requires a list of contingencies.

2.6 NRPF

This method solves an AC power flow problem, which is a nonlinear system of equations. For doing this, it uses the <code>OptSolverNR</code> Newton-Raphson solver from OPTALG. For now, its parameters are a 'quiet' flag and a low-voltage threshold 'vmin_thresh'.

2.5. DCOPF Prev 11

2.7 AugLPF

This method solves an AC power flow problem but formulated as an optimization problem with a strongly-convex objective function. For doing this, it uses the <code>OptSolverAugL</code> Augmented Lagrangian solver from OPTALG. The <code>OptSolverAugL</code> solver is similar to the one described in Chapter 3 of [TTR2015], but without the restriction of moving in the null-space of the linear equality constraints. For now, the parameters of this power flow method are the following:

Name	Description	Default
'weight_vmag'	Weight for bus voltage magnitude regularization	1e0
'weight_vang'	Weight for bus voltage angle regularization	1e-3
'weight_pq'	Weight for generator power regularization	1e-3
'weight_t'	Weight for transformer tap ratio regularization	1e1
'weight_b'	Weight for shunt susceptance regularization	1e-4
'vmin_thresh'	Low-voltage threshold	1e-1

2.8 AugLOPF

This method solves an AC optimal power flow problem. For doing this, it uses the <code>OptSolverAugL</code> Augmented Lagrangian solver from <code>OPTALG</code>. For now, the parameters of this optimal power flow method are the following:

Name	Description	Default
'weight_cost'	Weight for active power generation cost	1e-2
'weight_limit'	Weight for soft constraint violations	1e-2
'weight_reg'	Weight for regularization	1e-5
'vmin_thresh'	Low-voltage threshold	1e-1

THREE

API REFERENCE

3.1 Power Flow Method

```
gridopt.power_flow.new_method(name)
     Creates a power flow or optimal power flow method.
          Parameters name: string
class gridopt.power_flow.method.PFmethod
     Power flow method class.
     create_problem(net)
          Creates optimization problem.
              Parameters net: PFNET Network
              Returns prob: PFNET Problem
     get_info_printer()
          Gets function for printing information about method progress.
              Returns printer: Function
     get_results()
          Gets dictionary with results.
              Returns results: dict
     parameters = None
          Parameters (dictionary)
     results = None
          Results (dictionary)
     \mathtt{set\_dual\_variables}\,(d)
          Sets dual variables.
              Parameters d: list
     set_error_msg(msg)
          Sets method error message.
              Parameters msg: string
     set iterations(k)
          Sets method iterations.
```

Parameters k: int

```
set_net_properties (np)
          Sets network properties.
              Parameters np: dictionary
     set_parameters (params=None, strparams=None)
          Sets method parameters.
              Parameters params: dict
                    Name-value pairs
                  strparams: dict:
                    Name-value pairs where value is a string
     set_primal_variables(x)
          Sets primal variables.
              Parameters x: vector
     set_problem(p)
          Sets problem.
              Parameters p: PFNET problem
     set_results (results)
          Sets method results.
              Parameters results: dict
     set status(status)
          Sets method status.
              Parameters status: string
     solve (net)
          Solves power flow problem.
              Parameters net: PFNET Network
     update_network (net)
          Updates network with results.
              Parameters net: PFNET Network
class gridopt.power_flow.dc_pf.DCPF
     DC power flow method.
class gridopt.power_flow.dc_opf.DCOPF
     DC optimal power flow method.
class gridopt.power_flow.dc_opf_mp.DCOPF_MP
     Multi-period DC optimal power flow method.
     solve (net, T, net_modifier)
          Solves multi-period DC OPF problem.
              Parameters net: Network
                  T: int (time horizon)
                  net_modifier : function(net,t)
     update network (net, t, net modifier)
          Updates the network with part of the solution that corresponds to the given time.
```

```
Parameters net: Network
                T: int (time)
                net_modifier : function(net,t)
class gridopt.power_flow.dc_opf_corr.DCOPF_Corr
    Corrective DC optimal power flow method.
    solve (net, contingencies)
         Solves corrective DCOPF problem.
            Parameters net: Network
                contingencies: list of Contingencies
class gridopt.power_flow.dc_opf_prev.DCOPF_Prev
    Preventive DC optimal power flow method.
     solve (net, contingencies)
         Solves preventive DCOPF problem.
            Parameters net: Network
                contingencies: list of Contingencies
class gridopt.power_flow.nr_pf.NRPF
    Newton-Raphson power flow method.
class gridopt.power flow.augl pf.AugLPF
    Augmented Lagrangian-based power flow method.
class gridopt.power_flow.augl_opf.AugLOPF
    Augmented Lagrangian-based optimal power flow method.
class gridopt.power_flow.method_error.PFmethodError(method, msg)
3.1.1 Error Exceptions
class gridopt.power_flow.method_error.PFmethodError (method, msg)
class gridopt.power_flow.method_error.PFmethodError_NoProblem(method)
class gridopt.power_flow.method_error.PFmethodError_BadProblem (method)
class gridopt.power_flow.method_error.PFmethodError_BadFlowLimits (method)
class gridopt.power_flow.method_error.PFmethodError_BadVarLimits (method)
class gridopt.power_flow.method_error.PFmethodError_BadParam (method, param='')
class gridopt.power_flow.method_error.PFmethodError_ParamNotBool (method)
class gridopt.power_flow.method_error.PFmethodError_SolverError (method, msg)
```

3.2 References

3.2. References 15

CHAPTER

FOUR

INDICES AND TABLES

- genindex
- modindex
- search

1	R	2	n	R	1	ľ	T	\cap	١	(1	Ç	Α	. 1	D.	Ľ	۲V	
ı		ч	ш		М			١.	,,		п	`	$\overline{}$	ч	_			ı

[TTR2015] T. Tinoco De Rubira, Numerical Optimization and Modeling Techniques for Power System Operations and Planning. PhD thesis, Stanford University, March 2015.

20 Bibliography

PYTHON MODULE INDEX

g
gridopt, 1

22 Python Module Index

PYTHON MODULE INDEX

g
gridopt, 1

24 Python Module Index

A	PFmethodError_BadVarLimits (class in gri-
AugLOPF (class in gridopt.power_flow.augl_opf), 15	dopt.power_flow.method_error), 15
AugLPF (class in gridopt.power_flow.augl_pf), 15	PFmethodError_NoProblem (class in gridopt.power_flow.method_error), 15
C	PFmethodError_ParamNotBool (class in gri-
create_problem() (gridopt.power_flow.method.PFmethod	dopt.power_flow.method_error), 15 PFmethodError_SolverError (class in gri-
method), 13	dopt.power_flow.method_error), 15
D	R
DCOPF (class in gridopt.power_flow.dc_opf), 14 DCOPF_Corr (class in gridopt.power_flow.dc_opf_corr),	results (gridopt.power_flow.method.PFmethod attribute),
DCOPF_MP (class in gridopt.power_flow.dc_opf_mp),	S
14	set_dual_variables() (gri-
DCOPF_Prev (class in gridopt.power_flow.dc_opf_prev), 15	dopt.power_flow.method.PFmethod method),
DCPF (class in gridopt.power_flow.dc_pf), 14	set_error_msg() (gridopt.power_flow.method.PFmethod
G	method), 13
get_info_printer() (gridopt.power_flow.method.PFmethod	set_iterations() (gridopt.power_flow.method.PFmethod method), 13
method), 13	set_net_properties() (gri-
get_results() (gridopt.power_flow.method.PFmethod method), 13	dopt.power_flow.method.PFmethod method),
gridopt (module), 1	$set_parameters() \ (grid opt.power_flow.method.PFmethod$
N	method), 14
new_method() (in module gridopt.power_flow), 13	set_primal_variables() (gri- dopt.power_flow.method.PFmethod method),
NRPF (class in gridopt.power_flow.nr_pf), 15	14
P	set_problem() (gridopt.power_flow.method.PFmethod method), 14
parameters (gridopt.power_flow.method.PFmethod attribute), 13	set_results() (gridopt.power_flow.method.PFmethod method), 14
PFmethod (class in gridopt.power_flow.method), 13	set_status() (gridopt.power_flow.method.PFmethod
PFmethodError (class in gri-	method), 14
dopt.power_flow.method_error), 15	solve() (gridopt.power_flow.dc_opf_corr.DCOPF_Corr method), 15
PFmethodError_BadFlowLimits (class in gridopt.power_flow.method_error), 15	solve() (gridopt.power_flow.dc_opf_mp.DCOPF_MP
PFmethodError_BadParam (class in gri-	method), 14
dopt.power_flow.method_error), 15	solve() (gridopt.power_flow.dc_opf_prev.DCOPF_Prev
PFmethodError_BadProblem (class in gri-	method), 15
dopt.power_flow.method_error), 15	solve() (gridopt.power_flow.method.PFmethod method), 14



update_network() (gridopt.power_flow.dc_opf_mp.DCOPF_MP method), 14 update_network() (gridopt.power_flow.method.PFmethod method), 14

26 Index