# Timer Lab

# Example 1:

# Write Embedded C code using ATmega328P $\mu$ C to control led by Timer2. Requirements:

- 1- The LED is connected to pin 0 in PORTC.
- 2- Connect the Led using Positive Logic configuration.
- 3- Configure the timer clock to F CPU/1024.
- 4- Timing should be count using Timer2 in Normal Mode.
- **5-** Toggle the led every half second.

#### Steps Main:

- 1- Configure the led pin to be output pin.
- 2- Make LED off at the beginning(Positive Logic).
- 3- Enable global interrupts in MC by setting the I-Bit.
- 4- Start the timer.

#### Steps Timer init:

- 1- initial the value of timer counter register (TCNT) to zero.
- 2- Enable overflow interrupt.
- 3- Configure the timer control register
  - ✓ Non PWM mode FOC0=1
  - ✓ Normal Mode WGM01=0 & WGM00=0
  - ✓ Normal Mode COM00=0 & COM01=0
  - √ clock = F\_CPU/1024 CS00=1 CS01=0 CS02=1

#### ISR:

Increase the count of a global or static variable in ISR and check the count if it reach the required counts to obtain the required time (0.5 sec).

# Example2:

# Write Embedded C code using ATmega328P $\mu$ C to control a 7-sgment using Timer2.

### Requirements:

- **1-** 7-segment connected to PORTC.
- **2-** Configure the timer clock to F CPU/256.
- **3-** Timing should be count using Timer0 in Normal Mode.
- **4-** Every second the 7-segment should be incremented by one. If the first 7-sement reached 9 overflow will occur.

### Example 3:

# Repeat Example 1 but use Timer2 Clear timer on compare (CTC) Mode.

♣ In this example CTC mode will act exactly as timer normal mode in Example 1.

#### Example 4:

Write Embedded C code using ATmega328P  $\mu$ C to generate a 15.625 KHz clock using Timer2 CTC Mode.

### Requirements:

- 1. Use Timer2 in CTC Mode with clock equals to F\_CPU/1024 clock.
- 2. Clock duty cycle is 50%.
- 3. Connect the output to speaker of kit

#### Steps Timer init:

- 1. initial the value of timer counter register (TCNT) to zero.
- 2. Set Compare value (OCR=250)
- 3. Set OC2A (PB3) Pin as output pin
- 4- Configure the timer control register
  - ✓ Non PWM mode FOC0=1
  - ✓ CTC Mode WGM01=1 & WGM00=0
  - ✓ Toggle OC2A on compare match COM00=1 & COM01=0
  - ✓ clock = CPU/1024 clock CS00=1 CS01=1 CS02=1
  - √ clock = F\_CPU/128 CS20=1 CS21=0 CS22=1.

# Example 5:

Assuming that the clock pulses are fed into the pin ICP1 (PB0), following program will read TCNT1 value at every rising edge and place the result on serial monitor using Serial.println() function.

#### Steps Main:

- 1- Clear the timer counter TCNT1.
- 2- Clear input capture flag.
- 3- Configure capture on rising edge.
- 4- Wait for capture (ICF1)
- 5- Capture current time in ICR1 on a variable.
- 6- Clear capture flag.
- 7- Wait for next rising edge capture
- 8- Capture recent time in ICR1 and calculate period= recent capture- previous capture.
- 9- Put period count on serial monitor